Diagnostic List Isuzu_V5.44

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Model	System	System	System	Version Info	Rear DTC	Erase DTC	Read Data stream	Action test	Injector data	Remark (other functions)
Rodeo	Powertrain	4JH1-TC Bosch		√	√	√	–	–	–	–
Rodeo	Powertrain	2.2L L4 SOHC		–	√	√	√	√	–	–
Rodeo	Powertrain	3.2L V6 6VD1 Hitachi		√	√	√	√	√	–	–
Rodeo	Powertrain	4L30E		√	√	√	√	√	–	–
Rodeo	Powertrain	AW30-40LE		√	√	√	–	–	–	–
Rodeo	Body	Immobiliser		√	√	√	√	–	–	–
Rodeo	Body	Airbag		√	√	√	√	–	–	–
RA Rodeo	Engine	2.4L LG1 Euro3		√	√	√	√	√	–	–
RA Rodeo	Engine	V6 Engine		√	√	√	√	√	–	√
RA Rodeo	Transmission	Automatic Transmission		√	√	√	√	√	–	√
YG Cruze	Engine	2.0 L (Diesel)		√	√	√	√	√	–	–
YG Cruze	Transmission	Automatic Transmission		√	√	√	√	–	–	–
YG Cruze	Chassis	ABS		√	√	√	√	–	–	–
YG Cruze	Chassis	Electronic Power Steering		√	√	√	√	–	–	–
YG Cruze	Body	Airbag		√	√	√	√	–	–	–
Jackaroo	Powertrain	3.0L L4 4JX1		√	√	√	–	–	–	–
Jackaroo	Powertrain	3.5L V6 6VE1		√	√	√	√	√	–	–
Jackaroo	Powertrain	4L30E		√	√	√	–	–	–	–
Jackaroo	Powertrain	AW30-40LE		√	√	√	–	–	–	–
Jackaroo	Chassis	ABS		–	√	√	–	–	–	–
Jackaroo	Chassis	TOD		–	√	√	–	–	–	–
Jackaroo	Body	Immobiliser		–	√	√	√	–	–	–
Jackaroo	Body	Airbag		√	√	√	–	–	–	–
Jackaroo	Body	Anti Theft Warning		√	√	√	–	–	–	–
Colorado	Engine	V6 Engine		√	√	√	√	√	–	–
Colorado	Engine	2.4L LG1 Euro3		√	√	√	√	√	–	–
Colorado	Body	Powertrain Interface Module		√	√	√	√	√	–	–
Colorado	Body	Immobiliser		√	√	√	√	–	–	–
Colorado	Body	Airbag		√	√	√	√	–	–	–
Colorado	Chassis	ABS		√	√	√	√	√	–	–
(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Engine	3.2L V6 6VD1 Hitachi		√	√	√	√	√	–	–
(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Engine	3.5L V6 6VE1 Hitachi		√	√	√	√	√	–	–
(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Immobiliser		√	√	√	√	–	–	–
(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Airbag		√	√	√	√	–	–	–
(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Anti Theft Warning		√	√	√	√	√	–	–
D-Max	Powertrain	4JH1-TC DESNO		√	√	√	√	√	–	Initial capacity,Limit capacity, Idle speed,Exhaust gas recirculation
D-Max	Powertrain	4JJ1-TC(Delphi)		√	√	√	√	√	√	DPD Forced Regeneration, DPD Slowly Forced Regeneration, DPD Regeneration Data Reset, Injector ID Code Read, Injector programming

Diagnostic List Isuzu_V5.44

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Model	System	System	System	Function						
				Version Info	Rear DTC	Erase DTC	Read Data stream	Action test	Injector data	Remark (other functions)
ELF/NPR/NQR/VFR/NL	Engine	3.0L 4JJ1-TC(Delphi)		√	√	√	√	√	√	DPD Forced Regeneration, DPD Regeneration Data Reset, Injector data,MAF calibration data service mode, Clear learned supply pump data
ELF/NPR/NQR/VFR/NL	Engine	4HG1 engine		√	√	√	√	-	-	Writing Number of Engine Start Times
ELF/NPR/NQR/VFR/NL	Engine	4HJ1 engine		√	√	√	√	√	-	-
ELF/NPR/NQR/VFR/NL	Engine	4HL1 engine		√	√	√	√	√	√	Injector data The number of engine starts flashing (when replacing ECU) The number of engine starts flashing (when replacing engine) Pump adjustment learning reset
ELF/NPR/NQR/VFR/NL	Engine	4HL1/4HJ1(Vehicle Interface Module)		√	-	-	√	-	-	The number of engine starts flashing The number of engine starts flashing (when replacing engine)
ELF/NPR/NQR/VFR/NL	Chassis	ABS/ARS	ABS	-	√	√	√	√	-	-
ELF/NPR/NQR/VFR/NL	Chassis	ABS/ARS	ABS/ASR(Euro IV)	-	√	√	√	-	-	-
ELF/NPR/NQR/VFR/NL	Chassis	ABS/ARS	ABS1	√	√	√	√	√	-	-
ELF/NPR/NQR/VFR/NL	Chassis	ABS/ARS	ABS2	√	√	√	√	√	-	Programming Tire Radius
ELF/NPR/NQR/VFR/NL	Chassis	HSA/CFS		√	√	√	√	-	-	Gear Shift,Select Stroke Learn Free Clutch Torque Point Position Learn 1 Free Clutch Torque Point Position Learn 2 Start position Learn for new clutch disk
ELF/NPR/NQR/VFR/NL	Body	SRS Airbag		√	√	√	√	-	-	-
Bighorn	Powertrain	4JG2	Isuzu 4JG2 engine syste	-	√	√	√	-	-	-
Bighorn	Powertrain	4JG2	Isuzu 4JG2 (LPG) engine systems	√	√	√	√	√	-	Clear ISC learning value, Clear oxygen sensor 1 threshold, Clear feedback average working in idle
Bighorn	Powertrain	4JX1(3.0 L4)		√	√	√	√	-	-	-
New D-MAX	Gasoline Engine	Z24SED		√	√	√	√	√	-	Idle learn, Fuel trim learn, Fuel trim reset, HO2S Heater learn
New D-MAX	Diesel Engine	RZ4E-TC(1.9 DDI)		√	√	√	√	√	√	Injector ID Code Read, Injector programming, Supply Pump Initialization

Diagnostic List Isuzu_V5.44

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Model	System	System	System	Function						
				Version Info	Rear DTC	Erase DTC	Read Data stream	Action test	Injector data	Remark (other functions)
New D-MAX	Diesel Engine	RZ4E-TC(1.9 DDI)	2301	√	√	√	√	√	√	DPD Slow regeneration;DPD Forced Regeneration;Injector programming;Vehicle speed correction data(Tire size);Clear DPD data(Exchange DPD filter);Clear learned value(Dew point);Clear learned value(Fuel injection);Clear learned value(Fuel rail pressure regulator);Clear learned value(Fuel Lambda sensor);Clear learned value(Fuel mass observer);Clear learned value(Wheel learning);Clear learned value(Intake throttle);Clear learned value(Lambda sensor adaptation);Reset oil dilution;Exhaust differential pressure sensor learning
New D-MAX	Diesel Engine	4JK1-TC(2.5)		√	√	√	√	√	√	Injector ID Code Read, Injector programming, Supply Pump Initialization, DPD Forced Regeneration, DPD Slow regeneration, DPD Automatic regeneration, DPD Automatic regeneration reset, DPD Regeneration Data Reset
New D-MAX	Diesel Engine	4JJ1-TC(3.0)		√	√	√	√	√	√	Injector ID Code Read, Injector programming, Supply Pump Initialization, DPD Forced Regeneration, DPD Slow regeneration, DPD Automatic regeneration, DPD Automatic regeneration reset, DPD Regeneration Data Reset
New D-MAX	Transmission	AT		√	√	√	√	√	–	Clear learning value
New D-MAX	Chassis	ABS		√	√	√	√	√	–	Clear steering centered position, Register steering centered position, Learning for G-sensor central position
New D-MAX	Chassis	Transfer case module	EATON	√	√	√	√	√	–	–
New D-MAX	Chassis	Transfer case module	MSG/MUA	√	√	√	√	√	–	–
New D-MAX	Body	Immobilizer(BETA)		√	√	√	√	–	–	Program transponder key, Erase transponder key
New D-MAX	Body	PESS(Passive entry and start system)		√	√	√	–	√	–	–
New D-MAX	Body	BCM		√	√	√	√	–	–	–
New D-MAX	Body	Meter		√	–	–	–	–	–	–
New D-MAX	Body	SRS Airbag		√	√	√	√	–	–	–
MU-7	Diesel Engine	4JJ1-TC		√	√	√	√	–	√	Injector ID Code Read, Injector programming, Supply Pump Initialization

Diagnostic List Isuzu_V5.44

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Model	System	System	System	Function						
				Version Info	Rear DTC	Erase DTC	Read Data stream	Action test	Injector data	Remark (other functions)
MU-7	Transmission	AT		√	√	√	√	√	-	-
MU-7	Chassis	ABS		√	√	√	√	√	-	-
MU-7	Body	Immobilizer		√	√	√	√	-	-	Program transponder key, Erase transponder key
MU-7	Body	BCM		√	√	√	√	√	-	Brake pedal position sensor learn
MU-7	Body	SRS Airbag		√	√	√	√	-	-	-
MU-X	Diesel Engine	4JJ1-TC		√	√	√	√	√	√	Injector ID Code Read, Injector programming, Supply Pump Initialization, DPD Forced Regeneration, DPD Slow regeneration, DPD Automatic regeneration, DPD Automatic regeneration reset, DPD Regeneration Data Reset
MU-X	Transmission	AT		√	√	√	√	√	-	Clear learning value
MU-X	Chassis	ABS		√	√	√	√	√	-	-
MU-X	Chassis	Transfer case module		√	√	√	√	√	-	-
MU-X	Body	Immobilizer(BETA)		√	√	√	√	-	-	Program transponder key, Erase transponder key
MU-X	Body	PESS(Passive entry and start system)		√	√	√	-	√	-	-
MU-X	Body	BCM		√	√	√	√	-	-	-
MU-X	Body	Meter		√	-	-	-	-	-	-
MU-X	Body	SRS Airbag		√	√	√	√	-	-	-
All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	6VD1		-	√	√	√	√	-	Reset O2 BLM
All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.2 L4 SOHC		√	√	√	√	-	-	-
All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.X L4 HV240		√	√	√	√	√	-	IAC Reset
All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.4 LP1 EURO3		√	√	√	√	√	-	Reset O2 loop block learn map VIN Programming
All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.2 V6 6VD1 hitachi		√	√	√	√	√	-	-
All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.5 V6 6VE1 hitachi		√	√	√	√	√	-	Fuel trim reset
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Delphi)(CAN)		√	√	√	√	√	√	Injector ID Code Read Injector programming Supply Pump Initialization
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Delphi)(KWP)		√	√	√	√	√	√	DPD Forced Regeneration DPD Slowly Forced Regeneration DPD Regeneration Data Reset Injector ID Code Read Injector programming
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Transtron)(CAN)		√	√	√	√	√	√	DPD Forced Regeneration DPD Slowly Forced Regeneration DPD Regeneration Data Reset Injector ID Code Read Injector programming

Diagnostic List Isuzu_V5.44

Remark:
1.√ : means that the system has this function
2. - : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Model	System	System	System	Function						
				Version Info	Rear DTC	Erase DTC	Read Data stream	Action test	Injector data	Remark (other functions)
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Delphi)(KWP)		√	√	√	√	√	√	DPD Forced Regeneration DPD Slowly Forced Regeneration DPD Regeneration Data Reset Injector ID Code Read Injector programming
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Delphi)(CAN)		-	√	√	√	-	√	Injector ID Code Read Injector programming Supply Pump Initialization
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Delphi)(KWP)		√	√	√	√	√	√	DPD Forced Regeneration DPD Slowly Forced Regeneration DPD Regeneration Data Reset Injector ID Code Read Injector programming
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Transtron)(CAN)		-	√	√	√	-	√	Injector ID Code Read Injector programming Supply Pump Initialization
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Transtron)(KWP)		√	√	√	√	√	√	DPD Forced Regeneration DPD Slowly Forced Regeneration DPD Regeneration Data Reset Injector ID Code Read Injector programming
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1-TC(2.5)		√	√	√	√	√	√	Injector ID Code Read, Injector programming, Supply Pump Initialization, DPD Forced Regeneration, DPD Slow regeneration, DPD Automatic regeneration, DPD Automatic regeneration reset, DPD Regeneration Data Reset
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Delphi)(CAN)		-	√	√	√	-	√	Injector ID Code Read Injector programming Supply Pump Initialization
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Delphi)(KWP)		√	√	√	√	√	√	DPD Forced Regeneration DPD Slowly Forced Regeneration DPD Regeneration Data Reset Injector ID Code Read Injector programming
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Transtron)(CAN)		-	√	√	√	-	√	Injector ID Code Read Injector programming Supply Pump Initialization
All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Transtron)(KWP)		√	√	√	√	√	√	DPD Forced Regeneration DPD Slowly Forced Regeneration DPD Regeneration Data Reset Injector ID Code Read Injector programming
All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT		√	√	√	√	√	-	-

Diagnostic List Isuzu_V5.44

Remark:
1.√ : means that the system has this function
2. - : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Model	System	System	System	Function						
				Version Info	Rear DTC	Erase DTC	Read Data stream	Action test	Injector data	Remark (other functions)
All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT(6SP)		√	√	√	√	√	-	Transmission adaptive pressure reset
All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	ABS/ASR		√	√	√	√	√	-	-
All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	EBCM(Electronic brake control module)		√	√	√	√	√	-	-
All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Transfer case module		√	√	√	√	√	-	Range actuator learn
All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Multi-Axis acceleration sensor module		√	√	√	-	-	-	-
All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Steering wheel angle sensor module		√	√	√	-	-	-	Steering wheel angle sensor reset Steering wheel angle sensor learn
All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(Old type)		√	√	√	√	-	-	Program transponder key Erase transponder key
All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New type)(KWP)		√	√	√	√	-	-	Program transponder key Erase transponder key Reset Immobilizer Program Immobilizer Immobilizer link to ECM/PIM(V6 Engine)
All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New type)(CAN)		√	√	√	√	-	-	Program transponder key Erase transponder key
All model(D-MAX/LUV/Frontera/Rodeo)	Body	PIM(Powertrain interface module)		√	√	√	-	-	-	Reset PIM Link to ECM/Immobilizer to PIM (V6 Engine)
All model(D-MAX/LUV/Frontera/Rodeo)	Body	SRS Airbag		√	√	√	√	-	-	-
All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM		√	√	√	√	√	-	-
All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM(MIMAMORI)		√	√	√	√	-	-	MIMAMORI All Data Clear
All model(D-MAX/LUV/Frontera/Rodeo)	Body	Aniti theft warning		√	√	√	√	-	-	-