Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Dynamic Guideline Camera	Dynamic Guideline Camera	√	√	√	√	–	–	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Dynamic Guideline Camera	Dynamic Guideline Camera	√	√	√	√	–	–	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Dynamic Guideline Camera	Dynamic Guideline Camera	√	√	√	√	–	–	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Dynamic Guideline Camera	Dynamic Guideline Camera	√	√	√	√	–	–	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT(HC),18~19	2018	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2007	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2006	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2005	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2004	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	AIRBAG	SRE-LC/HMC	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	AIRBAG	SRE-Smart(Dual Stage)	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2003	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2002	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2002	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2002	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2002	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2002	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2001	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2001	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2001	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2001	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2001	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(LC),00~07	2000	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2000	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(LC),00~07	2000	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(LC),00~07	2000	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ACCENT(LC),00~07	2000	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2011	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2010	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ABS	ABS(MGH-25)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ABS	ABS(MGH-40)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	ABS	ABS(MGH-25)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	ABS	ABS(MGH-40)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	ABS	ABS(MGH-25)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	ABS	ABS(MGH-40)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2009	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ABS	Anti-Lock Brake(MGH-25)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ABS	Anti-Lock Brake(MGH-40)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	ABS	Anti-Lock Brake(MGH-25)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	ABS	Anti-Lock Brake(MGH-40)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	ABS	Anti-Lock Brake(MGH-25)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	ABS	Anti-Lock Brake(MGH-40)	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2008	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2007	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2006	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2006	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT(MC),06~11	2006	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ACCENT(MC),06~11	2006	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(MC),06~11	2006	D 1.5 TCI-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	ACCENT(MC),06~11	2006	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2018	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	EPS	Motor driven Power Steering(~2012.02.22)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	EPS	Motor driven Power Steering(2012.02.23~)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	EPS	Motor driven Power Steering(2012.02.23~)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	EPS	Motor driven Power Steering(~2012.02.22)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	EPS	Motor driven Power Steering(2012.02.23~)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	EPS	Motor driven Power Steering(2012.02.23~)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	EPS	Motor driven Power Steering(~2012.02.22)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	EPS	Motor driven Power Steering(2012.02.23~)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	EPS	Motor driven Power Steering(2012.02.23~)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT(RB),11~19	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.3 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1999	G 1.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.3 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1998	G 1.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.3 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	ENGINE	Unleaded MAF	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	ENGINE	Unleaded MAF	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1997	G 1.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.3 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	ENGINE	Unleaded MAF	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	ENGINE	Unleaded MAF	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1996	G 1.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.3 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	ENGINE	Unleaded MAF	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	ENGINE	Unleaded MAF	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	ENGINE	Unleaded MAP	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ACCENT(X3),95~99	1995	G 1.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Tire Pressure Monitoring System	i-Tire pressure monitoring system	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Seat Belt Reminder/Lighting Module	Seat belt reminder/Lighting module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Body Control	Body control module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.4 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Tire Pressure Monitoring System	i-Tire pressure monitoring system	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Seat Belt Reminder/Lighting Module	Seat belt reminder/Lighting module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2020	G 1.6 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ACCENT/SOLARIS(HCR),18~20	2018	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	ACCENT/SOLARIS(RBr),11~17	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HC1),17~19	2019	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	i-Tire Pressure Monitoring System	i-Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ACCENT/VERNA(HCI),17~19	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2004	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2003	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2002	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2001	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS PRIME(MXL),00~04	2000	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MX),98~04	2004	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MX),98~04	2003	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MX),98~04	2002	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MX),98~04	2001	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MX),98~04	2000	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MX),98~04	1999	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MX),98~04	1998	G 1.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	B 1.1 LPG	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2013	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	B 1.1 LPG	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2012	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	B 1.1 LPG	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2011	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	B 1.1 LPG	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2010	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	B 1.1 LPG	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2009	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	B 1.1 LPG	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2008	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2007	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2006	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2005	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2004	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.0 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	ENGINE	Unleaded INDIA	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	ENGINE	Unleaded MEX	√	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ATOS(MXI)-PDF,03~13	2003	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2008	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2007	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2006	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2005	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2004	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ABSESP	ESP(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ABSESP	TCS(+)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2003	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ABSESP	ESP(CTC Type)(2002.09~)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ABSESP	ESP(Melco Type)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ABSESP	ESP(Melco Type)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ABSESP	TCS(CTC Type)(2002.09~)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ABSESP	TCS(ITT Type)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ABSESP	ESP(CTC Type)(2002.09~)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ABSESP	ESP(Melco Type)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ABSESP	ESP(Melco Type)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ABSESP	TCS(CTC Type)(2002.09~)	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ABSESP	TCS(ITT Type)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2002	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ABSESP	TCS(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ABSESP	VDC(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ABSESP	VDC(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ENGINE	Leaded MPI All	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ENGINE	Unleaded GDI All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ENGINE	Unleaded MPI EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ENGINE	Unleaded MPI EOBD	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ENGINE	Unleaded MPI GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ENGINE	Unleaded MPI GEN	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ABSESP	TCS(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ABSESP	VDC(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ABSESP	VDC(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2001	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ABSESP	TCS(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ABSESP	VDC(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ABSESP	VDC(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	ENGINE	Unleaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	ABSESP	TCS(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	ABSESP	VDC(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	ABSESP	VDC(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	2000	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ABSESP	TCS(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ABSESP	VDC(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ABSESP	VDC(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 3.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	ENGINE	Unleaded All	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	ABSESP	TCS(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	ABSESP	VDC(+)	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	ABSESP	VDC(+)	√	√	√	√	√	√	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	ECS	ECS	–	√	√	√	√	–	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	Automatic Headlamp Leveling	Automatic Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CENTENNIAL(LZ),99~08	1999	G 4.5 DOHC	LAN	LAN	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2018	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2017	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2016	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GS),15~19	2015	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2019	F 1.6 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSB),18~19	2018	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	CRETA(GSR),17~19	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA COUPE(JK),13~16	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	F 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	ELANTRA(AD),16~20	2020	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2019	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	ELANTRA(AD),16~20	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous Emergenc	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2019	G 2.0 MPI	Tire Pressure Monitoring System	Tire pressure monitoring	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(ADA),17~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD1),16~18	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(AD),16~18	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2011	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2010	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2009	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2008	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	ELANTRA(HD),07~11	2007	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.5 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.5 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.8 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(MD),12~16	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2013	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD),12~16	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2016	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2015	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2013	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(MD1),13~16	2013	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1998	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1997	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.5 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	ELANTRA(RD),96~00	1996	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	ELANTRA(UD),14~16	2016	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	ELANTRA(UD),14~16	2015	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	ELANTRA(UD),14~16	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	ENGINE	Unleaded GEN(CVVT-)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	ENGINE	Unleaded GEN(CVVT+)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	ENGINE	Unleaded GEN(CVVT-)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	ENGINE	Unleaded GEN(CVVT+)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2006	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	ENGINE	Unleaded GEN(CVVT-)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	ENGINE	Unleaded GEN(CVVT+)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	ENGINE	Unleaded GEN(CVVT-)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	ENGINE	Unleaded GEN(CVVT+)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2005	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	ENGINE	Unleaded GEN(CVVT-)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	ENGINE	Unleaded GEN(CVVT+)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	ENGINE	Unleaded GEN(CVVT-)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	ENGINE	Unleaded GEN(CVVT+)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2004	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	ENGINE	Unleaded OBD-II(Non SULEV)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	ENGINE	Unleaded OBD-II(SULEV)	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2003	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	D 2.0 TCI-D	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2003	D 2.0 TCI-D	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2003	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2003	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2003	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2002	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	D 2.0 TCI-D	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2002	D 2.0 TCI-D	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2002	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2002	D 2.0 TCI-D	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	D 2.0 TCI-D	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2002	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ELANTRA(XD),01~06	2001	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	D 2.0 TCI-D	AT	Melco TCM	√	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2001	D 2.0 TCI-D	AT	Siemens PCM	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	ELANTRA(XD),01~06	2001	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	ELANTRA(XD),01~06	2001	D 2.0 TCI-D	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	D 2.0 TCI-D	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	ELANTRA(XD),01~06	2001	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2019	G 0.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	EON(HA),12~19	2019	G 0.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2019	G 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	G 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2019	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	G 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2019	G 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2019	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2019	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2019	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	G 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2019	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2019	B 0.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2019	B 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	B 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2019	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2019	B 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2019	B 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2018	G 0.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2018	G 0.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2018	G 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	G 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2018	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	G 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2018	G 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2018	B 0.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2018	B 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	B 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2018	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	B 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2018	B 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2018	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2018	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2018	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2018	G 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2018	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2017	G 0.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2017	G 0.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2017	G 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	G 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2017	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	G 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2017	G 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2017	B 0.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2017	B 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	B 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2017	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	B 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2017	B 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2017	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2017	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2017	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2017	G 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2017	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2016	G 0.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2016	G 0.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2016	G 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	G 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2016	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	G 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2016	G 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2016	B 0.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2016	B 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	B 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2016	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	B 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2016	B 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2016	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2016	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2016	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2016	G 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2016	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2015	G 0.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2015	G 0.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2015	G 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	G 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2015	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	G 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2015	G 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2015	B 0.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2015	B 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	B 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2015	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	B 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2015	B 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2015	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2015	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2015	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2015	G 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2015	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2014	G 0.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2014	G 0.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2014	G 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	G 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2014	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	G 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2014	G 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2014	B 0.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2014	B 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	B 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2014	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	B 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2014	B 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2014	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2014	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	EON(HA),12~19	2014	G 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2014	G 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2014	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2013	G 0.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2013	G 0.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2013	G 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2013	G 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2013	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2013	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2013	G 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2013	G 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2013	B 0.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2013	B 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2013	B 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2013	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2013	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2013	B 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2013	B 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2012	G 0.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2012	G 0.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2012	G 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2012	G 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2012	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2012	G 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2012	G 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2012	G 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EON(HA),12~19	2012	B 0.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EON(HA),12~19	2012	B 0.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2012	B 0.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2012	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2012	B 0.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	–	
Europe/General Area	EON(HA),12~19	2012	B 0.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	EON(HA),12~19	2012	B 0.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	ECS	Electronic Control Suspension(Limousine)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	ECS	Electronic Control Suspension(Sedan)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	ECS	Electronic Control Suspension(Limousine)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	ECS	Electronic Control Suspension(Sedan)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2016	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	ECS	Electronic Control Suspension(Limousine)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	ECS	Electronic Control Suspension(Sedan)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	ECS	Electronic Control Suspension(Limousine)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	ECS	Electronic Control Suspension(Sedan)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2015	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	ECS	Electronic Control Suspension(Limousine)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	ECS	Electronic Control Suspension(Sedan)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	ECS	Electronic Control Suspension(Limousine)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	ECS	Electronic Control Suspension(Sedan)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2014	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	ESP	Electronic Stability Program(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	ESP	Electronic Stability Program(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	EPB	Electric Parking Brake(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	EPB	Electric Parking Brake(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AIRCON	Air Conditioner(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AIRCON	Air Conditioner(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	EPS	Electric Hydraulic Power Steering(New-F/	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	EPS	Electronic Power Steering(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	ECS	Electronic Control Suspension(Limousine)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	ECS	Electronic Control Suspension(Sedan)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	SCC	Smart Cruise Control(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	SCC	Smart Cruise Control(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	TPMS	Tire Pressure Monitoring(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	TPMS	Tire Pressure Monitoring(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	LDWS	Lane Departure Warning System(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	LDWS	Lane Departure Warning System(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AHLS	Auto Headlamp Leveling System(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AHLS	Auto Headlamp Leveling(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AFLS	Adaptive Front Lighting System(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	AFLS	Adaptive Front Lighting System(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Smart Key Unit(New-F/L)	Smart Key Unit(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Smart Key Code Saving(Old)	Smart Key Code Saving(Old)	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	PSB-L	Pre-safe Seat Belt-Left(New-F/L)	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	PSB-L	Pre-safe Seat Belt-Left(Old)	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	PSB-R	Pre-safe Seat Belt-Right(New-F/L)	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	PSB-R	Pre-safe Seat Belt-Right(Old)	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	IPM	Instrument Panel Module(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	IPM	Instrument Panel Module(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	DDM	Driver Door Module(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	DDM	Driver Door Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	ADM	Assist Door Module(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	ADM	Assist Door Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	FAM	Front Area Module(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	FAM	Front Area Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Smart Junction Block(New-F/L)	Smart Junction Block(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	CLU	Cluster Module(New-F/L)	√	–	–	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	CLU	Cluster Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Head Up Display(New-F/L)	Head Up Display(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	PSM	Power Seat Module(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	PSM	Power Seat Module(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Assist Power Seat Module(New-F/L)	Assist Power Seat Module(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	PTM	Power Trunk Module(New-F/L)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	PTM	Power Trunk Module(Old)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	MFSW	Multi Function Switch(New-F/L)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	MFSW	Multi Function Switch(Old)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	SCM	Steering Column Module(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	SCM	Steering Column Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Steering Wheel Remote Control(New-F/L)	Steering Wheel Remote Control(New-F/L)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Front Back Warning System(Old)	Front Back Warning System(Old)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	ECW	Electric Control Wiper(New-F/L)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	ECW	Electric Control Wiper(Old)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Power Distribution Module(Old)	Power Distribution Module(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	User Option(Old)	User Option(Old)	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Head Unit(Old)	Head Unit(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 5.0 GDI	Tuner/Amplifier(Old)	Tuner/Amplifier(Old)	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	ESP	Electronic Stability Program(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	ESP	Electronic Stability Program(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	EPB	Electric Parking Brake(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	EPB	Electric Parking Brake(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AIRCON	Air Conditioner(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AIRCON	Air Conditioner(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	EPS	Electric Hydraulic Power Steering(New-F/	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	EPS	Electric Hydraulic Power Steering(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	ECS	Electronic Control Suspension(Limousine)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	ECS	Electronic Control Suspension(Sedan)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	SCC	Smart Cruise Control(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	SCC	Smart Cruise Control(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	TPMS	Tire Pressure Monitoring(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	TPMS	Tire Pressure Monitoring(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	LDWS	Lane Departure Warning System(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	LDWS	Lane Departure Warning System(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AHLS	Auto Headlamp Leveling System(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AHLS	Auto Headlamp Leveling(Old)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AFLS	Adaptive Front Lighting System(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	AFLS	Adaptive Front Lighting System(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Smart Key Unit(New-F/L)	Smart Key Unit(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Smart Key Code Saving(Old)	Smart Key Code Saving(Old)	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	PSB-L	Pre-safe Seat Belt-Left(New-F/L)	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	PSB-L	Pre-safe Seat Belt-Left(Old)	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	PSB-R	Pre-safe Seat Belt-Right(New-F/L)	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	PSB-R	Pre-safe Seat Belt-Right(Old)	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	IPM	Instrument Panel Module(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	IPM	Instrument Panel Module(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	DDM	Driver Door Module(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	DDM	Driver Door Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	ADM	Assist Door Module(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	ADM	Assist Door Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	FAM	Front Area Module(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	FAM	Front Area Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Smart Junction Block(New-F/L)	Smart Junction Block(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	CLU	Cluster Module(New-F/L)	√	–	–	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	CLU	Cluster Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Head Up Display(New-F/L)	Head Up Display(New-F/L)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	PSM	Power Seat Module(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	PSM	Power Seat Module(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Assist Power Seat Module(New-F/L)	Assist Power Seat Module(New-F/L)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	PTM	Power Trunk Module(New-F/L)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	PTM	Power Trunk Module(Old)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	MFSW	Multi Function Switch(New-F/L)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	MFSW	Multi Function Switch(Old)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	SCM	Steering Column Module(New-F/L)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	SCM	Steering Column Module(Old)	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Steering Wheel Remote Control(New-F/L)	Steering Wheel Remote Control(New-F/L)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Front Back Warning System(Old)	Front Back Warning System(Old)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	ECW	Electric Control Wiper(New-F/L)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	ECW	Electric Control Wiper(Old)	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Power Distribution Module(Old)	Power Distribution Module(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	User Option(Old)	User Option(Old)	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Head Unit(Old)	Head Unit(Old)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2013	G 3.8 GDI	Tuner/Amplifier(Old)	Tuner/Amplifier(Old)	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 5.0 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	AFLS	Adaptive Front Lighting(6 Speed)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	AFLS	Adaptive Front Lighting(8 Speed)	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2012	G 3.8 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	LDWS	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	LDWS	Lane Departure Warning System(China)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	LDWS	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	LDWS	Lane Departure Warning System(China)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2011	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	LDWS	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	LDWS	Lane Departure Warning System(China)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	LDWS	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	LDWS	Lane Departure Warning System(China)	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	EQUUS/CENTENNIAL(VI),10~16	2010	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	EXCEL(X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G70(IK),18~19	2019	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	G70(IK),18~19	2019	G 3.3 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G70(IK),18~19	2018	G 3.3 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G70(IK),18~19	2018	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.3 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 3.8 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2019	G 5.0 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.3 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 5.0 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 3.8 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2018	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 5.0 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	G80(DH),17~19	2017	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Assist Power Seat Module	Assist power seat module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Power Seat Module-Rear Left	Power seat module-Rear left	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Power Seat Module-Rear Right	Power seat module-Rear right	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Smart Junction Block	Smart junction block	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Electronic Control Suspension	Electronic control suspension	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Advanced Driver Assistance Systems_Parki	Advanced Driver Assistance Systems_Parki	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Active Air Flap	Active air flap	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Eshifter	E-Shifter	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Pre-safe Seat Belt	Pre-Safe seat belt	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Central Control Panel	Central Control Panel (CCP)	√	√	√	–	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Rear Remote Controller	Rear remote controller	√	√	√	–	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Steering Column Module	Steering column module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Multi Function Switch	Multi function switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Rear Wireless Power Charger	Rear wireless power charger	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Integrated Body Control Unit-Smart Key U	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Assist Door Module	Assist door module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Rear Armrest Switch	Rear armrest switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Central Gateway	Central gateway	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 5.0 GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Assist Power Seat Module	Assist power seat module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Power Seat Module-Rear Left	Power seat module-Rear left	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Power Seat Module-Rear Right	Power seat module-Rear right	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Smart Junction Block	Smart junction block	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Electronic Control Suspension	Electronic control suspension	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Advanced Driver Assistance Systems_Parki	Advanced Driver Assistance Systems_Parki	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Active Air Flap	Active air flap	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Eshifter	E-Shifter	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Pre-safe Seat Belt	Pre-Safe seat belt	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Central Control Panel	Central Control Panel (CCP)	√	√	√	–	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Rear Remote Controller	Rear remote controller	√	√	√	–	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Steering Column Module	Steering column module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Multi Function Switch	Multi function switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Rear Wireless Power Charger	Rear wireless power charger	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Integrated Body Control Unit-Smart Key U	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Assist Door Module	Assist door module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Rear Armrest Switch	Rear armrest switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Central Gateway	Central gateway	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.8 GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Assist Power Seat Module	Assist power seat module	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Power Seat Module-Rear Left	Power seat module-Rear left	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Power Seat Module-Rear Right	Power seat module-Rear right	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Smart Junction Block	Smart junction block	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Electronic Control Suspension	Electronic control suspension	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Around View Monitor System	Around view monitor system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Advanced Driver Assistance Systems_Parki	Advanced Driver Assistance Systems_Parki	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Active Air Flap	Active air flap	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2020	G 3.3 T-GDI	Eshifter	E-Shifter	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-Safe seat belt	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Central Control Panel	Central Control Panel (CCP)	√	√	√	–	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Rear Remote Controller	Rear remote controller	√	√	√	–	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Steering Column Module	Steering column module	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Multi Function Switch	Multi function switch	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Rear Wireless Power Charger	Rear wireless power charger	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Integrated Body Control Unit-Smart Key U	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Assist Door Module	Assist door module	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Rear Armrest Switch	Rear armrest switch	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Central Gateway	Central gateway	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2020	G 3.3 T-GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2019	G 3.3 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2019	G 3.8 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	690(HI),17~20	2019	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2019	G 5.0 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2018	G 3.3 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2018	G 3.8 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	G90(HI),17~20	2018	G 5.0 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 3.3 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 3.8 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Amplifier	Amplifier	–	–	–	–	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	G90(HI),17~20	2017	G 5.0 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	IMMO	Unleaded	–	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	IMMO	Leaded	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2003	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	IMMO	Unleaded	–	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	IMMO	Leaded	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2002	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	IMMO	Unleaded	–	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	IMMO	Leaded	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2001	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	IMMO	Unleaded	–	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	IMMO	Leaded	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	2000	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	IMMO	Unleaded	–	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	IMMO	Leaded	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1999	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	IMMO	Unleaded	–	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	IMMO	Leaded	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1998	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	ENGINE	Unleaded IMMO	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	ENGINE	Leaded IMMO	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	ENGINE	Leaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	IMMO	Unleaded	–	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	IMMO	Leaded	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	G 3.0 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GALLOPER-2(M1)-PDF,97~03	1997	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	–	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2017	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2016	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2015	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2014	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2013	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2012	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	ESP	ESP(MGH-40)(~2010. 9.14)	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	ESP	ESP(MGH-40)(~2010. 9.14)	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	ESP	ESP(MGH-60)(2010. 9.15~)	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	ESP	ESP(MGH-40)(~2010. 9.14)	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	ESP	ESP(MGH-40)(~2010. 9.14)	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	ESP	ESP(MGH-60)(2010. 9.15~)	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2011	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2010	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	GENESIS COUPE(BK),09~17	2009	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	GENESIS COUPE(BK)-U.S.,13	2013	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	AFLS	Adaptive Front Lighting(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	AFLS	Adaptive Front Lighting(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2012	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Adaptive Front Lighting	Adaptive Front Lighting	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Europe/General Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	AFLS	AFLS(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	AFLS	AFLS(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	IPM	Instrument Panel Module(W/ SMK)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	IPM	Instrument Panel Module(W/O SMK)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	AFLS	AFLS(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	AFLS	AFLS(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	IPM	Instrument Panel Module(W/ SMK)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	IPM	Instrument Panel Module(W/O SMK)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	AFLS	AFLS(HID)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	AFLS	AFLS(LED)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	IPM	Instrument Panel Module(W/ SMK)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	IPM	Instrument Panel Module(W/O SMK)	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	GENESIS(BH)-U.S.,13	2013	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.3 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2017	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.3 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2016	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.3 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2015	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.3 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	–	–	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Europe/General Area	GENESIS(DH),14~17	2014	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2011	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2010	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2009	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2008	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2007	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	AIRBAG	Airbag Control(Without PAB SW)	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2006	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GETZ(TB),03~11	2005	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2005	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2005	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2005	D 1.5 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	D 1.5 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2005	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2004	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2004	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2004	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2004	D 1.5 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	D 1.5 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2004	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GETZ(TB),03~11	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2003	D 1.5 TCI-D	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GETZ(TB),03~11	2003	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GETZ(TB),03~11	2003	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GETZ(TB),03~11	2003	D 1.5 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	D 1.5 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GETZ(TB),03~11	2003	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	D 1.2 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2019	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	D 1.2 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2018	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2017	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2016	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2015	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND i10/Xcent(BA),14~19	2014	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2019	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2018	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2017	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	AHLS	Auto Headlamp Leveling System(After PE)	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	AHLS	Auto Headlamp Leveling System(Before PE)	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	AHLS	Auto Headlamp Leveling System(After PE)	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	AHLS	Auto Headlamp Leveling System(Before PE)	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	AHLS	Auto Headlamp Leveling System(After PE)	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	AHLS	Auto Headlamp Leveling System(Before PE)	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2016	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2015	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	GRAND SANTAFE(NC),14~19	2014	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1997	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1996	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(LX),89~98	1995	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1995	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.5 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1994	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(LX),89~98	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Leaded All(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Unleaded GEN(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Unleaded IMMO(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Unleaded IMMO(Zi02)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2005	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Leaded(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Unleaded GEN(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Unleaded IMMO(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Unleaded IMMO(Zi02)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2004	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	ENGINE	Unleaded IMMO(ZiO2)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Leaded(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Unleaded GEN(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Unleaded IMMO(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Unleaded IMMO(ZiO2)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2003	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Leaded(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Unleaded GEN(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Unleaded IMMO(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2002	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Leaded(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Unleaded GEN(EST+)	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Unleaded IMMO(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2001	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Leaded(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Unleaded GEN(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Unleaded IMMO(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	2000	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Leaded(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Unleaded GEN(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Unleaded IMMO(EST+)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Unleaded IMMO(TiO2)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	AHLS	AHLS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR(XG),99~05	1999	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2017	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2016	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	AIRBAG	Airbag(Event #1)(~2014.08.10)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	AIRBAG	Airbag(Event #1)(2014.08.11~)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	AIRBAG	Airbag(Event #2)(~2014.08.10)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	AIRBAG	Airbag(Event #2)(2014.08.11~)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	AIRCON	Air Conditioner(~2014.08.10)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	AIRCON	Air Conditioner(2014.08.11~)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	SCC	Smart Cruise Control(~2014.08.10)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	SCC	Smart Cruise Control(2014.08.11~)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	SMK	Smart Key Unit(~2014.08.10)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	SMK	Smart Key Unit(2014.08.11~)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	BCM	Body Control Module(~2014.08.10)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	BCM	Body Control Module(2014.08.11~)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	CLU	Cluster Module(~2014.08.10)	√	√	√	–	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	CLU	Cluster Module(2014.08.11~)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 3.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	ENGINE	Engine Control(2014.08.11~)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	ENGINE	Leaded All(~2014.08.10)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	ENGINE	Leaded All(~2014.08.10)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	ENGINE	Unleaded All(~2014.08.10)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	ENGINE	Unleaded All(~2014.08.10)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	AIRBAG	Airbag(Event #1)(~2014.08.10)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	AIRBAG	Airbag(Event #1)(2014.08.11~)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	AIRBAG	Airbag(Event #2)(~2014.08.10)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	AIRBAG	Airbag(Event #2)(2014.08.11~)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	AIRCON	Air Conditioner(~2014.08.10)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	AIRCON	Air Conditioner(2014.08.11~)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	SCC	Smart Cruise Control(~2014.08.10)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	SCC	Smart Cruise Control(2014.08.11~)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	SMK	Smart Key Unit(~2014.08.10)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	SMK	Smart Key Unit(2014.08.11~)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	BCM	Body Control Module(~2014.08.10)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	BCM	Body Control Module(2014.08.11~)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	CLU	Cluster Module(~2014.08.10)	√	√	√	–	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	CLU	Cluster Module(2014.08.11~)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2015	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 3.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2014	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 3.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2013	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 3.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(HG),12~17	2012	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Rear Remote Controller	Rear remote controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Power Trunk Module	Power trunk module	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Steering Column Module	Steering column module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 2.4 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Rear Remote Controller	Rear remote controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Power Trunk Module	Power trunk module	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Steering Column Module	Steering column module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Blind Spot Detection	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Rear Remote Controller	Rear remote controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Power Trunk Module	Power trunk module	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Steering Column Module	Steering column module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Blind Spot Detection	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Rear Remote Controller	Rear remote controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Power Trunk Module	Power trunk module	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Steering Column Module	Steering column module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2020	G 3.5 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2019	G 3.5 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.5 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(IG),18~20	2018	G 3.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	AIRBAG	Airbag Control(General)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	AIRBAG	Airbag Control(NAS)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Driver Door Module	Driver Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2011	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	AIRBAG	Airbag Control(General)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	AIRBAG	Airbag Control(NAS)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2010	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	CODE	Transmitter Code Saving(~2009.01.04)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.8 DOHC	CODE	Transmitter Code Saving(2009.01.05~)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	CODE	Transmitter Code Saving(~2009.01.04)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 3.3 DOHC	CODE	Transmitter Code Saving(2009.01.05~)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	CODE	Transmitter Code Saving(~2009.01.04)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	G 2.7 DOHC	CODE	Transmitter Code Saving(2009.01.05~)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	SMK	Smart Key Unit(Button)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	SMK	Smart Key Unit(Key)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Power Distribution Module(Button)	Power Distribution Module(Button)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	Interface Unit(Key)	Interface Unit(Key)	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	SMKCODE	Smart Key Code Saving(Button)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	SMKCODE	Smart Key Code Saving(Key)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	BCM	Body Control Module(~2009.01.05)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	BCM	Body Control Module(2009.01.05~)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	DDM	Driver Door Module(~2009.01.05)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	DDM	Driver Door Module(2009.01.05~)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ADM	Assist Door Module(~2009.01.05)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	ADM	Assist Door Module(2009.01.05~)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	IMS	Integrated Memory System(~2009.01.05)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	IMS	Integrated Memory System(2009.01.05~)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	OPTION	User Option(~2009.01.05)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	OPTION	User Option(2009.01.05~)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	TILT	Tilt/Telescope(~2009.01.05)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	TILT	Tilt/Telescope(2009.01.05~)	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	CODE	Transmitter Code Saving(~2009.01.05)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	L 2.7 DOHC	CODE	Transmitter Code Saving(2009.01.05~)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	AIRBAG	Airbag Control(General)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	AIRBAG	Airbag Control(NAS)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	CODE	Transmitter Code Saving(~2009.01.04)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2009	D 2.2 TCI-D	CODE	Transmitter Code Saving(2009.01.05~)	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	AIRBAG	Airbag Control(General)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	AIRBAG	Airbag Control(NAS)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2008	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	AIRBAG	Airbag Control(General)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	AIRBAG	Airbag Control(NAS)	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2007	D 2.2 TC1-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	GRANDEUR/AZERA(TG),06~11	2006	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2009	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2009	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2009	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2009	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2009	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2008	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2008	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2008	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2008	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2008	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2007	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2007	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2007	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2007	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2007	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2006	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2006	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2006	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2006	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2006	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2005	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2005	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2005	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2005	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2005	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2004	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2004	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2004	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2004	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2004	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2003	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2003	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2003	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2003	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2003	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2002	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2002	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2002	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2002	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2002	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2001	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2001	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2001	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-1 TRUCK(SR),01~09	2001	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1 TRUCK(SR),01~09	2001	D 2.5 TCI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2009	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2009	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2008	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2008	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2007	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2006	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	ENGINE	Engine Control(VGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	ENGINE	Engine Control(WGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2006	D 2.5 TCI-A(WGT)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2005	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	ENGINE	Engine Control(VGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	ENGINE	Engine Control(WGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2005	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2004	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	ENGINE	Engine Control(VGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	ENGINE	Engine Control(WGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2004	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2003	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	ENGINE	Engine Control(VGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	ENGINE	Engine Control(WGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2003	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2002	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	ENGINE	Engine Control(VGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	ENGINE	Engine Control(WGT)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2002	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2001	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	ENGINE	Engine Control(T/C)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	ENGINE	Engine Control(TCI)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2001	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2000	G 2.4 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	ENGINE	Engine Control(T/C)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	ENGINE	Engine Control(TCI)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	2000	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1999	G 2.4 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	ENGINE	Engine Control(T/C)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	ENGINE	Engine Control(TCI)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1999	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1998	G 2.4 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	ENGINE	Engine Control(T/C)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	ENGINE	Engine Control(TCI)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1998	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1997	G 2.4 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	ENGINE	Engine Control(T/C)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	ENGINE	Engine Control(TCI)	–	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1(A1),97~09	1997	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Body Control	Body control module	√	–	–	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Tire Pressure Monitoring System	TPM	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Tire Pressure Monitoring System	TPM	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	G 2.4 DOHC	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Body Control	Body control module	√	–	–	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel fired heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Tire Pressure Monitoring System	TPM	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Tire Pressure Monitoring System	TPM	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	–	–	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Body Control	Body control module	√	–	–	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel fired heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring System	TPMS	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring System	TPMS	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-5)	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	–	–	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Body Control	Body control module	√	–	–	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel fired heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Selective Catalytic Reduction	Selective catalytic reduction	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring System	TPM	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring System	TPM	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2020	D 2.5 TCI-A2(Euro-6)	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-5)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2019	D 2.5 TCI-A2(Euro-6)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-5)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-A2(Euro-6)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2018	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-5)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-A2(Euro-6)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2017	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-5)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-A2(Euro-6)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2016	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2015	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Engine Control	Engine Control	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2014	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2013	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2012	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2011	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2010	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2009	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-4D56	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	H-1/iMAX/iLOAD(TQ),08~20	2008	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(AU),96~03	2003	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2003	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2003	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2003	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2003	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2003	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2003	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2003	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2002	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2002	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2002	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2002	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2002	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2002	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-100 TRUCK(AU),96~03	2002	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2002	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2001	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2001	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2001	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2001	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2001	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2001	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2001	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2000	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2000	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	2000	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1999	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1999	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1999	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1998	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1998	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1998	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1997	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1997	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1997	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1996	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1996	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(AU),96~03	1996	D 2.5 TC/TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2019	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2017	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2016	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2016	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2016	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2016	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2016	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2016	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2016	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2015	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2015	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2015	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2015	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2015	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2015	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2014	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2014	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2014	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2014	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2014	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2014	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2014	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2013	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2013	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	–	√	√	–	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2013	D 2.5 TCI-A2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2013	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2013	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2013	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2013	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2012	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2012	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2012	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2012	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2012	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2012	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2011	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2011	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2011	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2011	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2011	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2011	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2010	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2010	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2010	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2010	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2010	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2010	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2009	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2009	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H-100 TRUCK(HR),03~19	2009	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2009	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2009	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2009	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2008	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2008	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2008	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2008	D 2.5 TCI-A	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2008	D 2.5 TCI-A	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2008	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2007	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2007	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2007	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2006	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2006	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2006	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2005	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2005	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2005	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2004	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2004	D 2.5 TCI-4D56	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2004	D 2.5 TCI-4D56	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100 TRUCK(HR),03~19	2003	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2003	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	H-100 TRUCK(HR),03~19	2003	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	H-100(AH),93~01	2001	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	2001	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	2001	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	2000	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	2000	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	2000	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	2000	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1999	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1999	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1999	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1999	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1998	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1998	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1998	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1998	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1997	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1997	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1997	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1997	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1996	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1995	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1994	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	D 2.5 TCI-4D56	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Unleaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H-100(AH),93~01	1993	G 2.4 SOHC	ENGINE	Leaded	–	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Engine	Engine control	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Airbag	Airbag control	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Air Conditioner	Air conditioner(CCM)	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Lane Depature Warning System	Lane departure warning system	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Cluster Module	Cluster module	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Smart Junction Block	Smart junction block	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Driver Door Module	Driver door module	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Assist Door Module	Assist door module	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Central Gateway	Central gateway	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Digital Tachograph	Digital tachograph	–	√	√	–	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	H350(EU),15~19	2019	D 2.5 TCI-A2	Selective Catalytic Reduction	Selective catalytic reductio	–	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Air Conditioner(CCM)	Air Conditioner(CCM)	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Central Gateway	Central Gateway	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Digital Tachograph	Digital Tachograph	√	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2018	D 2.5 TCI-A2	Selective Catalytic Reductio	Selective Catalytic Reductio	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Air Conditioner(CCM)	Air Conditioner(CCM)	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Central Gateway	Central Gateway	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Digital Tachograph	Digital Tachograph	√	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2017	D 2.5 TCI-A2	Selective Catalytic Reductio	Selective Catalytic Reductio	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Air Conditioner(CCM)	Air Conditioner(CCM)	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Central Gateway	Central Gateway	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Digital Tachograph	Digital Tachograph	√	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2016	D 2.5 TCI-A2	Selective Catalytic Reductio	Selective Catalytic Reductio	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Airbag Control	Airbag Control	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Air Conditioner(CCM)	Air Conditioner(CCM)	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Central Gateway	Central Gateway	√	√	√	√	√	√	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Digital Tachograph	Digital Tachograph	√	√	√	–	–	–	
Europe/General Area	H350(EU),15~19	2015	D 2.5 TCI-A2	Selective Catalytic Reductio	Selective Catalytic Reductio	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Cluster Module	Cluster module	√	–	–	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Anti Lock Brake	Anti lock brake	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Telematics Unit	Telematics unit	√	√	√	–	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Cluster Module	Cluster module	√	–	–	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Anti Lock Brake	Anti lock brake	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Telematics Unit	Telematics unit	√	√	√	–	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.6 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Cluster Module	Cluster module	√	–	–	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Anti Lock Brake	Anti lock brake	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Telematics Unit	Telematics unit	√	√	√	–	–	–	
Europe/General Area	HB20(HB),13~19	2019	F 1.0 T-MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2018	F 1.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2017	F 1.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2016	F 1.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2015	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2014	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	√	
Europe/General Area	HB20(HB),13~19	2013	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2008	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2007	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2006	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2005	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2004	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	ENGINE	Unleaded(+CVVT) EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	ENGINE	Unleaded(+CVVT) GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	ENGINE	Unleaded(+CVVT) OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	ENGINE	Unleaded(-CVVT) EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	ENGINE	Unleaded(-CVVT) GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	ENGINE	Unleaded(-CVVT) OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	ENGINE	Unleaded(Ti 02S) EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	ENGINE	Unleaded(Ti 02S) OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	ENGINE	Unleaded(Ti 02S) OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	ENGINE	Unleaded(Zr 02S) EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	ENGINE	Unleaded(Zr 02S) OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2003	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Body Control Module	Body Control Module	–	–	–	√	√	–	
Europe/General Area	HD COUPE(GK),02~08	2002	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	ENGINE	Unleaded EOBD	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2001	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	2000	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1999	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1998	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.6 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	HD COUPE(RC),97~01	1997	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-KWP	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.0 MPI-UDS	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2019	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-UDS	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2018	G 1.0 MPI-KWP	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-UDS	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2017	G 1.0 MPI-KWP	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2016	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2015	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	B 1.0 LPGI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i10(IA),14~19	2014	G 1.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2017	B 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2017	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2017	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2017	G 1.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2017	G 1.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2017	G 1.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2017	G 1.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2016	B 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2016	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2016	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2016	G 1.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2016	G 1.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2016	G 1.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2016	G 1.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2015	B 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2015	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2015	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2015	G 1.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2015	G 1.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2015	G 1.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2015	G 1.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2014	B 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2014	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2014	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2014	G 1.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2014	G 1.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2014	G 1.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2014	G 1.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2013	B 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2013	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2013	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2013	G 1.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2013	G 1.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2013	G 1.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2013	G 1.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2012	B 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2012	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2012	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2012	G 1.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2012	G 1.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2012	G 1.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2012	G 1.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2011	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2011	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2011	G 1.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2011	G 1.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2011	G 1.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2011	G 1.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2010	D 1.1 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	D 1.1 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	D 1.1 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	D 1.1 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2010	D 1.1 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2010	D 1.1 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2010	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2010	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2009	D 1.1 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	D 1.1 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	D 1.1 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2009	D 1.1 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2009	D 1.1 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2009	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2009	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2009	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2009	G 1.2 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.2 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.2 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.2 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.2 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2009	G 1.2 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2009	G 1.2 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2009	G 1.2 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2008	D 1.1 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2008	D 1.1 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i10(PA),08~17	2008	D 1.1 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2008	D 1.1 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2008	D 1.1 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i10(PA),08~17	2008	G 1.1 SOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2008	G 1.1 SOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2008	G 1.1 SOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2008	G 1.1 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2008	G 1.1 SOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i10(PA),08~17	2008	G 1.1 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i10(PA),08~17	2008	G 1.1 SOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i10(PA),08~17	2008	G 1.1 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2019	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(GB),14~19	2018	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2018	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2017	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2016	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2015	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	i20(GB),14~19	2014	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2019	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2018	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2017	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2016	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2015	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i20(IB),14~19	2014	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2016	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(PB),09~16	2015	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2015	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2014	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.1 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	SMK	Smart Key Unit(W/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	SMK	Smart Key Unit(WO/ESCL)	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2013	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2012	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2012	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2011	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	AIRCON	Air Conditioner(India)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	AIRCON	Air Conditioner(Turkey)	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2011	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2010	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2010	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.4 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2009	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i20(PB),09~16	2009	G 1.2 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	ENGINE	Engine Control(ISG-/CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	ENGINE	Engine Control(ISG-/CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	ENGINE	Engine Control(ISG+/CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	ENGINE	Engine Control(ISG+/CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	ENGINE	Engine Control(ISG-/CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	ENGINE	Engine Control(ISG-/CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	ENGINE	Engine Control(ISG+/CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	ENGINE	Engine Control(ISG+/CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	ENGINE	Engine Control(ISG-/CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	ENGINE	Engine Control(ISG-/CPF+)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	ENGINE	Engine Control(ISG+/CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	ENGINE	Engine Control(ISG+/CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2010	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30(FDe),09~12	2009	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2018	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2018	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2017	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2017	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2016	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	i30(GD),13~18	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2014	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2013	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2013	F 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GD),13~18	2013	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Service Reminder	Service Reminder	–	–			–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GDe),13~17	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i30(GDe),13~17	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2019	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2018	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2018	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PD),18~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Anti Lock Brake	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Tire Pressure Monitoring System	i-Tire pressure monitoring system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system(5DR)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system(Fastback)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system(WGN)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Anti Lock Brake	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Tire Pressure Monitoring System	i-Tire pressure monitoring system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system(5DR)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system(Fastback)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system(WGN)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.6 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Anti Lock Brake	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Tire Pressure Monitoring System	i-Tire pressure monitoring system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Automatic Headlamp Leveling	Auto headlamp leveling system(5DR)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Automatic Headlamp Leveling	Auto headlamp leveling system(Fastback)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Automatic Headlamp Leveling	Auto headlamp leveling system(WGN)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Anti Lock Brake	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Tire Pressure Monitoring System	i-Tire pressure monitoring system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system(5DR)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system(Fastback)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system(WGN)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.0 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Anti Lock Brake	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Tire Pressure Monitoring System	i-Tire pressure monitoring system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system(5DR)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system(Fastback)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system(WGN)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	i30(PDE),17~20	2020	G 1.4 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Anti Lock Brake	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Selective Catalytic Reduction	Selective catalytic reduction	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Tire Pressure Monitoring System	i-Tire pressure monitoring system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Automatic Headlamp Leveling	Auto headlamp leveling system(5DR)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Automatic Headlamp Leveling	Auto headlamp leveling system(Fastback)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Automatic Headlamp Leveling	Auto headlamp leveling system(WGN)	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	i30(PDE),17~20	2020	D 1.6 TCI-NEW-U	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2019	D 1.6 TCI-NEW-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	e-Call	e-Call	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2018	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	AHLS	Auto Headlamp Leveling System(5DR)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	AHLS	Auto Headlamp Leveling System(Fastback)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	AHLS	Auto Headlamp Leveling System(WGN)	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2017	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30(PDE),17~20	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	ENGINE	ISG(-)/CPF(-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	ENGINE	ISG(-)/CPF(+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	ENGINE	ISG(+)/CPF(-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	ENGINE	ISG(+)/CPF(+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2011	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2011	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NE0S(FD),08~12	2011	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	ENGINE	ISG(-)/CPF(-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	ENGINE	ISG(-)/CPF(+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	ENGINE	ISG(+)/CPF(-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	ENGINE	ISG(+)/CPF(+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	ENGINE	ISG(-)/CPF(-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	ENGINE	ISG(-)/CPF(+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	ENGINE	ISG(+)/CPF(-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	ENGINE	ISG(+)/CPF(+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2010	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2009	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	TPMS	TPMS	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	TPMS	TPMS	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	TPMS	TPMS	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	TPMS	TPMS	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	TPMS	TPMS	√	√	√	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	i30/ELANTRA NEOS(FD),08~12	2008	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Electronic Limited Slip Differential	Electronic limited slip differential	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Electronic Sound Generator	Electronic Sound Generator (ESG)	√	√	√	–	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Electronic Control Suspension	Electronic control suspension	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	i30N(PDEN),18~20	2020	G 2.0 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Electronic Limited Slip Differential	Electronic limited slip differential	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Electronic Sound Generator	Electronic Sound Generator (ESG)	√	√	√	–	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Electronic Control Suspension	Electronic control suspension	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	i30N(PDEN),18~20	2019	G 2.0 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Electronic Limited Slip Differential	Electronic Limited Slip Differential	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Electronic Sound Generator	Electronic Sound Generator	√	√	√	–	–	–	
Europe/General Area	i30N(PDEN),18~20	2018	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.6 TCI-NEW-U	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 1.6 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2019	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2019	D 1.7 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2018	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2018	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2018	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2017	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2017	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2016	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Europe/General Area	i40(VF),12~19	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i40(VF),12~19	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2013	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2012	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Europe/General Area	i40(VF),12~19	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	EV Motor Control System	EV Motor Control System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	EV Battery System	EV Battery System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	VCULDC	VCULDC	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2019	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	EV Motor Control System	EV Motor Control System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	EV Battery System	EV Battery System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	VCULDC	VCULDC	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2018	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	EV Motor Control System	EV Motor Control System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	EV Battery System	EV Battery System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	VCULDC	VCULDC	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ electric(AE EV),17~19	2017	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2019	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2018	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ hybrid(AE HEV),17~19	2017	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Motor Control System	Motor Control System	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	PHEV Battery System	PHEV Battery System	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	On Board Charger	On Board Charger	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix20(JC),11~19	2014	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix20(JC),11~19	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2018	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2017	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2016	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2015	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	ABS/ESP	ABS/ESP	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2014	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35 FCEV(LM FCEV),13~18	2013	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	D 2.0 TCI-R(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	D 2.0 TCI-R(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	D 2.0 TCI-R(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix35(EL),10~16	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2011	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2010	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	ix35(EL),10~16	2010	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	D 3.0 TCI-S2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	D 3.0 TCI-S2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	4WD Control	4WD Control	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2011	D 3.0 TCI-S	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2010	D 3.0 TCI-S	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2009	D 3.0 TCI-S	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2008	D 3.0 TCI-S	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Body Control Module	Body Control Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	User Option	User Option	–	–	–	√	–	√	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	IMS	IMS	√	√	√	√	√	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
Europe/General Area	ix55/VERACRUZ(EN),07~13	2007	D 3.0 TCI-S	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2019	150KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	KONA electric(OS EV),18~19	2018	150KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	G 1.0 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	4WD Control	4WD Control	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Selective Catalytic Reduction	Selective catalytic reduction	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2020	D 1.6 TCI-NEW-U	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	4WD	4WD	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	D 1.6 TCI-NEW-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	4WD	4WD	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	4WD	4WD	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	KONA(OS),18~20	2018	G 1.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1998	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1997	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	MARCIA(HL),96~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MARCIA(HL),96~98	1996	G 2.5 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2011	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2010	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2009	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2008	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2007	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2006	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2006	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-U	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-U	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2005	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2004	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2004	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2004	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2004	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2004	D 1.5 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2004	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2004	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2004	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2003	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2003	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2003	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2003	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2003	D 1.5 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2003	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2003	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2003	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	ENGINE	Leaded All	–	√	√	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	ENGINE	Unleaded GEN	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2002	G 1.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	MATRIX(FC),02~11	2002	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2002	D 1.5 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2002	D 1.5 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	MATRIX(FC),02~11	2002	D 1.5 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	MATRIX(FC),02~11	2002	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2002	D 1.5 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	MATRIX(FC),02~11	2002	D 1.5 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Active Hydraulic Booster	Active hydraulic booster	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Motor Control System	FCEV Motor control system	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Battery Management System	FCEV Battery system	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Hydrogen storage system	Hydrogen storage system	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Bi-directional High DC/DC Convertor	Bi-Directional high DC/DC Convertor	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Fuel Cell System	Fuel cell system	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Fuel Cell System	Fuel cell system	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Stack Volt Monitor	Stack volt monitor	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Blower Pump Control Unit	Blower pump control unit	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Remote Smart Parking Assist	Remote smart parking assist	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Auto Flush-Handle Control Unit-DRV	Auto flush-Handle control unit-DRV	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Auto Flush-Handle Control Unit-PAS	Auto flush-Handle control unit-PAS	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Auto Flush-Handle Control Unit-RL	Auto flush-Handle control unit-RL	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Auto Flush-Handle Control Unit-RR	Auto flush-Handle control unit-RR	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Radiator Fan-Left	Radiator fan-Left	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Radiator Fan-Right	Radiator fan-Right	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Active Hood System	Active hood system	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Eshifter	E-Shifter(SBW)	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2020	113KW	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	–	–	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Integrated Central Control Unit	Integrated Central Control Unit	–	√	√	√	–	–	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	NEXO(FE),19~20	2019	113KW	E-Shifter(SBW)	E-Shifter(SBW)	√	√	√	√	√	–	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	NEXO(FE),19~20	2019	113KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	NEXO(FE),19~20	2019	113KW	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Power Tailgate	Power Tailgate	√	√	√	√	–	√	
Europe/General Area	NEXO(FE),19~20	2019	113KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	PODS-F	PODS-F	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	PODS-F	PODS-F	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Telematics Unit	Telematics Unit	–	–	–	–	–	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 3.5 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2013	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 3.5 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2012	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(CM),06~13	2011	G 3.5 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2011	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 3.5 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	AIRBAG	Airbag(GEN)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	AIRBAG	Airbag(NAS)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2010	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	G 2.7 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	AIRBAG	Airbag(GEN)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	AIRBAG	Airbag(NAS)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2009	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(CM),06~13	2008	G 2.7 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	AIRBAG	Airbag(GEN)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	AIRBAG	Airbag(NAS)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2008	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	G 2.7 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	AIRBAG	Airbag(GEN)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	AIRBAG	Airbag(NAS)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2007	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	G 2.7 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SANTAFE(CM),06~13	2006	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2018	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2017	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	AHLS	Auto Headlamp Leveling System(After PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	AHLS	Auto Headlamp Leveling System(Before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	AHLS	Auto Headlamp Leveling System(After PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	AHLS	Auto Headlamp Leveling System(Before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	AHLS	Auto Headlamp Leveling System(After PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	AHLS	Auto Headlamp Leveling System(Before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	AHLS	Auto Headlamp Leveling System(After PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	AHLS	Auto Headlamp Leveling System(Before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	AHLS	Auto Headlamp Leveling System(After PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	AHLS	Auto Headlamp Leveling System(Before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(DM),13~18	2016	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	AHLS	Auto Headlamp Leveling System(after PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	AHLS	Auto Headlamp Leveling System(after PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2015	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	AHLS	Auto Headlamp Leveling System(after PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	AHLS	Auto Headlamp Leveling System(after PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	AHLS	Auto Headlamp Leveling System(after PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(DM),13~18	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	Engine	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	A/T (Automatic Transaxle)	A/T (Automatic Transaxle)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	ABS/ESP	ABS/ESP (Anti Lock Brake/Electronic Stab	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	CLU (Cluster Module)	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	EPB (Electric Parking Brake)	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	TPMS (Tire Pressure Monitoring System)	Tire Pressure Monitoring System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	IMMO (Immobilizer)	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	CODE (Transmitter Code Saving)	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	AIRCON (Air Conditioner)	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	EPS (Motor Driven Power Steering)	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	EPS (Motor Driven Power Steering)	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	BCM (Body Control)	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	AHLS (Automatic Headlamp Leveling)	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	AFLS (Adaptive Front Lighting System)	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	LDWS (Lane Depature Warning System)	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	TMU (Telematics Unit)	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	4WD (4WD Control)	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	SPAS (Smart Parking Assist System)	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	SMK (Smart Key Unit)	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	PSM (Power Seat Module)	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	SJB (Smart Junction Block)	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	SJB (Smart Junction Block)	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	DDM (Driver Door Module)	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DM),13~18	2013	G 3.0 GDI	ADM (Assist Door Module)	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2018	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2017	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2016	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2015	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(DMI),14~18	2014	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(VGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2006	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(VGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	Traction Control	Traction Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	AIRBAG	General	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	AIRBAG	NAS	√	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2005	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(VGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2004	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ENGINE	Unleaded EOBD(TiO2)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ENGINE	Unleaded EOBD(ZrO2)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ENGINE	Unleaded GEN(TiO2)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ENGINE	Unleaded GEN(ZrO2)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ENGINE	Unleaded OBD-II(TiO2)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ENGINE	Unleaded OBD-II(ZrO2)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(VGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2003	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(VGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	ENGINE	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2002	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	D 2.0 TCI-D(WGT)	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	D 2.0 TCI-D(WGT)	D 2.0 TCI-D(WGT)	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	ABS	2WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	ABS	4WD	√	√	√	√	√	√	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	4WD Control	4WD Control	–	√	√	–	–	–	
Europe/General Area	SANTAFE(SM),01~06	2001	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Surround View Monitoring	Surround View Monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Parking Assist	Parking assist	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Surround View Monitoring	Surround View Monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Parking Assist	Parking assist	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 2.4 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Surround View Monitoring	Surround View Monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Parking Assist	Parking assist	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	G 3.5 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Surround View Monitoring	Surround View Monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Parking Assist	Parking assist	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-5)	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Surround View Monitoring	Surround View Monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Parking Assist	Parking assist	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Euro-6)	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Selective Catalytic Reduction	Selective catalytic reduction	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Surround View Monitoring	Surround View Monitor	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Parking Assist	Parking assist	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.0 TCI-R(Enhanced euro	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Selective Catalytic Reduction	Selective catalytic reduction	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Surround View Monitoring	Surround View Monitor	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Parking Assist	Parking assist	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	SANTAFE(TM),19~20	2020	D 2.2 TCI-R(Enhanced euro	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Surround View Monitor	Surround View Monitor	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Parking Assist	Parking Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Power Tailgate	Power Tailgate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Surround View Monitor	Surround View Monitor	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Parking Assist	Parking Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Front View Camera	Front View Camera	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Power Tailgate	Power Tailgate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Surround View Monitor	Surround View Monitor	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Parking Assist	Parking Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Front View Camera	Front View Camera	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Power Tailgate	Power Tailgate	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	G 3.5 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Surround View Monitor	Surround View Monitor	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Parking Assist	Parking Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Front View Camera	Front View Camera	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Power Tailgate	Power Tailgate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Euro-6)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Surround View Monitor	Surround View Monitor	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Parking Assist	Parking Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Front View Camera	Front View Camera	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Power Tailgate	Power Tailgate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.0 TCI-R(Enhanced Euro	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Surround View Monitor	Surround View Monitor	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Parking Assist	Parking Assist	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Front View Camera	Front View Camera	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Power Tailgate	Power Tailgate	√	√	√	√	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SANTAFE(TM),19~20	2019	D 2.2 TCI-R(Enhanced Euro	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2002	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2001	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	2000	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1999	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1998	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
Europe/General Area	SANTAMO(M2),97~03	1997	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Unleaded CAL	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Unleaded FED	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Unleaded FED	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Unleaded T/C	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Unleaded T/C	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Unleaded CAL	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Unleaded FED	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Unleaded FED	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Unleaded T/C	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Unleaded T/C	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Unleaded GEN	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Unleaded T/C(92~94)	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Unleaded T/C(92~94)	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Unleaded T/C(94~96)	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Unleaded T/C(94~96)	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	ENGINE	Leaded All	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Melco)	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	ENGINE	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	ENGINE	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	ENGINE	Unleaded T/C	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	ENGINE	Unleaded T/C	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC(Bosch)	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Unleaded All	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Unleaded All	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Unleaded All	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Unleaded All	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Unleaded All	Unleaded All	√	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Inter Panel Module	Inter Panel Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2019	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	CD Player	CD Player	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Inter Panel Module	Inter Panel Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2018	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Inter Panel Module	Inter Panel Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2017	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Inter Panel Module	Inter Panel Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2016	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Inter Panel Module	Inter Panel Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	SONATA hybrid(LF HEV),15~19	2015	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Motor Control System	HEV Motor system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Hybrid Control/Low DC-DC Converter	Hybrid control/Low DC-DC Converter	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Battery Management System	HEV Battery system	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Electronic Stability Control/Active Hydr	Electronic stability control/Active hyd	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Occupant Detection Sensor	Weight classification system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Smart Cruise Control	Smart cruise control	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Tire Pressure Monitoring System	TPM	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Lane Depature Warning System	Lane departure warning system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Blind Spot Detection-L	Blind Spot Detection (BSD) - left	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Blind Spot Detection-R	Blind Spot Detection (BSD) - right	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Central Gateway	Central gateway	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Telematics Unit	Telematics unit	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2018	G 2.0 HEV	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Motor Control System	HEV Motor system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Hybrid Control/Low DC-DC Converter	Hybrid control/Low DC-DC Converter	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Battery Management System	HEV Battery system	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Electronic Stability Control/Active Hydr	Electronic stability control/Active hyd	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Occupant Detection Sensor	Weight classification system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Smart Cruise Control	Smart cruise control	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Tire Pressure Monitoring System	TPM	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Lane Depature Warning System	Lane departure warning system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Blind Spot Detection-L	Blind Spot Detection (BSD) - left	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Blind Spot Detection-R	Blind Spot Detection (BSD) - right	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Central Gateway	Central gateway	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Telematics Unit	Telematics unit	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2017	G 2.0 HEV	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~1	2016	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2016	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Motor Control System	HEV Motor system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Hybrid Control/Low DC-DC Converter	Hybrid control/Low DC-DC Converter	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Battery Management System	HEV Battery system	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Electronic Stability Control/Active Hydr	Electronic stability control/Active hydr	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Occupant Detection Sensor	Weight classification system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Smart Cruise Control	Smart cruise control	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Tire Pressure Monitoring System	TPM	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Lane Depature Warning System	Lane departure warning system	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Blind Spot Detection-L	Blind Spot Detection (BSD) - left	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Blind Spot Detection-R	Blind Spot Detection (BSD) - right	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Active Air Flap	Active air flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Central Gateway	Central gateway	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Telematics Unit	Telematics unit	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(LF HEV)-U.S.,15~	2015	G 2.0 HEV	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2015	G 2.4 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV),14~15	2014	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~	2014	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2014	G 2.4 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA hybrid(YF HEV)-U.S.,13~1	2013	G 2.4 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	ENGINE	Engine Control(EOBD)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	ENGINE	Engine Control(RUSSIA)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	ENGINE	Engine Control(EOBD)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	ENGINE	Engine Control(RUSSIA)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2005	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2004	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	ENGINE	Unleaded(Ti O2S) EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	ENGINE	Unleaded(Ti O2S) OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	ENGINE	Unleaded(Zr O2S) EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	ENGINE	Unleaded(Zr O2S) OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2003	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2002	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2001	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	2000	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	ENGINE	Unleaded GEN(Melco)	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	ENGINE	Unleaded GEN(Siemens)	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	ENGINE	Unleaded IMMO	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Traction Control	Traction Control	–	√	√	√	√	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA(EF),99~06	1999	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2019	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	EPS	Motor Driven Power Steering(After FL)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	EPS	Motor Driven Power Steering(After FL)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	EPS	Motor Driven Power Steering(Before FL)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	EPS	Motor Driven Power Steering(Before FL)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	SCC	Smart Cruise Control(After FL)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	SCC	Smart Cruise Control(Before FL)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	BSD-L	Blind Spot Detection-Left(Before FL)	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	BSD-L	Blind Spot Detection-Left(After FL)	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	BSD-R	Blind Spot Detection-Right(After FL)	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	BSD-R	Blind Spot Detection-Right(Before FL)	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	AHLS	Auto Headlamp Leveling System(After FL)	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	AHLS	Auto Headlamp Leveling System(Before FL)	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	SONATA(LF),15~19	2018	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2017	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(LF),15~19	2016	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LF),15~19	2015	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Air Conditioner	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-L	Blind spot detection-left	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-R	Blind spot detection-right	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Smart Cruise Control	Smart cruise control	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Tire Pressure Monitoring System	Tire pressure monitoring	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Air Conditioner	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Blind Spot Detection-L	Blind spot detection-left	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Blind Spot Detection-R	Blind spot detection-right	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Smart Cruise Control	Smart cruise control	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Tire Pressure Monitoring System	Tire pressure monitoring	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Air Conditioner	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Blind Spot Detection-L	Blind spot detection-left	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Blind Spot Detection-R	Blind spot detection-right	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Driver Door Module	Driver door module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Smart Cruise Control	Smart cruise control	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Tire Pressure Monitoring System	Tire pressure monitoring	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	BODY CONTROL MODULE	BODY CONTROL MODULE	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2010	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	BODY CONTROL MODULE	BODY CONTROL MODULE	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2009	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	AGCS	AGCS	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(NF),05~10	2008	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2007	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	AT	4-Speed	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	AT	5-Speed	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2006	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	–	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(NF),05~10	2005	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(Y2),89~93	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1993	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1992	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(Y2),89~93	1991	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1991	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1990	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y2),89~93	1989	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Unleaded OBD-II	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Unleaded OBD-II	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Unleaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	ENGINE	Leaded All	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	AIRBAG	AIRBAG	–	√	√	√	–	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Cruise Control	Cruise Control	√	√	√	√	√	√	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Europe/General Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2013	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	EPS	Motor Driven Power Steering(~September23	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	EPS	Motor Driven Power Steering(~September23	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	EPS	Motor Driven Power Steering(September24/	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	EPS	Motor Driven Power Steering(~September23	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	EPS	Motor Driven Power Steering(~September23	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	EPS	Motor Driven Power Steering(September24/	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2012	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YFA)-U.S.,11~14	2011	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YFI),12~15	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFI),12~15	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YFI),12~15	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YFI),12~15	2015	G 2.4 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	SONATA(YFI),12~15	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YFI),12~15	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2013	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA(YF1),12~15	2012	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2013	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	ESP	Electronic Stability Program(Bosch)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	ESP	Electronic Stability Program(Mobis)	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2012	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Auto Headlamp Leveling	Auto Headlamp Leveling	√	√	√	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	SONATA/i45(YF),11~15	2011	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.9 TCI	Immobilizer	Immobilizer	–	–	–	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2006	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.9 TCI	Immobilizer	Immobilizer	–	–	–	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2005	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.9 TCI	Immobilizer	Immobilizer	–	–	–	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2004	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.9 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2003	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.9 TCI	Immobilizer	Immobilizer	–	–	–	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2002	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.9 TCI	Immobilizer	Immobilizer	–	–	–	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	AIRBAG	AIRBAG	√	√	√	√	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	4WD	TOD	√	√	√	–	–	–	
Europe/General Area	TERRACAN(HP),01~06	2001	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	AIRBAG	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	ENGINE	VGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	ENGINE	WGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2007	D 2.0 TCI-D	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	ENGINE	VGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	ENGINE	WGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2006	D 2.0 TCI-D	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	ENGINE	VGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	ENGINE	WGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2005	D 2.0 TCI-D	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Siemens)	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Siemens)	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Siemens)	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Siemens)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Siemens)	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Siemens)	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Siemens)	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Siemens)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.0 DOHC(Melco)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	ENGINE	VGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	ENGINE	WGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2004	D 2.0 TCI-D	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	ENGINE	Unleaded(Ti 02S) EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	ENGINE	Unleaded(Ti 02S) GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	ENGINE	Unleaded(Zr 02S) EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	ENGINE	Unleaded(Zr 02S) GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	ENGINE	VGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	ENGINE	WGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2003	D 2.0 TCI-D	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	ENGINE	Engine Control	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	ENGINE	WGT	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2002	D 2.0 TCI-D	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2001	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2001	D 2.0 TCI-D	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	D 2.0 TCI-D	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	2000	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	2000	D 2.0 TCI-D	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TRAJET XG(FO),99~07	1999	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	ABSESP	ABS/ESP(MGH25)	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	ABSESP	ABS/ESP(MGH40)	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Body Control Module	Body Control Module	√	–	–	√	√	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Body Control Module	Body Control Module	√	–	–	√	√	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2013	F 2.0 E-FFV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	ABSESP	ABS/ESP(MGH25)	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	ABSESP	ABS/ESP(MGH40)	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Body Control Module	Body Control Module	√	–	–	√	√	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Body Control Module	Body Control Module	√	–	–	√	√	–	
Europe/General Area	TUCSON FFV(JM FFV),12~13	2012	F 2.0 E-FFV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2010	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2009	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	ABSESP	ABS/ESP(MGH-25)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	ABSESP	ABS/ESP(MGH-40)	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2008	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2007	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2007	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2006	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2006	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	ENGINE	Unleaded OBD-II	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2005	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	Airbag Control	Airbag Control	√	√	√	√	–	–	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	4WD Control	4WD Control	√	√	√	–	–	–	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	ETACS	ETACS	√	–	–	√	√	–	
Europe/General Area	TUCSON(JM),05~10	2005	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2018	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(LM)-BRAZIL,17~18	2017	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Euro-6)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2019	D 2.0 TCI-R(Enhanced Euro	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2018	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2017	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TL),15~19	2016	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2016	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(High Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 1.7 TCI-U2(Low Power)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TL),15~19	2015	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 1.6 TCI-NEW-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	ENGINE	Engine Control(Before FL)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	ENGINE	Engine Control(After FL)	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	ENGINE	Engine Control(After FL)	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	AT	Automatic Transaxle(Before FL)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	AT	Automatic Transaxle(After FL)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	EPS	R-MDPS(RHD-Western Europe)(Before FL)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	EPS	R-MDPS(LHD-Western Europe)(Before FL)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	EPS	C-MDPS(Eastern Europe/General)(Before FL	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Lane Departure Warning System(Before FL)	Lane Departure Warning System(Before FL)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	BSD-L	Blind Spot Detection-Left(Before FL)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	BSD-L	Blind Spot Detection-Left(After FL)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	BSD-R	Blind Spot Detection-Right(Before FL)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Around View Monitor	Around View Monitor	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Parking Guide System	Parking Guide System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2019	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2018	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TLe),15~19	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	AT	Automatic Transaxle(2WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	AT	Automatic Transaxle(4WD)	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	EPS	C-MDPS(Eastern Europe/General)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	EPS	R-MDPS(LHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	EPS	R-MDPS(RHD-Western Europe)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	TUCSON(TLe),15~19	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2018	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Europe/General Area	TUCSON(TLD),17~18	2017	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-NU	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.0 MPI-Theta2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	F 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2011	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	ENGINE	Engine Control(CPF-)	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	ENGINE	Engine Control(CPF+)	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	ENGINE	Unleaded EOBD	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	ENGINE	Unleaded GEN	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	AIRCON	Air Conditioner(EURO)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	AIRCON	Air Conditioner(GEN)	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Europe/General Area	TUCSON/ix35(LM),10~16	2010	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	Electronic Limited Slip Differential	Electronic Limited Slip Differential	√	√	√	√	√	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	VELOSTER N(JSN),19	2019	G 2.0 T-GDI	Electronic Sound Generator	Electronic Sound Generator	√	√	√	–	–	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2018	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	AT	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	AT	Double Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	AT	Double Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	AT	Double Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	AT	Double Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(FS),11~18	2011	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Smart Cruise Control	Smart cruise control	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Integrated Gateway Power Control Module	Integrated gateway power module	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabi	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Smart Cruise Control	Smart cruise control	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	ECALL	e-Call	√	√	√	–	–	–	
Europe/General Area	VELOSTER(JS),19~20	2020	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Front View Camera	Front View Camera	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	e-Call	e-Call	√	√	√	–	–	√	
Europe/General Area	VELOSTER(JS),19~20	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2017	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2016	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2015	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2014	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2013	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2012	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	Engine Control	Engine Control	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	D 1.4 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	ENGINE	Leaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	ENGINE	Unleaded All	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	BCM	Body Control Module(SMK-)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	BCM	Body Control Module(SMK+)	√	√	√	√	√	√	
Europe/General Area	VERNA(RBI),11~17	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Cluster Module	Cluster module	√	–	–	√	√	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Reina(CB),20	2020	G 1.4 MPI	Immobilizer	Immobilizer		√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Automated Manual Transmission	Automated manual transmission	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Eshifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Body Control	Body control module	√	–	–	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Automated Manual Transmission	Automated manual transmission	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Eshifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Body Control	Body control module	√	–	–	√	√	–	
Europe/General Area	Santro(AH2),19~20	2020	G 1.1 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Automated Manual Transmission	Automated Manual Transmission	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Body Control	Body control module	√	–	–	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Eshifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Engine	Engine control	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Automated Manual Transmission	Automated Manual Transmission	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Body Control	Body control module	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Body Control	Body control module	√	–	–	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Eshifter	E-Shifter	√	√	√	√	√	–	
Europe/General Area	Santro(AH2),19~20	2019	G 1.1 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Anti Lock Brake/Electronic Stability Con	ABS/ESC(+EPB)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	SBW Control Unit	SBW Control Unit	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	E-Shifter SBW	E-Shifter	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Integrated Body Control Unit-Immobilizer	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Integrated Body Control Unit-Smart Key U	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.8 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Anti Lock Brake/Electronic Stability Con	ABS/ESC(+EPB)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	SBW Control Unit	SBW Control Unit	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	E-Shifter SBW	E-Shifter	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Integrated Body Control Unit-Immobilizer	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Integrated Body Control Unit-Smart Key U	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	G 3.5 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Anti Lock Brake/Electronic Stability Con	ABS/ESC(+EPB)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Selective Catalytic Reduction	Selective catalytic reduction	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	SBW Control Unit	SBW Control Unit	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	E-Shifter SBW	E-Shifter	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Integrated Body Control Unit-Immobilizer	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Integrated Body Control Unit-Smart Key U	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	Palisade (LX2),20	2020	D 2.2 DOHC	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Active Hood System	Active hood system	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Engine	Engine control	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Integrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Blind-Spot Collision Warning	Blind spot detection	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Active Hood System	Active hood system	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Audio Video Navigation	Audio video navigation	√	–	–	–	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Integrated Body Control Unit-Body Contro	Integrated body control unit-Body contro	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Integrated Body Control Unit-Immobilizer	Integrated body control unit-Immobilizer	–	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Integrated Body Control Unit-Smart Key U	Integrated body control unit-Smart key u	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Integrated Body Control Unit-Tire Pressu	Integrated body control unit-Tire pressu	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
Europe/General Area	Santafe (TMA),19	2019	G 2.0 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Engine	Engine control	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Continuously Variable Transmission	Continuously variable transmission	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Body Control	Body control module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Tire Pressure Monitoring System	Tire pressure monitoring(low)	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Tire Pressure Monitoring System	Tire pressure monitoring(high)	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Seat Belt Reminder/Lighting Module	Seat belt reminder/Lighting module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2021	G 1.6 MPI-GAMMA II	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Seat Belt Reminder/Lighting Module	Seat belt reminder/Lighting module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Tire Pressure Monitoring System	Tire pressure monitoring(low)	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Tire Pressure Monitoring System	Tire pressure monitoring(high)	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Body Control	Body control module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Engine	Engine control	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Continuously Variable Transmission	Continuously variable transmission	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Tire Pressure Monitoring System	Tire pressure monitoring(low)	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Tire Pressure Monitoring System	Tire pressure monitoring(high)	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Seat Belt Reminder/Lighting Module	Seat belt reminder/Lighting module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Body Control	Body control module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2020	G 1.6 MPI-GAMMA II	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	TPMS	Tire Pressure Monitoring System(Low)	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	TPMS	Tire Pressure Monitoring System(High)	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2019	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	TPMS	Tire Pressure Monitoring System(High)	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	TPMS	Tire Pressure Monitoring System(Low)	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Seat Belt Reminder/Lighting Module	Seat Belt Reminder/Lighting Module	√	√	√	√	√	–	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ACCENT(HC),18~21	2018	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2005	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2005	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2005	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2005	G 1.5 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2005	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2005	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2005	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2005	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2005	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2005	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2005	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2004	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2004	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2004	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2004	G 1.5 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2004	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2004	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2004	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2004	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2004	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2004	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2004	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2003	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2003	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2003	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2003	G 1.5 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2003	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2003	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2003	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2003	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2003	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2003	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2003	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2003	G 1.6 DOHC	Transmitter Code Saving								
US Area	ACCENT(LC),00~05	2002	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2002	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2002	G 1.5 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2002	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2002	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2002	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2002	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2002	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2002	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2002	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2002	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2001	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2001	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2001	G 1.5 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2001	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2001	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2001	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2001	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2001	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2001	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2001	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ACCENT(LC),00~05	2001	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2001	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2000	G 1.5 SOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2000	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2000	G 1.5 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2000	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2000	G 1.5 SOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2000	G 1.5 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(LC),00~05	2000	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	–	√	
US Area	ACCENT(LC),00~05	2000	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(LC),00~05	2000	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(LC),00~05	2000	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2000	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ACCENT(LC),00~05	2000	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ABS	ABS(MGH-25)	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ABS	ABS(MGH-40)	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	ABS	ABS(MGH-60)	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ABS	ABS(MGH-25)	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	ABS	ABS(MGH-40)	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	ACCENT(MC),06~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ACCENT(RB),12~17	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ACCENT(RB),12~17	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ACCENT(RB),12~17	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ACCENT(RB),12~17	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ACCENT(RB),12~17	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1999	G 1.5 SOHC/DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1998	G 1.5 SOHC/DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1997	G 1.5 SOHC/DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1996	G 1.5 SOHC/DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Engine Control	Engine Control	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Engine Control	Engine Control	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ACCENT(X3),95~99	1995	G 1.5 SOHC/DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	AZERA(HG),12~17	2017	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	AZERA(HG),12~17	2016	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	AZERA(HG),12~17	2015	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	AZERA(HG),12~17	2014	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	AZERA(HG),12~17	2013	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	AZERA(HG),12~17	2012	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2011	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2010	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	CODE	Transmitter Code Saving(~January 04/2009	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.8 DOHC	CODE	Transmitter Code Saving(January 05/2009~	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	CODE	Transmitter Code Saving(~January 04/2009	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2009	G 3.3 DOHC	CODE	Transmitter Code Saving(January 05/2009~	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2008	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	AZERA(TG),06~11	2006	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2015	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA COUPE(JK),13~15	2013	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2017	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2017	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Service Reminder	Service Reminder	√	–	–	–	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2016	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2015	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA GT(GD),13~17	2013	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergend	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergend	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ELANTRA GT(PD),18~20	2020	G 2.0 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergend	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 1.6 T-GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergend	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2019	G 2.0 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	ELANTRA GT(PD),18~20	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2012	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2010	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ELANTRA TOURING(FD),09~12	2009	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Automatic Transaxle	Continuously Variable Transmission	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Assist Door Module	Assist door module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Intergrated Body Control Unit-Tire Press	Integrated Body Control Unit-TPMS	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Intergrated Body Control Unit-Body Contr	Integrated Body Control Unit-BCM	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 2.0 MPI	Front View Camera	Front View Camera	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated Body Control Unit-BCM	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated Body Control Unit-TPMS	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2020	G 1.6 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(AD),17~20	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Power Seat Module	Power seat module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Assist Door Module	Assist door module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous Emergenc	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated Body Control Unit-BCM	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated Body Control Unit-TPMS	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 1.4 T-GDI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Assist Door Module	Assist door module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Blind Spot Detection	Blind spot detection	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Intergrated Body Control Unit-Body Contr	Integrated Body Control Unit-BCM	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Automatic Transaxle	Continuously Variable Transmission	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Power Seat Module	Power seat module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous Emergenc	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Intergrated Body Control Unit-Tire Press	Integrated Body Control Unit-TPMS	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2020	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2018	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	ELANTRA(ADA),17~20	2017	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ELANTRA(HD),07~10	2010	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ELANTRA(HD),07~10	2009	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ELANTRA(HD),07~10	2008	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	ELANTRA(HD),07~10	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1995	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1994	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.8 DOHC	Cruise Control								
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1993	G 1.6 DOHC	Cruise Control								
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(J1),92~95	1992	G 1.6 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(MD),11~16	2016	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(MD),11~16	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(MD),11~16	2015	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(MD),11~16	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(MD),11~16	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(MD),11~16	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2013	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2012	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(MD),11~16	2011	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	2000	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	AT	Automatic Transaxle(June1/1999~)	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1999	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1998	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1997	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Engine Control	Engine Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Engine Control	Engine Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(RD),96~00	1996	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(UD),11~16	2016	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(UD),11~16	2015	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	ELANTRA(UD),11~16	2014	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2013	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2012	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	ELANTRA(UD),11~16	2011	G 1.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	ENGINE	Engine Control(Non SULEV)	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	ENGINE	Engine Control(SULEV)	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	AT	Automatic Transaxle(Non SULEV)	√	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	AT	Automatic Transaxle(SULEV)	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2002	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	ELANTRA(XD),01~06	2001	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Rear Area Module	Rear Area Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Power Sliding Door-Left	Power Sliding Door-Left	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Power Sliding Door-Right	Power Sliding Door-Right	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2010	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Rear Area Module	Rear Area Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Power Sliding Door-Left	Power Sliding Door-Left	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Power Sliding Door-Right	Power Sliding Door-Right	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2009	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Rear Area Module	Rear Area Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Power Sliding Door-Left	Power Sliding Door-Left	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Power Sliding Door-Right	Power Sliding Door-Right	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2008	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Rear Area Module	Rear Area Module	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Power Sliding Door-Left	Power Sliding Door-Left	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Power Sliding Door-Right	Power Sliding Door-Right	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	ENTOURAGE(EP),07~10	2007	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Electronic Hydraulic Power Steering Syst	Electronic Hydraulic Power Steering Syst	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2016	G 5.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Electronic Hydraulic Power Steering Syst	Electronic Hydraulic Power Steering Syst	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2015	G 5.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Electronic Hydraulic Power Steering Syst	Electronic Hydraulic Power Steering Syst	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2014	G 5.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Electronic Hydraulic Power Steering Syst	Electronic Hydraulic Power Steering Syst	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Electronic Hydraulic Power Steering Syst	Electronic Hydraulic Power Steering Syst	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	EQUUS(VI),11~16	2013	G 5.0 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Electronic Hydraulic Power Steering Syst	Electronic Hydraulic Power Steering Syst	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Electronic Hydraulic Power Steering Syst	Electronic Hydraulic Power Steering Syst	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	EQUUS(VI),11~16	2012	G 5.0 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Electronic Hydraulic Power Steering Syst	Electronic Hydraulic Power Steering Syst	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	EQUUS(VI),11~16	2011	G 4.6 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	EXCEL(X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Surround View Monitor	Surround View Monitor	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Blind-Spot Collision Warning-Left	Blind-Spot Collision Warning-Left	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Blind-Spot Collision Warning-Right	Blind-Spot Collision Warning-Right	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G70(IK),18~19	2019	G 3.3 T-GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Surround View Monitor	Surround View Monitor	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Blind-Spot Collision Warning-Left	Blind-Spot Collision Warning-Left	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Blind-Spot Collision Warning-Right	Blind-Spot Collision Warning-Right	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G70(IK),18~19	2019	G 2.0 T-GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Surround View Monitor	Surround View Monitor	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Blind-Spot Collision Warning-Left	Blind-Spot Collision Warning-Left	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Blind-Spot Collision Warning-Right	Blind-Spot Collision Warning-Right	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G70(IK),18~19	2018	G 3.3 T-GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Surround View Monitor	Surround View Monitor	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Blind-Spot Collision Warning-Left	Blind-Spot Collision Warning-Left	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Blind-Spot Collision Warning-Right	Blind-Spot Collision Warning-Right	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G70(IK),18~19	2018	G 2.0 T-GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.3 T-GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	G80(DH),17~19	2019	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2019	G 5.0 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.3 T-GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	G80(DH),17~19	2018	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 5.0 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	AT	Automatic Transaxle(SBC)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	AT	Automatic Transaxle(SBW)	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Parking Brake	Parking Brake	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Electronic Stability Program	Electronic Stability Program	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	AVN	Audio Video Navigation(Premium)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	AVN	Audio Video Navigation(Standard)	√	–	–	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2018	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	AVN	Audio Video Navigation(Non DIS)	√	–	–	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	AVN	Audio Video Navigation(with DIS)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	G80(DH),17~19	2017	G 5.0 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	AVN	Audio Video Navigation(Non DIS)	√	–	–	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	AVN	Audio Video Navigation(with DIS)	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	G80(DH),17~19	2017	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Integrated Body Control Unit-SMK	Integrated Body Control Unit-SMK	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Integrated Body Control Unit-SMK	Integrated Body Control Unit-SMK	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
US Area	G90(HI),17~19	2019	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Integrated Body Control Unit-SMK	Integrated Body Control Unit-SMK	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	G90(HI),17~19	2018	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Integrated Body Control Unit-SMK	Integrated Body Control Unit-SMK	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
US Area	G90(HI),17~19	2018	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Integrated Body Control Unit-SMK	Integrated Body Control Unit-SMK	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Power Seat Module-Rear Left	Power Seat Module-Rear Left	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Integrated Body Control Unit-SMK	Integrated Body Control Unit-SMK	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Power Seat Module-Rear Right	Power Seat Module-Rear Right	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Rear Armrest Switch	Rear Armrest Switch	√	√	√	√	√	√	
US Area	G90(HI),17~19	2017	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS COUPE(BK),10~16	2016	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS COUPE(BK),10~16	2015	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS COUPE(BK),10~16	2014	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS COUPE(BK),10~16	2013	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2012	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2011	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	GENESIS COUPE(BK),10~16	2010	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AHLS	AHLS	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	AFLS	AFLS(LED)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	IPM	Inter Panel Module(with SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Multimedia								
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS(BH),09~14	2014	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	AFLS	AFLS(LED)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	IPM	Inter Panel Module(with SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Multimedia								
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS(BH),09~14	2014	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AHLS	AHLS	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	AFLS	AFLS(LED)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	IPM	Inter Panel Module(with SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Multimedia								
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS(BH),09~14	2014	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AHLS	AHLS	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	AFLS	AFLS(LED)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Multimedia								
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS(BH),09~14	2013	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	AFLS	AFLS(LED)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Multimedia								
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS(BH),09~14	2013	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AHLS	AHLS	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	AFLS	AFLS(LED)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Multimedia								
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	GENESIS(BH),09~14	2013	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AHLS	AHLS	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	AFLS	AFLS(LED)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2012	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	AFLS	AFLS(LED)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2012	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	AHLS	AHLS	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	AFLS	AFLS(HID)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	AFLS	AFLS(LED)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2012	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2011	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2011	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2010	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2010	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2009	G 4.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	IPM	Inter Panel Module(Non DIS)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	IPM	Inter Panel Module(with DIS)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electric Hydraulic Power Steering	Electric Hydraulic Power Steering	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	IPM	Inter Panel Module(Non SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	IPM	Inter Panel Module(With SMK)	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
US Area	GENESIS(BH),09~14	2009	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	AVN	Audio Video Navigation(Non DIS)	√	–	–	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	AVN	Audio Video Navigation(with DIS)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2017	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	AVN	Audio Video Navigation(Non DIS)	√	–	–	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	AVN	Audio Video Navigation(with DIS)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2017	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	AVN	Audio Video Navigation(Non DIS)	√	–	–	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	AVN	Audio Video Navigation(with DIS)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	GENESIS(DH),15~16	2016	G 5.0 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	AVN	Audio Video Navigation(Non DIS)	√	–	–	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	AVN	Audio Video Navigation(with DIS)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	GENESIS(DH),15~16	2016	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	AVN	Audio Video Navigation(Non DIS)	√	–	–	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	AVN	Audio Video Navigation(with DIS)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	GENESIS(DH),15~16	2015	G 5.0 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Occupant Classification Sensor	Occupant Classification Sensor	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Electronic Control Suspension	Electronic Control Suspension	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	AVN	Audio Video Navigation(Non DIS)	√	–	–	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	AVN	Audio Video Navigation(with DIS)	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	GENESIS(DH),15~16	2015	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Electronic Stability Program/Active Hydr	Electronic stability program/Active hyda	–	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Power Seat Module	Power seat module	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Electric Parking Brake	Electric parking brake	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	–	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Vehicle Control System/Low DC-DC Convert	Vehicle control system/Low DC-DC Convert	–	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	On Board Charger	On board charger	–	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Assist Door Module	Assist door module	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Battery Management System	EV Battery system	–	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Motor Control System	EV Motor control system	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Charging Control Module	Charging control module	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Active Air Flap	Active Air Flap 2	√	–	–	–	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Active Air Flap	Active Air Flap 1	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Blind Spot Detection-L	Blind spot detection left	–	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Blind Spot Detection-R	Blind spot detection right	–	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	E-Shifter SBW	E-Shifter	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Multi Function Camera	Multi function camera	–	√	√	–	–	–	
US Area	IONIQ Electric(AE EV),17~20	2020	100KW	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	EV Motor Control System	EV Motor Control System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	EV Battery System	EV Battery System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	VCULDC	VCULDC	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2019	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	EV Motor Control System	EV Motor Control System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	EV Battery System	EV Battery System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	VCULDC	VCULDC	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2018	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	EV Motor Control System	EV Motor Control System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	EV Battery System	EV Battery System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	VCULDC	VCULDC	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	ESP/AHB	ESP/AHB	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
US Area	IONIQ Electric(AE EV),17~20	2017	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Engine	Engine control	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Power Seat Module	Power seat module	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Electric Parking Brake	Parking brake	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Multi Function Camera	Multi function camera	–	√	√	–	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Assist Door Module	Assist door module	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Motor Control System	Hybrid Electric Vehicle (HEV) motor cont	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Active Air Flap-Right	Active air flap-Right	√	–	–	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Battery Management System	HEV Battery system	–	√	√	–	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Hybrid Control/Low DC-DC Converter	Hybrid control/Low DC-DC Converter	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Active Air Flap-Left	Active air flap-Left	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Blind Spot Detection-R	Blind spot detection right	–	√	√	–	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	–	√	√	–	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Electronic Stability Control/Active Hydr	Electronic stability control/Active hyd	–	√	√	–	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Automatic Transaxle	Double Clutch Transmission	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Blind Spot Detection-L	Blind spot detection left	–	√	√	–	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Automatic Headlamp Leveling	Auto headlamp leveling system	–	√	√	–	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2020	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2019	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2018	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	IONIQ Hybrid(AE HEV),17~20	2017	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Engine	Engine control	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Power Seat Module	Power seat module	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Electric Parking Brake	Parking brake	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Hybrid Control/Low DC-DC Converter	Hybrid control/Low DC-DC Converter	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Assist Door Module	Assist door module	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	On Board Charger	On board charger	–	√	√	–	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	On Board Charger	On board charger	–	√	√	–	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Active Air Flap-Left	Active air flap-Left	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Battery Management System	PHEV Battery system	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Blind Spot Detection-R	Blind spot detection right	–	√	√	–	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Automatic Transaxle	Double Clutch Transmission	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Anti Lock Brake/Electronic Stability Con	Electronic stability control/Active hyd	–	√	√	–	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	–	√	√	–	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Multi Function Camera	Multi function camera	–	√	√	–	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Adaptive Front Lighting System	Adaptive front lighting system	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Motor Control System	PHEV Motor control system	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Automatic Headlamp Leveling	Auto headlamp leveling system	–	√	√	–	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Blind Spot Detection-L	Blind spot detection left	–	√	√	–	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2020	G 1.6 GDI PHEV	Active Air Flap-Right	Active air flap-Right	√	–	–	–	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	PHEV Motor Control System	PHEV Motor Control System	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	PHEV Battery System	PHEV Battery System	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	On Board Charger	On Board Charger	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2019	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	PHEV Motor Control System	PHEV Motor Control System	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	PHEV Battery System	PHEV Battery System	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	SCC/AEB	SCC/AEB	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	On Board Charger	On Board Charger	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Integrated Gateway Power Module	Integrated Gateway Power Module	√	√	√	√	√	√	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	IONIQ Plug-in Hybrid(AE PHEV),1	2018	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	KONA electric(OS EV),19~21	2021	150KW	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Air Conditioner	Air conditioner	–	√	√	–	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	E-Shifter SBW	E-Shifter	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Active Air Flap	Active air flap	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Occupant Detection Sensor	Occupant Detection System (ODS)	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Motor Control System	EV Motor control system	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Vehicle Control System/Low DC-DC Convert	Vehicle control system/Low DC-DC Convert	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Battery Management System	EV Battery system	–	√	√	–	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	On Board Charger	On board charger	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Charging Control Module	Charging control module	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2021	150KW	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Battery Management System	EV Battery system	–	√	√	–	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Charging Control Module	Charging control module	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	On Board Charger	On board charger	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	E-Shifter SBW	E-Shifter	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Active Air Flap	Active air flap	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Vehicle Control System/Low DC-DC Convert	Vehicle control system/Low DC-DC Convert	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Air Conditioner	Air conditioner	–	√	√	–	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Occupant Detection Sensor	Occupant Detection System (ODS)	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2020	150KW	Motor Control System	EV Motor control system	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2019	150KW	EV Motor Control System	EV Motor Control System	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	EV Battery System	EV Battery System	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	VCULDC	VCULDC	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	ABS/ESP	ABS/ESP	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2019	150KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2019	150KW	Charging Control Module	Charging Control Module	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2019	150KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2019	150KW	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Occupant Detection System	Occupant Detection System	√	√	√	√	–	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	KONA electric(OS EV),19~21	2019	150KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2019	150KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	KONA electric(OS EV),19~21	2019	150KW	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	KONA electric(OS EV),19~21	2019	150KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability cos	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning(Ironman)	–	√	√	–	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Active Air Flap	Active air flap	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 2.0 MPI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability cos	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning(Ironman)	–	√	√	–	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Automatic Transaxle	Double Clutch Transmission	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2021	G 1.6 T-GDI	Active Air Flap	Active air flap	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Active Air Flap	Active air flap	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning(Ironman)	–	√	√	–	–	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 2.0 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning(Ironman)	–	√	√	–	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Active Air Flap	Active air flap	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Lane Keeping Assist System	Lane keeping assist system	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	KONA(OS),18~21	2020	G 1.6 T-GDI	Automatic Transaxle	Double Clutch Transmission	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	4WD	4WD	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	4WD	4WD	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	4WD	4WD	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	4WD	4WD	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Lane Keeping Assist	Lane Keeping Assist	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	KONA(OS),18~21	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	NEXO(FE),19~21	2021	113KW	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Auto Flush-Handle Control Unit-PAS	Auto flush-Handle control unit-PAS	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Remote Smart Parking Assist	Remote smart parking assist	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Auto Flush-Handle Control Unit-RR	Auto flush-Handle control unit-RR	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Low DC/DC Converter	Low DC/DC Converte	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Blower Pump Control Unit	Blower pump control unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Active Hood System	Active hood system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Intergrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Hydrogen Storage System	Hydrogen storage system management unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Stack Volt Monitor	Stack volt monitor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Fuel Cell System	Fuel cell unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Fuel Cell System	Fuel cell unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	E-Shifter SBW	E-Shifter(SBW)	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Auto Flush-Handle Control Unit-RL	Auto flush-Handle control unit-RL	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Battery Management System	FCEV Battery system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Radiator Fan-Left	Radiator fan-Left	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Bi-directional High DC/DC Convertor	Bi-Directional high DC/DC Convertor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Auto Flush-Handle Control Unit-DRV	Auto flush-Handle control unit-DRV	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Motor Control System	FCEV Motor control system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2021	113KW	Radiator Fan-Right	Radiator fan-Right	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Blower Pump Control Unit	Blower pump control unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	E-Shifter SBW	E-Shifter(SBW)	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Low DC/DC Converter	Low DC/DC Converte	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Radiator Fan-Left	Radiator fan-Left	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Auto Flush-Handle Control Unit-RL	Auto flush-Handle control unit-RL	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Radiator Fan-Right	Radiator fan-Right	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Battery Management System	FCEV Battery system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Hydrogen Storage System	Hydrogen storage system management unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Remote Smart Parking Assist	Remote smart parking assist	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Active Hood System	Active hood system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Intergrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Bi-directional High DC/DC Convertor	Bi-Directional high DC/DC Convertor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Auto Flush-Handle Control Unit-RR	Auto flush-Handle control unit-RR	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Motor Control System	FCEV Motor control system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Auto Flush-Handle Control Unit-PAS	Auto flush-Handle control unit-PAS	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Fuel Cell System	Fuel cell unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Fuel Cell System	Fuel cell unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Stack Volt Monitor	Stack volt monitor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Auto Flush-Handle Control Unit-DRV	Auto flush-Handle control unit-DRV	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2020	113KW	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2019	113KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	FCEV Battery System	FCEV Battery System	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Hydrogen storage system Management Unit	Hydrogen storage system Management Unit	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Bi-directional High DC/DC Convertor	Bi-directional High DC/DC Convertor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2019	113KW	Low DC/DC Converte	Low DC/DC Converte	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2019	113KW	Fuel Cell Unit	Fuel Cell Unit	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2019	113KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2019	113KW	Surround View Monitor System	Surround View Monitor System	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	NEXO(FE),19~21	2019	113KW	Remote Smart Parking Assist	Remote Smart Parking Assist	√	√	√	√	–	√	
US Area	NEXO(FE),19~21	2019	113KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	NEXO(FE),19~21	2019	113KW	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Auto Flush-Handle Control Unit-PAS	Auto Flush-Handle Control Unit-PAS	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Auto Flush-Handle Control Unit-RL	Auto Flush-Handle Control Unit-RL	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Auto Flush-Handle Control Unit-RR	Auto Flush-Handle Control Unit-RR	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Auto Flush-Handle Control Unit-DRV	Auto Flush-Handle Control Unit-DRV	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Radiator Fan-Left	Radiator Fan-Left	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Radiator Fan-Right	Radiator Fan-Right	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	NEXO(FE),19~21	2019	113KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	NEXO(FE),19~21	2019	113KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	NEXO(FE),19~21	2019	113KW	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	NEXO(FE),19~21	2019	113KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	NEXO(FE),19~21	2019	113KW	Active Hood System	Active Hood System	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	E-Shifter(SBW)	E-Shifter(SBW)	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Integrated Body Control Unit-SMK	Integrated Body Control Unit-SMK	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
US Area	NEXO(FE),19~21	2019	113KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	NEXO(FE),19~21	2019	113KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	NEXO(FE),19~21	2019	113KW	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	NEXO(FE),19~21	2019	113KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	PODS-F	PODS-F	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Amplifier								
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Amplifier								
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2018	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	PODS-F	PODS-F	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Amplifier								
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Amplifier								
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2017	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE SPORT(DMA),13~18	2013	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 3.5 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2012	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 3.5 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2011	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	AIRBAG	Event #1	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	AIRBAG	Event #2	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 3.5 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	AIRBAG	Event #1	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	AIRBAG	Event #2	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2010	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2009	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2008	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SANTAFE(CM),07~12	2007	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE(NC),13~19	2019	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE(NC),13~19	2018	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Multi-View Camera System	Multi-View Camera System	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE(NC),13~19	2017	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE(NC),13~19	2016	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE(NC),13~19	2015	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE(NC),13~19	2014	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SANTAFE(NC),13~19	2013	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Traction Control System	Traction Control System	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2006	G 2.4 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Traction Control System	Traction Control System	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2006	G 2.7 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	ABS	2WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	ABS	4WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Traction Control System	Traction Control System	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2006	G 3.5 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ABS	2WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ABS	4WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Traction Control System	Traction Control System	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2005	G 2.4 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ABS	2WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ABS	4WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Traction Control System	Traction Control System	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2005	G 2.7 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	ABS	2WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	ABS	4WD	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Traction Control System	Traction Control System	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2005	G 3.5 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2004	G 2.4 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2004	G 2.7 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2004	G 3.5 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2003	G 2.4 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2003	G 2.7 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2003	G 3.5 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2002	G 2.4 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	ABS	2WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	ABS	4WD	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2002	G 2.7 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2001	G 2.4 DOHC	Transmitter Code Saving								
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	–	√	√	√	√	√	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	4WD Control	4WD Control	–	√	√	–	–	–	
US Area	SANTAFE(SM),01~06	2001	G 2.7 DOHC	Transmitter Code Saving								
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Engine	Engine control	–	–	–	–	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Active Hood System	Active hood system	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Intergrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Intergrated Body Control Unit-Immobilize	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.0 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Engine	Engine control	–	–	–	–	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Intergrated Body Control Unit-Immobilize	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Active Hood System	Active hood system	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist(FCA/S	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Intergrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2020	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Surround View Monitor System	Surround View Monitor System	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Surround View Monitor System	Surround View Monitor System	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Integrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Rear View Monitor	Rear View Monitor	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Surround View Monitor System	Surround View Monitor System	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	IBU-IMMO	IBU-IMMO	–	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	IBU-SMK	IBU-SMK	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	SANTAFE(TMA),19~20	2019	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Engine Control(California)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Engine Control(Federal)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1996	G 1.5 SOHC	Cruise Control								
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Engine Control(California)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Engine Control(Federal)	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1995	G 1.5 SOHC	Cruise Control								
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Engine Control(California)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Engine Control(Federal)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1994	G 1.5 SOHC	Cruise Control								
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	ENGINE	Engine Control(California)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	ENGINE	Engine Control(Federal)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1993	G 1.5 SOHC	Cruise Control								
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	ENGINE	Engine Control(California)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	ENGINE	Engine Control(California)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	ENGINE	Engine Control(Federal)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	ENGINE	Engine Control(Federal)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	ENGINE	Engine Control(Turbo)	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1992	G 1.5 SOHC	Cruise Control								
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	California	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	California	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	California	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	California	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	California	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	California	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	California	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	California	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	Federal	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	Federal	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	Federal	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	Federal	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	ENGINE	Federal	√	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SCOUPE(L1),91~96	1991	G 1.5 SOHC	Cruise Control								
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	CD Player	CD Player	√	√	√	–	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2019	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	CD Player	CD Player	√	√	√	–	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2018	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA Hybrid(LF HEV),16~19	2017	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	HEV Motor Control System	HEV Motor Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA Hybrid(LF HEV),16~19	2016	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2015	G 2.4 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2014	G 2.4 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2013	G 2.4 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2012	G 2.4 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	HEV Motor System	HEV Motor System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	HEV Battery System	HEV Battery System	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA Hybrid(YF HEV),11~15	2011	G 2.4 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	PHEV Motor Control System	PHEV Motor Control System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	PHEV Battery System	PHEV Battery System	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	CD Player	CD Player	√	√	√	–	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2019	G 2.0 PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	PHEV Motor Control System	PHEV Motor Control System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	PHEV Battery System	PHEV Battery System	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Around View Monitor System	Around View Monitor System	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	CD Player	CD Player	√	√	√	–	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2018	G 2.0 PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	PHEV Motor Control System	PHEV Motor Control System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	PHEV Battery System	PHEV Battery System	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2017	G 2.0 PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	PHEV Motor Control System	PHEV Motor Control System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	PHEV Battery System	PHEV Battery System	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	ESC/AHB	ESC/AHB	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	On Board Charger	On Board Charger	√	√	√	√	–	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA Plug-in Hybrid(LF PHEV),	2016	G 2.0 PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2005	G 2.4 DOHC	Transmitter Code Saving								
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2005	G 2.7 DOHC	Transmitter Code Saving								
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2004	G 2.4 DOHC	Transmitter Code Saving								
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2004	G 2.7 DOHC	Transmitter Code Saving								
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Electronic Power Steering								

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2003	G 2.4 DOHC	Transmitter Code Saving								
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2003	G 2.7 DOHC	Transmitter Code Saving								
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	ABS	`February15/2002(ITT)	–	√	√	√	√	√	
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	ABS	February15/2002`(Bosch)	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2002	G 2.4 DOHC	Transmitter Code Saving								
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	ABS	`February15/2002(ITT)	–	√	√	√	√	√	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	ABS	February15/2002`(Bosch)	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2002	G 2.7 DOHC	Transmitter Code Saving								
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2001	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2001	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2000	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	2000	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	1999	G 2.4 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Electronic Power Steering								
US Area	SONATA(EF),99~05	1999	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2018	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Amplifier								
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Amplifier								
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Amplifier								
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2017	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Amplifier								
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Amplifier								
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Amplifier								
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2016	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Amplifier								
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2015	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Amplifier								
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Electronic Parking Brake	Electronic Parking Brake	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	FATC/MTC	FATC/MTC	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Smart Cruise Control	Smart Cruise Control	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Amplifier								
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(LFA),15~19	2015	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2010	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2010	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2009	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Weight Classification	Weight Classification	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2009	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2008	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2008	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2007	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	AT	4-Speed	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	AT	5-Speed	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(NF),06~10	2006	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	–	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Body Control Module	Body Control Module	√	–	–	√	√	√	
US Area	SONATA(NF),06~10	2006	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1994	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1994	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Cruise Control								

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(Y2),89~94	1993	G 2.0 DOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1993	G 3.0 SOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1992	G 2.0 DOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1992	G 3.0 SOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1991	G 3.0 SOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1991	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1990	G 3.0 SOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1990	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1989	G 3.0 SOHC	Electronic Power Steering								
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Cruise Control								
US Area	SONATA(Y2),89~94	1989	G 2.4 DOHC	Electronic Power Steering								
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1998	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1997	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1996	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1995	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 3.0 SOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	SONATA(Y3),94~98	1994	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(YFA),11~14	2014	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(YFA),11~14	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(YFA),11~14	2013	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(YFA),11~14	2013	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	EPS	Motor Driven Power Steering(~September23	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	EPS	Motor Driven Power Steering(~September23	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	EPS	Motor Driven Power Steering(September24/	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(YFA),11~14	2012	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	EPS	Motor Driven Power Steering(~September23	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	EPS	Motor Driven Power Steering(~September23	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	EPS	Motor Driven Power Steering(September24/	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	SONATA(YFA),11~14	2012	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2011	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	SONATA(YFA),11~14	2011	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	ABS/ESC	ABS/ESC	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2008	G 2.7 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2008	G 2.7 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	ABS/ESC	ABS/ESC	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2007	G 2.0 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Immobilizer								
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2007	G 2.7 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Electronic Stability Control	Electronic Stability Control	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2006	G 2.0 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Immobilizer								
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2006	G 2.7 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Electronic Stability Control	Electronic Stability Control	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2005	G 2.0 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Automatic Headlamp Leveling System	Automatic Headlamp Leveling System	√	√	√	√	–	√	
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Immobilizer								
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2005	G 2.7 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Electronic Stability Control	Electronic Stability Control	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2004	G 2.0 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Electronic Stability Control	Electronic Stability Control	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Immobilizer								
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2004	G 2.7 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2003	G 2.0 DOHC	Transmitter Code Saving								
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	ENGINE	Engine Control(~January1/2003)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	ENGINE	Engine Control(~January1/2003)	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	ENGINE	Engine Control(January1/2003~)	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Immobilizer								
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Body Control Module								
US Area	TIBURON(GK),03~08	2003	G 2.7 DOHC	Transmitter Code Saving								
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Cruise Control								
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Electronic Power Steering								
US Area	TIBURON(RC),97~01	2001	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Cruise Control								
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Electronic Power Steering								
US Area	TIBURON(RC),97~01	2000	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	AT	Automatic Transaxle(June1/1999~)	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	AT	Automatic Transaxle(~June1/1999)	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Cruise Control								
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Electronic Power Steering								
US Area	TIBURON(RC),97~01	1999	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Cruise Control								
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Electronic Power Steering								
US Area	TIBURON(RC),97~01	1998	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	–	√	√	√	√	√	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Cruise Control								
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Electronic Power Steering								
US Area	TIBURON(RC),97~01	1998	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	–	√	√	√	√	√	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Cruise Control								
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Electronic Power Steering								
US Area	TIBURON(RC),97~01	1997	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	–	√	√	√	√	√	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Airbag Control	Airbag Control	–	√	√	√	–	–	
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Cruise Control								
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Electronic Power Steering								
US Area	TIBURON(RC),97~01	1997	G 1.8 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2017	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2016	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	FCEV Motor Control System	FCEV Motor Control System	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	EV Battery System	EV Battery System	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	High DC/DC Converter	High DC/DC Converter	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Fuel Processing Driver	Fuel Processing Driver	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Electronic Power Steering	Electronic Power Steering	√	√	√	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON Fuel Cell(LM FCEV),15~17	2015	100KW	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	ABSESC	ABS/ESC(MGH-25)	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	ABSESC	ABS/ESC(MGH-40)	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2009	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	ABSESC	ABS/ESC(MGH-25)	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	ABSESC	ABS/ESC(MGH-40)	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2009	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	ABSESC	ABS/ESC(MGH-25)	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	ABSESC	ABS/ESC(MGH-40)	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2008	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	ABSESC	ABS/ESC(MGH-25)	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	ABSESC	ABS/ESC(MGH-40)	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2008	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2007	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2006	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2006	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2005	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	4WD Control	4WD Control	√	√	√	–	–	–	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	ETACS	ETACS	√	–	–	√	√	–	
US Area	TUCSON(JM),05~09	2005	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	TUCSON(LM),10~15	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	TUCSON(LM),10~15	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	TUCSON(LM),10~15	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	TUCSON(LM),10~15	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2013	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2013	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2012	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2012	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2011	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2010	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(LM),10~15	2010	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Blind Spot Detection-L	Blind spot detection left	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Blind Spot Detection-L	Blind spot detection left	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Cluster Module	Cluster module	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Tire Pressure Monitoring System	TPM	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Body Control	Body control module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Blind Spot Detection-R	Blind spot detection right	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.4 GDI	Blind Spot Detection-R	Blind spot detection right	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Blind Spot Detection-R	Blind spot detection right	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Blind Spot Detection-R	Blind spot detection right	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Blind Spot Detection-L	Blind spot detection left	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Blind Spot Detection-L	Blind spot detection left	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Cluster Module	Cluster module	–	√	√	–	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Tire Pressure Monitoring System	TPM	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Body Control	Body control module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2021	G 2.0 GDI	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Tire Pressure Monitoring System	TPM	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Body Control	Body control module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Blind Spot Detection-L	Blind spot detection left	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.4 GDI	Blind Spot Detection-R	Blind spot detection right	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Smart Junction Block	Smart junction block	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Body Control	Body control module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Blind Spot Detection-R	Blind spot detection right	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Tire Pressure Monitoring System	TPM	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Blind Spot Detection-L	Blind spot detection left	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Air Conditioner	Air conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	TUCSON(TL),16~21	2020	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Blind Spot Detection-L	Blind spot detection left	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Body Control	Body control module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	4WD Control	4WD control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Tire Pressure Monitoring System	Tire pressure monitoring	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Blind Spot Detection-R	Blind spot detection right	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.0 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Blind Spot Detection-R	Blind spot detection right	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Automatic Transaxle	Dual clutch transmission	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Body Control	Body control module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	4WD Control	4WD control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Blind Spot Detection-L	Blind spot detection left	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Tire Pressure Monitoring System	Tire pressure monitoring	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 1.6 T-GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Around View Monitor System	Around view monitor system	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Tire Pressure Monitoring System	Tire pressure monitoring	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Blind Spot Detection-L	Blind spot detection left	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Body Control	Body control module	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Multi Function Camera	Multi function camera	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	4WD Control	4WD control	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Parking Guide System	Parking guide system	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Autonomous Emergency Braking	Autonomous emergency braking	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Blind Spot Detection-R	Blind spot detection right	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Amplifier								
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Amplifier								
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	TUCSON(TL),16~21	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Amplifier								
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Amplifier								
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Amplifier								
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Autonomous Emergency Braking System	Autonomous Emergency Braking System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	4WD Control	4WD Control	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Amplifier								
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
US Area	TUCSON(TL),16~21	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2018	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	VELOSTER(FS),12~18	2015	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2014	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2013	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	AT	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	AT	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	PODS-F	PODS-F	√	√	√	–	–	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Motor driven Power Steering	Motor driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Body Control Module	Body Control Module	√	√	√	√	√	√	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Telematics Unit	Telematics Unit	√	√	√	–	–	–	
US Area	VELOSTER(FS),12~18	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Automatic Transaxle	Double Clutch Transmission	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	VELOSTER(JS),19~21	2021	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Engine	Engine control	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Automatic Transaxle	Automatic transaxle	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 2.0 MPI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward collision-Avoidance assist	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2020	G 1.6 T-GDI	Automatic Transaxle	Double Clutch Transmission	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Dual Clutch Transmission	Dual Clutch Transmission	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	ABS/ESC	ABS/ESC	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Motor Driven Power Steering	Motor Driven Power Steering	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Integrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	√	
US Area	VELOSTER(JS),19~21	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2013	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2012	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2011	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2010	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2009	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2008	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Electronic Stability Control	Electronic Stability Control	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Airbag Control Unit	Airbag Control Unit	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Weight Classification System	Weight Classification System	√	√	√	√	–	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	4WD Control	4WD Control	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Tire Pressure Monitoring System	Tire Pressure Monitoring System	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Smart Key Unit	Smart Key Unit	√	√	√	√	√	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Body Control Module	Body Control Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Integrated Memory System	Integrated Memory System	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Tilt & Telescope	Tilt & Telescope	√	√	√	√	√	–	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Power Tailgate	Power Tailgate	√	√	√	√	–	–	
US Area	VERACRUZ(EN),07~13	2007	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
US Area	XG(XG),01~05	2005	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	XG(XG),01~05	2005	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	√	
US Area	XG(XG),01~05	2005	G 3.5 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	XG(XG),01~05	2005	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	XG(XG),01~05	2005	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2005	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2005	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	XG(XG),01~05	2004	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	XG(XG),01~05	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	XG(XG),01~05	2004	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	XG(XG),01~05	2004	G 3.5 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	XG(XG),01~05	2004	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	XG(XG),01~05	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2004	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2004	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	XG(XG),01~05	2003	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	XG(XG),01~05	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	XG(XG),01~05	2003	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	XG(XG),01~05	2003	G 3.5 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	XG(XG),01~05	2003	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	XG(XG),01~05	2003	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2003	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2003	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	XG(XG),01~05	2002	G 3.5 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	XG(XG),01~05	2002	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	XG(XG),01~05	2002	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	XG(XG),01~05	2002	G 3.5 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	XG(XG),01~05	2002	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	XG(XG),01~05	2002	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2002	G 3.5 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2002	G 3.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	XG(XG),01~05	2001	G 3.0 DOHC	Engine Control	Engine Control	√	√	√	√	√	√	
US Area	XG(XG),01~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	XG(XG),01~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
US Area	XG(XG),01~05	2001	G 3.0 DOHC	Anti-Lock Brake System	Anti-Lock Brake System	–	√	√	√	√	√	
US Area	XG(XG),01~05	2001	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
US Area	XG(XG),01~05	2001	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2001	G 3.0 DOHC	Airbag Control	Airbag Control	√	√	√	√	–	–	
US Area	XG(XG),01~05	2001	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	√	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Electronic Control Suspension	Electronic control suspension	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Electronic Limited Slip Differential	Electronic Limited Slip Differential	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated Body Control Unit-BCM	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated Body Control Unit-TPMS	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2020	G 2.0 T-GDI	Electronic Sound Generator	Electronic Sound Generator	√	√	√	–	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Engine	Engine control	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Intergrated Body Control Unit-Tire Press	Integrated Body Control Unit-TPMS	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Intergrated Gateway Power Control Module	Integrated Gateway Power Control Module	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Smart Key Unit	Smart key unit	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Electronic Control Suspension	Electronic control suspension	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Anti Lock Brake/Electronic Stability Pro	Anti lock brake system/Electronic stabil	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Electronic Sound Generator	Electronic Sound Generator	√	√	√	–	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Intergrated Body Control Unit-Body Contr	Integrated Body Control Unit-BCM	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Cluster Module	Cluster module	√	√	√	√	√	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Occupant Detection Sensor	Occupant detection sensor	√	√	√	√	–	–	
US Area	Veloster N(JSN),19~20	2019	G 2.0 T-GDI	Electronic Limited Slip Differential	Electronic Limited Slip Differential	√	√	√	√	√	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Engine	Engine control	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Anti Lock Brake/Electronic Stability Con	ABS/ESC(ESC+EPB)	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	4WD Control	4WD Control	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Front View Camera	Front view camera	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	E-Shifter SBW	E-Shifter	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Intergrated Body Control Unit-Immobilize	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Cluster Module	Cluster module	–	√	√	–	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	SBW Control Unit	SBW Control Unit	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Mood Lamp Module	Mood Lamp Module (MLM)	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning (BCW)	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Intergrated Central Control Unit	Integrated central control unit	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Surround View Monitoring	Surround view monitor system	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2021	G 3.8 GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous emergenc	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Engine	Engine control	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Airbag	Airbag(event #1)	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Airbag	Airbag(event #2)	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Anti Lock Brake/Electronic Stability Con	ABS/ESC(ESC+EPB)	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Intergrated Central Control Unit	Integrated Central Control Unit	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Surround View Monitoring	Surround View Monitor System	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Power Seat Module	Power seat module	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	4WD Control	4WD control	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Power Tail Gate	Power tailgate	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Eshifter_BS	E-Shifter	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Front View Camera	Front View Camera	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Intergrated Body Control Unit-Body Contr	Integrated Body Control Unit-BCM	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Automatic Headlamp Leveling	Auto headlamp leveling system	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Intergrated Body Control Unit-Tire Press	Integrated Body Control Unit-TPMS	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Intergrated Body Control Unit-Smart Key	Integrated Body Control Unit-SMK	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Intergrated Body Control Unit-Immobilize	Integrated Body Control Unit-IMMO	–	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	SBW Control Unit	SBW Control Unit	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Smart Cruise Control/Autonomous Emergenc	Smart cruise control/Autonomous Emergenc	√	√	√	√	–	–	
US Area	Palisade(LX2),20~21	2020	G 3.8 GDI	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Engine	Engine control	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Power Seat Module	Power seat module	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Rear Corner Radar-Left	Rear Corner Radar-Left	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Intergrated Central Control Unit	Integrated central control unit	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Seat heater Ventilation control Unit-Fro	Seat heater Ventilation control Unit-Fro	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Seat heater Ventilation control Unit-Rea	Seat heater Ventilation control Unit-Rea	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Front View Camera	Front view camera	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Multi Function Switch	Multi function switch	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Motor Driven Power Steering	Motor driven power steering	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Motor Driven Power Steering	Motor driven power steering	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Identity Authentication Unit	Identity Authentication Unit	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Mood Lamp Module	Mood Lamp Module (MLM)	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	SBW Control Unit	SBW Control Unit	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Intergrated Body Control Unit-Immobilize	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Around View Monitor System	Around view monitor system	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Advanced Driver Assistance Systems_Parki	Advanced Driver Assistance Systems_Parki	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Front Radar	Front Radar	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Air Conditioner	Air conditioner	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	E-Shifter SBW	E-Shifter	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Cluster Module	Cluster module	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 2.5 GDI THETA III	Rear Corner Radar-Right	Rear Corner Radar-Right	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Engine	Engine control	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	SBW Control Unit	SBW Control Unit	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Intergrated Body Control Unit-Immobilize	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Multi Function Switch	Multi function switch	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Mood Lamp Module	Mood Lamp Module (MLM)	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Cluster Module	Cluster module	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Power Seat Module	Power seat module	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Front Radar	Front Radar	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Air Conditioner	Air conditioner	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Around View Monitor System	Around view monitor system	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Motor Driven Power Steering	Motor driven power steering	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Motor Driven Power Steering	Motor driven power steering	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Automatic Transaxle	Automatic transaxle	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Wireless Power Charger	Wireless power charger	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Seat heater Ventilation control Unit-Rea	Seat heater Ventilation control Unit-Rea	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Rear Corner Radar-Right	Rear Corner Radar-Right	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Identity Authentication Unit	Identity Authentication Unit	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	E-Shifter SBW	E-Shifter	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Seat heater Ventilation control Unit-Fro	Seat heater Ventilation control Unit-Fro	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Rear Corner Radar-Left	Rear Corner Radar-Left	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Front View Camera	Front view camera	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Intergrated Central Control Unit	Integrated central control unit	–	√	√	–	–	–	
US Area	SONATA(DN8A),20	2020	G 1.6 T-GDI GAMMA II	Advanced Driver Assistance Systems_Parki	Advanced Driver Assistance Systems_Parki	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Engine	Engine control	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Driver Door Module	Driver door module	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Automatic Transaxle	Automatic transaxle	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Motor Control System	Hybrid Electric Vehicle (HEV) motor cont	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Battery Management System	HEV Battery system	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Occupant Classification System	Occupant classification system	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Around View Monitor System	Around view monitor system	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Advanced Driver Assistance Systems_Parki	Advanced Driver Assistance Systems_Parki	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Head Up Display	Head up display	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Multi Function Switch	Multi function switch	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Mood Lamp Module	Mood Lamp Module (MLM)	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Seat heater Ventilation control Unit-Fro	Seat heater&Ventilation control Unit-Fro	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Seat heater Ventilation control Unit-Rea	Seat heater&Ventilation control Unit-Rea	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Rear Corner Radar-Left	Rear Corner Radar-Left	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Audio Video Navigation	Audio video navigation	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Identity Authentication Unit	Identity Authentication Unit	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Solar DCDC Converter	Solar DCDC Converter	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Digital Video Recorder System	Digital Video Recorder System	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Motor Driven Power Steering	Motor driven power steering	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Front View Camera	Front view camera	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Intergrated Body Control Unit-Immobilize	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Wireless Power Charger	Wireless power charger	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Hybrid Control/Low DC-DC Converter	Hybrid control/Low DC-DC Converter	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Front Radar	Front Radar	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Power Seat Module	Power seat module	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Virtual Engine Sound System	Virtual engine sound system	√	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	E-Shifter SBW	E-Shifter	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Airbag	Airbag(Event #1)	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Airbag	Airbag(Event #2)	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	SBW Control Unit	SBW Control Unit	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Rear Corner Radar-Right	Rear Corner Radar-Right	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Cluster Module	Cluster module	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Intergrated Central Control Unit	Integrated central control unit	–	√	√	–	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	√	√	√	√	–	–	
US Area	SONATA hybrid(DN8 HEV),20	2020	G 2.0 GDI HEV	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Engine	Engine control	√	√	√	√	√	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Motor Driven Power Steering	Motor driven power steering	√	√	√	√	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Airbag	Airbag(Event #1)	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Airbag	Airbag(Event #2)	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Rear View Monitor	Rear view monitor	√	√	√	√	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Intergrated Body Control Unit-Smart Key	Integrated Body Unit (IBU) - Smart Key U	√	√	√	√	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Transmitter Code Saving	Transmitter code saving	–	–	–	√	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Intergrated Body Control Unit-Body Contr	Integrated body control unit-BCM	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Intergrated Body Control Unit-Tire Press	Integrated body control unit-TPMS	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Cluster Module	Cluster module	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Continuously Variable Transmission	Continuously variable transmission	√	√	√	√	√	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Front View Camera	Front view camera	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Air Conditioner	Air conditioner	√	√	√	√	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Front Radar	Front Radar	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Occupant Detection Sensor	Occupant Detection System (ODS)	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Anti Lock Brake/Electronic Stability Con	Anti lock brake/Electronic stability con	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Rear Corner Radar	Rear Corner Radar	–	√	√	–	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Intergrated Body Control Unit-Immobilize	Integrated Body Unit (IBU) - immobilizer	–	√	√	√	–	–	
US Area	VENUE(QX),20	2020	G 1.6 MPI GAMMA II	Intergrated Central Control Unit	Integrated central control unit	–	√	√	–	–	–	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2018	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	AT	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	AT	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	TPMS	Tire Pressure Monitoring(High)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	TPMS	Tire Pressure Monitoring(Low)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Continuously Variable Transmission	Continuously Variable Transmission	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-KAPPA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.4 MPI-GAMMA	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	BCM	Body Control(SMK-/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	BCM	Body Control(SMK+/Auto Light+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	BCM	Body Control(SMK-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	BCM	Body Control(SMK+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	BCM	Body Control(SMK-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	BCM	Body Control(SMK+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	EPS	Power Steering(~2012.02.22)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	EPS	Power Steering(2012.02.23~)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	BCM	Body Control(SMK-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	BCM	Body Control(SMK+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	BCM	Body Control(SMK-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	BCM	Body Control(SMK+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	BCM	Body Control(SMK-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	BCM	Body Control(SMK+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	BCM	Body Control(SMK-)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	BCM	Body Control(SMK+)	√	√	√	√	√	√	
Korea Area	Accent (RB),11~19	2011	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Engine Control								
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1999	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1999	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Engine Control								
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1998	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1998	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Engine Control								
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1997	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC-MAF)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC-MAF)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC-MAP)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC-MAP)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1997	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Engine Control								
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1996	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1996	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Engine Control								
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1995	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1995	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Engine Control								
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1994	G 1.3 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Anti-Lock Brake								
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Accent (X3),94~99	1994	G 1.5 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2018	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Engine	Engine	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.3 GDI(after PE)	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Engine	Engine	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Suspension	Suspension	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI(after PE)	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2017	G 3.0 GDI	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.0 GDI	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2016	G 3.3 GDI	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.0 GDI	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Alsan(AG),15~18	2015	G 3.3 GDI	Haptic Steering-Wheel Warning System	Haptic Steering-Wheel Warning System	√	√	√	–	–	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 SOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2002	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2002	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 T/C	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2002	G 0.8 T/C	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 T/C	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 T/C	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 T/C	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 T/C	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2002	G 0.8 T/C	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	G 0.8 T/C	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	L 0.8 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2002	L 0.8 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	L 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	L 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2002	L 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2002	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2002	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 SOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2001	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2001	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Atos (MX),97~02	2001	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 T/C	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2001	G 0.8 T/C	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 T/C	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 T/C	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 T/C	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 T/C	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2001	G 0.8 T/C	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	G 0.8 T/C	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	L 0.8 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2001	L 0.8 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	L 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	L 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2001	L 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2001	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2001	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 SOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2000	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2000	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 T/C	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2000	G 0.8 T/C	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 T/C	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 T/C	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 T/C	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 T/C	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2000	G 0.8 T/C	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	G 0.8 T/C	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	L 0.8 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2000	L 0.8 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	L 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	L 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	2000	L 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	2000	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	2000	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1999	G 0.8 SOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1999	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1999	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1999	G 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1999	G 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1999	G 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1999	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1999	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1999	L 0.8 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1999	L 0.8 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1999	L 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1999	L 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1999	L 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1999	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1999	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1998	G 0.8 SOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1998	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1998	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1998	G 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1998	G 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1998	G 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1998	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1998	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1998	L 0.8 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1998	L 0.8 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1998	L 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1998	L 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1998	L 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1998	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1998	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1997	G 0.8 SOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1997	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1997	G 0.8 SOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1997	G 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1997	G 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1997	G 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1997	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1997	G 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1997	L 0.8 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1997	L 0.8 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1997	L 0.8 SOHC	AT	Semi Auto	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1997	L 0.8 SOHC	AT	Transmission	√	√	√	√	√	–	
Korea Area	Atos (MX),97~02	1997	L 0.8 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Atos (MX),97~02	1997	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Atos (MX),97~02	1997	L 0.8 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2011	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2011	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2010	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2010	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2009	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2009	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2008	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2008	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2007	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2007	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2006	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante (HD),06~11	2006	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2016	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2015	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Service Reminder	Service Reminder	–	–	–	–	–	√	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2014	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	AT	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante (MD),11~16	2013	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	AT	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2012	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2011	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Avante (MD),11~16	2011	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	ENGINE								
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	2000	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	2000	G 1.8 DOHC	Engine Control								
Korea Area	Avante (RD),95~00	2000	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Korea Area	Avante (RD),95~00	2000	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	2000	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	2000	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	2000	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	2000	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	ENGINE								
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1999	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Engine Control								
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	√	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1999	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	ENGINE	Engine Control (Lean Burn-)	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	ENGINE	Engine Control (Lean Burn-)	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	ENGINE	Engine Control (Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1998	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Engine Control								
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1998	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Engine Control								
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1997	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1997	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1996	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Engine Control								
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1996	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1995	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Engine Control								
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante (RD),95~00	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante Coupe (JK),13~16	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante Coupe (JK),13~16	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante Coupe (JK),13~16	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Adaptive Headlamp Lighting System	Adaptive Headlamp Lighting System	√	√	√	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Avante Coupe (JK),13~16	2013	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	–	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Transmission(CVT)	Transmission(CVT)	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2014	L 1.6 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	–	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Transmission(CVT)	Transmission(CVT)	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2013	L 1.6 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	–	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Transmission(CVT)	Transmission(CVT)	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2012	L 1.6 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	–	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Transmission(CVT)	Transmission(CVT)	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2011	L 1.6 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	–	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Transmission(CVT)	Transmission(CVT)	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Avante Hybrid(HD HEV),10~14	2010	L 1.6 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2006	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2006	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2006	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2006	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2006	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2006	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2006	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2006	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2006	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2006	D 1.5 TCI-U	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2006	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2006	D 1.5 TCI-U	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2006	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2006	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2006	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2006	D 1.5 TCI-U	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2005	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2005	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2005	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2005	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2005	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2005	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2005	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2005	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2005	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2005	D 1.5 TCI-U	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	D 1.5 TCI-U	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2005	D 1.5 TCI-U	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2005	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2005	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2005	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2005	D 1.5 TCI-U	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2004	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2004	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2004	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2004	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2004	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2004	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2004	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2004	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2004	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2003	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2003	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2003	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2003	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2003	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2003	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2003	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2003	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Avante XD(XD),99~06	2003	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	ENGINE	Engine(Lean Burn-)	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	ENGINE	Engine(Lean Burn+)	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	ENGINE	Engine(Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2002	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2002	G 2.0 DOHC	ENGINE	Engine(CVVT-)	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2002	G 2.0 DOHC	ENGINE	Engine(CVVT+)	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2002	G 2.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2002	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2002	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2002	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2002	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2002	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	ENGINE	Engine(Lean Burn-)	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	ENGINE	Engine(Lean Burn+)	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	ENGINE	Engine(Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	AT	1.5(Integrated ECU)	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	AT	1.5(Lean Burn)	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2001	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2001	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2001	G 2.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2001	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2001	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2001	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2001	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2001	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	ENGINE	Engine(Lean Burn-)	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	ENGINE	Engine(Lean Burn+)	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	ENGINE	Engine(Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	AT	1.5(Integrated ECU)	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	AT	1.5(Lean Burn)	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2000	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	2000	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2000	G 2.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2000	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	2000	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	2000	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2000	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	2000	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	ENGINE	Engine(Lean Burn-)	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	ENGINE	Engine(Lean Burn+)	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	ENGINE	Engine(Lean Burn+)	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	AT	1.5(Integrated ECU)	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	AT	1.5(Lean Burn)	√	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	1999	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Avante XD(XD),99~06	1999	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	1999	G 2.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Avante XD(XD),99~06	1999	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Avante XD(XD),99~06	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Avante XD(XD),99~06	1999	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2019	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2018	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2017	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Avante(AD),16~19	2016	L 1.6 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Blueone (EAEV),11	2011	50KW	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	Blueone (EAEV),11	2011	50KW	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Blueone (EAEV),11	2011	50KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Blueone (EAEV),11	2011	50KW	Vehicle Control System	Vehicle Control System	√	√	√	√	–	–	
Korea Area	Blueone (EAEV),11	2011	50KW	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Blueone (EAEV),11	2011	50KW	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Korea Area	Blueone (EAEV),11	2011	50KW	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Blueone (EAEV),11	2011	50KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Blueone (EAEV),11	2011	50KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	Blueone (EAEV),11	2011	50KW	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Blueone (EAEV),11	2011	50KW	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2011	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2011	G 1.4 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2011	D 1.5 TCI-U	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2010	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2010	G 1.4 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2010	D 1.5 TCI-U	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2009	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2009	G 1.4 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2009	D 1.5 TCI-U	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2008	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2008	G 1.4 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2008	D 1.5 TCI-U	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2007	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2007	G 1.4 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2007	D 1.5 TCI-U	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2006	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2006	G 1.4 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2006	D 1.5 TCI-U	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2005	G 1.3 SOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2005	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2005	G 1.6 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2005	G 1.4 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2004	G 1.3 SOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2004	G 1.5 DOHC	Transmitter Code Saving								

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2003	G 1.3 SOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2003	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2002	G 1.3 SOHC	Transmitter Code Saving								
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Click (TB),02~11	2002	G 1.5 DOHC	Transmitter Code Saving								
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2005	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2004	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	ABS								
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	ABS	Anti-Lock Brake (2003.5~)	√	√	√	√	√	√	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	ABS								
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	ABS	Anti-Lock Brake (2003.5~)	√	√	√	√	√	√	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2003	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2002	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2001	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	2000	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Anti-Lock Brake								
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1999	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1998	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 3.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1997	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Transmission	Transmission	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Traction control system	Traction control system	–	√	√	√	–	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Dynasty (LX),96~05	1996	G 3.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Airbag	Airbag	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Elantra (J1),90~95	1994	G 1.6 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1994	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.6 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1993	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1992	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1991	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Anti-Lock Brake								
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Elantra (J1),90~95	1990	G 1.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.3 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 3.8 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2018	G 5.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.3 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 3.8 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2017	G 5.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.3 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Engine	Engine	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 3.8 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Audio Video Navigation	Audio Video Navigation	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Amplifier								
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Rear Wireless Power Charger	Rear Wireless Power Charger	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Power Seat Module-RL	Power Seat Module-RL	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Power Seat Module-RR	Power Seat Module-RR	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Rear Arm Rest Switch	Rear Arm Rest Switch	√	√	√	√	√	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Central Gateway	Central Gateway	√	√	√	√	–	√	
Korea Area	EQ900(HI),16~18	2016	G 5.0 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.8 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 3.3 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2009	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.8 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 3.3 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2008	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	BCM	Body Control(CAN 2005.02~)	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	BCM	Body Control(CAN 2007.10~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.8 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	BCM	Body Control(CAN 2005.02~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	BCM	Body Control(CAN 2007.10~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 3.3 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	BCM	Body Control(CAN 2005.02~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	BCM	Body Control(CAN 2007.10~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2007	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.8 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 3.3 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2006	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ENGINE	Engine(ETS-)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	BCM	Body Control(CAN 2005.02~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	BCM	Body Control(LAN ~2005.01)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	BCM	Body Control(CAN 2005.02~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	BCM	Body Control(LAN ~2005.01)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	BCM	Body Control(CAN 2005.02~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	BCM	Body Control(LAN ~2005.01)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 3.8 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Smart Key	Smart Key	–	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	BCM	Body Control(CAN 2005.02~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	BCM	Body Control(LAN ~2005.01)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2005	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ENGINE	Engine(ETS-)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 3.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2004	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ENGINE	Engine(ETS-)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 3.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Engine	Engine	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	ABSVDC	Brake(TCS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2003	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ENGINE	Engine(ETS-)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ABSVDC	Brake(TCS+)(CTC 2002.09~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ABSVDC	Brake(TCS+)(ITT)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ABSVDC	Brake(VDC+)(CTC 2002.09~)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ABSVDC	Brake(VDC+)(Melco)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ABSVDC	Brake(VDC+)(Melco)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ABSVDC	Brake(TCS+)(CTC 2002.09~)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ABSVDC	Brake(TCS+)(ITT)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ABSVDC	Brake(VDC+)(CTC 2002.09~)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ABSVDC	Brake(VDC+)(Melco)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ABSVDC	Brake(VDC+)(Melco)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 3.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ENGINE	Engine GDI	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ENGINE	Engine MPI	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ABSVDC	Brake(TCS+)(CTC 2002.09~)	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ABSVDC	Brake(TCS+)(ITT)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ABSVDC	Brake(VDC+)(CTC 2002.09~)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ABSVDC	Brake(VDC+)(Melco)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ABSVDC	Brake(VDC+)(Melco)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2002	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ENGINE	Engine(ETS-)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 3.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ENGINE	Engine GDI	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ENGINE	Engine MPI	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2001	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ENGINE	Engine(ETS-)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 3.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	2000	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ENGINE	Engine(ETS-)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ENGINE	Engine(ETS+)	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	ECS	Suspension	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 3.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Engine GDI	Engine GDI	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	ABSVDC	Brake(TCS+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	ABSVDC	Brake(VDC+)	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	ABSVDC	Brake(VDC+)	√	√	√	√	√	√	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Power Steering								
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	ECS	Active ECS	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	ECS	Suspension	–	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Equus (LZ),99~09	1999	G 4.5 DOHC	Transmitter Code Saving								
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	ECS	Suspension(Sedan)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	DIS								
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	I-BOX								
Korea Area	Equus (VI),10~16	2016	G 5.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	ECS	Suspension(Sedan)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	DIS								
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	I-BOX								
Korea Area	Equus (VI),10~16	2016	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	ECS	Suspension(Sedan)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	DIS								
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Equus (VI),10~16	2015	G 5.0 GDI	I-BOX								
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	ECS	Suspension(Sedan)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	DIS								
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Equus (VI),10~16	2015	G 3.8 GDI	I-BOX								
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	ECS	Suspension(Sedan)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	DIS								
Korea Area	Equus (VI),10~16	2014	G 5.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	ECS	Suspension(Sedan)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	DIS								
Korea Area	Equus (VI),10~16	2014	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	ECS	Suspension(Sedan)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	DIS								
Korea Area	Equus (VI),10~16	2013	G 5.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	ECS	Suspension(Sedan)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Assist Power Seat Module	Assist Power Seat Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	DIS								
Korea Area	Equus (VI),10~16	2013	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2012	G 5.0 GDI	TV	TV	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	ECS	Suspension	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2012	G 3.8 GDI	TV	TV	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 4.6 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 5.0 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	VDC	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	VDC	Vehicle Dynamic Control(Limousine)	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	ECS	Suspension	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	AFLS	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	AFLS	Adaptive Front Lighting System(Limousine	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	PSB-L	Pre-safe Seat Belt-Left(Limousine)	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	PSB-L	Pre-safe Seat Belt-Left(Sedan)	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	PSB-R	Pre-safe Seat Belt-Right(Limousine)	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	PSB-R	Pre-safe Seat Belt-Right(Sedan)	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2011	G 3.8 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 4.6 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 5.0 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	VDC	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	VDC	Vehicle Dynamic Control(Limousine)	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	ECS	Suspension	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	ECS	Suspension(Limousine)	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	AFLS	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	AFLS	Adaptive Front Lighting System(Limousine	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	PSB-L	Pre-safe Seat Belt-Left(Limousine)	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	PSB-L	Pre-safe Seat Belt-Left(Sedan)	√	√	√	–	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	PSB-R	Pre-safe Seat Belt-Right(Limousine)	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	PSB-R	Pre-safe Seat Belt-Right(Sedan)	√	√	√	–	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Instrument Panel Module	Instrument Panel Module	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Equus (VI),10~16	2010	G 3.8 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.3 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Excel (X2),90~94	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G70(IK),18~19	2019	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G70(IK),18~19	2019	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G70(IK),18~19	2019	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	G 3.3 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	G 2.0 T-GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	G70(IK),18~19	2018	D 2.2 TCI-R	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	AT	Transmission(SBC)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	AT	Transmission(SBW)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	AVN	AVN Premium	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	AVN	AVN Standard	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 T-GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	AT	Transmission(SBC)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	AT	Transmission(SBW)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	AVN	AVN Premium	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	AVN	AVN Standard	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.3 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	AT	Transmission(SBC)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	AT	Transmission(SBW)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	AVN	AVN Premium	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	AVN	AVN Standard	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	AT	Transmission(SBC)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	AT	Transmission(SBW)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	AVN	AVN Premium	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	AVN	AVN Standard	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Amplifier	Amplifier	–	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2018	D 2.2 TCI-R	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	AT	Transmission(SBC)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	AT	Transmission(SBW)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	AVN	AVN Premium	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	AVN	AVN Standard	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 T-GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	AT	Transmission(SBC)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	AT	Transmission(SBW)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	AVN	AVN Premium	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	AVN	AVN Standard	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.3 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	AT	Transmission(SBC)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	AT	Transmission(SBW)	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	AVN	AVN Premium	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	AVN	AVN Standard	√	–	–	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Amplifier	Amplifier	–	√	√	–	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	G80(DH),17~18	2017	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	Galloper (M1),97~03	2003	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2003	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2003	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2003	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2003	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2003	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2003	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2003	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2003	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2003	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2003	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2003	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2003	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2003	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2003	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2003	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2002	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2002	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2002	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2002	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2002	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2002	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2002	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2002	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2002	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2002	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2002	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2002	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2002	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2002	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2002	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2002	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2001	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2001	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2001	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2001	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2001	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2001	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2001	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2001	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2001	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2001	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2001	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2001	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2001	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2001	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2001	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2001	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2000	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2000	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	L 3.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	L 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	2000	L 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1999	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1999	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	L 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1999	L 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1998	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Galloper (M1),97~03	1998	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1998	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	L 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1998	L 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1998	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1998	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1997	G 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	G 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1997	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	L 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (M1),97~03	1997	L 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	–	
Korea Area	Galloper (M1),97~03	1997	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (M1),97~03	1997	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Galloper (QA),91~96	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1996	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1996	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1996	G 3.0 SOHC	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1996	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1996	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1996	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1996	D 2.5 TCI	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1995	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1995	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1995	G 3.0 SOHC	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1995	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1995	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1995	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1995	D 2.5 TCI	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1994	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1994	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1994	G 3.0 SOHC	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1994	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1994	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1994	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1994	D 2.5 TCI	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1993	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1993	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1993	G 3.0 SOHC	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1993	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1993	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1993	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1993	D 2.5 TCI	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1992	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1992	G 3.0 SOHC	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1992	G 3.0 SOHC	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1992	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1992	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1992	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1992	D 2.5 TCI	Anti-Lock Brake								
Korea Area	Galloper (QA),91~96	1991	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1991	D 2.5 TCI	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Galloper (QA),91~96	1991	D 2.5 TCI	Automatic Transaxle								
Korea Area	Galloper (QA),91~96	1991	D 2.5 TCI	Anti-Lock Brake								
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Multimedia								
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis (BH),08~14	2014	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–		√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Multimedia								
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Multimedia								
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis (BH),08~14	2014	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Multimedia								
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis (BH),08~14	2013	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Multimedia								
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Multimedia								
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis (BH),08~14	2013	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 5.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	AFLS	Adaptive Front Lighting System(HID)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	AFLS	Adaptive Front Lighting System(LED)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Intelligent Accel Pedal	Intelligent Accel Pedal	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Pre-safe Seat Belt-Left	Pre-safe Seat Belt-Left	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Pre-safe Seat Belt-Right	Pre-safe Seat Belt-Right	√	√	√	–	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2012	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2011	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2010	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2009	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Power Steering	Power Steering	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	IMMO	Immobilizer(SMK-)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	IMMO	Immobilizer(SMK+)	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	IPM	Instrument Panel Module(SMK-)	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	IPM	Instrument Panel Module(SMK+)	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Front Area Module	Front Area Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Front Back Warning System	Front Back Warning System	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Electric Control Wiper	Electric Control Wiper	√	√	√	√	–	–	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	User Option	User Option	–	–	–	√	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Head Unit	Head Unit	√	√	√	√	√	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Tuner/Amplifier	Tuner/Amplifier	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Voice Recognition System	Voice Recognition System	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	MOZEN	MOZEN	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	TV	TV	√	√	√	–	–	√	
Korea Area	Genesis (BH),08~14	2008	G 3.3 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	AVN	AVN Premium	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	AVN	AVN Standard	√	–	–	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.3 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Driveshaft	Driveshaft	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Suspension	Suspension	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	AVN	AVN Premium	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	AVN	AVN Standard	√	–	–	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Genesis (DH),14~16	2016	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	AVN	AVN Premium	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	AVN	AVN Standard	√	–	–	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.3 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Driveshaft	Driveshaft	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Suspension	Suspension	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	AVN	AVN Premium	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	AVN	AVN Standard	√	–	–	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Genesis (DH),14~16	2015	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	AVN	AVN Premium	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	AVN	AVN Standard	√	–	–	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.3 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Driveshaft	Driveshaft	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Suspension	Suspension	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Parking Guide System	Parking Guide System	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Pre-safe Seat Belt	Pre-safe Seat Belt	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	AVN	AVN Premium	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	AVN	AVN Standard	√	–	–	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Head Up Display	Head Up Display	√	√	√	√	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Driver Seat Switch	Driver Seat Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Seat Lumbar Bolster	Seat Lumbar Bolster	√	√	√	√	√	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Haptic Steering Warning System	Haptic Steering Warning System	√	√	√	–	–	–	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Genesis (DH),14~16	2014	G 3.8 GDI	I-BOX	I-BOX	√	√	√	–	–	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis Coupe (BK),09~16	2016	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis Coupe (BK),09~16	2015	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Genesis Coupe (BK),09~16	2014	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2013	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2013	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2012	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Cluster Module	Cluster Module	√	–	–	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2012	G 3.8 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2011	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2010	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 3.8 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Genesis Coupe (BK),09~16	2009	G 2.0 T-MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grace (AH),93~01	2001	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	2001	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	2001	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	2001	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Grace (AH),93~01	2001	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Grace (AH),93~01	2001	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grace (AH),93~01	2000	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	2000	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	2000	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	2000	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Grace (AH),93~01	2000	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Grace (AH),93~01	2000	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1999	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1999	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1999	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1999	L 2.4 SOHC	Engine Control								
Korea Area	Grace (AH),93~01	1999	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1998	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1998	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1998	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1998	L 2.4 SOHC	Engine Control								
Korea Area	Grace (AH),93~01	1998	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1997	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1997	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1997	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1997	L 2.4 SOHC	Engine Control								
Korea Area	Grace (AH),93~01	1997	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1996	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1996	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1996	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1996	L 2.4 SOHC	Engine Control								
Korea Area	Grace (AH),93~01	1996	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1995	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1995	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1995	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1995	L 2.4 SOHC	Engine Control								
Korea Area	Grace (AH),93~01	1995	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1994	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1994	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1994	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1994	L 2.4 SOHC	Engine Control								
Korea Area	Grace (AH),93~01	1994	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1993	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1993	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grace (AH),93~01	1993	D 2.5 T/C	Automatic Transaxle								
Korea Area	Grace (AH),93~01	1993	L 2.4 SOHC	Engine Control								
Korea Area	Grace (AH),93~01	1993	L 2.4 SOHC	Automatic Transaxle								
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	ABSVDC	Brake(before PE)	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	ABSVDC	Brake(after PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	AT	Transmission(Before PE)	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	AT	Transmission(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	AIRBAG	Airbag(Event #2)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	AIRBAG	Airbag(Event #1)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	AIRBAG	Airbag(Before PE)	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	AIRCON	Air Conditioner(Before PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	AIRCON	Air Conditioner(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	ABSVDC	Brake(before PE)	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	ABSVDC	Brake(after PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2019	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	ABSVDC	Brake(after PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	ABSVDC	Brake(before PE)	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	AT	Transmission(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	AT	Transmission(Before PE)	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	ABSVDC	Brake(after PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	ABSVDC	Brake(before PE)	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	AIRBAG	Airbag(Before PE)	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	AIRBAG	Airbag(Event #1)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	AIRBAG	Airbag(Event #2)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	AIRCON	Air Conditioner(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	AIRCON	Air Conditioner(Before PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grand Starex (TQ),08~19	2018	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Before PE)	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #1)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #2)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	AIRCON	Air Conditioner(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	AIRCON	Air Conditioner(Before PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-5)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	D 2.5 TCI-A2(Euro-6)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	AT	Transmission(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	AT	Transmission(Before PE)	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	AIRBAG	Airbag(Before PE)	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	AIRBAG	Airbag(Event #1)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	AIRBAG	Airbag(Event #2)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	AIRCON	Air Conditioner(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	AIRCON	Air Conditioner(Before PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2017	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Before PE)	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #1)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #2)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	AIRCON	Air Conditioner(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	AIRCON	Air Conditioner(Before PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-5)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	D 2.5 TCI-A2(Euro-6)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	AT	Transmission(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	AT	Transmission(Before PE)	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	AIRBAG	Airbag(Before PE)	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	AIRBAG	Airbag(Event #1)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	AIRBAG	Airbag(Event #2)(After PE)	√	√	√	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	AIRCON	Air Conditioner(After PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	AIRCON	Air Conditioner(Before PE)	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2016	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2015	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2015	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2014	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2014	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2014	L 2.4 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2014	L 2.4 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2014	L 2.4 LPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2014	L 2.4 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2014	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2014	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grand Starex (TQ),08~19	2014	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2013	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2013	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	L 2.4 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	L 2.4 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	L 2.4 LPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2013	L 2.4 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2013	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2013	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2013	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2012	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2012	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	L 2.4 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	L 2.4 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	L 2.4 LPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2012	L 2.4 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2012	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2012	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2012	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2011	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2011	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2010	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2010	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2009	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2009	L 2.4 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2009	L 2.4 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2009	L 2.4 LPI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2009	L 2.4 LPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2009	L 2.4 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2009	L 2.4 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2009	L 2.4 LPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2009	L 2.4 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Fuel Fired Heater	Fuel Fired Heater	–	√	√	√	√	–	
Korea Area	Grand Starex (TQ),08~19	2008	D 2.5 TCI-A	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Amplifier								
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Amplifier								
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Amplifier								
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Amplifier								
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2017	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Amplifier								
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Amplifier								
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Amplifier								
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Amplifier								
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2016	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Amplifier								
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Amplifier								
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Amplifier								
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Amplifier								
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2015	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	CUBIS	CUBIS	√	√	√	–	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	CUBIS	CUBIS	√	√	√	–	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	CUBIS	CUBIS	√	√	√	–	–	–	
Korea Area	Grandeur (HG),11~17	2014	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	CUBIS	CUBIS	√	√	√	–	–	–	
Korea Area	Grandeur (HG),11~17	2014	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	CUBIS	CUBIS	√	√	√	–	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	CUBIS	CUBIS	√	√	√	–	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	ENGINE	IPB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	CUBIS	CUBIS	√	√	√	–	–	–	
Korea Area	Grandeur (HG),11~17	2013	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	CUBIS	CUBIS	√	√	√	–	–	–	
Korea Area	Grandeur (HG),11~17	2013	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2012	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Cruise Control	Cruise Control	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Grandeur (HG),11~17	2011	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2019	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2018	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	ENGINE	EMS ECU	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	L 3.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	G 3.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	√	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur (IG),17~19	2017	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1999	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1998	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 3.0 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1997	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1996	L 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1995	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 2.5 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1994	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	ABS								
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.4 SOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1993	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Cruise Module								
Korea Area	Grandeur (LX),86~99	1992	G 2.4 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 2.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	ABS								
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Traction Control System	Traction Control System	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Air Conditioner	Air Conditioner	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1992	G 3.0 DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.4 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1991	G 3.0 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.4 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 3.0 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1990	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.4 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 3.0 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1989	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.4 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 3.0 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1988	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.4 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 3.0 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (LX),86~99	1987	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.4 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 3.0 SOHC	Electronic Control Suspension								
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Grandeur (LX),86~99	1986	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2011	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2010	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Thetal)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	ENGINE	Engine(~2009.01.04)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	ENGINE	Engine(~2009.01.04)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	ENGINE	Engine(~2009.01.04)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	ENGINE	Engine(2009.01.05~)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	AT	Transmission(5-Speed)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	AT	Transmission(5-Speed)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	AT	Transmission(6-Speed)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	SMK	Smart Key(Button)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	SMK	Smart Key(Key)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Power Distribution Module(Button)	Power Distribution Module(Button)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	Interface Unit(Key)	Interface Unit(Key)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	SMKCODE	Smart Key Code Saving(Button)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	SMKCODE	Smart Key Code Saving(Key)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	BCM	Body Control(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	BCM	Body Control(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	DDM	Driver Door Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	DDM	Driver Door Module(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	ADM	Assist Door Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	ADM	Assist Door Module(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	PSM	Power Seat Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	PSM	Power Seat Module(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	OPTION	User Option(~2009.01.04)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	OPTION	User Option(2009.01.05~)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	TILT	Tilt/Telescope(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	TILT	Tilt/Telescope(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	CODE	Transmitter Code Saving(~2009.01.04)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 3.3 DOHC	CODE	Transmitter Code Saving(2009.01.05~)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	ENGINE	Engine(~2009.01.04)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	ENGINE	Engine(~2009.01.04)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	ENGINE	Engine(2009.01.05~)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	ENGINE	Engine(2009.01.05~)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	AT	Transmission(5-Speed)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	AT	Transmission(5-Speed)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	AT	Transmission(6-Speed)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	SMK	Smart Key(Button)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	SMK	Smart Key(Key)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Power Distribution Module(Button)	Power Distribution Module(Button)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	Interface Unit(Key)	Interface Unit(Key)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	SMKCODE	Smart Key Code Saving(Button)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	SMKCODE	Smart Key Code Saving(Key)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	BCM	Body Control(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	BCM	Body Control(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	DDM	Driver Door Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	DDM	Driver Door Module(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	ADM	Assist Door Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	ADM	Assist Door Module(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	PSM	Power Seat Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	PSM	Power Seat Module(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	OPTION	User Option(~2009.01.04)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	OPTION	User Option(2009.01.05~)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	TILT	Tilt/Telescope(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	TILT	Tilt/Telescope(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	CODE	Transmitter Code Saving(~2009.01.04)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.7 DOHC	CODE	Transmitter Code Saving(2009.01.05~)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	SMK	Smart Key(Button)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	SMK	Smart Key(Key)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Power Distribution Module(Button)	Power Distribution Module(Button)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	Interface Unit(Key)	Interface Unit(Key)	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	SMKCODE	Smart Key Code Saving(Button)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	SMKCODE	Smart Key Code Saving(Key)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	BCM	Body Control(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	BCM	Body Control(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	DDM	Driver Door Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	DDM	Driver Door Module(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	ADM	Assist Door Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	ADM	Assist Door Module(2009.01.05~)	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	PSM	Power Seat Module(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	PSM	Power Seat Module(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	OPTION	User Option(~2009.01.04)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	OPTION	User Option(2009.01.05~)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	TILT	Tilt/Telescope(~2009.01.04)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	TILT	Tilt/Telescope(2009.01.05~)	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	CODE	Transmitter Code Saving(~2009.01.04)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	L 2.7 DOHC	CODE	Transmitter Code Saving(2009.01.05~)	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2009	G 2.4 DOHC(Theta2)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2008	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2007	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2006	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Interface Unit	Interface Unit	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	G 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	User Option	User Option	–	–	–	√	–	√	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Tilt/Telescope	Tilt/Telescope	√	√	√	√	√	–	
Korea Area	Grandeur (TG),05~11	2005	L 2.7 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	CUBIS-T	CUBIS-T	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2017	G 2.4 HEV	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	CUBIS-T	CUBIS-T	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2016	G 2.4 HEV	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	CUBIS-T	CUBIS-T	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2015	G 2.4 HEV	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Cluster Module	Cluster Module	√	√	√	–	–	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Multi Function Switch	Multi Function Switch	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Steering Column Module	Steering Column Module	√	√	√	√	√	√	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	Steering Wheel Remote Control	Steering Wheel Remote Control	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	CUBIS-T	CUBIS-T	√	√	√	√	–	–	
Korea Area	Grandeur Hybrid(HG HEV),14~17	2014	G 2.4 HEV	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2019	G 2.4 MPI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	HEV Control System	HEV Control System	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Brake	Brake	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Blind Spot Detection	Blind Spot Detection	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Rear Remote Controller	Rear Remote Controller	√	√	√	–	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Steering Column Module	Steering Column Module	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	Grandeur hybrid(IG HEV),18~19	2018	G 2.4 MPI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Power Steering								
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Power Steering								
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 2.5 DOHC	Transmitter Code Saving								
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Power Steering								
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Power Steering								
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2005	L 2.7 DOHC	Transmitter Code Saving								
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Power Steering								
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Power Steering								
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 2.5 DOHC	Transmitter Code Saving								
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Power Steering								
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	G 3.0 DOHC	Transmitter Code Saving								
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Power Steering								
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2004	L 2.7 DOHC	Transmitter Code Saving								
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	ENGINE	EMS ECU(LPI)	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	ENGINE	Engine(LPG)	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	ENGINE	IFB ECU(LPI)	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2003	L 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 2.5 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	G 3.0 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2002	L 2.7 DOHC	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2001	L 2.7 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	2000	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1999	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Grandeur XG(XG),98~05	1998	G 3.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2011	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2011	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2010	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2010	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2009	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2009	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2008	D 1.6 TCI-U	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	i30 (FD),08~11	2008	G 1.6 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Service Reminder	Service Reminder	√	–	–	–	–	√	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	AT	Transmission	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	AT	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Service Reminder	Service Reminder	√	–	–	–	–	√	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2016	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	AT	Transmission	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	AT	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	ABSVDC	Brake((New-F/L))	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	ABSVDC	Brake((New-F/L))	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	ABSVDC	Brake((Old-F/L))	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	ABSVDC	Brake((Old-F/L))	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	EPS	Power Steering((New-F/L))	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	EPS	Power Steering((Old-F/L))	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	SPAS	Smart Parking Assist System((New-F/L))	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	SPAS	Smart Parking Assist System((Old-F/L))	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2015	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	AT	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	AT	Transmission(ISG-)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2015	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	AT	Transmission(ISG-)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2014	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	AT	Transmission(ISG-)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2014	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	AT	Transmission(ISG-)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2013	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	AT	Transmission(ISG-)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2013	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	AT	Transmission(ISG-)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2012	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	AT	Transmission(ISG-)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Cluster Variant Coding	Cluster Variant Coding	√	√	√	–	–	√	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	i30 (GD),12~16	2012	G 1.6 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	G 1.4 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Blind Spot Detection	Blind Spot Detection	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Integrated Body Control Unit-BCM	Integrated Body Control Unit-BCM	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Integrated Body Control Unit-TPMS	Integrated Body Control Unit-TPMS	√	√	√	√	–	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	i30(PD),17~18	2017	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Suspension	Suspension	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2019	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2018	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2017	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2017	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2016	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2016	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2015	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Transmission(AT)	Transmission(AT)	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2015	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2014	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2014	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2013	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2013	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2012	G 2.0 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Power Trunk Module	Power Trunk Module	√	√	√	√	–	–	
Korea Area	i40 (VF),12~19	2012	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	VCULDC	VCULDC	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	VDC/AHB	VDC/AHB	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2019	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	VCULDC	VCULDC	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	VDC/AHB	VDC/AHB	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2018	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	VCULDC	VCULDC	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	VDC/AHB	VDC/AHB	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ electric(AE EV),17~19	2017	88KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	VDC/AHB	VDC/AHB	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2019	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	VDC/AHB	VDC/AHB	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2018	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	VDC/AHB	VDC/AHB	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2017	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	HCU/Low DC-DC Converter	HCU/Low DC-DC Converter	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	VDC/AHB	VDC/AHB	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ Hybrid(AE HEV),16~19	2016	G 1.6 GDI HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Brake	Brake	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2019	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Brake	Brake	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2018	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Engine	Engine	√	√	√	√	√	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	SCC/AEB	SCC/AEB	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Brake	Brake	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Active Air Flap-Left	Active Air Flap-Left	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Active Air Flap-Right	Active Air Flap-Right	√	–	–	–	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	IONIQ plug-in(AE PHEV),17~19	2017	G 1.6 GDI PHEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	KONA electric(OS EV),19	2019	150KW	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	VCULDC	VCULDC	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Charge control Module	Charge control Module	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	KONA electric(OS EV),19	2019	150KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	KONA electric(OS EV),19	2019	150KW	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Brake	Brake	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Occupant Classification System	Occupant Classification System	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	KONA electric(OS EV),19	2019	150KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	KONA electric(OS EV),19	2019	150KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2019	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Brake	Brake	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Lane Keeping Assist System	Lane Keeping Assist System	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	IBU-TPMS	IBU-TPMS	√	√	√	√	–	√	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	IBU-BCM	IBU-BCM	√	√	√	√	√	√	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	IGPM	IGPM	√	√	√	√	√	–	
Korea Area	KONA(OS),18~19	2018	D 1.6 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	AT	Transmission(Bosch) PCU	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	AT	Transmission(Melco)	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Lavita (FC),01~07	2007	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	AT	Transmission(Bosch) PCU	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	AT	Transmission(Melco)	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Lavita (FC),01~07	2006	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2005	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2005	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2005	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.5 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.6 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.6 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2005	G 1.6 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2005	G 1.6 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2005	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.6 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.6 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2005	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2005	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2005	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2005	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2005	G 1.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2004	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2004	G 1.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2004	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2004	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2004	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2004	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2004	G 1.5 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2004	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2004	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2004	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2004	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Lavita (FC),01~07	2004	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2004	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2004	G 1.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2003	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2003	G 1.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2003	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2003	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2003	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2003	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2003	G 1.5 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2003	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2003	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2003	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2003	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2003	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2003	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2003	G 1.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2002	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2002	G 1.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2002	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2002	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2002	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2002	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2002	G 1.5 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2002	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2002	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2002	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2002	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2002	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2002	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2002	G 1.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2001	G 1.5 DOHC	Engine	Engine	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2001	G 1.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2001	G 1.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2001	G 1.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2001	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2001	G 1.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2001	G 1.5 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Lavita (FC),01~07	2001	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2001	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2001	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Lavita (FC),01~07	2001	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Lavita (FC),01~07	2001	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2001	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Lavita (FC),01~07	2001	G 1.8 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	–	–	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Libero (SR),00~09	2009	D 2.5 TCI-A	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Libero (SR),00~09	2008	D 2.5 TCI-A	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Libero (SR),00~09	2007	D 2.5 TCI-A	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Libero (SR),00~09	2006	D 2.5 TCI-A	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2005	D 2.5 TCI-A	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Libero (SR),00~09	2004	D 2.5 TCI-A	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI-A	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2003	D 2.5 TCI-A	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2003	L 3.0 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2003	L 3.0 SOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2003	L 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2003	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2003	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2003	L 3.0 SOHC	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2002	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2002	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2002	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2002	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2002	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2002	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2002	L 3.0 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2002	L 3.0 SOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2002	L 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2002	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2002	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2002	L 3.0 SOHC	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2001	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2001	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2001	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2001	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2001	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2001	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2001	L 3.0 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2001	L 3.0 SOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2001	L 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2001	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2001	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2001	L 3.0 SOHC	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2000	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2000	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2000	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2000	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2000	D 2.5 TCI	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2000	D 2.5 TCI	Transmitter Code Saving								
Korea Area	Libero (SR),00~09	2000	L 3.0 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2000	L 3.0 SOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Libero (SR),00~09	2000	L 3.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Libero (SR),00~09	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2000	L 3.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Libero (SR),00~09	2000	L 3.0 SOHC	Transmitter Code Saving								
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Anti-Lock Brake								
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Traction Control System								
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Marcia (H1),96~98	1998	G 2.5 DOHC	Electronic Control Suspension								
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Anti-Lock Brake								
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Traction Control System								
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Marcia (H1),96~98	1998	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Anti-Lock Brake								
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Traction Control System								
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Marcia (H1),96~98	1997	G 2.5 DOHC	Electronic Control Suspension								
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Anti-Lock Brake								
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Traction Control System								
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Marcia (H1),96~98	1997	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Anti-Lock Brake								
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Traction Control System								
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Marcia (H1),96~98	1996	G 2.5 DOHC	Electronic Control Suspension								
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Anti-Lock Brake								
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Traction Control System								
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Electronic Hydraulic Power Steering System								
Korea Area	Marcia (H1),96~98	1996	G 2.0 DOHC	Electronic Control Suspension								
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	G 3.3 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	AT	Transmission(8-Speed)	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	AT	Transmission(6-Speed)	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2019	D 2.2 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	AT	Transmission(6-Speed)	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	AT	Transmission(8-Speed)	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	D 2.2 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2018	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	AT	Transmission(6-Speed)	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	AT	Transmission(8-Speed)	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	D 2.2 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2017	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-5)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Occupant Classification System	Occupant Classification System	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	AHLS	Auto Headlamp Leveling System (after PE)	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	D 2.2 TCI-R(Euro-6)	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Occupant Classification System	Occupant Classification System	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	AHLS	Auto Headlamp Leveling System (after PE)	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2016	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2015	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2015	G 3.3 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Maxcruz (NC),14~19	2014	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	New Poter (AU),96~04	2004	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2004	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2004	D 2.5 T/C	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2004	D 2.5 T/C	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	2003	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2003	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2003	D 2.5 T/C	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2003	D 2.5 T/C	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	2003	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2003	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2003	L 2.4 SOHC	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2003	L 2.4 SOHC	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	2002	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2002	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	New Poter (AU),96~04	2002	D 2.5 T/C	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2002	D 2.5 T/C	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	2002	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2002	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2002	L 2.4 SOHC	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2002	L 2.4 SOHC	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	2001	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2001	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2001	D 2.5 T/C	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2001	D 2.5 T/C	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	2001	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2001	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2001	L 2.4 SOHC	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2001	L 2.4 SOHC	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	2000	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2000	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2000	D 2.5 T/C	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2000	D 2.5 T/C	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	2000	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2000	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	2000	L 2.4 SOHC	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	2000	L 2.4 SOHC	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	1999	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1999	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1999	D 2.5 T/C	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	1999	D 2.5 T/C	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	1999	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1999	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1999	L 2.4 SOHC	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	1999	L 2.4 SOHC	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	1998	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1998	D 2.5 T/C	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1998	D 2.5 T/C	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	1998	D 2.5 T/C	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	1998	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1998	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1998	L 2.4 SOHC	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	1998	L 2.4 SOHC	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	1997	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1997	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1997	L 2.4 SOHC	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	1997	L 2.4 SOHC	Anti-Lock Brake								
Korea Area	New Poter (AU),96~04	1996	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1996	L 2.4 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	New Poter (AU),96~04	1996	L 2.4 SOHC	Automatic Transaxle								
Korea Area	New Poter (AU),96~04	1996	L 2.4 SOHC	Anti-Lock Brake								
Korea Area	NEXO (FE),18~19	2019	113KW	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Bi-directional High DC/DC Convertor	Bi-directional High DC/DC Convertor	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Brake	Brake	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	NEXO (FE),18~19	2019	113KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Surround View Monitoring	Surround View Monitoring	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Remote Smart Parking Assist	Remote Smart Parking Assist	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Front View Camera	Front View Camera	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	NEXO (FE),18~19	2019	113KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Auto Flush-Handle Control Unit-DRV	Auto Flush-Handle Control Unit-DRV	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Auto Flush-Handle Control Unit-PAS	Auto Flush-Handle Control Unit-PAS	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Auto Flush-Handle Control Unit-RL	Auto Flush-Handle Control Unit-RL	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Auto Flush-Handle Control Unit-RR	Auto Flush-Handle Control Unit-RR	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Radiator Fan-Left	Radiator Fan-Left	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2019	113KW	Radiator Fan-Right	Radiator Fan-Right	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Motor Control System	Motor Control System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Hydrogen Storage System	Hydrogen Storage System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Bi-directional High DC/DC Convertor	Bi-directional High DC/DC Convertor	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Fuel Cell System	Fuel Cell System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Stack Volt Monitor	Stack Volt Monitor	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Blower Pump Control Unit	Blower Pump Control Unit	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Brake	Brake	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	NEXO (FE),18~19	2018	113KW	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Surround View Monitoring	Surround View Monitoring	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Remote Smart Parking Assist	Remote Smart Parking Assist	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Front View Camera	Front View Camera	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	E-Shifter	E-Shifter	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	NEXO (FE),18~19	2018	113KW	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Auto Flush-Handle Control Unit-DRV	Auto Flush-Handle Control Unit-DRV	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Auto Flush-Handle Control Unit-PAS	Auto Flush-Handle Control Unit-PAS	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Auto Flush-Handle Control Unit-RL	Auto Flush-Handle Control Unit-RL	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Auto Flush-Handle Control Unit-RR	Auto Flush-Handle Control Unit-RR	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Radiator Fan-Left	Radiator Fan-Left	√	√	√	√	√	–	
Korea Area	NEXO (FE),18~19	2018	113KW	Radiator Fan-Right	Radiator Fan-Right	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Poter2 (HR),04~19	2019	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Poter2 (HR),04~19	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-5)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-5)	Transmission	Transmission	–	√	√	–	–	–	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-5)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-5)	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-5)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-5)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	Engine	Engine	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Poter2 (HR),04~19	2017	D 2.5 TCI-A2(Euro-6)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2016	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2016	D 2.5 TCI-A2	Transmission	Transmission	–	√	√	–	–	–	
Korea Area	Poter2 (HR),04~19	2016	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2016	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2016	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2016	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2016	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2016	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2015	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2015	D 2.5 TCI-A2	Transmission	Transmission	–	√	√	–	–	–	
Korea Area	Poter2 (HR),04~19	2015	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2015	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2015	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2015	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2015	D 2.5 TCI-A2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2014	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2014	D 2.5 TCI-A2	Transmission	Transmission	–	√	√	–	–	–	
Korea Area	Poter2 (HR),04~19	2014	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2014	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2014	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2014	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2014	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2014	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2013	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2013	D 2.5 TCI-A2	Transmission	Transmission	–	√	√	–	–	–	
Korea Area	Poter2 (HR),04~19	2013	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2013	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2013	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2013	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2013	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A2	Transmission	Transmission	–	√	√	–	–	–	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A2	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2012	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2011	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2011	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2011	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2011	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2011	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2011	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2010	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2009	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2008	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2007	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2007	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2007	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2007	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2007	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2007	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2007	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2007	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2006	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2006	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2006	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2006	D 2.5 TCI	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	Poter2 (HR),04~19	2006	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2006	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2006	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2006	D 2.5 TCI-A	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Poter2 (HR),04~19	2005	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2005	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2005	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2005	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2005	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2005	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Poter2 (HR),04~19	2004	D 2.5 TCI	Engine	Engine	–	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2004	D 2.5 TCI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2004	D 2.5 TCI	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2004	D 2.5 TCI-A	Engine	Engine	√	√	√	√	√	√	
Korea Area	Poter2 (HR),04~19	2004	D 2.5 TCI-A	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Poter2 (HR),04~19	2004	D 2.5 TCI-A	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	L 2.7 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2012	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2011	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2011	L 2.7 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2011	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2010	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	ENGINE	EMS ECU	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	ENGINE	IFB ECU	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2010	L 2.7 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2010	G 2.4 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Driveshaft	Driveshaft	√	√	√	–	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Driveshaft	Driveshaft	√	√	√	–	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2009	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Driveshaft	Driveshaft	√	√	√	–	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Driveshaft	Driveshaft	√	√	√	–	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2008	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	ENGINE	Engine(CPF-)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	ENGINE	Engine(CPF+)	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Driveshaft	Driveshaft	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Driveshaft	Driveshaft	√	√	√	–	–	–	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2007	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Driveshaft	Driveshaft	√	√	√	–	–	–	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Santafe (CM),06~12	2006	D 2.2 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Active Hood System	Active Hood System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2018	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Body Control	Body Control	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2017	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	AHLS	Auto Headlamp Leveling System (after PE)	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	AHLS	Auto Headlamp Leveling System (after PE)	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	AHLS	Auto Headlamp Leveling System(before PE)	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2016	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Santafe (DM),13~18	2015	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Santafe (DM),13~18	2014	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Santafe (DM),13~18	2014	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Santafe (DM),13~18	2013	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Santafe (DM),13~18	2013	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	ENGINE	Engine(VGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	ENGINE	Engine(WGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Traction control system	Traction control system	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Santafe (SM),00~05	2005	D 2.0 TCI-D	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2004	G 2.7 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	ENGINE	Engine(VGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	ENGINE	Engine(VGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	ENGINE	Engine(WGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2004	D 2.0 TCI-D	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2003	G 2.7 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	ENGINE	Engine(VGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	ENGINE	Engine(WGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	Traction control system	Traction control system	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2003	D 2.0 TCI-D	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2002	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2002	G 2.7 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	ENGINE	Engine(VGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	ENGINE	Engine(WGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2002	D 2.0 TCI-D	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2002	L 2.7 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2001	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2001	G 2.7 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	ENGINE	Engine(VGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	ENGINE	Engine(WGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2001	D 2.0 TCI-D	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2001	L 2.7 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2000	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2000	G 2.7 DOHC	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	ENGINE	Engine(VGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	ENGINE	Engine(WGT)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2000	D 2.0 TCI-D	Transmitter Code Saving								
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	ABS	Anti-Lock Brake(2WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	ABS	Anti-Lock Brake(4WD)	√	√	√	√	√	√	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	Driveshaft	Driveshaft	–	√	√	–	–	–	
Korea Area	Santafe (SM),00~05	2000	L 2.7 DOHC	Transmitter Code Saving								
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Surround View Monitoring	Surround View Monitoring	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Parking Assist	Parking Assist	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Front View Camera	Front View Camera	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Brake	Brake	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Surround View Monitoring	Surround View Monitoring	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Parking Assist	Parking Assist	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Front View Camera	Front View Camera	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.0 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Engine	Engine	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Brake	Brake	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Forward Collision-Avoidance Assist	Forward Collision-Avoidance Assist	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #1)	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	AIRBAG	Airbag(Event #2)	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Driveshaft	Driveshaft	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Surround View Monitoring	Surround View Monitoring	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Rear View Monitor	Rear View Monitor	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Parking Assist	Parking Assist	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Front View Camera	Front View Camera	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Blind-Spot Collision Warning	Blind-Spot Collision Warning	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Head Up Display	Head Up Display	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	IBU-BCM	IBU-BCM	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	IBU-IMMO	IBU-IMMO	–	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	IBU-SMK	IBU-SMK	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	IBU-TPMS	IBU-TPMS	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Intergrated Central Control Unit	Intergrated Central Control Unit	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Power Tail Gate	Power Tail Gate	√	√	√	√	–	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	Santafe (TM),19	2019	D 2.2 TCI-R	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2002	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2001	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Engine Control	Engine Control	√	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	2000	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1999	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1999	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1998	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1997	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Santamo (M2),96~02	1996	G 2.0 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	ENGINE	Engine Control (Turbo-)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	ENGINE	Engine Control (Turbo-)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	ENGINE	Engine Control (Turbo+)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	ENGINE	Engine Control (Turbo+)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1995	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	ENGINE	Engine Control (Turbo-)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	ENGINE	Engine Control (Turbo-)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	ENGINE	Engine Control (Turbo+)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	ENGINE	Engine Control (Turbo+)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1994	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	ENGINE	Engine Control (Turbo-)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	ENGINE	Engine Control (Turbo-)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	ENGINE	Engine Control (Turbo+)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	ENGINE	Engine Control (Turbo+)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1993	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	ENGINE	Engine Control (Turbo-)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	ENGINE	Engine Control (Turbo-)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	ENGINE	Engine Control (Turbo+)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	ENGINE	Engine Control (Turbo+)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1992	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Melco)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Melco)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Melco)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Melco)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Melco)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Melco)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Melco)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Melco)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Bosch)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	ENGINE	Engine Control (Bosch)	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1991	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Scoupe (L1),90~95	1990	G 1.5 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Brake	Brake	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Air Conditioner(CCM)	Air Conditioner(CCM)	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Central Gateway	Central Gateway	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Digital Tachograph	Digital Tachograph	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2018	D 2.5 TCI-A2	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Brake	Brake	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Air Conditioner(CCM)	Air Conditioner(CCM)	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Central Gateway	Central Gateway	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Digital Tachograph	Digital Tachograph	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2017	D 2.5 TCI-A2	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Brake	Brake	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Air Conditioner(CCM)	Air Conditioner(CCM)	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Central Gateway	Central Gateway	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Digital Tachograph	Digital Tachograph	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2016	D 2.5 TCI-A2	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Engine	Engine	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Brake	Brake	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Air Conditioner(CCM)	Air Conditioner(CCM)	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Immobilizer	Immobilizer	–	√	√	√	–	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Driver Door Module	Driver Door Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Central Gateway	Central Gateway	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Digital Tachograph	Digital Tachograph	√	√	√	√	√	–	
Korea Area	SOLATI(EU),15~18	2015	D 2.5 TCI-A2	Selective Catalytic Reduction	Selective Catalytic Reduction	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2006	L 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2005	L 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 1.8 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	G 2.5 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2004	L 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 1.8 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	G 2.5 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2003	L 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 1.8 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	G 2.5 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2002	L 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	ENGINE	Engine(EF Sonata)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	ENGINE	Engine(New EF Sonata)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	ENGINE	Engine(New EF Sonata)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 1.8 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 SOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	G 2.5 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	ENGINE	Engine(Beta)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	ENGINE	Engine(Sirius)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2001	L 2.0 DOHC	Transmitter Code Saving								
Korea Area	Sonata (EF),98~06	2000	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2000	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2000	G 1.8 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2000	G 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2000	L 2.0 SOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	2000	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1999	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1999	G 1.8 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1999	G 2.0 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1999	L 2.0 SOHC	Power Steering								
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	1999	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 1.8 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	G 1.8 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 1.8 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	G 1.8 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1998	G 1.8 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1998	G 1.8 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1998	G 2.0 DOHC	Power Steering								

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	AT	Transmission(A/T)	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	AT	Transmission(A/T)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	AT	Transmission(CVT)	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1998	L 2.0 SOHC	Power Steering								
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Anti-Lock Brake	Anti-Lock Brake	√	√	√	√	√	√	
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Traction control system	Traction control system	–	√	√	√	√	–	
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Power Steering								
Korea Area	Sonata (EF),98~06	1998	G 2.5 DOHC	Suspension	Suspension	–	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	AT	Transmission(FL After)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	AT	Transmission(FL Before)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	EPS	Power Steering(FL Before)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	EPS	Power Steering(FL Before)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	EPS	Power Steering(FL After)	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	EPS	Power Steering(FL After)	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	BSD-R	Blind Spot Detection-Right(FL Before)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	BSD-R	Blind Spot Detection-Right(FL After)	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	BSD-L	Blind Spot Detection-Left(FL Before)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	BSD-L	Blind Spot Detection-Left(FL After)	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Multi Function Camera(FL After)	Multi Function Camera(FL After)	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Lane Departure Warning System(FL Before)	Lane Departure Warning System(FL Before)	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	AHLS	Auto Headlamp Leveling System(FL After)	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	AHLS	Auto Headlamp Leveling System(FL Before)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2019	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	AT	Transmission(FL After)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	AT	Transmission(FL Before)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	EPS	Power Steering(FL After)	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	EPS	Power Steering(FL After)	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	EPS	Power Steering(FL Before)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	EPS	Power Steering(FL Before)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	BSD-R	Blind Spot Detection-Right(FL After)	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	BSD-R	Blind Spot Detection-Right(FL Before)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	BSD-L	Blind Spot Detection-Left(FL After)	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	BSD-L	Blind Spot Detection-Left(FL Before)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Multi Function Camera(FL After)	Multi Function Camera(FL After)	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Lane Departure Warning System(FL Before)	Lane Departure Warning System(FL Before)	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	AHLS	Auto Headlamp Leveling System(FL After)	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	AHLS	Auto Headlamp Leveling System(FL Before)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2018	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2017	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 1.6 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Transmission(DCT)	Transmission(DCT)	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Autonomous Emergency Braking	Autonomous Emergency Braking	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2016	D 1.7 TCI-U2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Immobilizer	Immobilizer	–	√	√	√	–	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata (LF),15~19	2015	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2014	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2013	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2012	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2011	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2010	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	ENGINE	Engine(Integrated)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2010	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2010	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2009	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	ENGINE	Engine(Integrated)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2009	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2009	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta1)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Engine(Theta1)	Engine(Theta1)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Engine(Theta1)	Engine(Theta1)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta1)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	SMK	Smart Key(Button)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	SMK	Smart Key(Key)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	SMKCODE	Smart Key Code Saving(Button)	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	SMKCODE	Smart Key Code Saving(Key)	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	Engine(EMS:F/L)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	Engine(EMS:F/L)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	Engine(EMS:Older)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	Engine(EMS:Older)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	Engine(IFB:F/L)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	Engine(IFB:F/L)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	Engine(IFB:Older)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	ENGINE	Engine(IFB:Older)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	SMK	Smart Key(Button)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	SMK	Smart Key(Key)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	SMKCODE	Smart Key Code Saving(Button)	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	SMKCODE	Smart Key Code Saving(Key)	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.0 DOHC(Theta2)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Body Control	Body Control	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2008	G 2.4 DOHC(Theta2)	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2007	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2007	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Active Geometry Control Suspension	Active Geometry Control Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Smart Key	Smart Key	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2007	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	AT	Transmission(4-Speed)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	AT	Transmission(5-Speed)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2006	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2006	D 2.0 TCI-D	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2006	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2005	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2005	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 2.4 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Suspension	Suspension	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2004	G 3.3 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	ENGINE	All Systems	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	ENGINE	Engine(EMS)	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	ENGINE	Engine(IFB)	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	Airbag	Airbag	√	√	√	√	–	–	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	BCM	Rain Sensor(-)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	BCM	Rain Sensor(+)	√	–	–	√	√	√	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	–	
Korea Area	Sonata (NF),04~14	2004	L 2.0 DOHC	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 1.8 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1993	G 2.0 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 1.8 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1992	G 2.0 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 1.8 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1991	G 2.0 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1990	G 1.8 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1990	G 2.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1989	G 1.8 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1989	G 2.0 SOHC	Cruise Module								
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1988	G 1.8 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1988	G 2.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1987	G 1.8 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Anti-Lock Brake								
Korea Area	Sonata (Y2),87~93	1987	G 2.0 SOHC	Cruise Module	Cruise Module	√	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	2000	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1999	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1998	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1997	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1996	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1995	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1994	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (DOHC)	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	ENGINE	Engine Control (SOHC)	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 2.0 SOHC/DOHC	Electronic Control Suspension	Electronic Control Suspension	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Engine Control	Engine Control	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	G 1.8 DOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	L 2.0 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Engine Control	Engine Control	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Automatic Transaxle	Automatic Transaxle	–	√	√	√	√	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (Y3),93~00	1993	L 1.8 SOHC	Airbag	Airbag	–	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata (YF),10~16	2016	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata (YF),10~16	2015	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	AT	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata (YF),10~16	2014	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata (YF),10~16	2014	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	AT	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata (YF),10~16	2013	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata (YF),10~16	2013	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	AT	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	AT	Transmission(ISG+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-NU	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2012	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	ABSVDC	Brake(Bosch)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	ABSVDC	Brake(Mobis)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 MPI-Theta2	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	ABSVDC	Brake(Bosch)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	ABSVDC	Brake(Mobis)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2012	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	SMK	Smart Key(ESCL-)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	SMK	Smart Key(ESCL+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	PDM	Power Distribution Module(ESCL-)	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	PDM	Power Distribution Module(ESCL+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	SMKCODE	Smart Key Code Saving(ESCL-)	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	SMKCODE	Smart Key Code Saving(ESCL+)	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	SMK	Smart Key(ESCL-)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	SMK	Smart Key(ESCL+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	PDM	Power Distribution Module(ESCL-)	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	PDM	Power Distribution Module(ESCL+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	SMKCODE	Smart Key Code Saving(ESCL-)	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	SMKCODE	Smart Key Code Saving(ESCL+)	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2011	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	SMK	Smart Key(ESCL-)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	SMK	Smart Key(ESCL+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	PDM	Power Distribution Module(ESCL-)	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	PDM	Power Distribution Module(ESCL+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	SMKCODE	Smart Key Code Saving(ESCL-)	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	SMKCODE	Smart Key Code Saving(ESCL+)	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2011	G 2.0 T-GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	SMK	Smart Key(ESCL-)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	SMK	Smart Key(ESCL+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	PDM	Power Distribution Module(ESCL-)	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	PDM	Power Distribution Module(ESCL+)	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	SMKCODE	Smart Key Code Saving(ESCL-)	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	SMKCODE	Smart Key Code Saving(ESCL+)	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2011	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2010	G 2.0 MPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2010	L 2.0 LPI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Engine	Engine	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Power Distribution Module	Power Distribution Module	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata (YF),10~16	2010	G 2.4 GDI	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Brake	Brake	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	CD Player	CD Player	√	√	√	–	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2019	G 2.0 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Brake	Brake	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Occupant Classification System	Occupant Classification System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	CD Player	CD Player	√	√	√	–	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Wireless Power Charger	Wireless Power Charger	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2018	G 2.0 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Motor Control System	Motor Control System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2017	G 2.0 GDI HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Motor Control System	Motor Control System	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2016	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Motor Control System	Motor Control System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	HCU/LDC	HCU/LDC	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Brake	Brake	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Lane Departure Warning System	Lane Departure Warning System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Assist Door Module	Assist Door Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Central Gateway	Central Gateway	√	√	√	–	–	√	
Korea Area	Sonata Hybrid(LF HEV),15~19	2015	G 2.0 HEV	Virtual Engine Sound System	Virtual Engine Sound System	√	√	√	–	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	HEV Control System	HEV Control System	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2015	G 2.0 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	HEV Control System	HEV Control System	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2014	G 2.0 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	HEV Control System	HEV Control System	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	

Diagnostic List HYUNDAI_v10.50

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3.compared with the last version, the new added function is marked in red color.

Area	Vehicle	Year	Displacement	System	Subsystem	Function						
						System Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Function	Remark
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	CUBIS-T	CUBIS-T	√	√	√	–	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2013	G 2.0 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2012	G 2.0 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Motor Control System	Motor Control System	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	HEV Control System	HEV Control System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Low DC/DC Converter	Low DC/DC Converter	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Transmission	Transmission	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Vehicle Dynamic Control	Vehicle Dynamic Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Active Hydraulic Booster	Active Hydraulic Booster	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Power Steering	Power Steering	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Immobilizer	Immobilizer	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Power Distribution Module	Power Distribution Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Smart Key Code Saving	Smart Key Code Saving	–	–	–	√	–	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Body Control	Body Control	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Cluster Module	Cluster Module	√	√	√	√	√	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	CUBIS	CUBIS	√	√	√	√	–	–	
Korea Area	Sonata Hybrid(YF HEV),11~15	2011	G 2.0 HEV	Transmitter Code Saving	Transmitter Code Saving	–	–	–	√	–	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Engine	Engine	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Motor Control System	Motor Control System	√	√	√	√	–	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	HCU/LDC	HCU/LDC	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Battery Management System	Battery Management System	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Transmission	Transmission	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Electric Parking Brake	Electric Parking Brake	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Brake	Brake	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	AIRBAG	Airbag(Event #1)	√	√	√	√	–	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	AIRBAG	Airbag(Event #2)	√	√	√	√	–	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Occupant Detection Sensor	Occupant Detection Sensor	√	√	√	√	–	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Air Conditioner	Air Conditioner	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	On Board Charger	On Board Charger	√	√	√	√	–	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Power Steering	Power Steering	√	√	√	√	–	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Cruise Control	Cruise Control	√	√	√	√	–	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Tire Pressure Monitoring	Tire Pressure Monitoring	√	√	√	√	–	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Around View Monitoring System	Around View Monitoring System	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Parking Guide System	Parking Guide System	√	√	√	√	–	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Smart Parking Assist System	Smart Parking Assist System	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Blind Spot Detection-Left	Blind Spot Detection-Left	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Blind Spot Detection-Right	Blind Spot Detection-Right	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Multi Function Camera	Multi Function Camera	√	√	√	√	–	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Auto Headlamp Leveling System	Auto Headlamp Leveling System	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Adaptive Front Lighting System	Adaptive Front Lighting System	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Active Air Flap	Active Air Flap	√	√	√	√	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Smart Key	Smart Key	√	√	√	√	√	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	CD Player	CD Player	√	√	√	–	√	–	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Cluster Module	Cluster Module	√	√	√	√	√	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Power Seat Module	Power Seat Module	√	√	√	√	√	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Smart Junction Block	Smart Junction Block	√	√	√	√	√	√	
Korea Area	Sonata plug-in(LF PHEV),16~19	2019	G 2.0 GDI PHEV	Driver Door Module	Driver Door Module	√	√	√	√	√	√	