Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
106R		Engine	Petrol	CDY BOSCH MA3.1		Read ECU Information		Y		
106R		Engine	Petrol	CDY BOSCH MA3.1		Read Fault Code		Y		
106R		Engine	Petrol	CDY BOSCH MA3.1		Erase Fault Code		Y		
106R		Engine	Petrol	CDY BOSCH MA3.1		Live Data		Y		
106R		Engine	Petrol	CDZ BOSCH MA3.1		Read ECU Information		Y		
106R		Engine	Petrol	CDZ BOSCH MA3.1		Read Fault Code		Y		
106R		Engine	Petrol	CDZ BOSCH MA3.1		Erase Fault Code		Y		
106R		Engine	Petrol	CDZ BOSCH MA3.1		Live Data		Y		
106R		Engine	Petrol	HDY BOSCH MA3.1		Read ECU Information		Y		
106R		Engine	Petrol	HDY BOSCH MA3.1		Read Fault Code		Y		
106R		Engine	Petrol	HDY BOSCH MA3.1		Erase Fault Code		Y		
106R		Engine	Petrol	HDY BOSCH MA3.1		Live Data		Y		
106R		Engine	Petrol	HDZ BOSCH MA3.1		Read ECU Information		Y		
106R		Engine	Petrol	HDZ BOSCH MA3.1		Read Fault Code		Y		
106R		Engine	Petrol	HDZ BOSCH MA3.1		Erase Fault Code		Y		
106R		Engine	Petrol	HDZ BOSCH MA3.1		Live Data		Y		
106R		Engine	Petrol	HFX BOSCH M7.4.4		Read ECU Information		Y		
106R		Engine	Petrol	HFX BOSCH M7.4.4		Read Fault Code		Y		
106R		Engine	Petrol	HFX BOSCH M7.4.4		Erase Fault Code		Y		
106R		Engine	Petrol	HFX BOSCH M7.4.4		Live Data		Y		
106R		Engine	Petrol	HFX BOSCH M7.4.4		Special Function	Initialising the autoadaptives	Y		
106R		Engine	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Live Data		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Actuation Test		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
106R		Engine	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Live Data		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Actuation Test		Y		
106R		Engine	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
106R		Engine	Petrol	KFX BOSCH MP7.3		Read ECU Information		Y		
106R		Engine	Petrol	KFX BOSCH MP7.3		Read Fault Code		Y		
106R		Engine	Petrol	KFX BOSCH MP7.3		Erase Fault Code		Y		
106R		Engine	Petrol	KFX BOSCH MP7.3		Live Data		Y		
106R		Engine	Petrol	KFX BOSCH MP7.3		Actuation Test		Y		
106R		Engine	Petrol	KFX BOSCH MP7.3		Special Function	Injection ECU initialisation procedure	Y		
106R		Engine	Petrol	KFX MM1AP		Read ECU Information		Y		
106R		Engine	Petrol	KFX MM1AP		Read Fault Code		Y		
106R		Engine	Petrol	KFX MM1AP		Erase Fault Code		Y		
106R		Engine	Petrol	KFX MM1AP		Live Data		Y		
106R		Engine	Petrol	KFX MM1AP		Actuation Test		Y		
106R		Engine	Petrol	KFX MM1AP		Special Function	Ignition advance setting	Y		
106R		Engine	Petrol	KFX MM1AP		Special Function	Injection ECU initialisation procedure	Y		
106R		Engine	Petrol	NFX MM1AP		Read ECU Information		Y		
106R		Engine	Petrol	NFX MM1AP		Read Fault Code		Y		
106R		Engine	Petrol	NFX MM1AP		Erase Fault Code		Y		
106R		Engine	Petrol	NFX MM1AP		Live Data		Y		
106R		Engine	Petrol	NFX MM1AP		Actuation Test		Y		
106R		Engine	Petrol	NFX MM1AP		Special Function	Ignition advance setting	Y		
106R		Engine	Petrol	NFX MM1AP		Special Function	Injection ECU initialisation procedure	Y		
106R		Engine	Petrol	NFX MM48P		Read ECU Information		Y		
106R		Engine	Petrol	NFX MM48P		Read Fault Code		Y		
106R		Engine	Petrol	NFX MM48P		Erase Fault Code		Y		
106R		Engine	Petrol	NFX MM48P		Live Data		Y		
106R		Engine	Petrol	NFX MM48P		Actuation Test		Y		
106R		Engine	Petrol	NFX MM48P		Special Function	Injection ECU initialisation procedure	Y		
106R		Engine	Petrol	NFX MM48P		Special Function	Initialising the autoadaptives	Y		
106R		Engine	Petrol	NFZ BOSCH MP5.2		Read Fault Code		Y		
106R		Engine	Petrol	NFZ BOSCH MP5.2		Erase Fault Code		Y		
106R		Engine	Petrol	NFZ BOSCH MP5.2		Live Data		Y		
106R		Engine	Diesel	VJU BOSCH VP20		Read ECU Information		Y		
106R		Engine	Diesel	VJU BOSCH VP20		Read Fault Code		Y		
106R		Engine	Diesel	VJU BOSCH VP20		Erase Fault Code		Y		
106R		Engine	Diesel	VJU BOSCH VP20		Live Data		Y		
106R		Engine	Diesel	VJX BOSCH VP20		Read ECU Information		Y		
106R		Engine	Diesel	VJX BOSCH VP20		Read Fault Code		Y		
106R		Engine	Diesel	VJX BOSCH VP20		Erase Fault Code		Y		
106R		Engine	Diesel	VJX BOSCH VP20		Live Data		Y		
106R		Air bag and seat belt				Read ECU Information		Y		
106R		Air bag and seat belt				Read Fault Code		Y		
106R		Air bag and seat belt				Erase Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES MKIVGI			Read ECU Information		Y		
106R		Active safety	Anti-lock brakes TEVES MKIVGI			Read Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES MKIVGI			Erase Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES MKIVGI			Live Data		Y		
106R		Active safety	Anti-lock brakes TEVES MKIVGI			Special Function	Bleeding	Y		
106R		Active safety	Anti-lock brakes TEVES MK20E			Read ECU Information		Y		
106R		Active safety	Anti-lock brakes TEVES MK20E			Read Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES MK20E			Erase Fault Code		Y		
106R		Active safety	Anti-lock brakes TEVES MK20E			Live Data		Y		
106R		Active safety	Anti-lock brakes TEVES MK20E			Special Function	Bleeding	Y		
107		Engine ECU	CFA BOSCH ME7.9.5			Read Fault Code		Y		
107		Engine ECU	CFA BOSCH ME7.9.5			Erase Fault Code		Y		
107		Engine ECU	8HT SIEMENS SID805			Read ECU Information		Y		
107		Engine ECU	8HT SIEMENS SID805			Read Fault Code		Y		
107		Engine ECU	8HT SIEMENS SID805			Erase Fault Code		Y		
107		Engine ECU	8HT SIEMENS SID805			Live Data		Y		
107		Engine ECU	8HT SIEMENS SID805			Actuation Test		Y		
107		Engine ECU	8HT SIEMENS SID805			Special Function	Configuration	Y		
107		Gearbox ECU				Read Fault Code		Y		
107		Gearbox ECU				Erase Fault Code		Y		
107		Gearbox ECU				Live Data		Y		
107		Gearbox ECU				Actuation Test		Y		
107		Gearbox ECU				Special Function	Pack repair	Y		
107		Airbag ECU				Read ECU Information		Y		
107		Airbag ECU				Read Fault Code		Y		
107		Airbag ECU				Erase Fault Code		Y		
107		Airbag ECU				Live Data		Y		
107		Power steering				Read ECU Information		Y		
107		Power steering				Read Fault Code		Y		
107		Power steering				Erase Fault Code		Y		
107		Power steering				Live Data		Y		
107		Power steering				Special Function	Calibration	Y		
107		Coded anti-start				Read Fault Code		Y		
107		Coded anti-start				Erase Fault Code		Y		
107		Coded anti-start				Live Data		Y		
107		Radio				Read ECU Information		Y		
107		Radio				Read Fault Code		Y		
107		Radio				Erase Fault Code		Y		
107		Radio				Live Data		Y		
107		Radio				Actuation Test		Y		
107		Radio				Special Function	Configuration	Y		
108		Engine ECU	V46			Read ECU Information		Y		
108		Engine ECU	V46			Read Fault Code		Y		
108		Engine ECU	V46			Erase Fault Code		Y		
108		Engine ECU	V46			Live Data		Y		
108		Engine ECU	V46			Actuation Test		Y		
108		Engine ECU(1KR)				Read ECU Information		Y		
108		Engine ECU(1KR)				Read Fault Code		Y		
108		Engine ECU(1KR)				Erase Fault Code		Y		
108		Engine ECU(1KR)				Live Data		Y		
108		ABS or ESP ECU				Read ECU Information		Y		
108		ABS or ESP ECU				Read Fault Code		Y		
108		ABS or ESP ECU				Erase Fault Code		Y		
108		ABS or ESP ECU				Live Data		Y		
108		Climate control				Read ECU Information		Y		
108		Climate control				Read Fault Code		Y		
108		Climate control				Erase Fault Code		Y		
108		Climate control				Live Data		Y		
108		Climate control				Actuation Test		Y		
108		Power steering				Read ECU Information		Y		
108		Power steering				Read Fault Code		Y		
108		Power steering				Erase Fault Code		Y		
108		Power steering				Live Data		Y		
108		Gearbox ECU				Read ECU Information		Y		
108		Gearbox ECU				Read Fault Code		Y		
108		Gearbox ECU				Erase Fault Code		Y		
108		Gearbox ECU				Live Data		Y		
108		Stop and Start ECU				Read ECU Information		Y		
108		Stop and Start ECU				Read Fault Code		Y		
108		Stop and Start ECU				Erase Fault Code		Y		
108		Stop and Start ECU				Live Data		Y		
108		Hands-free control unit				Read Fault Code		Y		
108		Hands-free control unit				Erase Fault Code		Y		
108		Hands-free control unit				Live Data		Y		
108		Keyless entry unit(entry and start):Automatic monitoring				Read Fault Code		Y		
108		Keyless entry unit(entry and start):Automatic monitoring				Erase Fault Code		Y		
108		Keyless entry unit(entry and start):Automatic monitoring				Live Data		Y		
108		Keyless entry unit(entry and start):Allow to start				Read Fault Code		Y		
108		Keyless entry unit(entry and start):Allow to start				Erase Fault Code		Y		
108		Keyless entry unit(entry and start):Allow to start				Live Data		Y		
108		Keyless entry unit(entry and start):Entry and Start				Read ECU Information		Y		
108		Keyless entry unit(entry and start):Entry and Start				Read Fault Code		Y		
108		Keyless entry unit(entry and start):Entry and Start				Erase Fault Code		Y		
108		Keyless entry unit(entry and start):Entry and Start				Live Data		Y		
108		Instrument cluster				Read ECU Information		Y		
108		Instrument cluster				Read Fault Code		Y		
108		Instrument cluster				Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
108		Instrument cluster				Live Data		Y		
108		Multifunction display				Read Fault Code		Y		
108		Multifunction display				Erase Fault Code		Y		
108		Multifunction display				Live Data		Y		
108		Airbag ECU				Read ECU Information		Y		
108		Airbag ECU				Read Fault Code		Y		
108		Airbag ECU				Erase Fault Code		Y		
108		Airbag ECU				Live Data		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Live Data		Y		
206	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Special Function	Ignition advance setting	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Special Function	Ignition advance setting	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Special Function	Ignition advance setting	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Special Function	Ignition advance setting	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Special Function	Injection ECU initialisation procedure	Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Read ECU Information		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Read Fault Code		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Erase Fault Code		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Live Data		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Actuation Test		Y		
206	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Read ECU Information		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Read Fault Code		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Erase Fault Code		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Live Data		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Actuation Test		Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Special Function	Configuration	Y		
206	Production date before 13 September 2001	Active safety	ABS MK70			Special Function	Bleeding	Y		
206	Production date before 13 September 2001	Airbags	Air bag and seat belt			Read ECU Information		Y		
206	Production date before 13 September 2001	Airbags	Air bag and seat belt			Read Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Air bag and seat belt			Erase Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(right side)			Read ECU Information		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(right side)			Read Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(right side)			Erase Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(right side)			Actuation Test		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(left side)			Read ECU Information		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(left side)			Read Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(left side)			Erase Fault Code		Y		
206	Production date before 13 September 2001	Airbags	Side airbag(left side)			Actuation Test		Y		
206	Production date before 13 September 2001	Programming of the built-in systems interface (Engine immobiliser code and				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
206	Production date before 13 September 2001	Multifunction display				Read ECU Information		Y		
206	Production date before 13 September 2001	Multifunction display				Read Fault Code		Y		
206	Production date before 13 September 2001	Multifunction display				Erase Fault Code		Y		
206	Production date before 13 September 2001	Multifunction display				Actuation Test		Y		
206	Production date before 13 September 2001	On-board navigation system				Read ECU Information		Y		
206	Production date before 13 September 2001	On-board navigation system				Read Fault Code		Y		
206	Production date before 13 September 2001	On-board navigation system				Erase Fault Code		Y		
206	Production date before 13 September 2001	On-board navigation system				Live Data		Y		
206	Production date before 13 September 2001	Service module				Special Function		Y		
206	Production date before 13 September 2001	Electric retractable roof				Read ECU Information		Y		
206	Production date before 13 September 2001	Electric retractable roof				Read Fault Code		Y		
206	Production date before 13 September 2001	Electric retractable roof				Erase Fault Code		Y		
206	Production date before 13 September 2001	Electric retractable roof				Live Data		Y		
206	Production date before 13 September 2001	Electric retractable roof				Actuation Test		Y		
206	Production date before 13 September 2001	Heating/ventilation				Read ECU Information		Y		
206	Production date before 13 September 2001	Heating/ventilation				Read Fault Code		Y		
206	Production date before 13 September 2001	Heating/ventilation				Erase Fault Code		Y		
206	Production date before 13 September 2001	Heating/ventilation				Live Data		Y		
206	Production date before 13 September 2001	Heating/ventilation				Actuation Test		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Live Data		Y		
206	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Special Function	Programming / Pairing	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Special Function	Programming / Pairing	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Special Function	Programming / Pairing	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Special Function	Programming / Pairing	Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Special Function	After sales operation(Particle emission filter and fuel additive adding)	Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Read ECU Information		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Read Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Erase Fault Code		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Live Data		Y		
206	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Read ECU Information		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Read Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Erase Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Live Data		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Read ECU Information		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Read Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Erase Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Live Data		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Read ECU Information		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Read Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Erase Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Live Data		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Read ECU Information		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Read Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Erase Fault Code		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Live Data		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Actuation Test		Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Special Function	Accelerator pedal learning	Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Special Function	Initialising the autoadaptives	Y		
206	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Special Function	Oil wear counter	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Read ECU Information		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Read Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Erase Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Actuation Test		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Read ECU Information		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Read Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Erase Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Live Data		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Actuation Test		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Special Function	Configuration	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Special Function	Bleeding	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Read ECU Information		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Read Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Erase Fault Code		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Live Data		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Actuation Test		Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	Steering wheel angle sensor calibration	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	De-calibration of the steering wheel angle sensor	Y		
206	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	Bleeding	Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Read ECU Information		Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Read Fault Code		Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Erase Fault Code		Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Special Function	Locking	Y		
206	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Special Function	Unlocking	Y		
206	Production date after 13 September 2001	Programming of the built-in systems interface (Engine immobiliser code and				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
206	Production date after 13 September 2001	Anti-theft alarm				Read ECU Information		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Read Fault Code		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Erase Fault Code		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Live Data		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Actuation Test		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Special Function	Configuration	Y		
206	Production date after 13 September 2001	Anti-theft alarm				Actuation Test		Y		
206	Production date after 13 September 2001	Anti-theft alarm				Special Function	Configuration	Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Read ECU Information		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Read Fault Code		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Erase Fault Code		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Live Data		Y		
206	Production date after 13 September 2001	Display / Telematics	AMF			Actuation Test		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Read ECU Information		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Read Fault Code		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Erase Fault Code		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Live Data		Y		
206	Production date after 13 September 2001	Display / Telematics	RT3			Actuation Test		Y		
206	Production date after 13 September 2001	Radio	Radio			Read ECU Information		Y		
206	Production date after 13 September 2001	Radio	Radio			Read Fault Code		Y		
206	Production date after 13 September 2001	Radio	Radio			Erase Fault Code		Y		
206	Production date after 13 September 2001	Radio	Radio			Live Data		Y		
206	Production date after 13 September 2001	Radio	Radio			Actuation Test		Y		
206	Production date after 13 September 2001	Radio	RDE filament			Read ECU Information		Y		
206	Production date after 13 September 2001	Radio	RDE filament			Read Fault Code		Y		
206	Production date after 13 September 2001	Radio	RDE filament			Erase Fault Code		Y		
206	Production date after 13 September 2001	Radio	RDE filament			Live Data		Y		
206	Production date after 13 September 2001	Radio	RDE filament			Actuation Test		Y		
206	Production date after 13 September 2001	CD player				Read ECU Information		Y		
206	Production date after 13 September 2001	CD player				Read Fault Code		Y		
206	Production date after 13 September 2001	CD player				Erase Fault Code		Y		
206	Production date after 13 September 2001	CD player				Live Data		Y		
206	Production date after 13 September 2001	CD player				Actuation Test		Y		
206	Production date after 13 September 2001	Instrument panel				Read ECU Information		Y		
206	Production date after 13 September 2001	Instrument panel				Read Fault Code		Y		
206	Production date after 13 September 2001	Instrument panel				Erase Fault Code		Y		
206	Production date after 13 September 2001	Instrument panel				Live Data		Y		
206	Production date after 13 September 2001	Instrument panel				Actuation Test		Y		
206	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
206	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
206	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
206	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Live Data		Y		
206	Production date after 13 September 2001	On-board navigation system				Read ECU Information		Y		
206	Production date after 13 September 2001	On-board navigation system				Read Fault Code		Y		
206	Production date after 13 September 2001	On-board navigation system				Erase Fault Code		Y		
206	Production date after 13 September 2001	On-board navigation system				Live Data		Y		
206	Production date after 13 September 2001	Driving school				Read ECU Information		Y		
206	Production date after 13 September 2001	Driving school				Live Data		Y		
206	Production date after 13 September 2001	Driving school				Actuation Test		Y		
206	Production date after 13 September 2001	Rain and brightness sensor				Read ECU Information		Y		
206	Production date after 13 September 2001	Rain and brightness sensor				Read Fault Code		Y		
206	Production date after 13 September 2001	Rain and brightness sensor				Erase Fault Code		Y		
206	Production date after 13 September 2001	Electric retractable roof				Read ECU Information		Y		
206	Production date after 13 September 2001	Electric retractable roof				Read Fault Code		Y		
206	Production date after 13 September 2001	Electric retractable roof				Erase Fault Code		Y		
206	Production date after 13 September 2001	Electric retractable roof				Live Data		Y		
206	Production date after 13 September 2001	Electric retractable roof				Actuation Test		Y		
206	Production date after 13 September 2001	Heating/ventilation				Read ECU Information		Y		
206	Production date after 13 September 2001	Heating/ventilation				Read Fault Code		Y		
206	Production date after 13 September 2001	Heating/ventilation				Erase Fault Code		Y		
206	Production date after 13 September 2001	Heating/ventilation				Live Data		Y		
206	Production date after 13 September 2001	Heating/ventilation				Actuation Test		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Read ECU Information		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Read Fault Code		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Erase Fault Code		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Live Data		Y		
206	Production date after 13 September 2001	Diesel fuel additive control unit				Actuation Test		Y		
206	Production date after 13 September 2001	Electric pump unit(power steering)				Read ECU Information		Y		
206	Production date after 13 September 2001	Electric pump unit(power steering)				Read Fault Code		Y		
206	Production date after 13 September 2001	Electric pump unit(power steering)				Erase Fault Code		Y		
206	Production date after 13 September 2001	Electric pump unit(power steering)				Live Data		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Live Data		Y		
206 MUX	Production date before 13 September 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFR MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Special Function	Ignition advance setting	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFY MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Special Function	Ignition advance setting	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	HFZ MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Special Function	Ignition advance setting	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6C MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX BOSCH MP7.3		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Special Function	Ignition advance setting	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	KFX MM1AP		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Petrol	NFZ BOSCH MP7.2		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	WJZ LUCAS DCN2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206 MUX	Production date before 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Live Data		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Active safety	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Live Data		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Special Function	Configuration	Y		
206 MUX	Production date before 13 September 2001	Active safety	ABS MK70			Special Function	Bleeding	Y		
206 MUX	Production date before 13 September 2001	Airbags	Air bag and seat belt			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Airbags	Air bag and seat belt			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Air bag and seat belt			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(right side)			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(right side)			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(right side)			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(right side)			Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(left side)			Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(left side)			Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(left side)			Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Airbags	Side airbag(left side)			Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Programming of the built-in systems interface (Engine immobiliser code and				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
206 MUX	Production date before 13 September 2001	Multifunction display				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Multifunction display				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Multifunction display				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Multifunction display				Actuation Test		Y		
206 MUX	Production date before 13 September 2001	On-board navigation system				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	On-board navigation system				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	On-board navigation system				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	On-board navigation system				Live Data		Y		
206 MUX	Production date before 13 September 2001	Service module				Special Function		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Live Data		Y		
206 MUX	Production date before 13 September 2001	Electric retractable roof				Actuation Test		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Read ECU Information		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Read Fault Code		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Erase Fault Code		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Live Data		Y		
206 MUX	Production date before 13 September 2001	Heating/ventilation				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Live Data		Y		
206 MUX	Production date after 13 September 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	7LZ MM5NP		Special Function	Programming / Pairing	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW BOSCH ME7.4.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU BOSCH ME745		Special Function	Programming / Pairing	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	N6A BOSCH ME745		Special Function	Programming / Pairing	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	HFX MM4.8P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFU MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFK MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	RFN MM6LP		Special Function	Re-centring of autoadaptive systems	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW J34P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	K6D J34P		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU Or N6A or N6B ME749 BIO FLEX		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	KFW ME749 BIO FLEX		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Petrol	NFU J35		Special Function	Programming / Pairing	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HX/8HZ BOSCH EDC16C3 EURO3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	8HZ BOSCH EDC16C3 EURO4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3 EURO4		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HY BOSCH EDC16C3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HZ BOSCH EDC16C3		Special Function	After sales operation(Particle emission filter and fuel additive adding)	Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HX BOSCH EDC16C3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Live Data		Y		
206 MUX	Production date after 13 September 2001	Engine management ECU	Diesel	9HT BOSCH EDC16C3		Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	BVA_AL4_AT8			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_1			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_2			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Live Data		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Special Function	Accelerator pedal learning	Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Special Function	Initialising the autoadaptives	Y		
206 MUX	Production date after 13 September 2001	Automatic gearbox or controlled manual gearbox	Automatic gearbox AL4_3			Special Function	Oil wear counter	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Live Data		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	Anti-lock brakes TEVES			Special Function	Bleeding	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Live Data		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Special Function	Configuration	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK70			Special Function	Bleeding	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Live Data		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	Steering wheel angle sensor calibration	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	De-calibration of the steering wheel angle sensor	Y		
206 MUX	Production date after 13 September 2001	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK60			Special Function	Bleeding	Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Special Function	Locking	Y		
206 MUX	Production date after 13 September 2001	Air bags and pre-tensioners control unit				Special Function	Unlocking	Y		
206 MUX	Production date after 13 September 2001	Programming of the built-in systems interface (Engine immobiliser code and				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Live Data		Y		
206 MUX	Production date after 13 September 2001	Anti-theft alarm				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Live Data		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	AMF			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Live Data		Y		
206 MUX	Production date after 13 September 2001	Display / Telematics	RT3			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Radio	Radio			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Radio	Radio			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Radio	Radio			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Radio	Radio			Live Data		Y		
206 MUX	Production date after 13 September 2001	Radio	Radio			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Live Data		Y		
206 MUX	Production date after 13 September 2001	Radio	RDE filament			Actuation Test		Y		
206 MUX	Production date after 13 September 2001	CD player				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	CD player				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	CD player				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	CD player				Live Data		Y		
206 MUX	Production date after 13 September 2001	CD player				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Live Data		Y		
206 MUX	Production date after 13 September 2001	Instrument panel				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Switching module below steering wheel (COM 2000)				Live Data		Y		
206 MUX	Production date after 13 September 2001	On-board navigation system				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	On-board navigation system				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	On-board navigation system				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	On-board navigation system				Live Data		Y		
206 MUX	Production date after 13 September 2001	Driving school				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Driving school				Live Data		Y		
206 MUX	Production date after 13 September 2001	Driving school				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Rain and brightness sensor				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Rain and brightness sensor				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Rain and brightness sensor				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Live Data		Y		
206 MUX	Production date after 13 September 2001	Electric retractable roof				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Heating/ventilation				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Heating/ventilation				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Heating/ventilation				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Heating/ventilation				Live Data		Y		
206 MUX	Production date after 13 September 2001	Heating/ventilation				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Live Data		Y		
206 MUX	Production date after 13 September 2001	Diesel fuel additive control unit				Actuation Test		Y		
206 MUX	Production date after 13 September 2001	Electric pump unit(power steering)				Read ECU Information		Y		
206 MUX	Production date after 13 September 2001	Electric pump unit(power steering)				Read Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric pump unit(power steering)				Erase Fault Code		Y		
206 MUX	Production date after 13 September 2001	Electric pump unit(power steering)				Live Data		Y		
206 +		BSI(Built-in Systems Interface)				Read ECU Information		Y		
206 +		BSI(Built-in Systems Interface)				Read Fault Code		Y		
206 +		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
206 +		BSI(Built-in Systems Interface)				Live Data		Y		
206 +		BSI(Built-in Systems Interface)				Actuation Test		Y		
206 +		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
206 +		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
206 +		Engine management ECU	Petrol engine	ME745		Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	ME745		Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	ME745		Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	ME745		Live Data		Y		
206 +		Engine management ECU	Petrol engine	ME745		Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	ME745		Special Function	Initialising the autoadaptives	Y		
206 +		Engine management ECU	Petrol engine	ME745		Special Function	Configuration	Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Live Data		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P KFW	Special Function	Configuration	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Live Data		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Petrol engine	J34P	J34P HFX	Special Function	Configuration	Y		
206 +		Engine management ECU	Petrol engine	ME749		Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	ME749		Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	ME749		Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	ME749		Live Data		Y		
206 +		Engine management ECU	Petrol engine	ME749		Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	ME749		Special Function	Pack Repair	Y		
206 +		Engine management ECU	Petrol engine	ME749		Special Function	Configuration	Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Live Data		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 HFV	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Read ECU Information		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Read Fault Code		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Erase Fault Code		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Live Data		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Actuation Test		Y		
206 +		Engine management ECU	Petrol engine	V343	V343 KFT	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Live Data		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	EDC15C2		Special Function	Configuration	Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Live Data		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 WJY	Special Function	Configuration	Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Live Data		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	DCN2	DCN2 HFX	Special Function	Configuration	Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Live Data		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HX - DV4TD	Special Function	Pairing	Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Live Data		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Special Function	Pack Repair	Y		
206 +		Engine management ECU	Diesel engine	EDC16C3DV4	8HZ - DV4TD	Special Function	Pairing	Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Read ECU Information		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Read Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Erase Fault Code		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Live Data		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Actuation Test		Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Special Function	Configuration	Y		
206 +		Engine management ECU	Diesel engine	EDC17C10_BR2	8HR-DV4CTED-70 CV	Special Function	Pack Repair	Y		
206 +		Gearbox				Read ECU Information		Y		
206 +		Gearbox				Read Fault Code		Y		
206 +		Gearbox				Erase Fault Code		Y		
206 +		Gearbox				Live Data		Y		
206 +		Gearbox				Actuation Test		Y		
206 +		Gearbox				Special Function	Configuration	Y		
206 +		Gearbox				Special Function	Pack Repair	Y		
206 +		ABS/traction control	ABS MK70			Read ECU Information		Y		
206 +		ABS/traction control	ABS MK70			Read Fault Code		Y		
206 +		ABS/traction control	ABS MK70			Erase Fault Code		Y		
206 +		ABS/traction control	ABS MK70			Live Data		Y		
206 +		ABS/traction control	ABS MK70			Actuation Test		Y		
206 +		ABS/traction control	ABS MK70			Special Function	Replacement parts	Y		
206 +		ABS/traction control	ABS MK70			Special Function	Configuration	Y		
206 +		ABS/traction control	ESP MK60			Read ECU Information		Y		
206 +		ABS/traction control	ESP MK60			Read Fault Code		Y		
206 +		ABS/traction control	ESP MK60			Erase Fault Code		Y		
206 +		ABS/traction control	ESP MK60			Live Data		Y		
206 +		ABS/traction control	ESP MK60			Actuation Test		Y		
206 +		ABS/traction control	ESP MK60			Special Function	Replacement parts	Y		
206 +		ABS/traction control	ESP MK60			Special Function	Configuration	Y		
206 +		Driver and passenger airbags				Read ECU Information		Y		
206 +		Driver and passenger airbags				Read Fault Code		Y		
206 +		Driver and passenger airbags				Erase Fault Code		Y		
206 +		Driver and passenger airbags				Special Function	Replacement parts	Y		
206 +		Driver and passenger airbags				Special Function	Configuration	Y		
206 +		Multifunction display	RT3			Read ECU Information		Y		
206 +		Multifunction display	RT3			Read Fault Code		Y		
206 +		Multifunction display	RT3			Erase Fault Code		Y		
206 +		Multifunction display	RT3			Actuation Test		Y		
206 +		Multifunction display	RT3			Special Function	Configuration	Y		
206 +		Multifunction display	AMF			Read ECU Information		Y		
206 +		Multifunction display	AMF			Read Fault Code		Y		
206 +		Multifunction display	AMF			Erase Fault Code		Y		
206 +		Multifunction display	AMF			Live Data		Y		
206 +		Multifunction display	AMF			Actuation Test		Y		
206 +		Multifunction display	AMF			Special Function	Configuration	Y		
206 +		Anti-theft alarm				Read ECU Information		Y		
206 +		Anti-theft alarm				Read Fault Code		Y		
206 +		Anti-theft alarm				Erase Fault Code		Y		
206 +		Anti-theft alarm				Actuation Test		Y		
206 +		Anti-theft alarm				Special Function	Configuration	Y		
206 +		Radio or radiotelephone(radio part)	Radio			Read ECU Information		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Read Fault Code		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Erase Fault Code		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Live Data		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Actuation Test		Y		
206 +		Radio or radiotelephone(radio part)	Radio			Special Function	Configuration	Y		
206 +		Radio or radiotelephone(radio part)	RDE			Read ECU Information		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Read Fault Code		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Erase Fault Code		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Live Data		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Actuation Test		Y		
206 +		Radio or radiotelephone(radio part)	RDE			Special Function	Configuration	Y		
206 +		Radio or radiotelephone(radio part)	RDE			Special Function	Spare part	Y		
206 +		CD player				Read ECU Information		Y		
206 +		CD player				Read Fault Code		Y		
206 +		CD player				Erase Fault Code		Y		
206 +		CD player				Live Data		Y		
206 +		CD player				Actuation Test		Y		
206 +		CD player				Special Function	Configuration	Y		
206 +		Heating/ventilation				Read ECU Information		Y		
206 +		Heating/ventilation				Read Fault Code		Y		
206 +		Heating/ventilation				Erase Fault Code		Y		
206 +		Heating/ventilation				Live Data		Y		
206 +		Heating/ventilation				Special Function	Configuration	Y		
206 +		Instrument panel				Read ECU Information		Y		
206 +		Instrument panel				Read Fault Code		Y		
206 +		Instrument panel				Erase Fault Code		Y		
206 +		Instrument panel				Live Data		Y		
206 +		Instrument panel				Actuation Test		Y		
206 +		Instrument panel				Special Function	Configuration	Y		
206 +		Rain and brightness sensor				Read ECU Information		Y		
206 +		Rain and brightness sensor				Read Fault Code		Y		
206 +		Rain and brightness sensor				Erase Fault Code		Y		
206 +		Switch module at the steering wheel				Read ECU Information		Y		
206 +		Switch module at the steering wheel				Read Fault Code		Y		
206 +		Switch module at the steering wheel				Erase Fault Code		Y		
206 +		Switch module at the steering wheel				Live Data		Y		
206 +		Power steering electric pump unit				Read ECU Information		Y		
206 +		Power steering electric pump unit				Read Fault Code		Y		
206 +		Power steering electric pump unit				Erase Fault Code		Y		
206 +		Power steering electric pump unit				Live Data		Y		
206 +		Services module				Read ECU Information		Y		
206 +		Services module				Read Fault Code		Y		
206 +		Services module				Erase Fault Code		Y		
206 +		Services module				Live Data		Y		
206 +		Services module				Actuation Test		Y		
206 +		Services module				Special Function	Configuration	Y		
207 VAN		Engine ECU	EDC15C2			Read ECU Information		Y		
207 VAN		Engine ECU	EDC15C2			Read Fault Code		Y		
207 VAN		Engine ECU	EDC15C2			Erase Fault Code		Y		
207 VAN		Engine ECU	EDC15C2			Live Data		Y		
207 VAN		Engine ECU	EDC15C2			Actuation Test		Y		
207 VAN		Engine ECU	EDC15C2			Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME745			Read ECU Information		Y		
207 VAN		Engine ECU	ME745			Read Fault Code		Y		
207 VAN		Engine ECU	ME745			Erase Fault Code		Y		
207 VAN		Engine ECU	ME745			Live Data		Y		
207 VAN		Engine ECU	ME745			Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
207 VAN		Engine ECU	ME745			Special Function	Initialising the autoadaptives	Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Read ECU Information		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Read Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Erase Fault Code		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Live Data		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Actuation Test		Y		
207 VAN		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
207 VAN		Engine ECU	J34P	J34P KFW		Read ECU Information		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Read Fault Code		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Erase Fault Code		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Live Data		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Actuation Test		Y		
207 VAN		Engine ECU	J34P	J34P KFW		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	J34P	J34P HFX		Read ECU Information		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Read Fault Code		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Erase Fault Code		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Live Data		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Actuation Test		Y		
207 VAN		Engine ECU	J34P	J34P HFX		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Read ECU Information		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Read Fault Code		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Erase Fault Code		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Live Data		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Actuation Test		Y		
207 VAN		Engine ECU	DCN2	DCN2 WJY		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Read ECU Information		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Read Fault Code		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Erase Fault Code		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Live Data		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Actuation Test		Y		
207 VAN		Engine ECU	DCN2	DCN2 HFX		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Read ECU Information		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Read Fault Code		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Erase Fault Code		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Live Data		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Actuation Test		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	EDC16C3DV4	8HX - DV4TD		Special Function	Pairing	Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Read ECU Information		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Read Fault Code		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Erase Fault Code		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Live Data		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Actuation Test		Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Special Function	Pairing	Y		
207 VAN		Engine ECU	V343	V343 HFV		Read ECU Information		Y		
207 VAN		Engine ECU	V343	V343 HFV		Read Fault Code		Y		
207 VAN		Engine ECU	V343	V343 HFV		Erase Fault Code		Y		
207 VAN		Engine ECU	V343	V343 HFV		Live Data		Y		
207 VAN		Engine ECU	V343	V343 HFV		Actuation Test		Y		
207 VAN		Engine ECU	V343	V343 HFV		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	V343	V343 KFT		Read ECU Information		Y		
207 VAN		Engine ECU	V343	V343 KFT		Read Fault Code		Y		
207 VAN		Engine ECU	V343	V343 KFT		Erase Fault Code		Y		
207 VAN		Engine ECU	V343	V343 KFT		Live Data		Y		
207 VAN		Engine ECU	V343	V343 KFT		Actuation Test		Y		
207 VAN		Engine ECU	V343	V343 KFT		Special Function	Pack Repair	Y		
207 VAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
207 VAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
207 VAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
207 VAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Live Data		Y		
207 VAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
207 VAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
207 VAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
207 VAN		Gearbox				Read ECU Information		Y		
207 VAN		Gearbox				Read Fault Code		Y		
207 VAN		Gearbox				Erase Fault Code		Y		
207 VAN		Gearbox				Live Data		Y		
207 VAN		Gearbox				Actuation Test		Y		
207 VAN		Gearbox				Special Function	Configuration	Y		
207 VAN		Gearbox				Special Function	Pack Repair	Y		
207 VAN		ABS/traction control	ABS MK70			Read ECU Information		Y		
207 VAN		ABS/traction control	ABS MK70			Read Fault Code		Y		
207 VAN		ABS/traction control	ABS MK70			Erase Fault Code		Y		
207 VAN		ABS/traction control	ABS MK70			Live Data		Y		
207 VAN		ABS/traction control	ABS MK70			Actuation Test		Y		
207 VAN		ABS/traction control	ABS MK70			Special Function	Replacement parts	Y		
207 VAN		ABS/traction control	ESP MK60			Read ECU Information		Y		
207 VAN		ABS/traction control	ESP MK60			Read Fault Code		Y		
207 VAN		ABS/traction control	ESP MK60			Erase Fault Code		Y		
207 VAN		ABS/traction control	ESP MK60			Live Data		Y		
207 VAN		ABS/traction control	ESP MK60			Actuation Test		Y		
207 VAN		ABS/traction control	ESP MK60			Special Function	Replacement parts	Y		
207 VAN		Driver and passenger airbags				Read ECU Information		Y		
207 VAN		Driver and passenger airbags				Read Fault Code		Y		
207 VAN		Driver and passenger airbags				Erase Fault Code		Y		
207 VAN		Driver and passenger airbags				Special Function	Replacement parts	Y		
207 VAN		Multifunction display	RT3			Read ECU Information		Y		
207 VAN		Multifunction display	RT3			Read Fault Code		Y		
207 VAN		Multifunction display	RT3			Erase Fault Code		Y		
207 VAN		Multifunction display	RT3			Actuation Test		Y		
207 VAN		Multifunction display	AMF			Read ECU Information		Y		
207 VAN		Multifunction display	AMF			Read Fault Code		Y		
207 VAN		Multifunction display	AMF			Erase Fault Code		Y		
207 VAN		Multifunction display	AMF			Live Data		Y		
207 VAN		Multifunction display	AMF			Actuation Test		Y		
207 VAN		Anti-theft alarm				Read ECU Information		Y		
207 VAN		Anti-theft alarm				Read Fault Code		Y		
207 VAN		Anti-theft alarm				Erase Fault Code		Y		
207 VAN		Anti-theft alarm				Actuation Test		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Read ECU Information		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Read Fault Code		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Erase Fault Code		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Live Data		Y		
207 VAN		Radio or radiotelephone(radio part)	Radio			Actuation Test		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Read ECU Information		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Read Fault Code		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Erase Fault Code		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Live Data		Y		
207 VAN		Radio or radiotelephone(radio part)	RDE			Actuation Test		Y		
207 VAN		Built-in Systems Interface (BSI)				Read ECU Information		Y		
207 VAN		Built-in Systems Interface (BSI)				Read Fault Code		Y		
207 VAN		Built-in Systems Interface (BSI)				Erase Fault Code		Y		
207 VAN		Built-in Systems Interface (BSI)				Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
207 VAN		Built-in Systems Interface (BSI)				Actuation Test		Y		
207 VAN		CD player				Read ECU Information		Y		
207 VAN		CD player				Read Fault Code		Y		
207 VAN		CD player				Erase Fault Code		Y		
207 VAN		CD player				Live Data		Y		
207 VAN		CD player				Actuation Test		Y		
207 VAN		Heating/ventilation				Read ECU Information		Y		
207 VAN		Heating/ventilation				Read Fault Code		Y		
207 VAN		Heating/ventilation				Erase Fault Code		Y		
207 VAN		Heating/ventilation				Live Data		Y		
207 VAN		Instrument panel				Read ECU Information		Y		
207 VAN		Instrument panel				Read Fault Code		Y		
207 VAN		Instrument panel				Erase Fault Code		Y		
207 VAN		Instrument panel				Live Data		Y		
207 VAN		Instrument panel				Actuation Test		Y		
207 VAN		Rain and brightness sensor				Read ECU Information		Y		
207 VAN		Rain and brightness sensor				Read Fault Code		Y		
207 VAN		Rain and brightness sensor				Erase Fault Code		Y		
207 VAN		Switch module at the steering wheel				Read ECU Information		Y		
207 VAN		Switch module at the steering wheel				Read Fault Code		Y		
207 VAN		Switch module at the steering wheel				Erase Fault Code		Y		
207 VAN		Switch module at the steering wheel				Live Data		Y		
207 VAN		Power steering electric pump unit				Read ECU Information		Y		
207 VAN		Power steering electric pump unit				Read Fault Code		Y		
207 VAN		Power steering electric pump unit				Erase Fault Code		Y		
207 VAN		Power steering electric pump unit				Live Data		Y		
207 VAN		Services module				Read ECU Information		Y		
207 VAN		Services module				Read Fault Code		Y		
207 VAN		Services module				Erase Fault Code		Y		
207 VAN		Services module				Live Data		Y		
207 VAN		Services module				Actuation Test		Y		
207 CAN		BSI (Built-in Systems Interface)				Read ECU Information		Y		
207 CAN		BSI (Built-in Systems Interface)				Read Fault Code		Y		
207 CAN		BSI (Built-in Systems Interface)				Erase Fault Code		Y		
207 CAN		BSI (Built-in Systems Interface)				Live Data		Y		
207 CAN		BSI (Built-in Systems Interface)				Actuation Test		Y		
207 CAN		BSI (Built-in Systems Interface)				Special Function	Changing the mode Electrical	Y		
207 CAN		BSI (Built-in Systems Interface)				Special Function	Learning	Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Live Data		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Live Data		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Live Data		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Live Data		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Live Data		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Live Data		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Live Data		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Live Data		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Pairing	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Read ECU Information		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Read Fault Code		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Erase Fault Code		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Live Data		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Actuation Test		Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Pairing	Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Read ECU Information		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Read Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Erase Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Live Data		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Actuation Test		Y		
207 CAN		Engine ECU	ME745	ME745 N6B		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Read ECU Information		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Read Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Erase Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Live Data		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Actuation Test		Y		
207 CAN		Engine ECU	ME745	ME745 N6A		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Read ECU Information		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Read Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Erase Fault Code		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Live Data		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Actuation Test		Y		
207 CAN		Engine ECU	ME745	ME745 NFU		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Read ECU Information		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Read Fault Code		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Erase Fault Code		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Live Data		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Actuation Test		Y		
207 CAN		Engine ECU	MM6LPC	KFU MM6LPC		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Read ECU Information		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Read Fault Code		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Erase Fault Code		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Live Data		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Actuation Test		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Special Function	Configuration	Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Read ECU Information		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Read Fault Code		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Erase Fault Code		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Live Data		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Actuation Test		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Special Function	Configuration	Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Read ECU Information		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Read Fault Code		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Erase Fault Code		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Live Data		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Actuation Test		Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Special Function	Configuration	Y		
207 CAN		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Live Data		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Live Data		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	J34P	J34P KFW		Read ECU Information		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Read Fault Code		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Erase Fault Code		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Live Data		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Actuation Test		Y		
207 CAN		Engine ECU	J34P	J34P KFW		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	J34P	J34P KFV		Read ECU Information		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Read Fault Code		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Erase Fault Code		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Live Data		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Actuation Test		Y		
207 CAN		Engine ECU	J34P	J34P KFV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Live Data		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Live Data		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Read ECU Information		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Read Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Erase Fault Code		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Live Data		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Actuation Test		Y		
207 CAN		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HR		Read ECU Information		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HR		Read Fault Code		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HR		Erase Fault Code		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HR		Live Data		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HR		Actuation Test		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HR		Special Function	Configuration	Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HL		Read ECU Information		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HL		Read Fault Code		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HL		Erase Fault Code		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HL		Live Data		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HL		Actuation Test		Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HL		Special Function	Configuration	Y		
207 CAN		Engine ECU	HDI_SID807	HDI_SID807 9HL		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	V341			Read ECU Information		Y		
207 CAN		Engine ECU	V341			Read Fault Code		Y		
207 CAN		Engine ECU	V341			Erase Fault Code		Y		
207 CAN		Engine ECU	V341			Live Data		Y		
207 CAN		Engine ECU	V341			Actuation Test		Y		
207 CAN		Engine ECU	V341			Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Read ECU Information		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Read Fault Code		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Live Data		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Actuation Test		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 9HP		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Read ECU Information		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Read Fault Code		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Live Data		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Actuation Test		Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC17C10	EDC17C10 8HR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read ECU Information		Y		
207 CAN		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read Fault Code		Y		
207 CAN		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Erase Fault Code		Y		
207 CAN		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Live Data		Y		
207 CAN		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Actuation Test		Y		
207 CAN		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Configuration	Y		
207 CAN		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Live Data		Y		
207 CAN		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Special Function	Pack Repair	Y		
207 CAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
207 CAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
207 CAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
207 CAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Live Data		Y		
207 CAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
207 CAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
207 CAN		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
207 CAN		Gearbox	BVA_AL4			Read ECU Information		Y		
207 CAN		Gearbox	BVA_AL4			Read Fault Code		Y		
207 CAN		Gearbox	BVA_AL4			Erase Fault Code		Y		
207 CAN		Gearbox	BVA_AL4			Live Data		Y		
207 CAN		Gearbox	BVA_AL4			Actuation Test		Y		
207 CAN		Gearbox	BVA_AL4			Special Function	Configuration	Y		
207 CAN		Gearbox	BVA_AL4			Special Function	Pack Repair	Y		
207 CAN		Gearbox	BVMP_MA			Read ECU Information		Y		
207 CAN		Gearbox	BVMP_MA			Read Fault Code		Y		
207 CAN		Gearbox	BVMP_MA			Erase Fault Code		Y		
207 CAN		Gearbox	BVMP_MA			Live Data		Y		
207 CAN		Gearbox	BVMP_MA			Actuation Test		Y		
207 CAN		Gearbox	BVMP_MA			Special Function	Counters	Y		
207 CAN		Gearbox	BVMP_MA			Special Function	Pack Repair	Y		
207 CAN		ABS/traction control	ABS MK70_1			Read ECU Information		Y		
207 CAN		ABS/traction control	ABS MK70_1			Read Fault Code		Y		
207 CAN		ABS/traction control	ABS MK70_1			Erase Fault Code		Y		
207 CAN		ABS/traction control	ABS MK70_1			Live Data		Y		
207 CAN		ABS/traction control	ABS MK70_1			Actuation Test		Y		
207 CAN		ABS/traction control	ABS MK70_1			Special Function	Replacement parts	Y		
207 CAN		ABS/traction control	ESP MK60_0			Read ECU Information		Y		
207 CAN		ABS/traction control	ESP MK60_0			Read Fault Code		Y		
207 CAN		ABS/traction control	ESP MK60_0			Erase Fault Code		Y		
207 CAN		ABS/traction control	ESP MK60_0			Live Data		Y		
207 CAN		ABS/traction control	ESP MK60_0			Actuation Test		Y		
207 CAN		ABS/traction control	ESP MK60_0			Special Function	Pack Repair	Y		
207 CAN		Driver and passenger airbags				Read ECU Information		Y		
207 CAN		Driver and passenger airbags				Read Fault Code		Y		
207 CAN		Driver and passenger airbags				Erase Fault Code		Y		
207 CAN		Driver and passenger airbags				Live Data		Y		
207 CAN		Driver and passenger airbags				Special Function	Pack Repair	Y		
207 CAN		Electric power steering				Read ECU Information		Y		
207 CAN		Electric power steering				Read Fault Code		Y		
207 CAN		Electric power steering				Erase Fault Code		Y		
207 CAN		Electric power steering				Live Data		Y		
207 CAN		Diesel additive				Read ECU Information		Y		
207 CAN		Diesel additive				Read Fault Code		Y		
207 CAN		Diesel additive				Erase Fault Code		Y		
207 CAN		Diesel additive				Live Data		Y		
207 CAN		Diesel additive				Actuation Test		Y		
207 CAN		Under inflation detection				Read ECU Information		Y		
207 CAN		Under inflation detection				Read Fault Code		Y		
207 CAN		Under inflation detection				Erase Fault Code		Y		
207 CAN		Under inflation detection				Live Data		Y		
207 CAN		Battery charge status unit	BECB			Read ECU Information		Y		
207 CAN		Battery charge status unit	BECB			Read Fault Code		Y		
207 CAN		Battery charge status unit	BECB			Erase Fault Code		Y		
207 CAN		Battery charge status unit	BECB			Live Data		Y		
207 CAN		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
207 CAN		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
207 CAN		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
207 CAN		Battery charge status unit	BECB_GEN2			Live Data		Y		
207 CAN		Headlamp height adjuster/directional				Read ECU Information		Y		
207 CAN		Headlamp height adjuster/directional				Read Fault Code		Y		
207 CAN		Headlamp height adjuster/directional				Erase Fault Code		Y		
207 CAN		Headlamp height adjuster/directional				Live Data		Y		
207 CAN		Headlamp height adjuster/directional				Actuation Test		Y		
207 CAN		Engine relay unit				Read ECU Information		Y		
207 CAN		Engine relay unit				Actuation Test		Y		
207 CAN		Trailer relay unit				Read ECU Information		Y		
207 CAN		Trailer relay unit				Read Fault Code		Y		
207 CAN		Trailer relay unit				Erase Fault Code		Y		
207 CAN		Heating/ventilation				Read ECU Information		Y		
207 CAN		Heating/ventilation				Read Fault Code		Y		
207 CAN		Heating/ventilation				Erase Fault Code		Y		
207 CAN		Heating/ventilation				Live Data		Y		
207 CAN		Heating/ventilation				Actuation Test		Y		
207 CAN		Switch module under the steering wheel				Read ECU Information		Y		
207 CAN		Switch module under the steering wheel				Read Fault Code		Y		
207 CAN		Switch module under the steering wheel				Erase Fault Code		Y		
207 CAN		Switch module under the steering wheel				Live Data		Y		
207 CAN		Switch module under the steering wheel				Actuation Test		Y		
207 CAN		Instrument panel				Read ECU Information		Y		
207 CAN		Instrument panel				Read Fault Code		Y		
207 CAN		Instrument panel				Erase Fault Code		Y		
207 CAN		Instrument panel				Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
207 CAN		Instrument panel				Actuation Test		Y		
207 CAN		Multifunction display	Type "A" (segments) with buttons			Read ECU Information		Y		
207 CAN		Multifunction display	Type "A" (segments) with buttons			Read Fault Code		Y		
207 CAN		Multifunction display	Type "A" (segments) with buttons			Erase Fault Code		Y		
207 CAN		Multifunction display	Type "A" (segments) with buttons			Live Data		Y		
207 CAN		Multifunction display	Type "A" (segments) with buttons			Actuation Test		Y		
207 CAN		Multifunction display	Type "A" (segments) without buttons			Read ECU Information		Y		
207 CAN		Multifunction display	Type "A" (segments) without buttons			Read Fault Code		Y		
207 CAN		Multifunction display	Type "A" (segments) without buttons			Erase Fault Code		Y		
207 CAN		Multifunction display	Type "A" (segments) without buttons			Live Data		Y		
207 CAN		Multifunction display	Type "A" (segments) without buttons			Actuation Test		Y		
207 CAN		Multifunction display	Type "C" (dot matrix)			Read ECU Information		Y		
207 CAN		Multifunction display	Type "C" (dot matrix)			Read Fault Code		Y		
207 CAN		Multifunction display	Type "C" (dot matrix)			Erase Fault Code		Y		
207 CAN		Multifunction display	Type "C" (dot matrix)			Live Data		Y		
207 CAN		Multifunction display	Type "C" (dot matrix)			Actuation Test		Y		
207 CAN		Multifunction display	Type "C colour" (dot matrix)			Read ECU Information		Y		
207 CAN		Multifunction display	Type "C colour" (dot matrix)			Read Fault Code		Y		
207 CAN		Multifunction display	Type "C colour" (dot matrix)			Erase Fault Code		Y		
207 CAN		Multifunction display	Type "C colour" (dot matrix)			Live Data		Y		
207 CAN		Multifunction display	Type "C colour" (dot matrix)			Actuation Test		Y		
207 CAN		Parking aid				Read ECU Information		Y		
207 CAN		Parking aid				Read Fault Code		Y		
207 CAN		Parking aid				Erase Fault Code		Y		
207 CAN		Parking aid				Live Data		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Read ECU Information		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Read Fault Code		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Erase Fault Code		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Live Data		Y		
207 CAN		Radio or radiotelephone (radio part)	RD4			Actuation Test		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Read ECU Information		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Read Fault Code		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Erase Fault Code		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Live Data		Y		
207 CAN		Radio or radiotelephone (radio part)	RD45			Actuation Test		Y		
207 CAN		Telematics	RADIONAB_RNEG			Read ECU Information		Y		
207 CAN		Telematics	RADIONAB_RNEG			Read Fault Code		Y		
207 CAN		Telematics	RADIONAB_RNEG			Erase Fault Code		Y		
207 CAN		Telematics	RADIONAB_RNEG			Live Data		Y		
207 CAN		Telematics	RADIONAB_RNEG			Actuation Test		Y		
207 CAN		Telematics	BOITIER_TELEMATIQUE			Read ECU Information		Y		
207 CAN		Telematics	BOITIER_TELEMATIQUE			Read Fault Code		Y		
207 CAN		Telematics	BOITIER_TELEMATIQUE			Erase Fault Code		Y		
207 CAN		Telematics	BOITIER_TELEMATIQUE			Live Data		Y		
207 CAN		Telematics	BOITIER_TELEMATIQUE			Actuation Test		Y		
207 CAN		CD player				Read ECU Information		Y		
207 CAN		CD player				Read Fault Code		Y		
207 CAN		CD player				Erase Fault Code		Y		
207 CAN		CD player				Actuation Test		Y		
207 CAN		Hands-free kit (Telephone)	KML			Read ECU Information		Y		
207 CAN		Hands-free kit (Telephone)	KML			Read Fault Code		Y		
207 CAN		Hands-free kit (Telephone)	KML			Erase Fault Code		Y		
207 CAN		Hands-free kit (Telephone)	KML			Live Data		Y		
207 CAN		Hands-free kit (Telephone)	KML			Actuation Test		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER_NOMADE			Read ECU Information		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER_NOMADE			Read Fault Code		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER_NOMADE			Erase Fault Code		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER_NOMADE			Live Data		Y		
207 CAN		Hands-free kit (Telephone)	BOITIER_NOMADE			Actuation Test		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Read ECU Information		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Read Fault Code		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Erase Fault Code		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Live Data		Y		
207 CAN		Anti-theft alarm	Alarm without anti-lift module			Actuation Test		Y		
207 CAN		Folding roof				Read ECU Information		Y		
207 CAN		Folding roof				Read Fault Code		Y		
207 CAN		Folding roof				Erase Fault Code		Y		
207 CAN		Folding roof				Live Data		Y		
207 CAN		Folding roof				Actuation Test		Y		
207 CAN		Driving school module				Read ECU Information		Y		
207 CAN		Driving school module				Actuation Test		Y		
207 CAN		High frequency receiver				Read ECU Information		Y		
207 CAN		High frequency receiver				Read Fault Code		Y		
207 CAN		High frequency receiver				Erase Fault Code		Y		
207 CAN		High frequency receiver				Live Data		Y		
207 CAN		Seat belts not fastened LED unit				Read ECU Information		Y		
207 CAN		Seat belts not fastened LED unit				Actuation Test		Y		
207 CAN		Service module				Read ECU Information		Y		
207 CAN		Service module				Read Fault Code		Y		
207 CAN		Service module				Erase Fault Code		Y		
207 CAN		Service module				Live Data		Y		
207 CAN		Service module				Actuation Test		Y		
207 CAN		Rain and brightness sensor				Read ECU Information		Y		
207 CAN		Rain and brightness sensor				Read Fault Code		Y		
207 CAN		Rain and brightness sensor				Erase Fault Code		Y		
207i		BSI(Built-in Systems Interface)				Read ECU Information		Y		
207i		BSI(Built-in Systems Interface)				Read Fault Code		Y		
207i		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
207i		BSI(Built-in Systems Interface)				Live Data		Y		
207i		BSI(Built-in Systems Interface)				Actuation Test		Y		
207i		AL4 AT8 automatic gearbox				Read ECU Information		Y		
207i		AL4 AT8 automatic gearbox				Read Fault Code		Y		
207i		AL4 AT8 automatic gearbox				Erase Fault Code		Y		
207i		AL4 AT8 automatic gearbox				Live Data		Y		
207i		AL4 AT8 automatic gearbox				Actuation Test		Y		
207i		AL4 AT8 automatic gearbox				Special Function	Configuration	Y		
207i		AL4 AT8 automatic gearbox				Special Function	Pack Repair	Y		
207i		ABS or ESP ECU	ABS MK70			Read ECU Information		Y		
207i		ABS or ESP ECU	ABS MK70			Read Fault Code		Y		
207i		ABS or ESP ECU	ABS MK70			Erase Fault Code		Y		
207i		ABS or ESP ECU	ABS MK70			Live Data		Y		
207i		ABS or ESP ECU	ABS MK70			Actuation Test		Y		
207i		ABS or ESP ECU	ABS MK70			Special Function	Replacement parts	Y		
207i		ABS or ESP ECU	ESP MK60			Read ECU Information		Y		
207i		ABS or ESP ECU	ESP MK60			Read Fault Code		Y		
207i		ABS or ESP ECU	ESP MK60			Erase Fault Code		Y		
207i		ABS or ESP ECU	ESP MK60			Live Data		Y		
207i		ABS or ESP ECU	ESP MK60			Actuation Test		Y		
207i		ABS or ESP ECU	ESP MK60			Special Function	Replacement parts	Y		
207i		Air-bag				Read ECU Information		Y		
207i		Air-bag				Read Fault Code		Y		
207i		Air-bag				Erase Fault Code		Y		
207i		Air-bag				Special Function	Replacement parts	Y		
207i		Heating/ventilation				Read ECU Information		Y		
207i		Heating/ventilation				Read Fault Code		Y		
207i		Heating/ventilation				Erase Fault Code		Y		
207i		Heating/ventilation				Live Data		Y		
207i		Alarm				Read ECU Information		Y		
207i		Alarm				Read Fault Code		Y		
207i		Alarm				Erase Fault Code		Y		
207i		Alarm				Actuation Test		Y		
207i		Rain/sunlight sensor				Read ECU Information		Y		
207i		Rain/sunlight sensor				Read Fault Code		Y		
207i		Rain/sunlight sensor				Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Live Data		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Live Data		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Actuation Test		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Live Data		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
207 +		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CM	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Read ECU Information		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Read Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Live Data		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Actuation Test		Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3	9HX-DV6TED4-90CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Read ECU Information		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Read Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Live Data		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Actuation Test		Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3	9HV-DV6TED4B FAP-90CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read ECU Information		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Live Data		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Actuation Test		Y		
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Configuration	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
207 +		Engine ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Read ECU Information		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Read Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Live Data		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Actuation Test		Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3	9HY-DV6ATED4-110CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Read ECU Information		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Read Fault Code		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Live Data		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Actuation Test		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Less than Z56C	Special Function	Pairing	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Read ECU Information		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Read Fault Code		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Erase Fault Code		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Live Data		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Actuation Test		Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Configuration	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC16C3DV4	8HZ-DV4TD	EDC16C34 EURO 4 SOFT Greater than equal Z56C	Special Function	Pairing	Y		
207 +		Engine ECU	ME745	ME745 N6B		Read ECU Information		Y		
207 +		Engine ECU	ME745	ME745 N6B		Read Fault Code		Y		
207 +		Engine ECU	ME745	ME745 N6B		Erase Fault Code		Y		
207 +		Engine ECU	ME745	ME745 N6B		Live Data		Y		
207 +		Engine ECU	ME745	ME745 N6B		Actuation Test		Y		
207 +		Engine ECU	ME745	ME745 N6B		Special Function	Pack Repair	Y		
207 +		Engine ECU	ME745	ME745 N6A		Read ECU Information		Y		
207 +		Engine ECU	ME745	ME745 N6A		Read Fault Code		Y		
207 +		Engine ECU	ME745	ME745 N6A		Erase Fault Code		Y		
207 +		Engine ECU	ME745	ME745 N6A		Live Data		Y		
207 +		Engine ECU	ME745	ME745 N6A		Actuation Test		Y		
207 +		Engine ECU	ME745	ME745 N6A		Special Function	Pack Repair	Y		
207 +		Engine ECU	ME745	ME745 NFU		Read ECU Information		Y		
207 +		Engine ECU	ME745	ME745 NFU		Read Fault Code		Y		
207 +		Engine ECU	ME745	ME745 NFU		Erase Fault Code		Y		
207 +		Engine ECU	ME745	ME745 NFU		Live Data		Y		
207 +		Engine ECU	ME745	ME745 NFU		Actuation Test		Y		
207 +		Engine ECU	ME745	ME745 NFU		Special Function	Pack Repair	Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Read ECU Information		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Read Fault Code		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Erase Fault Code		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Live Data		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Actuation Test		Y		
207 +		Engine ECU	MM6LPC	KFU MM6LPC		Special Function	Pack Repair	Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Read ECU Information		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Read Fault Code		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Erase Fault Code		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Live Data		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Actuation Test		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Special Function	Configuration	Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Special Function	Pack Repair	Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Read ECU Information		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Read Fault Code		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Erase Fault Code		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Live Data		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Actuation Test		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Special Function	Configuration	Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4 5FY		Special Function	Pack Repair	Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Read ECU Information		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Read Fault Code		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Erase Fault Code		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Live Data		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Actuation Test		Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Special Function	Configuration	Y		
207 +		Engine ECU	MED17_4_EURO4	MED17_4_EURO4+ 5FR		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Live Data		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Actuation Test		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Live Data		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Actuation Test		Y		
207 +		Engine ECU	MEV17_4_EURO4	MEV17_4_EURO4 8FS		Special Function	Pack Repair	Y		
207 +		Engine ECU	J34P	J34P KFW		Read ECU Information		Y		
207 +		Engine ECU	J34P	J34P KFW		Read Fault Code		Y		
207 +		Engine ECU	J34P	J34P KFW		Erase Fault Code		Y		
207 +		Engine ECU	J34P	J34P KFW		Live Data		Y		
207 +		Engine ECU	J34P	J34P KFW		Actuation Test		Y		
207 +		Engine ECU	J34P	J34P KFW		Special Function	Pack Repair	Y		
207 +		Engine ECU	J34P	J34P KFV		Read ECU Information		Y		
207 +		Engine ECU	J34P	J34P KFV		Read Fault Code		Y		
207 +		Engine ECU	J34P	J34P KFV		Erase Fault Code		Y		
207 +		Engine ECU	J34P	J34P KFV		Live Data		Y		
207 +		Engine ECU	J34P	J34P KFV		Actuation Test		Y		
207 +		Engine ECU	J34P	J34P KFV		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Live Data		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Actuation Test		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Live Data		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Actuation Test		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FR		Special Function	Pack Repair	Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Read ECU Information		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Read Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Erase Fault Code		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Live Data		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Actuation Test		Y		
207 +		Engine ECU	MEV17_4_EURO5	MEV17_4_EURO5 8FP		Special Function	Pack Repair	Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HR		Read ECU Information		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HR		Read Fault Code		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HR		Erase Fault Code		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HR		Live Data		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HR		Actuation Test		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HR		Special Function	Configuration	Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HR		Special Function	Pack Repair	Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HL		Read ECU Information		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HL		Read Fault Code		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HL		Erase Fault Code		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HL		Live Data		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HL		Actuation Test		Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HL		Special Function	Configuration	Y		
207 +		Engine ECU	HDI_SID807	HDI_SID807 9HL		Special Function	Pack Repair	Y		
207 +		Engine ECU	V341			Read ECU Information		Y		
207 +		Engine ECU	V341			Read Fault Code		Y		
207 +		Engine ECU	V341			Erase Fault Code		Y		
207 +		Engine ECU	V341			Live Data		Y		
207 +		Engine ECU	V341			Actuation Test		Y		
207 +		Engine ECU	V341			Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Read ECU Information		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Read Fault Code		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Erase Fault Code		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Live Data		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Actuation Test		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Special Function	Configuration	Y		
207 +		Engine ECU	EDC17C10	EDC17C10 9HP		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Read ECU Information		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Read Fault Code		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Erase Fault Code		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Live Data		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Actuation Test		Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Special Function	Configuration	Y		
207 +		Engine ECU	EDC17C10	EDC17C10 8HR		Special Function	Pack Repair	Y		
207 +		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read ECU Information		Y		
207 +		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read Fault Code		Y		
207 +		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Erase Fault Code		Y		
207 +		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Live Data		Y		
207 +		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Actuation Test		Y		
207 +		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Configuration	Y		
207 +		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Read ECU Information		Y		
207 +		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Read Fault Code		Y		
207 +		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
207 +		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Actuation Test		Y		
207 +		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Special Function	Pack Repair	Y		
207 +		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
207 +		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
207 +		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
207 +		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Live Data		Y		
207 +		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
207 +		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
207 +		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
207 +		Gearbox	BVA_AL4			Read ECU Information		Y		
207 +		Gearbox	BVA_AL4			Read Fault Code		Y		
207 +		Gearbox	BVA_AL4			Erase Fault Code		Y		
207 +		Gearbox	BVA_AL4			Live Data		Y		
207 +		Gearbox	BVA_AL4			Actuation Test		Y		
207 +		Gearbox	BVA_AL4			Special Function	Configuration	Y		
207 +		Gearbox	BVA_AL4			Special Function	Pack Repair	Y		
207 +		Gearbox	BVMP_MA			Read ECU Information		Y		
207 +		Gearbox	BVMP_MA			Read Fault Code		Y		
207 +		Gearbox	BVMP_MA			Erase Fault Code		Y		
207 +		Gearbox	BVMP_MA			Live Data		Y		
207 +		Gearbox	BVMP_MA			Actuation Test		Y		
207 +		Gearbox	BVMP_MA			Special Function	Counters	Y		
207 +		Gearbox	BVMP_MA			Special Function	Pack Repair	Y		
207 +		ABS/traction control	ABS_MK70_1			Read ECU Information		Y		
207 +		ABS/traction control	ABS_MK70_1			Read Fault Code		Y		
207 +		ABS/traction control	ABS_MK70_1			Erase Fault Code		Y		
207 +		ABS/traction control	ABS_MK70_1			Live Data		Y		
207 +		ABS/traction control	ABS_MK70_1			Actuation Test		Y		
207 +		ABS/traction control	ABS_MK70_1			Special Function	Replacement parts	Y		
207 +		ABS/traction control	ESP_MK60_0			Read ECU Information		Y		
207 +		ABS/traction control	ESP_MK60_0			Read Fault Code		Y		
207 +		ABS/traction control	ESP_MK60_0			Erase Fault Code		Y		
207 +		ABS/traction control	ESP_MK60_0			Live Data		Y		
207 +		ABS/traction control	ESP_MK60_0			Actuation Test		Y		
207 +		ABS/traction control	ESP_MK60_0			Special Function	Pack Repair	Y		
207 +		Driver and passenger airbags				Read ECU Information		Y		
207 +		Driver and passenger airbags				Read Fault Code		Y		
207 +		Driver and passenger airbags				Erase Fault Code		Y		
207 +		Driver and passenger airbags				Live Data		Y		
207 +		Driver and passenger airbags				Special Function	Pack Repair	Y		
207 +		Electric power steering				Read ECU Information		Y		
207 +		Electric power steering				Read Fault Code		Y		
207 +		Electric power steering				Erase Fault Code		Y		
207 +		Electric power steering				Live Data		Y		
207 +		Diesel additive				Read ECU Information		Y		
207 +		Diesel additive				Read Fault Code		Y		
207 +		Diesel additive				Erase Fault Code		Y		
207 +		Diesel additive				Live Data		Y		
207 +		Diesel additive				Actuation Test		Y		
207 +		Under inflation detection				Read ECU Information		Y		
207 +		Under inflation detection				Read Fault Code		Y		
207 +		Under inflation detection				Erase Fault Code		Y		
207 +		Under inflation detection				Live Data		Y		
207 +		Battery charge status unit	BECB			Read ECU Information		Y		
207 +		Battery charge status unit	BECB			Read Fault Code		Y		
207 +		Battery charge status unit	BECB			Erase Fault Code		Y		
207 +		Battery charge status unit	BECB			Live Data		Y		
207 +		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
207 +		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
207 +		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
207 +		Battery charge status unit	BECB_GEN2			Live Data		Y		
207 +		Headlamp height adjuster/directional				Read ECU Information		Y		
207 +		Headlamp height adjuster/directional				Read Fault Code		Y		
207 +		Headlamp height adjuster/directional				Erase Fault Code		Y		
207 +		Headlamp height adjuster/directional				Live Data		Y		
207 +		Headlamp height adjuster/directional				Actuation Test		Y		
207 +		Engine relay unit				Read ECU Information		Y		
207 +		Engine relay unit				Actuation Test		Y		
207 +		Trailer relay unit				Read ECU Information		Y		
207 +		Trailer relay unit				Read Fault Code		Y		
207 +		Trailer relay unit				Erase Fault Code		Y		
207 +		Heating/ventilation				Read ECU Information		Y		
207 +		Heating/ventilation				Read Fault Code		Y		
207 +		Heating/ventilation				Erase Fault Code		Y		
207 +		Heating/ventilation				Live Data		Y		
207 +		Heating/ventilation				Actuation Test		Y		
207 +		Switch module under the steering wheel				Read ECU Information		Y		
207 +		Switch module under the steering wheel				Read Fault Code		Y		
207 +		Switch module under the steering wheel				Erase Fault Code		Y		
207 +		Switch module under the steering wheel				Live Data		Y		
207 +		Switch module under the steering wheel				Actuation Test		Y		
207 +		Instrument panel				Read ECU Information		Y		
207 +		Instrument panel				Read Fault Code		Y		
207 +		Instrument panel				Erase Fault Code		Y		
207 +		Instrument panel				Live Data		Y		
207 +		Instrument panel				Actuation Test		Y		
207 +		Multifunction display	Type "A" (segments) with buttons			Read ECU Information		Y		
207 +		Multifunction display	Type "A" (segments) with buttons			Read Fault Code		Y		
207 +		Multifunction display	Type "A" (segments) with buttons			Erase Fault Code		Y		
207 +		Multifunction display	Type "A" (segments) with buttons			Live Data		Y		
207 +		Multifunction display	Type "A" (segments) with buttons			Actuation Test		Y		
207 +		Multifunction display	Type "A" (segments) without buttons			Read ECU Information		Y		
207 +		Multifunction display	Type "A" (segments) without buttons			Read Fault Code		Y		
207 +		Multifunction display	Type "A" (segments) without buttons			Erase Fault Code		Y		
207 +		Multifunction display	Type "A" (segments) without buttons			Live Data		Y		
207 +		Multifunction display	Type "A" (segments) without buttons			Actuation Test		Y		
207 +		Multifunction display	Type "C" (dot matrix)			Read ECU Information		Y		
207 +		Multifunction display	Type "C" (dot matrix)			Read Fault Code		Y		
207 +		Multifunction display	Type "C" (dot matrix)			Erase Fault Code		Y		
207 +		Multifunction display	Type "C" (dot matrix)			Live Data		Y		
207 +		Multifunction display	Type "C" (dot matrix)			Actuation Test		Y		
207 +		Multifunction display	Type "C colour" (dot matrix)			Read ECU Information		Y		
207 +		Multifunction display	Type "C colour" (dot matrix)			Read Fault Code		Y		
207 +		Multifunction display	Type "C colour" (dot matrix)			Erase Fault Code		Y		
207 +		Multifunction display	Type "C colour" (dot matrix)			Live Data		Y		
207 +		Multifunction display	Type "C colour" (dot matrix)			Actuation Test		Y		
207 +		Parking aid				Read ECU Information		Y		
207 +		Parking aid				Read Fault Code		Y		
207 +		Parking aid				Erase Fault Code		Y		
207 +		Parking aid				Live Data		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Read ECU Information		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Read Fault Code		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Erase Fault Code		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Live Data		Y		
207 +		Radio or radiotelephone (radio part)	RD4			Actuation Test		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Read ECU Information		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Read Fault Code		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Erase Fault Code		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Live Data		Y		
207 +		Radio or radiotelephone (radio part)	RD45			Actuation Test		Y		
207 +		Telematics	RADIONAB_RNEG			Read ECU Information		Y		
207 +		Telematics	RADIONAB_RNEG			Read Fault Code		Y		
207 +		Telematics	RADIONAB_RNEG			Erase Fault Code		Y		
207 +		Telematics	RADIONAB_RNEG			Live Data		Y		
207 +		Telematics	RADIONAB_RNEG			Actuation Test		Y		
207 +		Telematics	BOITIER_TELEMATIQUE			Read ECU Information		Y		
207 +		Telematics	BOITIER_TELEMATIQUE			Read Fault Code		Y		
207 +		Telematics	BOITIER_TELEMATIQUE			Erase Fault Code		Y		
207 +		Telematics	BOITIER_TELEMATIQUE			Live Data		Y		
207 +		Telematics	BOITIER_TELEMATIQUE			Actuation Test		Y		
207 +		CD player				Read ECU Information		Y		
207 +		CD player				Read Fault Code		Y		
207 +		CD player				Erase Fault Code		Y		
207 +		CD player				Actuation Test		Y		
207 +		Hands-free kit (Telephone)	KML			Read ECU Information		Y		
207 +		Hands-free kit (Telephone)	KML			Read Fault Code		Y		
207 +		Hands-free kit (Telephone)	KML			Erase Fault Code		Y		
207 +		Hands-free kit (Telephone)	KML			Live Data		Y		
207 +		Hands-free kit (Telephone)	KML			Actuation Test		Y		
207 +		Hands-free kit (Telephone)	BOITIER_NOMADE			Read ECU Information		Y		
207 +		Hands-free kit (Telephone)	BOITIER_NOMADE			Read Fault Code		Y		
207 +		Hands-free kit (Telephone)	BOITIER_NOMADE			Erase Fault Code		Y		
207 +		Hands-free kit (Telephone)	BOITIER_NOMADE			Live Data		Y		
207 +		Hands-free kit (Telephone)	BOITIER_NOMADE			Actuation Test		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Read ECU Information		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Read Fault Code		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Erase Fault Code		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Live Data		Y		
207 +		Anti-theft alarm	Alarm without anti-lift module			Actuation Test		Y		
207 +		Folding roof				Read ECU Information		Y		
207 +		Folding roof				Read Fault Code		Y		
207 +		Folding roof				Erase Fault Code		Y		
207 +		Folding roof				Live Data		Y		
207 +		Folding roof				Actuation Test		Y		
207 +		Driving school module				Read ECU Information		Y		
207 +		Driving school module				Actuation Test		Y		
207 +		High frequency receiver				Read ECU Information		Y		
207 +		High frequency receiver				Read Fault Code		Y		
207 +		High frequency receiver				Erase Fault Code		Y		
207 +		High frequency receiver				Live Data		Y		
207 +		Seat belts not fastened LED unit				Read ECU Information		Y		
207 +		Seat belts not fastened LED unit				Actuation Test		Y		
207 +		Service module				Read ECU Information		Y		
207 +		Service module				Read Fault Code		Y		
207 +		Service module				Erase Fault Code		Y		
207 +		Service module				Live Data		Y		
207 +		Service module				Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
207 +		Rain and brightness sensor				Read ECU Information		Y		
207 +		Rain and brightness sensor				Read Fault Code		Y		
207 +		Rain and brightness sensor				Erase Fault Code		Y		
208		BSI(Built-in Systems Interface)				Read ECU Information		Y		
208		BSI(Built-in Systems Interface)				Read Fault Code		Y		
208		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
208		BSI(Built-in Systems Interface)				Live Data		Y		
208		BSI(Built-in Systems Interface)				Actuation Test		Y		
208		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
208		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
208		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Live Data		Y		
208		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Live Data		Y		
208		Engine ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Live Data		Y		
208		Engine ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Live Data		Y		
208		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Read ECU Information		Y		
208		Engine ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Read Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Erase Fault Code		Y		
208		Engine ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Live Data		Y		
208		Engine ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Actuation Test		Y		
208		Engine ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Special Function	Configuration	Y		
208		Engine ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Special Function	Pack Repair	Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Live Data		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Read ECU Information		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Read Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Erase Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Live Data		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Actuation Test		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Read ECU Information		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Read Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Erase Fault Code		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Live Data		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Actuation Test		Y		
208		Engine ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Read ECU Information		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Read Fault Code		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Erase Fault Code		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Live Data		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Actuation Test		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Special Function	Configuration	Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Special Function	Pack Repair	Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read ECU Information		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read Fault Code		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Erase Fault Code		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Live Data		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Actuation Test		Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Configuration	Y		
208		Engine ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Pack Repair	Y		
208		Engine ECU	V46	Yes		Read ECU Information		Y		
208		Engine ECU	V46	Yes		Read Fault Code		Y		
208		Engine ECU	V46	Yes		Erase Fault Code		Y		
208		Engine ECU	V46	Yes		Live Data		Y		
208		Engine ECU	V46	Yes		Actuation Test		Y		
208		Engine ECU	V46	Yes		Special Function	Pack Repair	Y		
208		Engine ECU	V46	No	ZMZ	Read ECU Information		Y		
208		Engine ECU	V46	No	ZMZ	Read Fault Code		Y		
208		Engine ECU	V46	No	ZMZ	Erase Fault Code		Y		
208		Engine ECU	V46	No	ZMZ	Live Data		Y		
208		Engine ECU	V46	No	ZMZ	Actuation Test		Y		
208		Engine ECU	V46	No	ZMZ	Special Function	Pack Repair	Y		
208		Engine ECU	V46	No	HMW	Read ECU Information		Y		
208		Engine ECU	V46	No	HMW	Read Fault Code		Y		
208		Engine ECU	V46	No	HMW	Erase Fault Code		Y		
208		Engine ECU	V46	No	HMW	Live Data		Y		
208		Engine ECU	V46	No	HMW	Actuation Test		Y		
208		Engine ECU	V46	No	HMW	Special Function	Pack Repair	Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Read ECU Information		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Read Fault Code		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Erase Fault Code		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Live Data		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Actuation Test		Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Special Function	Configuration	Y		
208		Engine ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Special Function	Pack Repair	Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Read ECU Information		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Read Fault Code		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Erase Fault Code		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Live Data		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Actuation Test		Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Special Function	Configuration	Y		
208		Engine ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Special Function	Pack Repair	Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Read ECU Information		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Read Fault Code		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Erase Fault Code		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Live Data		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Actuation Test		Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Special Function	Replacement parts	Y		
208		Engine ECU	VD46			Read ECU Information		Y		
208		Engine ECU	VD46			Read Fault Code		Y		
208		Engine ECU	VD46			Erase Fault Code		Y		
208		Engine ECU	VD46			Live Data		Y		
208		Engine ECU	VD46			Actuation Test		Y		
208		Engine ECU	VD46			Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C60	Yes		Read ECU Information		Y		
208		Engine ECU	EDC17C60	Yes		Read Fault Code		Y		
208		Engine ECU	EDC17C60	Yes		Erase Fault Code		Y		
208		Engine ECU	EDC17C60	Yes		Live Data		Y		
208		Engine ECU	EDC17C60	Yes		Actuation Test		Y		
208		Engine ECU	EDC17C60	Yes		Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Read ECU Information		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Read Fault Code		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Erase Fault Code		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Live Data		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Actuation Test		Y		
208		Engine ECU	EDC17C60	No	BHZ/BHX	Special Function	Pack Repair	Y		
208		Engine ECU	EDC17C60	No	BHY	Read ECU Information		Y		
208		Engine ECU	EDC17C60	No	BHY	Read Fault Code		Y		
208		Engine ECU	EDC17C60	No	BHY	Erase Fault Code		Y		
208		Engine ECU	EDC17C60	No	BHY	Live Data		Y		
208		Engine ECU	EDC17C60	No	BHY	Actuation Test		Y		
208		Engine ECU	EDC17C60	No	BHY	Special Function	Pack Repair	Y		
208		Engine ECU	MEVD17_4_4			Read ECU Information		Y		
208		Engine ECU	MEVD17_4_4			Read Fault Code		Y		
208		Engine ECU	MEVD17_4_4			Erase Fault Code		Y		
208		Engine ECU	MEVD17_4_4			Live Data		Y		
208		Engine ECU	MEVD17_4_4			Actuation Test		Y		
208		Engine ECU	MEVD17_4_4			Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
208		Engine ECU	MEVD17_4_4			Special Function	Work on the ancillaries battery	Y		
208		Engine ECU	MEVD17_4_4			Special Function	Initialisation of the autoadaptive values	Y		
208		Engine ECU	MEVD17_4_4			Special Function	Replacement parts	Y		
208		Engine ECU	ME745_EC5	ME745_EC5 NFP		Read ECU Information		Y		
208		Engine ECU	ME745_EC5	ME745_EC5 NFP		Read Fault Code		Y		
208		Engine ECU	ME745_EC5	ME745_EC5 NFP		Erase Fault Code		Y		
208		Engine ECU	ME745_EC5	ME745_EC5 NFP		Live Data		Y		
208		Engine ECU	ME745_EC5	ME745_EC5 NFP		Actuation Test		Y		
208		Engine ECU	ME745_EC5	ME745_EC5 NFP		Special Function	Configuration	Y		
208		Engine ECU	ME745_EC5	ME745_EC5 NFP		Special Function	Pack Repair	Y		
208		Engine ECU	MED17_4_4			Read ECU Information		Y		
208		Engine ECU	MED17_4_4			Read Fault Code		Y		
208		Engine ECU	MED17_4_4			Erase Fault Code		Y		
208		Engine ECU	MED17_4_4			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
208		Engine ECU	MED17_4_4			Actuation Test		Y		
208		Engine ECU	MED17_4_4			Special Function	Pack Repair	Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFP		Read ECU Information		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFP		Read Fault Code		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFP		Erase Fault Code		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFP		Live Data		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFP		Actuation Test		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFP		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFP		Special Function	Replacement parts	Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFN		Read ECU Information		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFN		Read Fault Code		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFN		Erase Fault Code		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFN		Live Data		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFN		Actuation Test		Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFN		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	ME749_EC5	ME749_EC5 NFN		Special Function	Replacement parts	Y		
208		Engine ECU	V34.4	V34.4 ESSENCE		Read ECU Information		Y		
208		Engine ECU	V34.4	V34.4 ESSENCE		Read Fault Code		Y		
208		Engine ECU	V34.4	V34.4 ESSENCE		Erase Fault Code		Y		
208		Engine ECU	V34.4	V34.4 ESSENCE		Live Data		Y		
208		Engine ECU	V34.4	V34.4 ESSENCE		Actuation Test		Y		
208		Engine ECU	V34.4	V34.4 ESSENCE		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	V34.4	V34.4 ESSENCE		Special Function	Replacement parts	Y		
208		Engine ECU	V34.4	V34.4 FLEX FUEL		Read ECU Information		Y		
208		Engine ECU	V34.4	V34.4 FLEX FUEL		Read Fault Code		Y		
208		Engine ECU	V34.4	V34.4 FLEX FUEL		Erase Fault Code		Y		
208		Engine ECU	V34.4	V34.4 FLEX FUEL		Live Data		Y		
208		Engine ECU	V34.4	V34.4 FLEX FUEL		Actuation Test		Y		
208		Engine ECU	V34.4	V34.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	V34.4	V34.4 FLEX FUEL		Special Function	Replacement parts	Y		
208		Engine ECU	V34.5	V34.5 ESSENCE		Read ECU Information		Y		
208		Engine ECU	V34.5	V34.5 ESSENCE		Read Fault Code		Y		
208		Engine ECU	V34.5	V34.5 ESSENCE		Erase Fault Code		Y		
208		Engine ECU	V34.5	V34.5 ESSENCE		Live Data		Y		
208		Engine ECU	V34.5	V34.5 ESSENCE		Actuation Test		Y		
208		Engine ECU	V34.5	V34.5 ESSENCE		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	V34.5	V34.5 ESSENCE		Special Function	Replacement parts	Y		
208		Engine ECU	V34.5	V34.5 FLEX FUEL		Read ECU Information		Y		
208		Engine ECU	V34.5	V34.5 FLEX FUEL		Read Fault Code		Y		
208		Engine ECU	V34.5	V34.5 FLEX FUEL		Erase Fault Code		Y		
208		Engine ECU	V34.5	V34.5 FLEX FUEL		Live Data		Y		
208		Engine ECU	V34.5	V34.5 FLEX FUEL		Actuation Test		Y		
208		Engine ECU	V34.5	V34.5 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
208		Engine ECU	V34.5	V34.5 FLEX FUEL		Special Function	Replacement parts	Y		
208		Gearbox	CFC300P			Read ECU Information		Y		
208		Gearbox	CFC300P			Read Fault Code		Y		
208		Gearbox	CFC300P			Erase Fault Code		Y		
208		Gearbox	CFC300P			Live Data		Y		
208		Gearbox	CFC300P			Actuation Test		Y		
208		Gearbox	CFC300P			Special Function	Replacement parts	Y		
208		Gearbox	BVMP			Read ECU Information		Y		
208		Gearbox	BVMP			Read Fault Code		Y		
208		Gearbox	BVMP			Erase Fault Code		Y		
208		Gearbox	BVMP			Live Data		Y		
208		Gearbox	BVMP			Actuation Test		Y		
208		Gearbox	BVMP			Special Function	Counters	Y		
208		Gearbox	BVMP			Special Function	Pack Repair	Y		
208		Gearbox	BVA_AL4			Read ECU Information		Y		
208		Gearbox	BVA_AL4			Read Fault Code		Y		
208		Gearbox	BVA_AL4			Erase Fault Code		Y		
208		Gearbox	BVA_AL4			Live Data		Y		
208		Gearbox	BVA_AL4			Actuation Test		Y		
208		Gearbox	BVA_AL4			Special Function	Configuration	Y		
208		Gearbox	BVA_AL4			Special Function	Pack Repair	Y		
208		Gearbox	MAPS_UDS			Read ECU Information		Y		
208		Gearbox	MAPS_UDS			Read Fault Code		Y		
208		Gearbox	MAPS_UDS			Erase Fault Code		Y		
208		Gearbox	MAPS_UDS			Live Data		Y		
208		Gearbox	MAPS_UDS			Actuation Test		Y		
208		Gearbox	MAPS_UDS			Special Function	Setting of the actuator	Y		
208		Gearbox	MAPS_UDS			Special Function	Programming	Y		
208		Gearbox	MAPS_UDS			Special Function	Replacement parts	Y		
208		ABS or ESP ECU	ABSMK100			Read ECU Information		Y		
208		ABS or ESP ECU	ABSMK100			Read Fault Code		Y		
208		ABS or ESP ECU	ABSMK100			Erase Fault Code		Y		
208		ABS or ESP ECU	ABSMK100			Live Data		Y		
208		ABS or ESP ECU	ABSMK100			Actuation Test		Y		
208		ABS or ESP ECU	ABSMK100			Special Function		Y		
208		ABS or ESP ECU	ESPMK100			Read ECU Information		Y		
208		ABS or ESP ECU	ESPMK100			Read Fault Code		Y		
208		ABS or ESP ECU	ESPMK100			Erase Fault Code		Y		
208		ABS or ESP ECU	ESPMK100			Live Data		Y		
208		ABS or ESP ECU	ESPMK100			Actuation Test		Y		
208		ABS or ESP ECU	ESPMK100			Special Function		Y		
208		Air bag				Read ECU Information		Y		
208		Air bag				Read Fault Code		Y		
208		Air bag				Erase Fault Code		Y		
208		Air bag				Live Data		Y		
208		Air bag				Special Function	Configuration	Y		
208		Air bag				Special Function	Pack Repair	Y		
208		Electric power steering				Read ECU Information		Y		
208		Electric power steering				Read Fault Code		Y		
208		Electric power steering				Erase Fault Code		Y		
208		Electric power steering				Live Data		Y		
208		Trailer relay unit				Read ECU Information		Y		
208		Trailer relay unit				Read Fault Code		Y		
208		Trailer relay unit				Erase Fault Code		Y		
208		Trailer relay unit				Live Data		Y		
208		Trailer relay unit				Actuation Test		Y		
208		Parking aid	4 parking assistance sensors			Read ECU Information		Y		
208		Parking aid	4 parking assistance sensors			Read Fault Code		Y		
208		Parking aid	4 parking assistance sensors			Erase Fault Code		Y		
208		Parking aid	4 parking assistance sensors			Live Data		Y		
208		Parking aid	8 parking assistance sensors			Read ECU Information		Y		
208		Parking aid	8 parking assistance sensors			Read Fault Code		Y		
208		Parking aid	8 parking assistance sensors			Erase Fault Code		Y		
208		Parking aid	8 parking assistance sensors			Live Data		Y		
208		Parking aid	10 parking assistance sensors			Read ECU Information		Y		
208		Parking aid	10 parking assistance sensors			Read Fault Code		Y		
208		Parking aid	10 parking assistance sensors			Erase Fault Code		Y		
208		Parking aid	10 parking assistance sensors			Live Data		Y		
208		Air conditioning				Read ECU Information		Y		
208		Air conditioning				Read Fault Code		Y		
208		Air conditioning				Erase Fault Code		Y		
208		Air conditioning				Live Data		Y		
208		Air conditioning				Actuation Test		Y		
208		Air conditioning				Special Function	Configuration	Y		
208		Air conditioning				Special Function	Pack Repair	Y		
208		Radio				Read ECU Information		Y		
208		Radio				Read Fault Code		Y		
208		Radio				Erase Fault Code		Y		
208		Radio				Live Data		Y		
208		Radio				Actuation Test		Y		
208		Rain and brightness sensor				Read ECU Information		Y		
208		Rain and brightness sensor				Read Fault Code		Y		
208		Rain and brightness sensor				Erase Fault Code		Y		
208		Rain and brightness sensor				Live Data		Y		
208		Rain and brightness sensor				Special Function	Pack Repair	Y		
208		Independent telematic unit	BTA			Read ECU Information		Y		
208		Independent telematic unit	BTA			Read Fault Code		Y		
208		Independent telematic unit	BTA			Erase Fault Code		Y		
208		Independent telematic unit	BTA			Live Data		Y		
208		Independent telematic unit	BTA			Actuation Test		Y		
208		Independent telematic unit	BTA			Special Function	Configuration	Y		
208		Independent telematic unit	BTA			Special Function	Pack Repair	Y		
208		Independent telematic unit	BTA_2			Read ECU Information		Y		
208		Independent telematic unit	BTA_2			Read Fault Code		Y		
208		Independent telematic unit	BTA_2			Erase Fault Code		Y		
208		Independent telematic unit	BTA_2			Live Data		Y		
208		Independent telematic unit	BTA_2			Actuation Test		Y		
208		Independent telematic unit	BTA_2			Special Function	Configuration	Y		
208		Independent telematic unit	BTA_2			Special Function	Pack Repair	Y		
208		Independent telematic unit	BTA_3R			Read ECU Information		Y		
208		Independent telematic unit	BTA_3R			Read Fault Code		Y		
208		Independent telematic unit	BTA_3R			Erase Fault Code		Y		
208		Independent telematic unit	BTA_3R			Live Data		Y		
208		Independent telematic unit	BTA_3R			Actuation Test		Y		
208		Instrument panel				Read ECU Information		Y		
208		Instrument panel				Read Fault Code		Y		
208		Instrument panel				Erase Fault Code		Y		
208		Instrument panel				Live Data		Y		
208		Instrument panel				Actuation Test		Y		
208		Audio amplifier				Read ECU Information		Y		
208		Audio amplifier				Read Fault Code		Y		
208		Audio amplifier				Erase Fault Code		Y		
208		Audio amplifier				Actuation Test		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Read ECU Information		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Read Fault Code		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Erase Fault Code		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Actuation Test		Y		
208		Matrix screen integral to the instrument panel	Yes	Colour matrix screen		Special Function	Configuration	Y		
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Read ECU Information		Y		
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Erase Fault Code		Y		
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Actuation Test		Y		
208		Matrix screen integral to the instrument panel	No	Monochrome matrix screen		Special Function	Configuration	Y		
208		External CD player				Read ECU Information		Y		
208		External CD player				Read Fault Code		Y		
208		External CD player				Erase Fault Code		Y		
208		External CD player				Live Data		Y		
208		External CD player				Actuation Test		Y		
208		Steering wheel with integral controls (VCI)				Read ECU Information		Y		
208		Steering wheel with integral controls (VCI)				Read Fault Code		Y		
208		Steering wheel with integral controls (VCI)				Erase Fault Code		Y		
208		Steering wheel with integral controls (VCI)				Live Data		Y		
208		Steering wheel with integral controls (VCI)				Actuation Test		Y		
208		Central voltage retention device	DMTC			Read ECU Information		Y		
208		Central voltage retention device	DMTR			Read ECU Information		Y		
208		Central voltage retention device	DMTR			Read Fault Code		Y		
208		Central voltage retention device	DMTR			Erase Fault Code		Y		
208		Battery charge status unit				Read ECU Information		Y		
208		Battery charge status unit				Read Fault Code		Y		
208		Battery charge status unit				Erase Fault Code		Y		
208		Battery charge status unit				Live Data		Y		
208		Telematics	SMEG			Read ECU Information		Y		
208		Telematics	SMEG			Read Fault Code		Y		
208		Telematics	SMEG			Erase Fault Code		Y		
208		Telematics	SMEG			Live Data		Y		
208		Telematics	SMEG			Actuation Test		Y		
208		Telematics	SMEG_PLUS			Read ECU Information		Y		
208		Telematics	SMEG_PLUS			Read Fault Code		Y		
208		Telematics	SMEG_PLUS			Erase Fault Code		Y		
208		Telematics	SMEG_PLUS			Live Data		Y		
208		Telematics	SMEG_PLUS			Actuation Test		Y		
208		Telematics	MRN			Read ECU Information		Y		
208		Telematics	MRN			Read Fault Code		Y		
208		Telematics	MRN			Erase Fault Code		Y		
208		Telematics	MRN			Live Data		Y		
208		Telematics	MRN			Actuation Test		Y		
208		Telematics	RCC			Read ECU Information		Y		
208		Telematics	RCC			Read Fault Code		Y		
208		Telematics	RCC			Erase Fault Code		Y		
208		Telematics	RCC			Live Data		Y		
208		Telematics	RCC			Actuation Test		Y		
208		Telematics	RCC			Special Function	Configuration	Y		
208		Telematics	NAC			Read ECU Information		Y		
208		Telematics	NAC			Read Fault Code		Y		
208		Telematics	NAC			Erase Fault Code		Y		
208		Telematics	NAC			Live Data		Y		
208		Telematics	NAC			Actuation Test		Y		
208		Telematics	NAC			Special Function	Configuration	Y		
208		Siren				Read ECU Information		Y		
208		Siren				Read Fault Code		Y		
208		Siren				Erase Fault Code		Y		
208		Siren				Live Data		Y		
208		Siren				Actuation Test		Y		
208		Anti-theft alarm				Read ECU Information		Y		
208		Anti-theft alarm				Read Fault Code		Y		
208		Anti-theft alarm				Erase Fault Code		Y		
208		Anti-theft alarm				Live Data		Y		
208		Anti-theft alarm				Actuation Test		Y		
208		Multiplexed additive pump				Read ECU Information		Y		
208		Multiplexed additive pump				Read Fault Code		Y		
208		Multiplexed additive pump				Erase Fault Code		Y		
208		Multiplexed additive pump				Live Data		Y		
208		Multiplexed additive pump				Actuation Test		Y		
208		Multiplexed additive pump				Special Function	Configuration	Y		
208		Multiplexed additive pump				Special Function	Pack repair	Y		
208		Switch module under the steering wheel(Top of column)				Read ECU Information		Y		
208		Switch module under the steering wheel(Top of column)				Read Fault Code		Y		
208		Switch module under the steering wheel(Top of column)				Erase Fault Code		Y		
208		Switch module under the steering wheel(Top of column)				Live Data		Y		
208		Switch module under the steering wheel(Top of column)				Actuation Test		Y		
208		Driving school module				Read ECU Information		Y		
208		Driving school module				Actuation Test		Y		
208		Lighting relay unit				Read ECU Information		Y		
208		Lighting relay unit				Read Fault Code		Y		
208		Lighting relay unit				Erase Fault Code		Y		
208		Lighting relay unit				Live Data		Y		
208		Lighting relay unit				Actuation Test		Y		
208(Ai91)		BSI(Built-in Systems Interface)				Read ECU Information		Y		
208(Ai91)		BSI(Built-in Systems Interface)				Read Fault Code		Y		
208(Ai91)		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
208(Ai91)		BSI(Built-in Systems Interface)				Live Data		Y		
208(Ai91)		BSI(Built-in Systems Interface)				Actuation Test		Y		
208(Ai91)		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
208(Ai91)		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
208(Ai91)		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFP		Read ECU Information		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFP		Read Fault Code		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFP		Erase Fault Code		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFP		Live Data		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFP		Actuation Test		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFP		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFP		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFN		Read ECU Information		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFN		Read Fault Code		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFN		Erase Fault Code		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFN		Live Data		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFN		Actuation Test		Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFN		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	ME749_EC5	ME749_EC5 NFN		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Read ECU Information		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Read Fault Code		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Erase Fault Code		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Live Data		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Actuation Test		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	V34.4	V34.4 ESSENCE		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Read ECU Information		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Read Fault Code		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Erase Fault Code		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Live Data		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Actuation Test		Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	V34.4	V34.4 FLEX FUEL		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Read ECU Information		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Read Fault Code		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Erase Fault Code		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Live Data		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Actuation Test		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	V34.5	V34.5 ESSENCE		Special Function	Replacement parts	Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Read ECU Information		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Read Fault Code		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Erase Fault Code		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Live Data		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Actuation Test		Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
208(Ai91)		Engine ECU	V34.5	V34.5 FLEX FUEL		Special Function	Replacement parts	Y		
208(Ai91)		Gearbox				Read ECU Information		Y		
208(Ai91)		Gearbox				Read Fault Code		Y		
208(Ai91)		Gearbox				Erase Fault Code		Y		
208(Ai91)		Gearbox				Live Data		Y		
208(Ai91)		Gearbox				Actuation Test		Y		
208(Ai91)		Gearbox				Special Function	Configuration	Y		
208(Ai91)		Gearbox				Special Function	Pack Repair	Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Read ECU Information		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Read Fault Code		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Erase Fault Code		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Live Data		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Actuation Test		Y		
208(Ai91)		ABS or ESP ECU	ABSMK100			Special Function		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Read ECU Information		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Read Fault Code		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Erase Fault Code		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Live Data		Y		
208(Ai91)		ABS or ESP ECU	ESPMK100			Actuation Test		Y		
208(Ai91)		Air bag				Read ECU Information		Y		
208(Ai91)		Air bag				Read Fault Code		Y		
208(Ai91)		Air bag				Erase Fault Code		Y		
208(Ai91)		Air bag				Live Data		Y		
208(Ai91)		Air bag				Special Function	Configuration	Y		
208(Ai91)		Air bag				Special Function	Pack Repair	Y		
208(Ai91)		Parking aid	Parking assistance sensors			Read ECU Information		Y		
208(Ai91)		Parking aid	Parking assistance sensors			Read Fault Code		Y		
208(Ai91)		Parking aid	Parking assistance sensors			Erase Fault Code		Y		
208(Ai91)		Parking aid	Parking assistance sensors			Live Data		Y		
208(Ai91)		Parking aid	Parking assistance sensors			Actuation Test		Y		
208(Ai91)		External CD player				Read ECU Information		Y		
208(Ai91)		External CD player				Read Fault Code		Y		
208(Ai91)		External CD player				Erase Fault Code		Y		
208(Ai91)		External CD player				Live Data		Y		
208(Ai91)		External CD player				Actuation Test		Y		
208(Ai91)		Telematics	SMEG			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
208(Ai91)		Telematics	SMEG			Read Fault Code		Y		
208(Ai91)		Telematics	SMEG			Erase Fault Code		Y		
208(Ai91)		Telematics	SMEG			Live Data		Y		
208(Ai91)		Telematics	SMEG			Actuation Test		Y		
208(Ai91)		Telematics	SMEG_PLUS			Read ECU Information		Y		
208(Ai91)		Telematics	SMEG_PLUS			Read Fault Code		Y		
208(Ai91)		Telematics	SMEG_PLUS			Erase Fault Code		Y		
208(Ai91)		Telematics	SMEG_PLUS			Live Data		Y		
208(Ai91)		Telematics	SMEG_PLUS			Actuation Test		Y		
208(Ai91)		Telematics	MRN			Read ECU Information		Y		
208(Ai91)		Telematics	MRN			Read Fault Code		Y		
208(Ai91)		Telematics	MRN			Erase Fault Code		Y		
208(Ai91)		Telematics	MRN			Live Data		Y		
208(Ai91)		Telematics	MRN			Actuation Test		Y		
208(Ai91)		Telematics	RCC			Read ECU Information		Y		
208(Ai91)		Telematics	RCC			Read Fault Code		Y		
208(Ai91)		Telematics	RCC			Erase Fault Code		Y		
208(Ai91)		Telematics	RCC			Live Data		Y		
208(Ai91)		Telematics	RCC			Actuation Test		Y		
208(Ai91)		Telematics	RCC			Special Function	Configuration	Y		
208(Ai91)		Telematics	NAC			Read ECU Information		Y		
208(Ai91)		Telematics	NAC			Read Fault Code		Y		
208(Ai91)		Telematics	NAC			Erase Fault Code		Y		
208(Ai91)		Telematics	NAC			Live Data		Y		
208(Ai91)		Telematics	NAC			Actuation Test		Y		
208(Ai91)		Telematics	NAC			Special Function	Configuration	Y		
208(Ai91)		Switch module under the steering wheel(Top of column)				Read ECU Information		Y		
208(Ai91)		Switch module under the steering wheel(Top of column)				Read Fault Code		Y		
208(Ai91)		Switch module under the steering wheel(Top of column)				Erase Fault Code		Y		
208(Ai91)		Switch module under the steering wheel(Top of column)				Live Data		Y		
208(Ai91)		Switch module under the steering wheel(Top of column)				Actuation Test		Y		
208(Ai91)		Air conditioning				Read ECU Information		Y		
208(Ai91)		Air conditioning				Read Fault Code		Y		
208(Ai91)		Air conditioning				Erase Fault Code		Y		
208(Ai91)		Air conditioning				Live Data		Y		
208(Ai91)		Air conditioning				Actuation Test		Y		
208(Ai91)		Air conditioning				Special Function	Configuration	Y		
208(Ai91)		Air conditioning				Special Function	Pack Repair	Y		
208(Ai91)		Radio				Read ECU Information		Y		
208(Ai91)		Radio				Read Fault Code		Y		
208(Ai91)		Radio				Erase Fault Code		Y		
208(Ai91)		Radio				Live Data		Y		
208(Ai91)		Radio				Actuation Test		Y		
208(Ai91)		Rain and brightness sensor				Read ECU Information		Y		
208(Ai91)		Rain and brightness sensor				Read Fault Code		Y		
208(Ai91)		Rain and brightness sensor				Erase Fault Code		Y		
208(Ai91)		Rain and brightness sensor				Live Data		Y		
208(Ai91)		Rain and brightness sensor				Special Function	Pack Repair	Y		
208(Ai91)		Electric power steering				Read ECU Information		Y		
208(Ai91)		Electric power steering				Read Fault Code		Y		
208(Ai91)		Electric power steering				Erase Fault Code		Y		
208(Ai91)		Electric power steering				Live Data		Y		
208(Ai91)		Electric power steering				Actuation Test		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Read ECU Information		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Read Fault Code		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Erase Fault Code		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Live Data		Y		
208(Ai91)		Steering wheel with integral controls (VCI)				Actuation Test		Y		
208(Ai91)		Instrument panel				Read ECU Information		Y		
208(Ai91)		Instrument panel				Read Fault Code		Y		
208(Ai91)		Instrument panel				Erase Fault Code		Y		
208(Ai91)		Instrument panel				Live Data		Y		
208(Ai91)		Instrument panel				Actuation Test		Y		
208(Ai91)		Instrument panel				Special Function	Configuration	Y		
208(Ai91)		Instrument panel				Special Function	Pack Repair	Y		
208(Ai91)		Siren				Read ECU Information		Y		
208(Ai91)		Siren				Read Fault Code		Y		
208(Ai91)		Siren				Erase Fault Code		Y		
208(Ai91)		Siren				Live Data		Y		
208(Ai91)		Siren				Actuation Test		Y		
208(Ai91)		Anti-theft alarm				Read ECU Information		Y		
208(Ai91)		Anti-theft alarm				Read Fault Code		Y		
208(Ai91)		Anti-theft alarm				Erase Fault Code		Y		
208(Ai91)		Anti-theft alarm				Live Data		Y		
208(Ai91)		Anti-theft alarm				Actuation Test		Y		
208(Ai91)		Stolen vehicle location control unit				Read ECU Information		Y		
208(Ai91)		Stolen vehicle location control unit				Read Fault Code		Y		
208(Ai91)		Stolen vehicle location control unit				Erase Fault Code		Y		
208(Ai91)		Stolen vehicle location control unit				Live Data		Y		
208(Ai91)		Stolen vehicle location control unit				Actuation Test		Y		
208(Ai91)		Stolen vehicle location control unit				Special Function	Configuration	Y		
208(Ai91)		Stolen vehicle location control unit				Special Function	Pack Repair	Y		
301		BSI(Built-in Systems Interface)				Read ECU Information		Y		
301		BSI(Built-in Systems Interface)				Read Fault Code		Y		
301		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
301		BSI(Built-in Systems Interface)				Live Data		Y		
301		BSI(Built-in Systems Interface)				Actuation Test		Y		
301		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
301		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
301		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
301		Engine management ECU	Petrol	ME745_EC5		Read ECU Information		Y		
301		Engine management ECU	Petrol	ME745_EC5		Read Fault Code		Y		
301		Engine management ECU	Petrol	ME745_EC5		Erase Fault Code		Y		
301		Engine management ECU	Petrol	ME745_EC5		Live Data		Y		
301		Engine management ECU	Petrol	ME745_EC5		Actuation Test		Y		
301		Engine management ECU	Petrol	ME745_EC5		Special Function	Configuration	Y		
301		Engine management ECU	Petrol	ME745_EC5		Special Function	Pack Repair	Y		
301		Engine management ECU	Petrol	V46_52		Read ECU Information		Y		
301		Engine management ECU	Petrol	V46_52		Read Fault Code		Y		
301		Engine management ECU	Petrol	V46_52		Erase Fault Code		Y		
301		Engine management ECU	Petrol	V46_52		Live Data		Y		
301		Engine management ECU	Petrol	V46_52		Actuation Test		Y		
301		Engine management ECU	Petrol	V46_52		Special Function	Initialisation of the autoadaptive values	Y		
301		Engine management ECU	Petrol	V46_52		Special Function	Replacement parts	Y		
301		Engine management ECU	Petrol	V46_21		Read ECU Information		Y		
301		Engine management ECU	Petrol	V46_21		Read Fault Code		Y		
301		Engine management ECU	Petrol	V46_21		Erase Fault Code		Y		
301		Engine management ECU	Petrol	V46_21		Live Data		Y		
301		Engine management ECU	Petrol	V46_21		Actuation Test		Y		
301		Engine management ECU	Petrol	V46_21		Special Function	Configuration	Y		
301		Engine management ECU	Petrol	V46_21		Special Function	Pack Repair	Y		
301		Engine management ECU	Petrol	V46		Read ECU Information		Y		
301		Engine management ECU	Petrol	V46		Read Fault Code		Y		
301		Engine management ECU	Petrol	V46		Erase Fault Code		Y		
301		Engine management ECU	Petrol	V46		Live Data		Y		
301		Engine management ECU	Petrol	V46		Actuation Test		Y		
301		Engine management ECU	Petrol	V46		Special Function	Pack Repair	Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Live Data		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV	Read ECU Information		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV	Read Fault Code		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV	Erase Fault Code		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV	Live Data		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV	Actuation Test		Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV	Special Function	Configuration	Y		
301		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV	Special Function	Pack Repair	Y		
301		Engine management ECU	Diesel	EDC17C60		Read ECU Information		Y		
301		Engine management ECU	Diesel	EDC17C60		Read Fault Code		Y		
301		Engine management ECU	Diesel	EDC17C60		Erase Fault Code		Y		
301		Engine management ECU	Diesel	EDC17C60		Live Data		Y		
301		Engine management ECU	Diesel	EDC17C60		Actuation Test		Y		
301		Engine management ECU	Diesel	EDC17C60		Special Function	Pack Repair	Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Read ECU Information		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Read Fault Code		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Erase Fault Code		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Live Data		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Actuation Test		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS MK100			Special Function		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Read ECU Information		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Read Fault Code		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Erase Fault Code		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Live Data		Y		
301		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP MK100			Actuation Test		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read ECU Information		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AT8			Erase Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AT8			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
301		Automatic gearbox or controlled manual gearbox	BVA_AT8			Actuation Test		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Configuration	Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Pack Repair	Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
301		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Read ECU Information		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Read Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Erase Fault Code		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Live Data		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Actuation Test		Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Special Function	Setting of the actuator	Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Special Function	Counters	Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Special Function	Programming	Y		
301		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Special Function	Replacement parts	Y		
301		Air bags and pre-tensioners control unit				Read ECU Information		Y		
301		Air bags and pre-tensioners control unit				Read Fault Code		Y		
301		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
301		Air bags and pre-tensioners control unit				Live Data		Y		
301		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
301		Multifunction screen	Multifunction screen with segments(A+)			Read ECU Information		Y		
301		Multifunction screen	Multifunction screen with segments(A+)			Read Fault Code		Y		
301		Multifunction screen	Multifunction screen with segments(A+)			Erase Fault Code		Y		
301		Multifunction screen	Multifunction screen with segments(A+)			Actuation Test		Y		
301		Multifunction screen	Multifunction screen with segments(A+)			Special Function	Configuration	Y		
301		Multifunction screen	Multifunction screen with segments(A+)			Special Function	Pack Repair	Y		
301		Multifunction screen	Multifunction screen with pixels(C-)			Read ECU Information		Y		
301		Multifunction screen	Multifunction screen with pixels(C-)			Read Fault Code		Y		
301		Multifunction screen	Multifunction screen with pixels(C-)			Erase Fault Code		Y		
301		Multifunction screen	Multifunction screen with pixels(C-)			Actuation Test		Y		
301		Multifunction screen	Multifunction screen with pixels(C-)			Special Function	Configuration	Y		
301		Multifunction screen	Multifunction screen with pixels(C-)			Special Function	Pack Repair	Y		
301		Electronic key reader				Read ECU Information		Y		
301		Electronic key reader				Read Fault Code		Y		
301		Electronic key reader				Erase Fault Code		Y		
301		Electronic key reader				Live Data		Y		
301		Electronic key reader				Read ECU Information		Y		
301		Electric steering lock				Read Fault Code		Y		
301		Electric steering lock				Erase Fault Code		Y		
301		Electric steering lock				Live Data		Y		
301		Controls under the steering wheel				Read ECU Information		Y		
301		Controls under the steering wheel				Read Fault Code		Y		
301		Controls under the steering wheel				Erase Fault Code		Y		
301		Controls under the steering wheel				Live Data		Y		
301		Controls under the steering wheel				Actuation Test		Y		
301		Power steering	DAE			Read ECU Information		Y		
301		Power steering	DAE			Read Fault Code		Y		
301		Power steering	DAE			Erase Fault Code		Y		
301		Power steering	DAE			Live Data		Y		
301		Parking assistance				Read ECU Information		Y		
301		Parking assistance				Read Fault Code		Y		
301		Parking assistance				Erase Fault Code		Y		
301		Parking assistance				Live Data		Y		
301		Parking assistance				Actuation Test		Y		
301		Hands-free control unit				Read ECU Information		Y		
301		Hands-free control unit				Read Fault Code		Y		
301		Hands-free control unit				Erase Fault Code		Y		
301		Hands-free control unit				Live Data		Y		
301		Hands-free control unit				Special Function	Configuration	Y		
301		Hands-free control unit				Special Function	Pack Repair	Y		
301		Multiplexed control panel				Read ECU Information		Y		
301		Multiplexed control panel				Read Fault Code		Y		
301		Multiplexed control panel				Erase Fault Code		Y		
301		Multiplexed control panel				Live Data		Y		
301		Multiplexed control panel				Actuation Test		Y		
301		Trailer relay unit				Read ECU Information		Y		
301		Trailer relay unit				Read Fault Code		Y		
301		Trailer relay unit				Erase Fault Code		Y		
301		Trailer relay unit				Live Data		Y		
301		Trailer relay unit				Actuation Test		Y		
301		Radio	RDE			Read ECU Information		Y		
301		Radio	RDE			Read Fault Code		Y		
301		Radio	RDE			Erase Fault Code		Y		
301		Radio	RDE			Live Data		Y		
301		Radio	RDE			Actuation Test		Y		
301		Radio	RDE			Special Function	Configuration	Y		
301		Radio	RDE			Special Function	Spare part	Y		
301		Radio	RD45			Read ECU Information		Y		
301		Radio	RD45			Read Fault Code		Y		
301		Radio	RD45			Erase Fault Code		Y		
301		Radio	RD45			Live Data		Y		
301		Radio	RD45			Actuation Test		Y		
301		Radio	RD45			Special Function	Configuration	Y		
301		Radio	RD45			Special Function	Pack Repair	Y		
301		Radio	RD6_CN			Read ECU Information		Y		
301		Radio	RD6_CN			Read Fault Code		Y		
301		Radio	RD6_CN			Erase Fault Code		Y		
301		Radio	RD6_CN			Live Data		Y		
301		Radio	RD6_CN			Actuation Test		Y		
301		Intrusion alarm siren				Read ECU Information		Y		
301		Intrusion alarm siren				Read Fault Code		Y		
301		Intrusion alarm siren				Erase Fault Code		Y		
301		Intrusion alarm siren				Live Data		Y		
301		Intrusion alarm siren				Actuation Test		Y		
301		Intrusion alarm siren				Special Function	Configuration	Y		
301		Diesel additive pump	PADDGO			Read ECU Information		Y		
301		Diesel additive pump	PADDGO			Read Fault Code		Y		
301		Diesel additive pump	PADDGO			Erase Fault Code		Y		
301		Diesel additive pump	PADDGO			Live Data		Y		
301		Diesel additive pump	PADDGO			Actuation Test		Y		
301		Diesel additive pump	PADDGO			Special Function	Configuration	Y		
301		Diesel additive pump	PADDGO			Special Function	Pack repair	Y		
301		Diesel additive pump	PADDGO_TI_E6			Read ECU Information		Y		
301		Diesel additive pump	PADDGO_TI_E6			Read Fault Code		Y		
301		Diesel additive pump	PADDGO_TI_E6			Erase Fault Code		Y		
301		Diesel additive pump	PADDGO_TI_E6			Live Data		Y		
301		Diesel additive pump	PADDGO_TI_E6			Special Function	Configuration	Y		
301		Voltage retaining device	DMTR			Read ECU Information		Y		
301		Voltage retaining device	DMTR			Read Fault Code		Y		
301		Voltage retaining device	DMTR			Erase Fault Code		Y		
301		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
301		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
301		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
301		Battery charge status unit				Read ECU Information		Y		
301		Battery charge status unit				Read Fault Code		Y		
301		Battery charge status unit				Erase Fault Code		Y		
301		Battery charge status unit				Live Data		Y		
301		Battery charge status unit				Special Function	Configuration	Y		
301		Battery charge status unit				Special Function	Pack Repair	Y		
301		Telematic unit(RTX) or audio-navigation	MRN			Read ECU Information		Y		
301		Telematic unit(RTX) or audio-navigation	MRN			Read Fault Code		Y		
301		Telematic unit(RTX) or audio-navigation	MRN			Erase Fault Code		Y		
301		Telematic unit(RTX) or audio-navigation	MRN			Live Data		Y		
301		Telematic unit(RTX) or audio-navigation	MRN			Actuation Test		Y		
301		Telematic unit(RTX) or audio-navigation	MRN			Special Function	Configuration	Y		
301		Telematic unit(RTX) or audio-navigation	RCC			Read ECU Information		Y		
301		Telematic unit(RTX) or audio-navigation	RCC			Read Fault Code		Y		
301		Telematic unit(RTX) or audio-navigation	RCC			Erase Fault Code		Y		
301		Telematic unit(RTX) or audio-navigation	RCC			Live Data		Y		
301		Telematic unit(RTX) or audio-navigation	RCC			Actuation Test		Y		
301		Telematic unit(RTX) or audio-navigation	NAC			Read ECU Information		Y		
301		Telematic unit(RTX) or audio-navigation	NAC			Read Fault Code		Y		
301		Telematic unit(RTX) or audio-navigation	NAC			Erase Fault Code		Y		
301		Telematic unit(RTX) or audio-navigation	NAC			Live Data		Y		
301		Telematic unit(RTX) or audio-navigation	NAC			Actuation Test		Y		
301		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
301		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
301		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
301		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
306		Air bag and seat belt				Read ECU Information		Y		
306		Air bag and seat belt				Read Fault Code		Y		
306		Air bag and seat belt				Erase Fault Code		Y		
306		Active safety	Anti-lock brakes BOSCH ABS5			Read ECU Information		Y		
306		Active safety	Anti-lock brakes BOSCH ABS5			Read Fault Code		Y		
306		Active safety	Anti-lock brakes BOSCH ABS5			Erase Fault Code		Y		
306		Active safety	Anti-lock brakes BOSCH ABS5			Live Data		Y		
306		Active safety	Anti-lock brakes BOSCH ABS5			Actuation Test		Y		
306		Engine/ automatic gearbox	All models	HDY BOSCH MA3.1		Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
306		Engine/ automatic gearbox	All models	HDY BOSCH MA3.1		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDY BOSCH MA3.1		Actuation Test		Y		
306		Engine/ automatic gearbox	All models	HDY BOSCH MA3.1		Special Function	Injection ECU initialisation procedure	Y		
306		Engine/ automatic gearbox	All models	HDY MAGNETI MARELLI MA3.1		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDY MAGNETI MARELLI MA3.1		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDY MAGNETI MARELLI MA3.1		Special Function	Injection ECU initialisation procedure	Y		
306		Engine/ automatic gearbox	All models	HDZ BOSCH MA3.1		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDZ BOSCH MA3.1		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDZ BOSCH MA3.1		Actuation Test		Y		
306		Engine/ automatic gearbox	All models	HDZ BOSCH MA3.1		Special Function	Injection ECU initialisation procedure	Y		
306		Engine/ automatic gearbox	All models	HDZ MAGNETI MARELLI MA3.1		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDZ MAGNETI MARELLI MA3.1		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	HDZ MAGNETI MARELLI MA3.1		Special Function	Injection ECU initialisation procedure	Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Read ECU Information		Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Live Data		Y		
306		Engine/ automatic gearbox	All models	KFX MM1AP		Special Function	Injection ECU initialisation procedure	Y		
306		Engine/ automatic gearbox	All models	NFZ BOSCH MP5.2		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	NFZ BOSCH MP5.2		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	NFZ BOSCH MP5.2		Live Data		Y		
306		Engine/ automatic gearbox	All models	NFZ BOSCH MP5.2		Special Function	Injection ECU initialisation procedure	Y		
306		Engine/ automatic gearbox	All models	NFL BOSCH MP5.2		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	NFL BOSCH MP5.2		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	NFL BOSCH MP5.2		Live Data		Y		
306		Engine/ automatic gearbox	All models	NFL BOSCH MP5.2		Special Function	Injection ECU initialisation procedure	Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Read ECU Information		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Read Fault Code		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Erase Fault Code		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Live Data		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Actuation Test		Y		
306		Engine/ automatic gearbox	All models	RFS MM1AP		Special Function	Injection ECU initialisation procedure	Y		
306R		Engine	Petrol	KFW SAGEM S2000		Read ECU Information		Y		
306R		Engine	Petrol	KFW SAGEM S2000		Read Fault Code		Y		
306R		Engine	Petrol	KFW SAGEM S2000		Erase Fault Code		Y		
306R		Engine	Petrol	KFW SAGEM S2000		Live Data		Y		
306R		Engine	Petrol	KFW SAGEM S2000		Actuation Test		Y		
306R		Engine	Petrol	KFW SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
306R		Engine	Petrol	K6D SAGEM S2000		Read ECU Information		Y		
306R		Engine	Petrol	K6D SAGEM S2000		Read Fault Code		Y		
306R		Engine	Petrol	K6D SAGEM S2000		Erase Fault Code		Y		
306R		Engine	Petrol	K6D SAGEM S2000		Live Data		Y		
306R		Engine	Petrol	K6D SAGEM S2000		Actuation Test		Y		
306R		Engine	Petrol	K6D SAGEM S2000		Special Function	Initialising the autoadaptives	Y		
306R		Engine	Petrol	KFX BOSCH MP7.3		Read ECU Information		Y		
306R		Engine	Petrol	KFX BOSCH MP7.3		Read Fault Code		Y		
306R		Engine	Petrol	KFX BOSCH MP7.3		Erase Fault Code		Y		
306R		Engine	Petrol	KFX BOSCH MP7.3		Live Data		Y		
306R		Engine	Petrol	KFX BOSCH MP7.3		Actuation Test		Y		
306R		Engine	Petrol	KFX BOSCH MP7.3		Special Function	Injection ECU initialisation procedure	Y		
306R		Engine	Petrol	KFX MM1AP		Read ECU Information		Y		
306R		Engine	Petrol	KFX MM1AP		Read Fault Code		Y		
306R		Engine	Petrol	KFX MM1AP		Erase Fault Code		Y		
306R		Engine	Petrol	KFX MM1AP		Live Data		Y		
306R		Engine	Petrol	KFX MM1AP		Actuation Test		Y		
306R		Engine	Petrol	KFX MM1AP		Special Function	Ignition advance setting	Y		
306R		Engine	Petrol	KFX MM1AP		Special Function	Injection ECU initialisation procedure	Y		
306R		Engine	Petrol	KFX SAGEM SL 96		Read ECU Information		Y		
306R		Engine	Petrol	KFX SAGEM SL 96		Read Fault Code		Y		
306R		Engine	Petrol	KFX SAGEM SL 96		Erase Fault Code		Y		
306R		Engine	Petrol	KFX SAGEM SL 96		Live Data		Y		
306R		Engine	Petrol	KFX SAGEM SL 96		Actuation Test		Y		
306R		Engine	Petrol	LFY BOSCH MP7.3		Read ECU Information		Y		
306R		Engine	Petrol	LFY BOSCH MP7.3		Read Fault Code		Y		
306R		Engine	Petrol	LFY BOSCH MP7.3		Erase Fault Code		Y		
306R		Engine	Petrol	LFY BOSCH MP7.3		Live Data		Y		
306R		Engine	Petrol	LFY BOSCH MP7.3		Actuation Test		Y		
306R		Engine	Petrol	LFY BOSCH MP7.3		Special Function	Injection ECU initialisation procedure	Y		
306R		Engine	Petrol	LFY SAGEM SL 96		Read ECU Information		Y		
306R		Engine	Petrol	LFY SAGEM SL 96		Read Fault Code		Y		
306R		Engine	Petrol	LFY SAGEM SL 96		Erase Fault Code		Y		
306R		Engine	Petrol	LFY SAGEM SL 96		Live Data		Y		
306R		Engine	Petrol	LFY SAGEM SL 96		Actuation Test		Y		
306R		Engine	Petrol	NFT BOSCH M7.4.4		Read ECU Information		Y		
306R		Engine	Petrol	NFT BOSCH M7.4.4		Read Fault Code		Y		
306R		Engine	Petrol	NFT BOSCH M7.4.4		Erase Fault Code		Y		
306R		Engine	Petrol	NFT BOSCH M7.4.4		Live Data		Y		
306R		Engine	Petrol	NFT BOSCH M7.4.4		Special Function	Initialising the autoadaptives	Y		
306R		Engine	Petrol	NFV BOSCH M7.4.4		Read ECU Information		Y		
306R		Engine	Petrol	NFV BOSCH M7.4.4		Read Fault Code		Y		
306R		Engine	Petrol	NFV BOSCH M7.4.4		Erase Fault Code		Y		
306R		Engine	Petrol	NFV BOSCH M7.4.4		Live Data		Y		
306R		Engine	Petrol	NFV BOSCH M7.4.4		Special Function	Initialising the autoadaptives	Y		
306R		Engine	Petrol	NFZ BOSCH MP5.2		Read Fault Code		Y		
306R		Engine	Petrol	NFZ BOSCH MP5.2		Erase Fault Code		Y		
306R		Engine	Petrol	NFZ BOSCH MP5.2		Live Data		Y		
306R		Engine	Petrol	NFZ BOSCH MP7.2		Read ECU Information		Y		
306R		Engine	Petrol	NFZ BOSCH MP7.2		Read Fault Code		Y		
306R		Engine	Petrol	NFZ BOSCH MP7.2		Erase Fault Code		Y		
306R		Engine	Petrol	NFZ BOSCH MP7.2		Live Data		Y		
306R		Engine	Petrol	NFZ BOSCH MP7.2		Actuation Test		Y		
306R		Engine	Petrol	NFZ BOSCH MP7.2		Special Function	Injection ECU initialisation procedure	Y		
306R		Engine	Petrol	R6E BOSCH MP5.2		Read Fault Code		Y		
306R		Engine	Petrol	R6E BOSCH MP5.2		Erase Fault Code		Y		
306R		Engine	Petrol	R6E BOSCH MP5.2		Live Data		Y		
306R		Engine	Petrol	RFS MM1AP		Read ECU Information		Y		
306R		Engine	Petrol	RFS MM1AP		Read Fault Code		Y		
306R		Engine	Petrol	RFS MM1AP		Erase Fault Code		Y		
306R		Engine	Petrol	RFS MM1AP		Live Data		Y		
306R		Engine	Petrol	RFS MM1AP		Actuation Test		Y		
306R		Engine	Petrol	RFS MM1AP		Special Function	Ignition advance setting	Y		
306R		Engine	Petrol	RFS MM1AP		Special Function	Injection ECU initialisation procedure	Y		
306R		Engine	Petrol	RFV BOSCH MP5.2		Read Fault Code		Y		
306R		Engine	Petrol	RFV BOSCH MP5.2		Erase Fault Code		Y		
306R		Engine	Petrol	RFV BOSCH MP5.2		Live Data		Y		
306R		Engine	Diesel	RHY BOSCH EDC15C2		Read ECU Information		Y		
306R		Engine	Diesel	RHY BOSCH EDC15C2		Read Fault Code		Y		
306R		Engine	Diesel	RHY BOSCH EDC15C2		Erase Fault Code		Y		
306R		Engine	Diesel	RHY BOSCH EDC15C2		Live Data		Y		
306R		Engine	Diesel	RHY BOSCH EDC15C2		Actuation Test		Y		
306R		Engine	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
306R		Engine	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
306R		Engine	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
306R		Engine	Diesel	WJY LUCAS DCN2		Live Data		Y		
306R		Engine	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
306R		Engine	Diesel	WJZ LUCAS DCN2		Read ECU Information		Y		
306R		Engine	Diesel	WJZ LUCAS DCN2		Read Fault Code		Y		
306R		Engine	Diesel	WJZ LUCAS DCN2		Erase Fault Code		Y		
306R		Engine	Diesel	WJZ LUCAS DCN2		Live Data		Y		
306R		Engine	Diesel	WJZ LUCAS DCN2		Actuation Test		Y		
306R		Airbags	Air bag and seat belt			Read ECU Information		Y		
306R		Airbags	Air bag and seat belt			Read Fault Code		Y		
306R		Airbags	Air bag and seat belt			Erase Fault Code		Y		
306R		Airbags	Side airbag(right side)			Read ECU Information		Y		
306R		Airbags	Side airbag(right side)			Read Fault Code		Y		
306R		Airbags	Side airbag(right side)			Erase Fault Code		Y		
306R		Airbags	Side airbag(right side)			Actuation Test		Y		
306R		Airbags	Side airbag(left side)			Read ECU Information		Y		
306R		Airbags	Side airbag(left side)			Read Fault Code		Y		
306R		Airbags	Side airbag(left side)			Erase Fault Code		Y		
306R		Airbags	Side airbag(left side)			Actuation Test		Y		
306R		Active safety	ABS BOSCH 53			Read ECU Information		Y		
306R		Active safety	ABS BOSCH 53			Read Fault Code		Y		
306R		Active safety	ABS BOSCH 53			Erase Fault Code		Y		
306R		Active safety	ABS BOSCH 53			Live Data		Y		
306R		Active safety	ABS BOSCH 53			Actuation Test		Y		
306R		Active safety	ABS BOSCH 53			Special Function	Bleeding	Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Read ECU Information		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Read Fault Code		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Live Data		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Actuation Test		Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Special Function	Changing the mode Electrical	Y		
308(2010.01 - 2014.09)		BSI(Built-in Systems Interface)				Special Function	Learning	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6A	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6A	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6A	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6A	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6A	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6A	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6A	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 NFU	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 NFU	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 NFU	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 NFU	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 NFU	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 NFU	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 NFU	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6B	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6B	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6B	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6B	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6B	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6B	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749	ME749 N6B	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_4		Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_4		Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_4		Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_4		Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_4		Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Configuration	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Live Data		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Actuation Test		Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read ECU Information		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Live Data		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Actuation Test		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read ECU Information		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Live Data		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Actuation Test		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Read ECU Information		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Read Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Live Data		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Actuation Test		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
308(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Read ECU Information		Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Read Fault Code		Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Live Data		Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Power steering				Read ECU Information		Y		
308(2010.01 - 2014.09)		Power steering				Read Fault Code		Y		
308(2010.01 - 2014.09)		Power steering				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Power steering				Live Data		Y		
308(2010.01 - 2014.09)		Power steering				Actuation Test		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Read ECU Information		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Read Fault Code		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Live Data		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Actuation Test		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Read ECU Information		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Read Fault Code		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Live Data		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Actuation Test		Y		
308(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG_UDS			Read ECU Information		Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG_UDS			Read Fault Code		Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG_UDS			Live Data		Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG			Read ECU Information		Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG			Read Fault Code		Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG			Live Data		Y		
308(2010.01 - 2014.09)		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Read ECU Information		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Read Fault Code		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Live Data		Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB			Read ECU Information		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB			Read Fault Code		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB			Live Data		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Live Data		Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Lane departure warning system				Read ECU Information		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Read Fault Code		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Live Data		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Actuation Test		Y		
308(2010.01 - 2014.09)		Lane departure warning system				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Engine relay unit				Read ECU Information		Y		
308(2010.01 - 2014.09)		Engine relay unit				Read Fault Code		Y		
308(2010.01 - 2014.09)		Engine relay unit				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Engine relay unit				Actuation Test		Y		
308(2010.01 - 2014.09)		Trailer relay unit				Read ECU Information		Y		
308(2010.01 - 2014.09)		Trailer relay unit				Read Fault Code		Y		
308(2010.01 - 2014.09)		Trailer relay unit				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Read ECU Information		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Read Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Live Data		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Actuation Test		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Read ECU Information		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Read Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Live Data		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Actuation Test		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Windscreen wiper				Read ECU Information		Y		
308(2010.01 - 2014.09)		Windscreen wiper				Actuation Test		Y		
308(2010.01 - 2014.09)		Windscreen wiper				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Read ECU Information		Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Read Fault Code		Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Live Data		Y		
308(2010.01 - 2014.09)		Parking assistance	Parking aid			Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Air conditioning				Read ECU Information		Y		
308(2010.01 - 2014.09)		Air conditioning				Read Fault Code		Y		
308(2010.01 - 2014.09)		Air conditioning				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Air conditioning				Live Data		Y		
308(2010.01 - 2014.09)		Air conditioning				Actuation Test		Y		
308(2010.01 - 2014.09)		Air conditioning				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Air conditioning				Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Read ECU Information		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Read Fault Code		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Live Data		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Actuation Test		Y		
308(2010.01 - 2014.09)		Controls under the steering wheel				Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Instrument panel				Read ECU Information		Y		
308(2010.01 - 2014.09)		Instrument panel				Read Fault Code		Y		
308(2010.01 - 2014.09)		Instrument panel				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Instrument panel				Live Data		Y		
308(2010.01 - 2014.09)		Instrument panel				Actuation Test		Y		
308(2010.01 - 2014.09)		Instrument panel				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Read ECU Information		Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Read Fault Code		Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Erase Fault Code		Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Actuation Test		Y		
308(2010.01 - 2014.09)		CD changer / external CD player				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Read ECU Information		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Read Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Live Data		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Actuation Test		Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Radio amplifier				Read ECU Information		Y		
308(2010.01 - 2014.09)		Radio amplifier				Read Fault Code		Y		
308(2010.01 - 2014.09)		Radio amplifier				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Radio amplifier				Actuation Test		Y		
308(2010.01 - 2014.09)		Radio amplifier				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Radio amplifier				Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Read ECU Information		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Read Fault Code		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Live Data		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Actuation Test		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read ECU Information		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read Fault Code		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Live Data		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Actuation Test		Y		
308(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Radio	RD4			Read ECU Information		Y		
308(2010.01 - 2014.09)		Radio	RD4			Read Fault Code		Y		
308(2010.01 - 2014.09)		Radio	RD4			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Radio	RD4			Live Data		Y		
308(2010.01 - 2014.09)		Radio	RD4			Actuation Test		Y		
308(2010.01 - 2014.09)		Radio	RD4			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Radio	RD4			Special Function	Spare part	Y		
308(2010.01 - 2014.09)		Radio	RD45			Read ECU Information		Y		
308(2010.01 - 2014.09)		Radio	RD45			Read Fault Code		Y		
308(2010.01 - 2014.09)		Radio	RD45			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Radio	RD45			Live Data		Y		
308(2010.01 - 2014.09)		Radio	RD45			Actuation Test		Y		
308(2010.01 - 2014.09)		Radio	RD45			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Radio	RD45			Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Seat driver position memory module				Read ECU Information		Y		
308(2010.01 - 2014.09)		Seat driver position memory module				Read Fault Code		Y		
308(2010.01 - 2014.09)		Seat driver position memory module				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Seat driver position memory module				Live Data		Y		
308(2010.01 - 2014.09)		Seat driver position memory module				Actuation Test		Y		
308(2010.01 - 2014.09)		Seat driver position memory module				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Seat driver position memory module				Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Read ECU Information		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Read Fault Code		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Live Data		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Actuation Test		Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Anti-theft alarm	Alarm with anti-lift module			Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Read ECU Information		Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Read Fault Code		Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Live Data		Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Anti-theft alarm				Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Seat passenger position memory module				Read ECU Information		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module				Read Fault Code		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module				Live Data		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module				Actuation Test		Y		
308(2010.01 - 2014.09)		Seat passenger position memory module				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Seat passenger position memory module				Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Read Fault Code		Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Live Data		Y		
308(2010.01 - 2014.09)		Driver's door module	Driver's door module			Actuation Test		Y		
308(2010.01 - 2014.09)		Sunroof				Read ECU Information		Y		
308(2010.01 - 2014.09)		Sunroof				Read Fault Code		Y		
308(2010.01 - 2014.09)		Sunroof				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Sunroof				Live Data		Y		
308(2010.01 - 2014.09)		Sunroof				Actuation Test		Y		
308(2010.01 - 2014.09)		Sunroof				Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Moving panel deflector				Read ECU Information		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Read Fault Code		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Live Data		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Actuation Test		Y		
308(2010.01 - 2014.09)		Moving panel deflector				Special Function	Pack repair	Y		
308(2010.01 - 2014.09)		Folding roof				Read ECU Information		Y		
308(2010.01 - 2014.09)		Folding roof				Read Fault Code		Y		
308(2010.01 - 2014.09)		Folding roof				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Folding roof				Live Data		Y		
308(2010.01 - 2014.09)		Folding roof				Actuation Test		Y		
308(2010.01 - 2014.09)		Folding roof				Special Function	Pack Repair	Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Read ECU Information		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Read Fault Code		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Live Data		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Actuation Test		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Live Data		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Actuation Test		Y		
308(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
308(2010.01 - 2014.09)		Driving school module				Read ECU Information		Y		
308(2010.01 - 2014.09)		Driving school module				Actuation Test		Y		
308(2010.01 - 2014.09)		Rain and light sensor				Read ECU Information		Y		
308(2010.01 - 2014.09)		Rain and light sensor				Read Fault Code		Y		
308(2010.01 - 2014.09)		Rain and light sensor				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Seat belt not fastened warning lights unit				Read ECU Information		Y		
308(2010.01 - 2014.09)		Seat belt not fastened warning lights unit				Actuation Test		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Read ECU Information		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Read Fault Code		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Erase Fault Code		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Live Data		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Actuation Test		Y		
308(2010.01 - 2014.09)		Control panel dot matrix display				Special Function	Configuration	Y		
308(2010.01 - 2014.09)		High frequency receiver				Read ECU Information		Y		
308(2010.01 - 2014.09)		High frequency receiver				Read Fault Code		Y		
308(2010.01 - 2014.09)		High frequency receiver				Erase Fault Code		Y		
308(2010.01 - 2014.09)		High frequency receiver				Live Data		Y		
308(2010.01 - 2014.09)		Voltage retaining device	DMTC			Read ECU Information		Y		
308(2010.01 - 2014.09)		Voltage retaining device	DMTR			Read ECU Information		Y		
308(2010.01 - 2014.09)		Voltage retaining device	DMTR			Read Fault Code		Y		
308(2010.01 - 2014.09)		Voltage retaining device	DMTR			Erase Fault Code		Y		
308(T9)(after 2014.09)		BSI(Built-in Systems Interface)				Read ECU Information		Y		
308(T9)(after 2014.09)		BSI(Built-in Systems Interface)				Read Fault Code		Y		
308(T9)(after 2014.09)		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
308(T9)(after 2014.09)		BSI(Built-in Systems Interface)				Live Data		Y		
308(T9)(after 2014.09)		BSI(Built-in Systems Interface)				Actuation Test		Y		
308(T9)(after 2014.09)		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
308(T9)(after 2014.09)		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
308(T9)(after 2014.09)		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FV MED 17.4.2 EURO 5	Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FV MED 17.4.2 EURO 5	Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FV MED 17.4.2 EURO 5	Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FV MED 17.4.2 EURO 5	Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FV MED 17.4.2 EURO 5	Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FV MED 17.4.2 EURO 5	Special Function	Configuration	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FV MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FN MED 17.4.2 EURO 5	Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FN MED 17.4.2 EURO 5	Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FN MED 17.4.2 EURO 5	Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FN MED 17.4.2 EURO 5	Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FN MED 17.4.2 EURO 5	Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FN MED 17.4.2 EURO 5	Special Function	Configuration	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FN MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FA MED 17.4.2 EURO 5	Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FA MED 17.4.2 EURO 5	Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FA MED 17.4.2 EURO 5	Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FA MED 17.4.2 EURO 5	Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FA MED 17.4.2 EURO 5	Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FA MED 17.4.2 EURO 5	Special Function	Configuration	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_2	5FA MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	V46		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	V46		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	V46		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	V46		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	V46		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	V46		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	VD46		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	VD46		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	VD46		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	VD46		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	VD46		Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(T9)(after 2014.09)		Engine management ECU	Petrol	VD46		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_4		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_4		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_4		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_4		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_4		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MED17_4_4		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Special Function	Work on the ancillaries battery	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Special Function	Initialisation of the autoadaptive values	Y		
308(T9)(after 2014.09)		Engine management ECU	Petrol	MEVD17_4_4		Special Function	Replacement parts	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	DCM6.2		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2		Special Function	Configuration	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	EDC17C60		Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_DCM71		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_DCM71		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_DCM71		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_DCM71		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_DCM71		Actuation Test		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_MD1CS003		Read ECU Information		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_MD1CS003		Read Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_MD1CS003		Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_MD1CS003		Live Data		Y		
308(T9)(after 2014.09)		Engine management ECU	Diesel	CMM_MD1CS003		Actuation Test		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read ECU Information		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read Fault Code		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Erase Fault Code		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Live Data		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Actuation Test		Y		
308(T9)(after 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Live Data		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
308(T9)(after 2014.09)		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Live Data		Y		
308(T9)(after 2014.09)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Trailer relay unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Trailer relay unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Trailer relay unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Trailer relay unit				Live Data		Y		
308(T9)(after 2014.09)		Trailer relay unit				Actuation Test		Y		
308(T9)(after 2014.09)		Engine relay unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Engine relay unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Engine relay unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Engine relay unit				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Engine relay unit				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Read ECU Information		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Read Fault Code		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Actuation Test		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with PIXELS(C-)			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Read ECU Information		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Read Fault Code		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Actuation Test		Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Multifunction screen	Multifunction screen with SEGMENTS(A+)			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Controls under the steering wheel	Yes			Read ECU Information		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	Yes			Read Fault Code		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	Yes			Erase Fault Code		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	Yes			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(T9)(after 2014.09)		Controls under the steering wheel	Yes			Actuation Test		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	Yes			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Controls under the steering wheel	No			Read ECU Information		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	No			Read Fault Code		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	No			Erase Fault Code		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	No			Live Data		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	No			Actuation Test		Y		
308(T9)(after 2014.09)		Controls under the steering wheel	No			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Push gear lever				Read ECU Information		Y		
308(T9)(after 2014.09)		Push gear lever				Read Fault Code		Y		
308(T9)(after 2014.09)		Push gear lever				Erase Fault Code		Y		
308(T9)(after 2014.09)		Push gear lever				Live Data		Y		
308(T9)(after 2014.09)		Push gear lever				Actuation Test		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Read ECU Information		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Read Fault Code		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Live Data		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Actuation Test		Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		External CD player				Read ECU Information		Y		
308(T9)(after 2014.09)		External CD player				Read Fault Code		Y		
308(T9)(after 2014.09)		External CD player				Erase Fault Code		Y		
308(T9)(after 2014.09)		External CD player				Live Data		Y		
308(T9)(after 2014.09)		External CD player				Actuation Test		Y		
308(T9)(after 2014.09)		External CD player				Special Function	Configuration	Y		
308(T9)(after 2014.09)		External CD player				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Supply protection and management unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Supply protection and management unit				Live Data		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Read ECU Information		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Read Fault Code		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Erase Fault Code		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Live Data		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Actuation Test		Y		
308(T9)(after 2014.09)		Anti-theft alarm				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Driver's door module				Read ECU Information		Y		
308(T9)(after 2014.09)		Driver's door module				Read Fault Code		Y		
308(T9)(after 2014.09)		Driver's door module				Erase Fault Code		Y		
308(T9)(after 2014.09)		Driver's door module				Live Data		Y		
308(T9)(after 2014.09)		Driver's door module				Actuation Test		Y		
308(T9)(after 2014.09)		Power steering				Read ECU Information		Y		
308(T9)(after 2014.09)		Power steering				Read Fault Code		Y		
308(T9)(after 2014.09)		Power steering				Erase Fault Code		Y		
308(T9)(after 2014.09)		Power steering				Live Data		Y		
308(T9)(after 2014.09)		Power steering				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Electronic key reader				Read ECU Information		Y		
308(T9)(after 2014.09)		Electronic key reader				Read Fault Code		Y		
308(T9)(after 2014.09)		Electronic key reader				Erase Fault Code		Y		
308(T9)(after 2014.09)		Electronic key reader				Live Data		Y		
308(T9)(after 2014.09)		Electric steering lock				Read ECU Information		Y		
308(T9)(after 2014.09)		Electric steering lock				Read Fault Code		Y		
308(T9)(after 2014.09)		Electric steering lock				Erase Fault Code		Y		
308(T9)(after 2014.09)		Electric steering lock				Live Data		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6CTED	9HC PADDGO_INERGY	Read ECU Information		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6CTED	9HC PADDGO_INERGY	Read Fault Code		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6CTED	9HC PADDGO_INERGY	Erase Fault Code		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6CTED	9HC PADDGO_INERGY	Live Data		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6CTED	9HC PADDGO_INERGY	Actuation Test		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6CTED	9HC PADDGO_INERGY	Special Function	Pack repair	Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6DTED	9HP PADDGO_INERGY	Read ECU Information		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6DTED	9HP PADDGO_INERGY	Read Fault Code		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6DTED	9HP PADDGO_INERGY	Erase Fault Code		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6DTED	9HP PADDGO_INERGY	Live Data		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6DTED	9HP PADDGO_INERGY	Actuation Test		Y		
308(T9)(after 2014.09)		Diesel additive pump	PADDGO_INERGY	PADDGO_INERGY DV6DTED	9HP PADDGO_INERGY	Special Function	Pack repair	Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Read ECU Information		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Read Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Erase Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Live Data		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Actuation Test		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	RCC			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Read ECU Information		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Read Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Erase Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Live Data		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Actuation Test		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	SMEG + audio/navigation			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Read ECU Information		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Read Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Erase Fault Code		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Live Data		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Actuation Test		Y		
308(T9)(after 2014.09)		Telematic unit(RTX) or audio-navigation	NAC			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Read ECU Information		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Read Fault Code		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Erase Fault Code		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Live Data		Y		
308(T9)(after 2014.09)		Vehicle Distance Assistance				Actuation Test		Y		
308(T9)(after 2014.09)		Air conditioning				Read ECU Information		Y		
308(T9)(after 2014.09)		Air conditioning				Read Fault Code		Y		
308(T9)(after 2014.09)		Air conditioning				Erase Fault Code		Y		
308(T9)(after 2014.09)		Air conditioning				Live Data		Y		
308(T9)(after 2014.09)		Air conditioning				Actuation Test		Y		
308(T9)(after 2014.09)		Air conditioning				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Read Fault Code		Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Erase Fault Code		Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Live Data		Y		
308(T9)(after 2014.09)		Control on the steering wheel / integral controls steering wheel	Control on the steering wheel / integral controls steering wheel			Actuation Test		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS			Read ECU Information		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS			Read Fault Code		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS			Erase Fault Code		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS			Live Data		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS			Actuation Test		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS_GP			Read ECU Information		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS_GP			Read Fault Code		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS_GP			Erase Fault Code		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS_GP			Live Data		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS_GP			Actuation Test		Y		
308(T9)(after 2014.09)		Touch screen	EMF_DGT_UDS_GP			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Read ECU Information		Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Read Fault Code		Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Erase Fault Code		Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Live Data		Y		
308(T9)(after 2014.09)		Rain and brightness sensor				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Parking assistance	4 parking assistance sensors			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Read ECU Information		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Read Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Erase Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Actuation Test		Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Parking assistance	8 parking assistance sensors			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Parking assistance	10 parking assistance sensors			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Read ECU Information		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Read Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Erase Fault Code		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Live Data		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Actuation Test		Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Parking assistance	12 parking assistance sensors			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Live Data		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Actuation Test		Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Driver's seat memorizing unit				Special Function	Pack repair	Y		
308(T9)(after 2014.09)		Battery charge status unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Battery charge status unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Battery charge status unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Battery charge status unit				Live Data		Y		
308(T9)(after 2014.09)		Battery charge status unit				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Battery charge status unit				Special Function	Pack repair	Y		
308(T9)(after 2014.09)		Radio amplifier				Read ECU Information		Y		
308(T9)(after 2014.09)		Radio amplifier				Read Fault Code		Y		
308(T9)(after 2014.09)		Radio amplifier				Erase Fault Code		Y		
308(T9)(after 2014.09)		Radio amplifier				Actuation Test		Y		
308(T9)(after 2014.09)		Radio amplifier				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Radio amplifier				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Hands-free control unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Hands-free control unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Hands-free control unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Hands-free control unit				Live Data		Y		
308(T9)(after 2014.09)		Hands-free control unit				Actuation Test		Y		
308(T9)(after 2014.09)		Hands-free control unit				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Hands-free control unit				Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Live Data		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Actuation Test		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_2			Read ECU Information		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_2			Read Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_2			Erase Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_2			Live Data		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_2			Actuation Test		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_2			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_2			Special Function	Pack Repair	Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_3S			Read ECU Information		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_3S			Read Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_3S			Erase Fault Code		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_3S			Live Data		Y		
308(T9)(after 2014.09)		Service module / Independent telematic unit	BTA_3S			Actuation Test		Y		
308(T9)(after 2014.09)		Multiplexed control panel	Accessory audio system and manual air conditioning			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(T9)(after 2014.09)		Multiplexed control panel	Accessory audio system and manual air conditioning			Read Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	Accessory audio system and manual air conditioning			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	Accessory audio system and manual air conditioning			Live Data		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read ECU Information		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Live Data		Y		
308(T9)(after 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Actuation Test		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Read ECU Information		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Read Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Live Data		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG audio-navigation+			Actuation Test		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Read ECU Information		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Read Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Live Data		Y		
308(T9)(after 2014.09)		Multiplexed control panel	SMEG+ audio-navigation with CD player			Actuation Test		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Read ECU Information		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Read Fault Code		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Erase Fault Code		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Live Data		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Actuation Test		Y		
308(T9)(after 2014.09)		Intrusion alarm siren				Special Function	Configuration	Y		
308(T9)(after 2014.09)		Control of the telematic unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Read Fault Code		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Erase Fault Code		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Live Data		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Actuation Test		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Live Data		Y		
308(T9)(after 2014.09)		Control of the telematic unit				Actuation Test		Y		
308(T9)(after 2014.09)		Radio	RD45			Read ECU Information		Y		
308(T9)(after 2014.09)		Radio	RD45			Read Fault Code		Y		
308(T9)(after 2014.09)		Radio	RD45			Erase Fault Code		Y		
308(T9)(after 2014.09)		Radio	RD45			Live Data		Y		
308(T9)(after 2014.09)		Radio	RD45			Actuation Test		Y		
308(T9)(after 2014.09)		Radio	RD45			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Radio	RD6			Read ECU Information		Y		
308(T9)(after 2014.09)		Radio	RD6			Read Fault Code		Y		
308(T9)(after 2014.09)		Radio	RD6			Erase Fault Code		Y		
308(T9)(after 2014.09)		Radio	RD6			Live Data		Y		
308(T9)(after 2014.09)		Radio	RD6			Actuation Test		Y		
308(T9)(after 2014.09)		Radio	RD6			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Control panel dot matrix display	No			Read ECU Information		Y		
308(T9)(after 2014.09)		Control panel dot matrix display	No			Read Fault Code		Y		
308(T9)(after 2014.09)		Control panel dot matrix display	No			Erase Fault Code		Y		
308(T9)(after 2014.09)		Control panel dot matrix display	No			Actuation Test		Y		
308(T9)(after 2014.09)		Control panel dot matrix display	Yes			Read ECU Information		Y		
308(T9)(after 2014.09)		Control panel dot matrix display	Yes			Read Fault Code		Y		
308(T9)(after 2014.09)		Control panel dot matrix display	Yes			Erase Fault Code		Y		
308(T9)(after 2014.09)		Control panel dot matrix display	Yes			Actuation Test		Y		
308(T9)(after 2014.09)		Control panel dot matrix display	Yes			Special Function	Configuration	Y		
308(T9)(after 2014.09)		Seat belts not fastened LED unit				Read ECU Information		Y		
308(T9)(after 2014.09)		Seat belts not fastened LED unit				Actuation Test		Y		
308(T9)(after 2014.09)		Additional heating				Read ECU Information		Y		
308(T9)(after 2014.09)		Additional heating				Read Fault Code		Y		
308(T9)(after 2014.09)		Additional heating				Erase Fault Code		Y		
308(T9)(after 2014.09)		Additional heating				Live Data		Y		
308(T9)(after 2014.09)		Additional heating				Actuation Test		Y		
308(T9)(after 2014.09)		Voltage retaining device	DMTC			Read ECU Information		Y		
308(T9)(after 2014.09)		Voltage retaining device	DMTR			Read ECU Information		Y		
308(T9)(after 2014.09)		Voltage retaining device	DMTR			Read Fault Code		Y		
308(T9)(after 2014.09)		Voltage retaining device	DMTR			Erase Fault Code		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Read ECU Information		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Read Fault Code		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Erase Fault Code		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Live Data		Y		
308(T9)(after 2014.09)		Multifunction video camera(CMF)				Actuation Test		Y		
308S(T9)		BSI(Built-in Systems Interface)				Read ECU Information		Y		
308S(T9)		BSI(Built-in Systems Interface)				Read Fault Code		Y		
308S(T9)		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
308S(T9)		BSI(Built-in Systems Interface)				Live Data		Y		
308S(T9)		BSI(Built-in Systems Interface)				Actuation Test		Y		
308S(T9)		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
308S(T9)		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
308S(T9)		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
308S(T9)		Engine management ECU	V46_52			Read ECU Information		Y		
308S(T9)		Engine management ECU	V46_52			Read Fault Code		Y		
308S(T9)		Engine management ECU	V46_52			Erase Fault Code		Y		
308S(T9)		Engine management ECU	V46_52			Live Data		Y		
308S(T9)		Engine management ECU	V46_52			Actuation Test		Y		
308S(T9)		Engine management ECU	V46_52			Special Function	Pack Repair	Y		
308S(T9)		Engine management ECU	VD46			Read ECU Information		Y		
308S(T9)		Engine management ECU	VD46			Read Fault Code		Y		
308S(T9)		Engine management ECU	VD46			Erase Fault Code		Y		
308S(T9)		Engine management ECU	VD46			Live Data		Y		
308S(T9)		Engine management ECU	VD46			Actuation Test		Y		
308S(T9)		Engine management ECU	VD46			Special Function	Pack Repair	Y		
308S(T9)		Engine management ECU	MED17_4_4			Read ECU Information		Y		
308S(T9)		Engine management ECU	MED17_4_4			Read Fault Code		Y		
308S(T9)		Engine management ECU	MED17_4_4			Erase Fault Code		Y		
308S(T9)		Engine management ECU	MED17_4_4			Live Data		Y		
308S(T9)		Engine management ECU	MED17_4_4			Actuation Test		Y		
308S(T9)		Engine management ECU	MED17_4_4			Special Function	Pack Repair	Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read ECU Information		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read Fault Code		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Erase Fault Code		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Live Data		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Actuation Test		Y		
308S(T9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Special Function	Pack Repair	Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Live Data		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
308S(T9)		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
308S(T9)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
308S(T9)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
308S(T9)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
308S(T9)		Air bags and pre-tensioners control unit				Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308S(T9)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Read ECU Information		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Read Fault Code		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Erase Fault Code		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Live Data		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Actuation Test		Y		
308S(T9)		Telematic unit(RTX) or audio-navigation	MRN audio/navigation			Special Function	Configuration	Y		
308S(T9)		Control of the telematic unit				Read ECU Information		Y		
308S(T9)		Control of the telematic unit				Read Fault Code		Y		
308S(T9)		Control of the telematic unit				Erase Fault Code		Y		
308S(T9)		Control of the telematic unit				Live Data		Y		
308S(T9)		Control of the telematic unit				Actuation Test		Y		
308S(T9)		Power steering				Read ECU Information		Y		
308S(T9)		Power steering				Read Fault Code		Y		
308S(T9)		Power steering				Erase Fault Code		Y		
308S(T9)		Power steering				Live Data		Y		
308S(T9)		Power steering				Special Function	Configuration	Y		
308S(T9)		Rain and brightness sensor				Read ECU Information		Y		
308S(T9)		Rain and brightness sensor				Read Fault Code		Y		
308S(T9)		Rain and brightness sensor				Erase Fault Code		Y		
308S(T9)		Rain and brightness sensor				Live Data		Y		
308S(T9)		Rain and brightness sensor				Special Function	Pack Repair	Y		
308S(T9)		Driver's seat memorizing unit				Read ECU Information		Y		
308S(T9)		Driver's seat memorizing unit				Read Fault Code		Y		
308S(T9)		Driver's seat memorizing unit				Erase Fault Code		Y		
308S(T9)		Driver's seat memorizing unit				Live Data		Y		
308S(T9)		Driver's seat memorizing unit				Actuation Test		Y		
308S(T9)		Driver's seat memorizing unit				Special Function	Configuration	Y		
308S(T9)		Driver's seat memorizing unit				Special Function	Pack repair	Y		
308S(T9)		Engine relay unit				Read ECU Information		Y		
308S(T9)		Engine relay unit				Read Fault Code		Y		
308S(T9)		Engine relay unit				Erase Fault Code		Y		
308S(T9)		Engine relay unit				Special Function	Pack Repair	Y		
308S(T9)		Engine relay unit				Special Function	Configuration	Y		
308S(T9)		Control panel dot matrix display	No			Read ECU Information		Y		
308S(T9)		Control panel dot matrix display	No			Read Fault Code		Y		
308S(T9)		Control panel dot matrix display	No			Erase Fault Code		Y		
308S(T9)		Control panel dot matrix display	No			Actuation Test		Y		
308S(T9)		Control panel dot matrix display	Yes			Read ECU Information		Y		
308S(T9)		Control panel dot matrix display	Yes			Read Fault Code		Y		
308S(T9)		Control panel dot matrix display	Yes			Erase Fault Code		Y		
308S(T9)		Control panel dot matrix display	Yes			Actuation Test		Y		
308S(T9)		Control panel dot matrix display	Yes			Special Function	Configuration	Y		
308S(T9)		Supply protection and management unit				Read ECU Information		Y		
308S(T9)		Supply protection and management unit				Live Data		Y		
308S(T9)		Electric steering lock				Read ECU Information		Y		
308S(T9)		Electric steering lock				Read Fault Code		Y		
308S(T9)		Electric steering lock				Erase Fault Code		Y		
308S(T9)		Electric steering lock				Live Data		Y		
308S(T9)		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
308S(T9)		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
308S(T9)		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
308S(T9)		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
308S(T9)		Battery charge status unit				Read Fault Code		Y		
308S(T9)		Battery charge status unit				Erase Fault Code		Y		
308S(T9)		Battery charge status unit				Live Data		Y		
308S(T9)		Battery charge status unit				Special Function	Configuration	Y		
308S(T9)		Battery charge status unit				Special Function	Pack repair	Y		
308S(T9)		Radio				Read ECU Information		Y		
308S(T9)		Radio				Read Fault Code		Y		
308S(T9)		Radio				Erase Fault Code		Y		
308S(T9)		Radio				Live Data		Y		
308S(T9)		Radio				Actuation Test		Y		
308S(T9)		Radio				Special Function	Configuration	Y		
308S(T9)		Controls under the steering wheel	Yes			Read ECU Information		Y		
308S(T9)		Controls under the steering wheel	Yes			Read Fault Code		Y		
308S(T9)		Controls under the steering wheel	Yes			Erase Fault Code		Y		
308S(T9)		Controls under the steering wheel	Yes			Live Data		Y		
308S(T9)		Controls under the steering wheel	Yes			Actuation Test		Y		
308S(T9)		Controls under the steering wheel	Yes			Special Function	Pack Repair	Y		
308S(T9)		Controls under the steering wheel	No			Read ECU Information		Y		
308S(T9)		Controls under the steering wheel	No			Read Fault Code		Y		
308S(T9)		Controls under the steering wheel	No			Erase Fault Code		Y		
308S(T9)		Controls under the steering wheel	No			Live Data		Y		
308S(T9)		Controls under the steering wheel	No			Actuation Test		Y		
308S(T9)		Controls under the steering wheel	No			Special Function	Pack Repair	Y		
308S(T9)		Dynamic headlamp height adjuster				Read ECU Information		Y		
308S(T9)		Dynamic headlamp height adjuster				Read Fault Code		Y		
308S(T9)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
308S(T9)		Dynamic headlamp height adjuster				Live Data		Y		
308S(T9)		Dynamic headlamp height adjuster				Actuation Test		Y		
308S(T9)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
308S(T9)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Special Function	Configuration	Y		
308S(T9)		Multifunction screen	EMF_C_UDS			Special Function	Pack Repair	Y		
308S(T9)		Hands-free starting access electronic				Read ECU Information		Y		
308S(T9)		Hands-free starting access electronic				Read Fault Code		Y		
308S(T9)		Hands-free starting access electronic				Erase Fault Code		Y		
308S(T9)		Hands-free starting access electronic				Live Data		Y		
308S(T9)		Hands-free starting access electronic				Actuation Test		Y		
308S(T9)		Hands-free starting access electronic				Special Function	Configuration	Y		
308S(T9)		Hands-free starting access electronic				Special Function	Pack Repair	Y		
308S(T9)		Air conditioning				Read ECU Information		Y		
308S(T9)		Air conditioning				Read Fault Code		Y		
308S(T9)		Air conditioning				Erase Fault Code		Y		
308S(T9)		Air conditioning				Live Data		Y		
308S(T9)		Air conditioning				Actuation Test		Y		
308S(T9)		Air conditioning				Special Function	Pack Repair	Y		
308S(T9)		Touch screen				Read ECU Information		Y		
308S(T9)		Touch screen				Read Fault Code		Y		
308S(T9)		Touch screen				Erase Fault Code		Y		
308S(T9)		Touch screen				Live Data		Y		
308S(T9)		Touch screen				Actuation Test		Y		
308S(T9)		Touch screen				Special Function	Configuration	Y		
308S(T9)		Service module / Independent telematic unit	BTA_CN			Read ECU Information		Y		
308S(T9)		Service module / Independent telematic unit	BTA_CN			Read Fault Code		Y		
308S(T9)		Service module / Independent telematic unit	BTA_CN			Erase Fault Code		Y		
308S(T9)		Service module / Independent telematic unit	BTA_CN			Live Data		Y		
308S(T9)		Service module / Independent telematic unit	BTA_CN			Actuation Test		Y		
308S(T9)		Service module / Independent telematic unit	BTA_CN			Special Function	Pack Repair	Y		
308S(T9)		Anti-theft alarm				Read ECU Information		Y		
308S(T9)		Anti-theft alarm				Read Fault Code		Y		
308S(T9)		Anti-theft alarm				Erase Fault Code		Y		
308S(T9)		Anti-theft alarm				Live Data		Y		
308S(T9)		Anti-theft alarm				Actuation Test		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	Yes			Actuation Test		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
308S(T9)		Control on the steering wheel / integral controls steering wheel	No			Actuation Test		Y		
308S(T9)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
308S(T9)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		
308S(T9)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
308S(T9)		Parking assistance	4 parking assistance sensors			Live Data		Y		
308S(T9)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
308S(T9)		Parking assistance	4 parking assistance sensors			Special Function	Configuration	Y		
308S(T9)		Parking assistance	4 parking assistance sensors			Special Function	Pack Repair	Y		
308S(T9)		Parking assistance	8 parking assistance sensors			Read ECU Information		Y		
308S(T9)		Parking assistance	8 parking assistance sensors			Read Fault Code		Y		
308S(T9)		Parking assistance	8 parking assistance sensors			Erase Fault Code		Y		
308S(T9)		Parking assistance	8 parking assistance sensors			Live Data		Y		
308S(T9)		Parking assistance	8 parking assistance sensors			Actuation Test		Y		
308S(T9)		Parking assistance	8 parking assistance sensors			Special Function	Configuration	Y		
308S(T9)		Parking assistance	8 parking assistance sensors			Special Function	Pack Repair	Y		
308S(T9)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
308S(T9)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
308S(T9)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
308S(T9)		Parking assistance	10 parking assistance sensors			Live Data		Y		
308S(T9)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
308S(T9)		Parking assistance	10 parking assistance sensors			Special Function	Configuration	Y		
308S(T9)		Parking assistance	10 parking assistance sensors			Special Function	Pack Repair	Y		
308S(T9)		Parking assistance	12 parking assistance sensors			Read ECU Information		Y		
308S(T9)		Parking assistance	12 parking assistance sensors			Read Fault Code		Y		
308S(T9)		Parking assistance	12 parking assistance sensors			Erase Fault Code		Y		
308S(T9)		Parking assistance	12 parking assistance sensors			Live Data		Y		
308S(T9)		Parking assistance	12 parking assistance sensors			Actuation Test		Y		
308S(T9)		Parking assistance	12 parking assistance sensors			Special Function	Configuration	Y		
308S(T9)		Parking assistance	12 parking assistance sensors			Special Function	Pack Repair	Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read ECU Information		Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read Fault Code		Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Erase Fault Code		Y		
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308S(T9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Actuation Test		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Read ECU Information		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Read Fault Code		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Erase Fault Code		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Live Data		Y		
308S(T9)		Multiplexed control panel	MRN audio-navigation			Actuation Test		Y		
308S(T9)		Electronic key reader				Read ECU Information		Y		
308S(T9)		Electronic key reader				Read Fault Code		Y		
308S(T9)		Electronic key reader				Erase Fault Code		Y		
308S(T9)		Electronic key reader				Live Data		Y		
308 4 portes		Built-in Systems Interface (BSI)				Read ECU Information		Y		
308 4 portes		Built-in Systems Interface (BSI)				Read Fault Code		Y		
308 4 portes		Built-in Systems Interface (BSI)				Erase Fault Code		Y		
308 4 portes		Built-in Systems Interface (BSI)				Live Data		Y		
308 4 portes		Built-in Systems Interface (BSI)				Actuation Test		Y		
308 4 portes		Built-in Systems Interface (BSI)				Special Function	Maintenance - BSI operating mode	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO4		Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO4		Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO4		Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO4		Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO4		Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO4		Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO4		Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO4		Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO4		Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO4		Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO4		Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO4		Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO4		Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO4		Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO5	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO5	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO5	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO5	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO5	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO5	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO5	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6C	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6C	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6C	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6C	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6C	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6C	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6C	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6CM	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6CM	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6CM	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6CM	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6CM	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6CM	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP6CM	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP3C	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP3C	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP3C	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP3C	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP3C	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP3C	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2_EP3C	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6B	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6B	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6B	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6B	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6B	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6A	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6A	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6A	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6A	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6A	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 NFU	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 NFU	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 NFU	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 NFU	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 NFU	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6A	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6A	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6A	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6A	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6A	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6A	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6A	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 NFU	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 NFU	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 NFU	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 NFU	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 NFU	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 NFU	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 NFU	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6B	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6B	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6B	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6B	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6B	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6B	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	ME749	ME749 N6B	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFP	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME749_EC5	ME749_EC5 NFN	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	ME745_EC5		Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	ME745_EC5		Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME745_EC5		Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	ME745_EC5		Live Data		Y		
308 4 portes		Engine management ECU	Petrol	ME745_EC5		Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	ME745_EC5		Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	ME745_EC5		Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Actuation Test		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_4		Read ECU Information		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_4		Read Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_4		Erase Fault Code		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_4		Live Data		Y		
308 4 portes		Engine management ECU	Petrol	MED17_4_4		Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Special Function	Pack Repair	Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Read ECU Information		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Read Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Erase Fault Code		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Live Data		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Actuation Test		Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Special Function	Configuration	Y		
308 4 portes		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Special Function	Pack Repair	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read ECU Information		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Erase Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Live Data		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Actuation Test		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Configuration	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Pack Repair	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read ECU Information		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AT8			Erase Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AT8			Live Data		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AT8			Actuation Test		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Configuration	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Pack Repair	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6			Read ECU Information		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6			Read Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6			Erase Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6			Live Data		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6			Actuation Test		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6			Special Function	Configuration	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	BVA_AM6			Special Function	Pack Repair	Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
308 4 portes		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
308 4 portes		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Read ECU Information		Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Read Fault Code		Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Erase Fault Code		Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Live Data		Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Special Function	Configuration	Y		
308 4 portes		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Special Function	Pack Repair	Y		
308 4 portes		Power steering				Read ECU Information		Y		
308 4 portes		Power steering				Read Fault Code		Y		
308 4 portes		Power steering				Erase Fault Code		Y		
308 4 portes		Power steering				Live Data		Y		
308 4 portes		Power steering				Actuation Test		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_MGI			Read ECU Information		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_MGI			Read Fault Code		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_MGI			Erase Fault Code		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_MGI			Live Data		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_MGI			Actuation Test		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_MGI			Special Function	Configuration	Y		
308 4 portes		Diesel additive pump	POMPE_MUX_MGI			Special Function	Pack repair	Y		
308 4 portes		Diesel additive pump	POMPE_MUX_TI			Read ECU Information		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_TI			Read Fault Code		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_TI			Erase Fault Code		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_TI			Live Data		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_TI			Actuation Test		Y		
308 4 portes		Diesel additive pump	POMPE_MUX_TI			Special Function	Configuration	Y		
308 4 portes		Diesel additive pump	POMPE_MUX_TI			Special Function	Pack Reparation	Y		
308 4 portes		Under inflation detection				Read ECU Information		Y		
308 4 portes		Under inflation detection				Read Fault Code		Y		
308 4 portes		Under inflation detection				Erase Fault Code		Y		
308 4 portes		Under inflation detection				Live Data		Y		
308 4 portes		Under inflation detection				Special Function	Pack Reparation	Y		
308 4 portes		Dynamic headlamp height adjuster				Read ECU Information		Y		
308 4 portes		Dynamic headlamp height adjuster				Read Fault Code		Y		
308 4 portes		Dynamic headlamp height adjuster				Erase Fault Code		Y		
308 4 portes		Dynamic headlamp height adjuster				Live Data		Y		
308 4 portes		Dynamic headlamp height adjuster				Actuation Test		Y		
308 4 portes		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
308 4 portes		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
308 4 portes		Battery charge status unit	BECB			Read ECU Information		Y		
308 4 portes		Battery charge status unit	BECB			Read Fault Code		Y		
308 4 portes		Battery charge status unit	BECB			Erase Fault Code		Y		
308 4 portes		Battery charge status unit	BECB			Live Data		Y		
308 4 portes		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
308 4 portes		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
308 4 portes		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
308 4 portes		Battery charge status unit	BECB_GEN2			Live Data		Y		
308 4 portes		Battery charge status unit	BECB_GEN2			Special Function	Configuration	Y		
308 4 portes		Battery charge status unit	BECB_GEN2			Special Function	Pack repair	Y		
308 4 portes		Lane departure warning system				Read ECU Information		Y		
308 4 portes		Lane departure warning system				Read Fault Code		Y		
308 4 portes		Lane departure warning system				Erase Fault Code		Y		
308 4 portes		Lane departure warning system				Live Data		Y		
308 4 portes		Lane departure warning system				Actuation Test		Y		
308 4 portes		Lane departure warning system				Special Function	Configuration	Y		
308 4 portes		Engine relay unit				Read ECU Information		Y		
308 4 portes		Engine relay unit				Read Fault Code		Y		
308 4 portes		Engine relay unit				Erase Fault Code		Y		
308 4 portes		Engine relay unit				Actuation Test		Y		
308 4 portes		Multifunction screen	Type "A" (segments) With buttons			Read ECU Information		Y		
308 4 portes		Multifunction screen	Type "A" (segments) With buttons			Read Fault Code		Y		
308 4 portes		Multifunction screen	Type "A" (segments) With buttons			Erase Fault Code		Y		
308 4 portes		Multifunction screen	Type "A" (segments) With buttons			Live Data		Y		
308 4 portes		Multifunction screen	Type "A" (segments) With buttons			Actuation Test		Y		
308 4 portes		Multifunction screen	Type "A" (segments) With buttons			Special Function	Configuration	Y		
308 4 portes		Multifunction screen	Type "A" (segments) With buttons			Special Function	Pack Repair	Y		
308 4 portes		Multifunction screen	Type "A" (segments) Without button			Read ECU Information		Y		
308 4 portes		Multifunction screen	Type "A" (segments) Without button			Read Fault Code		Y		
308 4 portes		Multifunction screen	Type "A" (segments) Without button			Erase Fault Code		Y		
308 4 portes		Multifunction screen	Type "A" (segments) Without button			Live Data		Y		
308 4 portes		Multifunction screen	Type "A" (segments) Without button			Actuation Test		Y		
308 4 portes		Multifunction screen	Type "A" (segments) Without button			Special Function	Configuration	Y		
308 4 portes		Multifunction screen	Type "A" (segments) Without button			Special Function	Pack Repair	Y		
308 4 portes		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
308 4 portes		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
308 4 portes		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
308 4 portes		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
308 4 portes		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
308 4 portes		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
308 4 portes		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack Repair	Y		
308 4 portes		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
308 4 portes		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
308 4 portes		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
308 4 portes		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
308 4 portes		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
308 4 portes		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
308 4 portes		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack Repair	Y		
308 4 portes		Windscreen wiper				Read ECU Information		Y		
308 4 portes		Windscreen wiper				Actuation Test		Y		
308 4 portes		Windscreen wiper				Special Function	Configuration	Y		
308 4 portes		Windscreen wiper				Special Function	Pack Repair	Y		
308 4 portes		Windscreen wiper				Read ECU Information		Y		
308 4 portes		Windscreen wiper				Actuation Test		Y		
308 4 portes		Windscreen wiper				Special Function	Configuration	Y		
308 4 portes		Parking assistance	Parking aid			Read ECU Information		Y		
308 4 portes		Parking assistance	Parking aid			Read Fault Code		Y		
308 4 portes		Parking assistance	Parking aid			Erase Fault Code		Y		
308 4 portes		Parking assistance	Parking aid			Live Data		Y		
308 4 portes		Parking assistance	Parking aid			Special Function	Pack repair	Y		
308 4 portes		Air conditioning				Read ECU Information		Y		
308 4 portes		Air conditioning				Read Fault Code		Y		
308 4 portes		Air conditioning				Erase Fault Code		Y		
308 4 portes		Air conditioning				Live Data		Y		
308 4 portes		Air conditioning				Actuation Test		Y		
308 4 portes		Air conditioning				Special Function	Configuration	Y		
308 4 portes		Air conditioning				Special Function	Pack repair	Y		
308 4 portes		Controls under the steering wheel				Read ECU Information		Y		
308 4 portes		Controls under the steering wheel				Read Fault Code		Y		
308 4 portes		Controls under the steering wheel				Erase Fault Code		Y		
308 4 portes		Controls under the steering wheel				Live Data		Y		
308 4 portes		Controls under the steering wheel				Actuation Test		Y		
308 4 portes		Controls under the steering wheel				Special Function	Pack Repair	Y		
308 4 portes		Instrument panel				Read ECU Information		Y		
308 4 portes		Instrument panel				Read Fault Code		Y		
308 4 portes		Instrument panel				Erase Fault Code		Y		
308 4 portes		Instrument panel				Live Data		Y		
308 4 portes		Instrument panel				Actuation Test		Y		
308 4 portes		Instrument panel				Special Function	Configuration	Y		
308 4 portes		CD changer / external CD player				Read ECU Information		Y		
308 4 portes		CD changer / external CD player				Read Fault Code		Y		
308 4 portes		CD changer / external CD player				Erase Fault Code		Y		
308 4 portes		CD changer / external CD player				Actuation Test		Y		
308 4 portes		CD changer / external CD player				Special Function	Configuration	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Special Function	Configuration	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Special Function	Configuration	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Configuration	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Pack repair	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Special Function	Configuration	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Special Function	Configuration	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Configuration	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Pack repair	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Read ECU Information		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Read Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Erase Fault Code		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Live Data		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Actuation Test		Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Special Function	Configuration	Y		
308 4 portes		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Special Function	Pack repair	Y		
308 4 portes		Radio amplifier				Read ECU Information		Y		
308 4 portes		Radio amplifier				Read Fault Code		Y		
308 4 portes		Radio amplifier				Erase Fault Code		Y		
308 4 portes		Radio amplifier				Actuation Test		Y		
308 4 portes		Radio amplifier				Special Function	Configuration	Y		
308 4 portes		Radio amplifier				Special Function	Pack Repair	Y		
308 4 portes		Hands-free Kit / Portable Unit	KML			Read ECU Information		Y		
308 4 portes		Hands-free Kit / Portable Unit	KML			Read Fault Code		Y		
308 4 portes		Hands-free Kit / Portable Unit	KML			Erase Fault Code		Y		
308 4 portes		Hands-free Kit / Portable Unit	KML			Live Data		Y		
308 4 portes		Hands-free Kit / Portable Unit	KML			Actuation Test		Y		
308 4 portes		Hands-free Kit / Portable Unit	KML			Special Function	Configuration	Y		
308 4 portes		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read ECU Information		Y		
308 4 portes		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read Fault Code		Y		
308 4 portes		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Erase Fault Code		Y		
308 4 portes		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Live Data		Y		
308 4 portes		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Actuation Test		Y		
308 4 portes		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Special Function	Configuration	Y		
308 4 portes		Seat driver position memory module				Read ECU Information		Y		
308 4 portes		Seat driver position memory module				Read Fault Code		Y		
308 4 portes		Seat driver position memory module				Erase Fault Code		Y		
308 4 portes		Seat driver position memory module				Live Data		Y		
308 4 portes		Seat driver position memory module				Actuation Test		Y		
308 4 portes		Seat driver position memory module				Special Function	Configuration	Y		
308 4 portes		Seat driver position memory module				Special Function	Pack repair	Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift module			Read ECU Information		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift module			Read Fault Code		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift module			Erase Fault Code		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift module			Live Data		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift module			Actuation Test		Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift module			Special Function	Configuration	Y		
308 4 portes		Anti-theft alarm	Alarm with anti-lift module			Special Function	Pack repair	Y		
308 4 portes		Anti-theft alarm				Read ECU Information		Y		
308 4 portes		Anti-theft alarm				Read Fault Code		Y		
308 4 portes		Anti-theft alarm				Erase Fault Code		Y		
308 4 portes		Anti-theft alarm				Live Data		Y		
308 4 portes		Anti-theft alarm				Special Function	Configuration	Y		
308 4 portes		Anti-theft alarm				Special Function	Pack repair	Y		
308 4 portes		Seat passenger position memory module				Read ECU Information		Y		
308 4 portes		Seat passenger position memory module				Read Fault Code		Y		
308 4 portes		Seat passenger position memory module				Erase Fault Code		Y		
308 4 portes		Seat passenger position memory module				Live Data		Y		
308 4 portes		Seat passenger position memory module				Actuation Test		Y		
308 4 portes		Seat passenger position memory module				Special Function	Configuration	Y		
308 4 portes		Seat passenger position memory module				Special Function	Pack repair	Y		
308 4 portes		Driver's door module	Driver's door module			Read ECU Information		Y		
308 4 portes		Driver's door module	Driver's door module			Read Fault Code		Y		
308 4 portes		Driver's door module	Driver's door module			Erase Fault Code		Y		
308 4 portes		Driver's door module	Driver's door module			Live Data		Y		
308 4 portes		Driver's door module	Driver's door module			Actuation Test		Y		
308 4 portes		Sunroof				Read ECU Information		Y		
308 4 portes		Sunroof				Read Fault Code		Y		
308 4 portes		Sunroof				Erase Fault Code		Y		
308 4 portes		Sunroof				Live Data		Y		
308 4 portes		Sunroof				Actuation Test		Y		
308 4 portes		Sunroof				Special Function	Pack repair	Y		
308 4 portes		Moving panel deflector				Read ECU Information		Y		
308 4 portes		Moving panel deflector				Read Fault Code		Y		
308 4 portes		Moving panel deflector				Erase Fault Code		Y		
308 4 portes		Moving panel deflector				Live Data		Y		
308 4 portes		Moving panel deflector				Actuation Test		Y		
308 4 portes		Moving panel deflector				Special Function	Pack repair	Y		
308 4 portes		Folding roof				Read ECU Information		Y		
308 4 portes		Folding roof				Read Fault Code		Y		
308 4 portes		Folding roof				Erase Fault Code		Y		
308 4 portes		Folding roof				Live Data		Y		
308 4 portes		Folding roof				Actuation Test		Y		
308 4 portes		Folding roof				Special Function	Pack Repair	Y		
308 4 portes		Service module / Independent telematic unit	MD_SERV			Read ECU Information		Y		
308 4 portes		Service module / Independent telematic unit	MD_SERV			Read Fault Code		Y		
308 4 portes		Service module / Independent telematic unit	MD_SERV			Erase Fault Code		Y		
308 4 portes		Service module / Independent telematic unit	MD_SERV			Live Data		Y		
308 4 portes		Service module / Independent telematic unit	MD_SERV			Actuation Test		Y		
308 4 portes		Service module / Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
308 4 portes		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Live Data		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Actuation Test		Y		
308 4 portes		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
308 4 portes		Driving school module				Read ECU Information		Y		
308 4 portes		Driving school module				Actuation Test		Y		
308 4 portes		Rain and light sensor				Read ECU Information		Y		
308 4 portes		Rain and light sensor				Read Fault Code		Y		
308 4 portes		Rain and light sensor				Erase Fault Code		Y		
308 4 portes		Seat belt not fastened warning lights unit				Read ECU Information		Y		
308 4 portes		Seat belt not fastened warning lights unit				Actuation Test		Y		
308 4 portes		Control panel dot matrix display				Read ECU Information		Y		
308 4 portes		Control panel dot matrix display				Read Fault Code		Y		
308 4 portes		Control panel dot matrix display				Erase Fault Code		Y		
308 4 portes		Control panel dot matrix display				Live Data		Y		
308 4 portes		Control panel dot matrix display				Actuation Test		Y		
308 4 portes		Control panel dot matrix display				Special Function	Configuration	Y		
308(TX9)		Engine management ECU	VD46			Read ECU Information		Y		
308(TX9)		Engine management ECU	VD46			Read Fault Code		Y		
308(TX9)		Engine management ECU	VD46			Erase Fault Code		Y		
308(TX9)		Engine management ECU	VD46			Live Data		Y		
308(TX9)		Engine management ECU	VD46			Actuation Test		Y		
308(TX9)		Engine management ECU	VD46			Special Function	Pack Repair	Y		
308(TX9)		Engine management ECU	V46_52			Read ECU Information		Y		
308(TX9)		Engine management ECU	V46_52			Read Fault Code		Y		
308(TX9)		Engine management ECU	V46_52			Erase Fault Code		Y		
308(TX9)		Engine management ECU	V46_52			Live Data		Y		
308(TX9)		Engine management ECU	V46_52			Actuation Test		Y		
308(TX9)		Engine management ECU	V46_52			Special Function	Pack Repair	Y		
308(TX9)		Engine management ECU	MED17_4_4			Read ECU Information		Y		
308(TX9)		Engine management ECU	MED17_4_4			Read Fault Code		Y		
308(TX9)		Engine management ECU	MED17_4_4			Erase Fault Code		Y		
308(TX9)		Engine management ECU	MED17_4_4			Live Data		Y		
308(TX9)		Engine management ECU	MED17_4_4			Actuation Test		Y		
308(TX9)		Engine management ECU	MED17_4_4			Special Function	Pack Repair	Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
308(TX9)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Live Data		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
308(TX9)		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
308(TX9)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
308(TX9)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
308(TX9)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
308(TX9)		Air bags and pre-tensioners control unit				Live Data		Y		
308(TX9)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
308(TX9)		Electric steering lock				Read ECU Information		Y		
308(TX9)		Electric steering lock				Read Fault Code		Y		
308(TX9)		Electric steering lock				Erase Fault Code		Y		
308(TX9)		Electric steering lock				Live Data		Y		
308(TX9)		Rain and brightness sensor				Read ECU Information		Y		
308(TX9)		Rain and brightness sensor				Read Fault Code		Y		
308(TX9)		Rain and brightness sensor				Erase Fault Code		Y		
308(TX9)		Rain and brightness sensor				Live Data		Y		
308(TX9)		Rain and brightness sensor				Special Function	Pack Repair	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
308(TX9)		Audio-navigation/telematic unit/connected audio system				Read ECU Information		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Read Fault Code		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Erase Fault Code		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Live Data		Y		
308(TX9)		Audio-navigation/telematic unit/connected audio system				Actuation Test		Y		
308(TX9)		Service module / Independent telematic unit				Read ECU Information		Y		
308(TX9)		Service module / Independent telematic unit				Read Fault Code		Y		
308(TX9)		Service module / Independent telematic unit				Erase Fault Code		Y		
308(TX9)		Service module / Independent telematic unit				Live Data		Y		
308(TX9)		Service module / Independent telematic unit				Actuation Test		Y		
308(TX9)		Service module / Independent telematic unit				Special Function	Pack Repair	Y		
308(TX9)		Power steering				Read ECU Information		Y		
308(TX9)		Power steering				Read Fault Code		Y		
308(TX9)		Power steering				Erase Fault Code		Y		
308(TX9)		Power steering				Live Data		Y		
308(TX9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read ECU Information		Y		
308(TX9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read Fault Code		Y		
308(TX9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Erase Fault Code		Y		
308(TX9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Live Data		Y		
308(TX9)		Multiplexed control panel	RD45 audio system and manual air conditioning			Actuation Test		Y		
308(TX9)		Multiplexed control panel	Audio/Navigation NAC			Read ECU Information		Y		
308(TX9)		Multiplexed control panel	Audio/Navigation NAC			Read Fault Code		Y		
308(TX9)		Multiplexed control panel	Audio/Navigation NAC			Erase Fault Code		Y		
308(TX9)		Multiplexed control panel	Audio/Navigation NAC			Actuation Test		Y		
308(TX9)		Controls under the steering wheel				Read ECU Information		Y		
308(TX9)		Controls under the steering wheel				Read Fault Code		Y		
308(TX9)		Controls under the steering wheel				Erase Fault Code		Y		
308(TX9)		Controls under the steering wheel				Live Data		Y		
308(TX9)		Controls under the steering wheel				Actuation Test		Y		
308(TX9)		Control panel dot matrix display	Colour matrix screen			Read ECU Information		Y		
308(TX9)		Control panel dot matrix display	Colour matrix screen			Read Fault Code		Y		
308(TX9)		Control panel dot matrix display	Colour matrix screen			Erase Fault Code		Y		
308(TX9)		Control panel dot matrix display	Colour matrix screen			Actuation Test		Y		
308(TX9)		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
308(TX9)		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
308(TX9)		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
308(TX9)		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
308(TX9)		Air conditioning				Read ECU Information		Y		
308(TX9)		Air conditioning				Read Fault Code		Y		
308(TX9)		Air conditioning				Erase Fault Code		Y		
308(TX9)		Air conditioning				Live Data		Y		
308(TX9)		Air conditioning				Actuation Test		Y		
308(TX9)		Air conditioning				Special Function	Pack Repair	Y		
308(TX9)		Battery charge status unit				Read ECU Information		Y		
308(TX9)		Battery charge status unit				Read Fault Code		Y		
308(TX9)		Battery charge status unit				Erase Fault Code		Y		
308(TX9)		Battery charge status unit				Live Data		Y		
308(TX9)		Battery charge status unit				Special Function	Configuration	Y		
308(TX9)		Battery charge status unit				Special Function	Pack repair	Y		
308(TX9)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
308(TX9)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		
308(TX9)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
308(TX9)		Parking assistance	4 parking assistance sensors			Live Data		Y		
308(TX9)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
308(TX9)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
308(TX9)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
308(TX9)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
308(TX9)		Parking assistance	10 parking assistance sensors			Live Data		Y		
308(TX9)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
308(TX9)		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
308(TX9)		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
308(TX9)		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
308(TX9)		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
308(TX9)		Radio				Read ECU Information		Y		
308(TX9)		Radio				Read Fault Code		Y		
308(TX9)		Radio				Erase Fault Code		Y		
308(TX9)		Radio				Live Data		Y		
308(TX9)		Radio				Actuation Test		Y		
308(TX9)		Radio				Special Function	Configuration	Y		
308(TX9)		Radio				Special Function	Pack repair	Y		
308(TX9)		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
308(TX9)		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
308(TX9)		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
308(TX9)		Touch screen				Read ECU Information		Y		
308(TX9)		Touch screen				Read Fault Code		Y		
308(TX9)		Touch screen				Erase Fault Code		Y		
308(TX9)		Touch screen				Live Data		Y		
308(TX9)		Touch screen				Actuation Test		Y		
308(TX9)		Touch screen				Special Function	Configuration	Y		
406		Engine	Petrol	LFX MM1AP		Read ECU Information		Y		
406		Engine	Petrol	LFX MM1AP		Read Fault Code		Y		
406		Engine	Petrol	LFX MM1AP		Erase Fault Code		Y		
406		Engine	Petrol	LFX MM1AP		Live Data		Y		
406		Engine	Petrol	LFX MM1AP		Actuation Test		Y		
406		Engine	Petrol	LFX BOSCH MP7.3		Read ECU Information		Y		
406		Engine	Petrol	LFX BOSCH MP7.3		Read Fault Code		Y		
406		Engine	Petrol	LFX BOSCH MP7.3		Erase Fault Code		Y		
406		Engine	Petrol	LFX BOSCH MP7.3		Live Data		Y		
406		Engine	Petrol	LFX BOSCH MP7.3		Actuation Test		Y		
406		Engine	Petrol	LFY SAGEM SL 96		Read ECU Information		Y		
406		Engine	Petrol	LFY SAGEM SL 96		Read Fault Code		Y		
406		Engine	Petrol	LFY SAGEM SL 96		Erase Fault Code		Y		
406		Engine	Petrol	LFY SAGEM SL 96		Live Data		Y		
406		Engine	Petrol	LFY SAGEM SL 96		Actuation Test		Y		
406		Engine	Petrol	XFZ BOSCH MP7.0		Read ECU Information		Y		
406		Engine	Petrol	XFZ BOSCH MP7.0		Read Fault Code		Y		
406		Engine	Petrol	XFZ BOSCH MP7.0		Erase Fault Code		Y		
406		Engine	Petrol	XFZ BOSCH MP7.0		Live Data		Y		
406		Engine	Petrol	XFZ BOSCH MP7.0		Actuation Test		Y		
406		Engine	Diesel	P8C LUCAS EP1C		Read ECU Information		Y		
406		Engine	Diesel	P8C LUCAS EP1C		Live Data		Y		
406		Engine	Diesel	RHZ BOSCH EDC15C2		Read ECU Information		Y		
406		Engine	Diesel	RHZ BOSCH EDC15C2		Read Fault Code		Y		
406		Engine	Diesel	RHZ BOSCH EDC15C2		Erase Fault Code		Y		
406		Engine	Diesel	RHZ BOSCH EDC15C2		Live Data		Y		
406		Engine	Diesel	RHZ BOSCH EDC15C2		Actuation Test		Y		
406		Automatic gearbox	4HP20 automatic gearbox			Read ECU Information		Y		
406		Automatic gearbox	4HP20 automatic gearbox			Read Fault Code		Y		
406		Automatic gearbox	4HP20 automatic gearbox			Erase Fault Code		Y		
406		Automatic gearbox	4HP20 automatic gearbox			Live Data		Y		
406		Automatic gearbox	4HP20 automatic gearbox			Actuation Test		Y		
406		Automatic gearbox	BVA_AL4_AT8			Read ECU Information		Y		
406		Automatic gearbox	BVA_AL4_AT8			Read Fault Code		Y		
406		Automatic gearbox	BVA_AL4_AT8			Erase Fault Code		Y		
406		Automatic gearbox	BVA_AL4_AT8			Live Data		Y		
406		Automatic gearbox	BVA_AL4_AT8			Actuation Test		Y		
406		Active safety	ABS5 BOSCH			Read ECU Information		Y		
406		Active safety	ABS5 BOSCH			Read Fault Code		Y		
406		Active safety	ABS5 BOSCH			Erase Fault Code		Y		
406		Active safety	ABS5 BOSCH			Live Data		Y		
406		Active safety	ABS5 BOSCH			Actuation Test		Y		
406		Active safety	ABS5 BOSCH 5.3			Read ECU Information		Y		
406		Active safety	ABS5 BOSCH 5.3			Read Fault Code		Y		
406		Active safety	ABS5 BOSCH 5.3			Erase Fault Code		Y		
406		Active safety	ABS5 BOSCH 5.3			Live Data		Y		
406		Active safety	ABS5 BOSCH 5.3			Actuation Test		Y		
406		Active safety	ABS5 BOSCH 5.3			Special Function	Bleeding	Y		
406		Airbags	Side airbag (right side)			Read ECU Information		Y		
406		Airbags	Side airbag (right side)			Read Fault Code		Y		
406		Airbags	Side airbag (right side)			Erase Fault Code		Y		
406		Airbags	Side airbag (right side)			Actuation Test		Y		
406		Airbags	Side airbag (left side)			Read ECU Information		Y		
406		Airbags	Side airbag (left side)			Read Fault Code		Y		
406		Airbags	Side airbag (left side)			Erase Fault Code		Y		
406		Airbags	Side airbag (left side)			Actuation Test		Y		
406		Protect the vehicle	Transponder peugeot	Engine type BFZ		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type BFZ		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type BFZ		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type BFZ		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHV		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHV		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHV		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHV		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHW		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHW		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHW		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHW		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHX		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHX		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHX		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type DHX		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type L6A		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type L6A		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type L6A		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type L6A		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFX		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFX		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFX		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFX		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.BOSCH MP5.2 system		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.BOSCH MP5.2 system		Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
406		Protect the vehicle	Transponder peugeot	Engine type LFY.BOSCH MP5.2 system		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.BOSCH MP5.2 system		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.BOSCH MP7.3 system		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.BOSCH MP7.3 system		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.BOSCH MP7.3 system		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.BOSCH MP7.3 system		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.SAGEM SL96 system		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.SAGEM SL96 system		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.SAGEM SL96 system		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type LFY.SAGEM SL96 system		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type P8C		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type P8C		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type P8C		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type P8C		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type R6E		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type R6E		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type R6E		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type R6E		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RFV		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RFV		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RFV		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RFV		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RGX		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RGX		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RGX		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RGX		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RHZ		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RHZ		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RHZ		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type RHZ		Live Data		Y		
406		Protect the vehicle	Transponder peugeot	Engine type XFZ		Read ECU Information		Y		
406		Protect the vehicle	Transponder peugeot	Engine type XFZ		Read Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type XFZ		Erase Fault Code		Y		
406		Protect the vehicle	Transponder peugeot	Engine type XFZ		Live Data		Y		
406		Electronically managed suspension				Read ECU Information		Y		
406		Electronically managed suspension				Read Fault Code		Y		
406		Electronically managed suspension				Erase Fault Code		Y		
406		Electronically managed suspension				Live Data		Y		
406		Variable power steering				Read ECU Information		Y		
406		Variable power steering				Read Fault Code		Y		
406		Variable power steering				Erase Fault Code		Y		
406		Seat and mirrors with memory				Read ECU Information		Y		
406		Seat and mirrors with memory				Read Fault Code		Y		
406		Seat and mirrors with memory				Erase Fault Code		Y		
406		Seat and mirrors with memory				Live Data		Y		
406 COUPE		Engine	Petrol	XFZ BOSCH MP7.0		Read ECU Information		Y		
406 COUPE		Engine	Petrol	XFZ BOSCH MP7.0		Read Fault Code		Y		
406 COUPE		Engine	Petrol	XFZ BOSCH MP7.0		Erase Fault Code		Y		
406 COUPE		Engine	Petrol	XFZ BOSCH MP7.0		Live Data		Y		
406 COUPE		Engine	Petrol	XFZ BOSCH MP7.0		Actuation Test		Y		
406 COUPE		Airbags	Side airbag (right side)			Read ECU Information		Y		
406 COUPE		Airbags	Side airbag (right side)			Read Fault Code		Y		
406 COUPE		Airbags	Side airbag (right side)			Erase Fault Code		Y		
406 COUPE		Airbags	Side airbag (right side)			Actuation Test		Y		
406 COUPE		Airbags	Side airbag (left side)			Read ECU Information		Y		
406 COUPE		Airbags	Side airbag (left side)			Read Fault Code		Y		
406 COUPE		Airbags	Side airbag (left side)			Erase Fault Code		Y		
406 COUPE		Airbags	Side airbag (left side)			Actuation Test		Y		
406 COUPE		Transponder peugeot	Engine type R6E			Read ECU Information		Y		
406 COUPE		Transponder peugeot	Engine type R6E			Read Fault Code		Y		
406 COUPE		Transponder peugeot	Engine type R6E			Erase Fault Code		Y		
406 COUPE		Transponder peugeot	Engine type R6E			Live Data		Y		
406 COUPE		Transponder peugeot	Engine type RFV			Read ECU Information		Y		
406 COUPE		Transponder peugeot	Engine type RFV			Read Fault Code		Y		
406 COUPE		Transponder peugeot	Engine type RFV			Erase Fault Code		Y		
406 COUPE		Transponder peugeot	Engine type RFV			Live Data		Y		
406 COUPE		Transponder peugeot	Engine type XFZ			Read ECU Information		Y		
406 COUPE		Transponder peugeot	Engine type XFZ			Read Fault Code		Y		
406 COUPE		Transponder peugeot	Engine type XFZ			Erase Fault Code		Y		
406 COUPE		Transponder peugeot	Engine type XFZ			Live Data		Y		
406 COUPE		Variable power steering				Read ECU Information		Y		
406 COUPE		Variable power steering				Read Fault Code		Y		
406 COUPE		Variable power steering				Erase Fault Code		Y		
406 COUPE		Seat and mirrors with memory				Read ECU Information		Y		
406 COUPE		Seat and mirrors with memory				Read Fault Code		Y		
406 COUPE		Seat and mirrors with memory				Erase Fault Code		Y		
406 COUPE		Seat and mirrors with memory				Live Data		Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type 3FZ	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type 4HX	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type 6FZ	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type BFZ	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type L6A	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type LFX	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type LFY BOSCH MP5.2 system	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type LFY BOSCH MP7.3 system	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type LFY SAGEM SL96 system	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type R6E	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type R6F	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RFN	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RFR	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RFV	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RHY	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RHZ	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RLZ	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type XFX	Y		
406R	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type XFZ	Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_1		Read ECU Information		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_1		Read Fault Code		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_1		Erase Fault Code		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_1		Live Data		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Read ECU Information		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Read Fault Code		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Erase Fault Code		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Live Data		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Actuation Test		Y		
406R	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Special Function	Initialising the autoadaptives	Y		
406R	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Read ECU Information		Y		
406R	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Read Fault Code		Y		
406R	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Live Data		Y		
406R	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Actuation Test		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Read ECU Information		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Read Fault Code		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Live Data		Y		
406R	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Actuation Test		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Read ECU Information		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Read Fault Code		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Live Data		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Actuation Test		Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Calibration of the steering wheel angle sensor	Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		
406R	Production date before 30 June 2001	Airbags	Air bag and seat belt			Read ECU Information		Y		
406R	Production date before 30 June 2001	Airbags	Air bag and seat belt			Read Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Air bag and seat belt			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (right side)			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
406R	Production date before 30 June 2001	Airbags	Side airbag (right side)			Read Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (right side)			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (right side)			Actuation Test		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (left side)			Read ECU Information		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (left side)			Read Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (left side)			Erase Fault Code		Y		
406R	Production date before 30 June 2001	Airbags	Side airbag (left side)			Actuation Test		Y		
406R	Production date before 30 June 2001	Multifunction display				Read ECU Information		Y		
406R	Production date before 30 June 2001	Multifunction display				Read Fault Code		Y		
406R	Production date before 30 June 2001	Multifunction display				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Multifunction display				Live Data		Y		
406R	Production date before 30 June 2001	Multifunction display				Actuation Test		Y		
406R	Production date before 30 June 2001	Radio				Read ECU Information		Y		
406R	Production date before 30 June 2001	Radio				Read Fault Code		Y		
406R	Production date before 30 June 2001	Radio				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Radio				Live Data		Y		
406R	Production date before 30 June 2001	Radio				Actuation Test		Y		
406R	Production date before 30 June 2001	CD player				Read ECU Information		Y		
406R	Production date before 30 June 2001	CD player				Read Fault Code		Y		
406R	Production date before 30 June 2001	CD player				Erase Fault Code		Y		
406R	Production date before 30 June 2001	CD player				Live Data		Y		
406R	Production date before 30 June 2001	CD player				Actuation Test		Y		
406R	Production date before 30 June 2001	Instrument panel				Read ECU Information		Y		
406R	Production date before 30 June 2001	Instrument panel				Read Fault Code		Y		
406R	Production date before 30 June 2001	Instrument panel				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Instrument panel				Live Data		Y		
406R	Production date before 30 June 2001	On-board navigation system				Read ECU Information		Y		
406R	Production date before 30 June 2001	On-board navigation system				Read Fault Code		Y		
406R	Production date before 30 June 2001	On-board navigation system				Erase Fault Code		Y		
406R	Production date before 30 June 2001	On-board navigation system				Live Data		Y		
406R	Production date before 30 June 2001	Heating/ventilation				Read ECU Information		Y		
406R	Production date before 30 June 2001	Heating/ventilation				Read Fault Code		Y		
406R	Production date before 30 June 2001	Heating/ventilation				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Heating/ventilation				Live Data		Y		
406R	Production date before 30 June 2001	Heating/ventilation				Actuation Test		Y		
406R	Production date before 30 June 2001	Electronically managed suspension				Read ECU Information		Y		
406R	Production date before 30 June 2001	Electronically managed suspension				Read Fault Code		Y		
406R	Production date before 30 June 2001	Electronically managed suspension				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Electronically managed suspension				Live Data		Y		
406R	Production date before 30 June 2001	Variable power steering				Read ECU Information		Y		
406R	Production date before 30 June 2001	Variable power steering				Read Fault Code		Y		
406R	Production date before 30 June 2001	Variable power steering				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Seat position memory ECU				Read ECU Information		Y		
406R	Production date before 30 June 2001	Seat position memory ECU				Read Fault Code		Y		
406R	Production date before 30 June 2001	Seat position memory ECU				Erase Fault Code		Y		
406R	Production date before 30 June 2001	Seat position memory ECU				Live Data		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Live Data		Y		
406R	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Read ECU Information		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Read Fault Code		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Erase Fault Code		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Live Data		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Actuation Test		Y		
406R	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Special Function	Bleeding	Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Read ECU Information		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Read Fault Code		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Erase Fault Code		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Live Data		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Actuation Test		Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Calibration of the steering wheel angle sensor	Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		
406R	Production date after 30 June 2001	Airbags				Read ECU Information		Y		
406R	Production date after 30 June 2001	Airbags				Read Fault Code		Y		
406R	Production date after 30 June 2001	Airbags				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Programming of the built-in systems interface (Engine immobiliser code and				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
406R	Production date after 30 June 2001	Alarm				Read ECU Information		Y		
406R	Production date after 30 June 2001	Alarm				Read Fault Code		Y		
406R	Production date after 30 June 2001	Alarm				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Alarm				Live Data		Y		
406R	Production date after 30 June 2001	Alarm				Actuation Test		Y		
406R	Production date after 30 June 2001	Multifunction display				Read ECU Information		Y		
406R	Production date after 30 June 2001	Multifunction display				Read Fault Code		Y		
406R	Production date after 30 June 2001	Multifunction display				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Multifunction display				Live Data		Y		
406R	Production date after 30 June 2001	Multifunction display				Actuation Test		Y		
406R	Production date after 30 June 2001	Instrument panel				Read ECU Information		Y		
406R	Production date after 30 June 2001	Instrument panel				Read Fault Code		Y		
406R	Production date after 30 June 2001	Instrument panel				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Instrument panel				Live Data		Y		
406R	Production date after 30 June 2001	Instrument panel				Actuation Test		Y		
406R	Production date after 30 June 2001	Radio				Read ECU Information		Y		
406R	Production date after 30 June 2001	Radio				Read Fault Code		Y		
406R	Production date after 30 June 2001	Radio				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Radio				Live Data		Y		
406R	Production date after 30 June 2001	Radio				Actuation Test		Y		
406R	Production date after 30 June 2001	CD player				Read ECU Information		Y		
406R	Production date after 30 June 2001	CD player				Read Fault Code		Y		
406R	Production date after 30 June 2001	CD player				Erase Fault Code		Y		
406R	Production date after 30 June 2001	CD player				Live Data		Y		
406R	Production date after 30 June 2001	CD player				Actuation Test		Y		
406R	Production date after 30 June 2001	On-board navigation system				Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
406R	Production date after 30 June 2001	On-board navigation system				Read Fault Code		Y		
406R	Production date after 30 June 2001	On-board navigation system				Erase Fault Code		Y		
406R	Production date after 30 June 2001	On-board navigation system				Live Data		Y		
406R	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
406R	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
406R	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Live Data		Y		
406R	Production date after 30 June 2001	Rain/sunlight sensor				Read ECU Information		Y		
406R	Production date after 30 June 2001	Rain/sunlight sensor				Read Fault Code		Y		
406R	Production date after 30 June 2001	Rain/sunlight sensor				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Heating/ventilation				Read ECU Information		Y		
406R	Production date after 30 June 2001	Heating/ventilation				Read Fault Code		Y		
406R	Production date after 30 June 2001	Heating/ventilation				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Heating/ventilation				Live Data		Y		
406R	Production date after 30 June 2001	Heating/ventilation				Actuation Test		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Read ECU Information		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Read Fault Code		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Live Data		Y		
406R	Production date after 30 June 2001	Diesel fuel additive control unit				Actuation Test		Y		
406R	Production date after 30 June 2001	Variable power steering				Read ECU Information		Y		
406R	Production date after 30 June 2001	Variable power steering				Read Fault Code		Y		
406R	Production date after 30 June 2001	Variable power steering				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Seat position memory ECU				Read ECU Information		Y		
406R	Production date after 30 June 2001	Seat position memory ECU				Read Fault Code		Y		
406R	Production date after 30 June 2001	Seat position memory ECU				Erase Fault Code		Y		
406R	Production date after 30 June 2001	Seat position memory ECU				Live Data		Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type 3FZ	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type 4HX	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type 6FZ	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type BFZ	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type L6A	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type LFX	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type LFY BOSCH MP5.2 system	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type LFY BOSCH MP7.3 system	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type LFY SAGEM SL96 system	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type R6E	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type R6F	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RFN	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RFR	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RFV	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RHY	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RHZ	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type RLZ	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type XFX	Y		
406R COUPE	Production date before 30 June 2001	BSI(Built-in Systems Interface)				Special Function	Engine type XFZ	Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_1		Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_1		Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_1		Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_1		Live Data		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Live Data		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	4HP20 automatic gearbox	4HP20_2		Special Function	Initialising the autoadaptives	Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Live Data		Y		
406R COUPE	Production date before 30 June 2001	Automatic gearbox	BVA_AL4_AT8			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Live Data		Y		
406R COUPE	Production date before 30 June 2001	Active safety	BOSCH ABS 5.3			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Live Data		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Calibration of the steering wheel angle sensor	Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R COUPE	Production date before 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		
406R COUPE	Production date before 30 June 2001	Airbags	Air bag and seat belt			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Air bag and seat belt			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Air bag and seat belt			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (right side)			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (right side)			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (right side)			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (right side)			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (left side)			Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (left side)			Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (left side)			Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Airbags	Side airbag (left side)			Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Live Data		Y		
406R COUPE	Production date before 30 June 2001	Multifunction display				Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Radio				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Radio				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Radio				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Radio				Live Data		Y		
406R COUPE	Production date before 30 June 2001	Radio				Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
406R COUPE	Production date before 30 June 2001	CD player				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	CD player				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	CD player				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	CD player				Live Data		Y		
406R COUPE	Production date before 30 June 2001	CD player				Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Instrument panel				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Instrument panel				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Instrument panel				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Instrument panel				Live Data		Y		
406R COUPE	Production date before 30 June 2001	On-board navigation system				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	On-board navigation system				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	On-board navigation system				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	On-board navigation system				Live Data		Y		
406R COUPE	Production date before 30 June 2001	Heating/ventilation				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Heating/ventilation				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Heating/ventilation				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Heating/ventilation				Live Data		Y		
406R COUPE	Production date before 30 June 2001	Heating/ventilation				Actuation Test		Y		
406R COUPE	Production date before 30 June 2001	Electronically managed suspension				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Electronically managed suspension				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Electronically managed suspension				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Electronically managed suspension				Live Data		Y		
406R COUPE	Production date before 30 June 2001	Variable power steering				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Variable power steering				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Variable power steering				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Seat position memory ECU				Read ECU Information		Y		
406R COUPE	Production date before 30 June 2001	Seat position memory ECU				Read Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Seat position memory ECU				Erase Fault Code		Y		
406R COUPE	Production date before 30 June 2001	Seat position memory ECU				Live Data		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Live Data		Y		
406R COUPE	Production date after 30 June 2001	BSI(Built-in Systems Interface)				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Live Data		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Active safety	BOSCH ABS 5.3			Special Function	Bleeding	Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Live Data		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Calibration of the steering wheel angle sensor	Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	De-calibration of the steering wheel angle sensor	Y		
406R COUPE	Production date after 30 June 2001	Active safety	ESP BOSCH 5.3			Special Function	Bleeding	Y		
406R COUPE	Production date after 30 June 2001	Airbags				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Airbags				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Airbags				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Programming of the built-in systems interface (Engine immobiliser code and				Special Function	Programming of the built-in systems interface (Engine immobiliser code and keys)	Y		
406R COUPE	Production date after 30 June 2001	Alarm				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Alarm				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Alarm				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Alarm				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Alarm				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Multifunction display				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Instrument panel				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Radio				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Radio				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Radio				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Radio				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Radio				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	CD player				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	CD player				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	CD player				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	CD player				Live Data		Y		
406R COUPE	Production date after 30 June 2001	CD player				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	On-board navigation system				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	On-board navigation system				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	On-board navigation system				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	On-board navigation system				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Switching module below steering wheel (COM 2000)				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Rain/sunlight sensor				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Rain/sunlight sensor				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Rain/sunlight sensor				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Heating/ventilation				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Heating/ventilation				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Heating/ventilation				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Heating/ventilation				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Heating/ventilation				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Live Data		Y		
406R COUPE	Production date after 30 June 2001	Diesel fuel additive control unit				Actuation Test		Y		
406R COUPE	Production date after 30 June 2001	Variable power steering				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Variable power steering				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Variable power steering				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Seat position memory ECU				Read ECU Information		Y		
406R COUPE	Production date after 30 June 2001	Seat position memory ECU				Read Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Seat position memory ECU				Erase Fault Code		Y		
406R COUPE	Production date after 30 June 2001	Seat position memory ECU				Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Special Function	Changing the mode Electrical	Y		
407		407 saloon or estate fitted with an old generation BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 saloon or estate fitted with an old generation BSI	Airbag ECU			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Airbag ECU			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Airbag ECU			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Airbag ECU			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Parking aid			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Additional heating			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Under inflation detection			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Power steering			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Piloted suspension			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Piloted suspension			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Piloted suspension			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Piloted suspension			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Battery charge status unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Battery charge status unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Battery charge status unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Stop and Start battery charge status unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Stop and Start battery charge status unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Stop and Start battery charge status unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Stop and Start battery charge status unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Multifunction display			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Radio			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	CD player			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	CD player			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	CD player			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	CD player			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Instrument panel			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Hands Free Kit			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	High frequency receiver			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	High frequency receiver			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	High frequency receiver			Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
407		407 saloon or estate fitted with an old generation BSI	High frequency receiver			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Portable unit			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Alarm			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Alarm			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Alarm			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Alarm			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Alarm			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Driver's door module			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Passenger door module			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Sun roof			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Control unit windscreen wipers			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Rain/sunlight sensor			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Master discharge bulb			Special Function	Calibration	Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Read ECU Information		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Read Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Erase Fault Code		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Live Data		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Actuation Test		Y		
407		407 saloon or estate fitted with an old generation BSI	Slave discharge bulb			Special Function	Calibration	Y		
407		407 hatchback or estate fitted with a cross range BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	BSI(Built-in Systems Interface)			Special Function	Changing the mode Electrical	Y		
407		407 hatchback or estate fitted with a cross range BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 hatchback or estate fitted with a cross range BSI	Airbag ECU			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Airbag ECU			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Airbag ECU			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Airbag ECU			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Parking aid			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Parking aid			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Parking aid			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Parking aid			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Parking aid			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Drivers seat memory unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Drivers seat memory unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger seat memorisation module			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Additional heating			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Additional heating			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Additional heating			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Additional heating			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Additional heating			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Under inflation detection			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Under inflation detection			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Under inflation detection			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Under inflation detection			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Under inflation detection			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Power steering			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Power steering			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Power steering			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Power steering			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Power steering			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Piloted suspension			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Piloted suspension			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Piloted suspension			Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
407		407 hatchback or estate fitted with a cross range BSI	Piloted suspension			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Battery charge status unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Battery charge status unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Battery charge status unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Stop and Start battery charge status unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Stop and Start battery charge status unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Stop and Start battery charge status unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Stop and Start battery charge status unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Multifunction display			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Multifunction display			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Multifunction display			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Multifunction display			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Multifunction display			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Radio			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Radio			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Radio			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Radio			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Radio			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	CD player			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	CD player			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	CD player			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	CD player			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Instrument panel			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Instrument panel			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Instrument panel			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Instrument panel			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Instrument panel			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Hands Free Kit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Hands Free Kit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Hands Free Kit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Hands Free Kit			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Switch module at the steering wheel			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Switch module at the steering wheel			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	High frequency receiver			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	High frequency receiver			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	High frequency receiver			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	High frequency receiver			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Portable unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Portable unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Portable unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Portable unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Portable unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Alarm			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Alarm			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Alarm			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Alarm			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Alarm			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Driver's door module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Driver's door module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Driver's door module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Driver's door module			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Driver's door module			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger door module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger door module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger door module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger door module			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Passenger door module			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Sun roof			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Sun roof			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Sun roof			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Sun roof			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Sun roof			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Control unit windscreen wipers			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Control unit windscreen wipers			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Control unit windscreen wipers			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Rain/sunlight sensor			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Master discharge bulb			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Master discharge bulb			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Master discharge bulb			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Master discharge bulb			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Master discharge bulb			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Master discharge bulb			Special Function	Calibration	Y		
407		407 hatchback or estate fitted with a cross range BSI	Slave discharge bulb			Read ECU Information		Y		
407		407 hatchback or estate fitted with a cross range BSI	Slave discharge bulb			Read Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Slave discharge bulb			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a cross range BSI	Slave discharge bulb			Live Data		Y		
407		407 hatchback or estate fitted with a cross range BSI	Slave discharge bulb			Actuation Test		Y		
407		407 hatchback or estate fitted with a cross range BSI	Slave discharge bulb			Special Function	Calibration	Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Special Function	Changing the mode Electrical	Y		
407		407 coupé fitted with a cross range BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 coupé fitted with a cross range BSI	Airbag ECU			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Airbag ECU			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Airbag ECU			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Airbag ECU			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Parking aid			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Additional heating			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Under inflation detection			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Power steering			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Piloted suspension			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Piloted suspension			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Piloted suspension			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Piloted suspension			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Battery charge status unit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Battery charge status unit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Battery charge status unit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Multifunction display			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Radio			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Radio			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Radio			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Radio			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Radio			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	CD player			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	CD player			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	CD player			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	CD player			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Instrument panel			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Hands Free Kit			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	High frequency receiver			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	High frequency receiver			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	High frequency receiver			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	High frequency receiver			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Portable unit			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Alarm			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Alarm			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Alarm			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Alarm			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Alarm			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Driver's door module			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Passenger door module			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Live Data		Y		
407		407 coupé fitted with a cross range BSI	Control unit windscreen wipers			Actuation Test		Y		
407		407 coupé fitted with a cross range BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 coupé fitted with a cross range BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 coupé fitted with a cross range BSI	Rain/sunlight sensor			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Special Function	Changing the mode Electrical	Y		
407		407 hatchback or estate fitted with a modified BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 hatchback or estate fitted with a modified BSI	Airbag ECU			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Airbag ECU			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Airbag ECU			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Airbag ECU			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Parking aid			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Additional heating			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Under inflation detection			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Power steering			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Piloted suspension			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Piloted suspension			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Piloted suspension			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Piloted suspension			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Battery charge status unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Battery charge status unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Battery charge status unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Stop and Start battery charge status unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Stop and Start battery charge status unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Stop and Start battery charge status unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Stop and Start battery charge status unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Multifunction display			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Radio			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	CD player			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	CD player			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	CD player			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	CD player			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Instrument panel			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Hands Free Kit			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	High frequency receiver			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	High frequency receiver			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	High frequency receiver			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	High frequency receiver			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Portable unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Alarm			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Alarm			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Alarm			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Alarm			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Alarm			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Alarm			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Alarm			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Driver's door module			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Passenger door module			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Sun roof			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Control unit windscreen wipers			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Rain/sunlight sensor			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Master discharge bulb			Special Function	Calibration	Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Read ECU Information		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Read Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Erase Fault Code		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Live Data		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Actuation Test		Y		
407		407 hatchback or estate fitted with a modified BSI	Slave discharge bulb			Special Function	Calibration	Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Live Data		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Special Function	Changing the mode Electrical	Y		
407		407 coupé fitted with a modified BSI	BSI(Built-in Systems Interface)			Special Function	Learning	Y		
407		407 coupé fitted with a modified BSI	Airbag ECU			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Airbag ECU			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Airbag ECU			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Airbag ECU			Live Data		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Live Data		Y		
407		407 coupé fitted with a modified BSI	Parking aid			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Drivers seat memory unit			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Live Data		Y		
407		407 coupé fitted with a modified BSI	Passenger seat memorisation module			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Live Data		Y		
407		407 coupé fitted with a modified BSI	Additional heating			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Live Data		Y		
407		407 coupé fitted with a modified BSI	Under inflation detection			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Power steering			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Power steering			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Power steering			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Power steering			Live Data		Y		
407		407 coupé fitted with a modified BSI	Power steering			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Piloted suspension			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Piloted suspension			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Piloted suspension			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Piloted suspension			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Battery charge status unit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Battery charge status unit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Battery charge status unit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Battery charge status unit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Live Data		Y		
407		407 coupé fitted with a modified BSI	Multifunction display			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Radio			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Radio			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Radio			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Radio			Live Data		Y		
407		407 coupé fitted with a modified BSI	Radio			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	CD player			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	CD player			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	CD player			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	CD player			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Live Data		Y		
407		407 coupé fitted with a modified BSI	Instrument panel			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Live Data		Y		
407		407 coupé fitted with a modified BSI	Switch module at the steering wheel			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Hands Free Kit			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	High frequency receiver			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	High frequency receiver			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	High frequency receiver			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	High frequency receiver			Live Data		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Portable unit			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Live Data		Y		
407		407 coupé fitted with a modified BSI	Diesel fuel additive control unit			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Alarm			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Alarm			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Alarm			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Alarm			Live Data		Y		
407		407 coupé fitted with a modified BSI	Alarm			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Live Data		Y		
407		407 coupé fitted with a modified BSI	Driver's door module			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Live Data		Y		
407		407 coupé fitted with a modified BSI	Passenger door module			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Erase Fault Code		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Live Data		Y		
407		407 coupé fitted with a modified BSI	Control unit windscreen wipers			Actuation Test		Y		
407		407 coupé fitted with a modified BSI	Rain/sunlight sensor			Read ECU Information		Y		
407		407 coupé fitted with a modified BSI	Rain/sunlight sensor			Read Fault Code		Y		
407		407 coupé fitted with a modified BSI	Rain/sunlight sensor			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Special Function	Changing the mode Electrical	Y		
408(T73)(2010.01 - 2014.09)		Built-in Systems Interface				Special Function	Learning	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FY	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FT	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FN	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 8FP	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 8FS	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FR	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 8FP	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FN	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEVD17_4_2	5FU MEVD17.4.2 EURO 5	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6C	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP6CM	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MEV17_4_2	MEV17_4_2 EP3C	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	ME745_EC5		Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HP-DV6DTED-92 CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10_BR2	9HJ-DV6DTED-90 CV	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Live Data		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	BVA_AM6			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Power steering				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Power steering				Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T73)(2010.01 - 2014.09)		Power steering				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Power steering				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Power steering				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_MGI			Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Diesel additive pump	POMPE_MUX_TI			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Under inflation detection				Special Function	Pack Reparation	Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Battery charge status unit	BECB_GEN2			Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Lane departure warning system				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Engine relay unit				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Engine relay unit				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine relay unit				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Engine relay unit				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Trailer relay unit				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Trailer relay unit				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Trailer relay unit				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) With buttons			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "A" (segments) Without button			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Windscreen wiper				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Windscreen wiper				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Windscreen wiper				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Parking assistance	Parking aid			Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Air conditioning				Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Controls under the steering wheel				Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Instrument panel				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		CD changer / external CD player				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Radio amplifier				Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	KML			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Radio	RD4			Special Function	Spare part	Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Radio	RD45			Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module				Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T73)(2010.01 - 2014.09)		Seat driver position memory module				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Seat driver position memory module				Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm: China version			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm: China version			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm: China version			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm: China version			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm	Alarm: China version			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Anti-theft alarm				Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module				Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Seat passenger position memory module				Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Driver's door module	Driver's door module			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Sunroof				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Sunroof				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Sunroof				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Sunroof				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Sunroof				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Sunroof				Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Moving panel deflector				Special Function	Pack repair	Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Live Data		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Folding roof				Special Function	Pack Repair	Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Live Data		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
408(T73)(2010.01 - 2014.09)		Rain and light sensor				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Rain and light sensor				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Rain and light sensor				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		Seat belt not fastened warning lights unit				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		Seat belt not fastened warning lights unit				Actuation Test		Y		
408(T73)(2010.01 - 2014.09)		High frequency receiver				Read ECU Information		Y		
408(T73)(2010.01 - 2014.09)		High frequency receiver				Read Fault Code		Y		
408(T73)(2010.01 - 2014.09)		High frequency receiver				Erase Fault Code		Y		
408(T73)(2010.01 - 2014.09)		High frequency receiver				Live Data		Y		
408(T93)(After 2014.09)		BSI(Built-in Systems Interface)				Read ECU Information		Y		
408(T93)(After 2014.09)		BSI(Built-in Systems Interface)				Read Fault Code		Y		
408(T93)(After 2014.09)		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
408(T93)(After 2014.09)		BSI(Built-in Systems Interface)				Live Data		Y		
408(T93)(After 2014.09)		BSI(Built-in Systems Interface)				Actuation Test		Y		
408(T93)(After 2014.09)		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
408(T93)(After 2014.09)		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
408(T93)(After 2014.09)		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	Yes		Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	Yes		Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	Yes		Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	Yes		Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	Yes		Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	Yes		Special Function	Configuration	Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	Yes		Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	No		Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	No		Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	No		Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	No		Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	No		Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	No		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	No		Special Function	Initialisation of the autoadaptive values	Y		
408(T93)(After 2014.09)		Engine management ECU	V46_32	No		Special Function	Replacement parts	Y		
408(T93)(After 2014.09)		Engine management ECU	V46_52			Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_52			Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_52			Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_52			Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	V46_52			Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T93)(After 2014.09)		Engine management ECU	V46_52			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	VD46			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Engine management ECU	MED17_4_4			Read ECU Information		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17_4_4			Read Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17_4_4			Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17_4_4			Live Data		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17_4_4			Actuation Test		Y		
408(T93)(After 2014.09)		Engine management ECU	MED17_4_4			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read ECU Information		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Read Fault Code		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Erase Fault Code		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Live Data		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Actuation Test		Y		
408(T93)(After 2014.09)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Live Data		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
408(T93)(After 2014.09)		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Live Data		Y		
408(T93)(After 2014.09)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Read ECU Information		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Read Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Erase Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Live Data		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Actuation Test		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	MRN audio/navigation			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Read ECU Information		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Read Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Erase Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Live Data		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Actuation Test		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	SMEG + audio/navigation			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Read ECU Information		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Read Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Erase Fault Code		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Live Data		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Actuation Test		Y		
408(T93)(After 2014.09)		Telematics unit(RTx) or radio navigation	NAC			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Control of the telematic unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Read Fault Code		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Erase Fault Code		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Live Data		Y		
408(T93)(After 2014.09)		Control of the telematic unit				Actuation Test		Y		
408(T93)(After 2014.09)		Power steering				Read ECU Information		Y		
408(T93)(After 2014.09)		Power steering				Read Fault Code		Y		
408(T93)(After 2014.09)		Power steering				Erase Fault Code		Y		
408(T93)(After 2014.09)		Power steering				Live Data		Y		
408(T93)(After 2014.09)		Power steering				Special Function	Configuration	Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Read ECU Information		Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Read Fault Code		Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Erase Fault Code		Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Live Data		Y		
408(T93)(After 2014.09)		Rain-sunlight sensor				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read ECU Information		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Read Fault Code		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Erase Fault Code		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Live Data		Y		
408(T93)(After 2014.09)		Multiplexed control panel	RD45 audio system and manual air conditioning			Actuation Test		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Read ECU Information		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Read Fault Code		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Erase Fault Code		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Live Data		Y		
408(T93)(After 2014.09)		Multiplexed control panel	MRN audio-navigation			Actuation Test		Y		
408(T93)(After 2014.09)		Seat driver position memory module				Read ECU Information		Y		
408(T93)(After 2014.09)		Seat driver position memory module				Read Fault Code		Y		
408(T93)(After 2014.09)		Seat driver position memory module				Erase Fault Code		Y		
408(T93)(After 2014.09)		Seat driver position memory module				Live Data		Y		
408(T93)(After 2014.09)		Seat driver position memory module				Actuation Test		Y		
408(T93)(After 2014.09)		Seat driver position memory module				Special Function	Configuration	Y		
408(T93)(After 2014.09)		Seat driver position memory module				Special Function	Pack repair	Y		
408(T93)(After 2014.09)		Engine relay unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Engine relay unit				Read Fault Code		Y		
408(T93)(After 2014.09)		Engine relay unit				Erase Fault Code		Y		
408(T93)(After 2014.09)		Engine relay unit				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Engine relay unit				Special Function	Configuration	Y		
408(T93)(After 2014.09)		Control panel dot matrix display	No			Read ECU Information		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	No			Read Fault Code		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	No			Erase Fault Code		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	No			Actuation Test		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Read ECU Information		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Read Fault Code		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Erase Fault Code		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Actuation Test		Y		
408(T93)(After 2014.09)		Control panel dot matrix display	Yes			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Supply protection and management unit				Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T93)(After 2014.09)		Supply protection and management unit				Live Data		Y		
408(T93)(After 2014.09)		Electronic key reader				Read ECU Information		Y		
408(T93)(After 2014.09)		Electronic key reader				Read Fault Code		Y		
408(T93)(After 2014.09)		Electronic key reader				Erase Fault Code		Y		
408(T93)(After 2014.09)		Electronic key reader				Live Data		Y		
408(T93)(After 2014.09)		Electric steering lock				Read ECU Information		Y		
408(T93)(After 2014.09)		Electric steering lock				Read Fault Code		Y		
408(T93)(After 2014.09)		Electric steering lock				Erase Fault Code		Y		
408(T93)(After 2014.09)		Electric steering lock				Live Data		Y		
408(T93)(After 2014.09)		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
408(T93)(After 2014.09)		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
408(T93)(After 2014.09)		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
408(T93)(After 2014.09)		Battery charge status unit				Read ECU Information		Y		
408(T93)(After 2014.09)		Battery charge status unit				Read Fault Code		Y		
408(T93)(After 2014.09)		Battery charge status unit				Erase Fault Code		Y		
408(T93)(After 2014.09)		Battery charge status unit				Live Data		Y		
408(T93)(After 2014.09)		Battery charge status unit				Special Function	Configuration	Y		
408(T93)(After 2014.09)		Battery charge status unit				Special Function	Pack repair	Y		
408(T93)(After 2014.09)		Radio				Read ECU Information		Y		
408(T93)(After 2014.09)		Radio				Read Fault Code		Y		
408(T93)(After 2014.09)		Radio				Erase Fault Code		Y		
408(T93)(After 2014.09)		Radio				Live Data		Y		
408(T93)(After 2014.09)		Radio				Actuation Test		Y		
408(T93)(After 2014.09)		Radio				Special Function	Configuration	Y		
408(T93)(After 2014.09)		Controls under the steering wheel	Yes			Read ECU Information		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	Yes			Read Fault Code		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	Yes			Erase Fault Code		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	Yes			Live Data		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	Yes			Actuation Test		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	Yes			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Controls under the steering wheel	No			Read ECU Information		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	No			Read Fault Code		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	No			Erase Fault Code		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	No			Live Data		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	No			Actuation Test		Y		
408(T93)(After 2014.09)		Controls under the steering wheel	No			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Read ECU Information		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Read Fault Code		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Live Data		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Actuation Test		Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
408(T93)(After 2014.09)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Parking assistance	4 parking assistance sensors			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Read ECU Information		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Read Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Erase Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Actuation Test		Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Parking assistance	8 parking assistance sensors			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Parking assistance	10 parking assistance sensors			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Read ECU Information		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Read Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Erase Fault Code		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Live Data		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Actuation Test		Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Parking assistance	12 parking assistance sensors			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Multifunction screen	EMF_C_UDS			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Read ECU Information		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Read Fault Code		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Erase Fault Code		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Live Data		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Actuation Test		Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Special Function	Configuration	Y		
408(T93)(After 2014.09)		Hands free starting access electronic module.				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Air conditioning				Read ECU Information		Y		
408(T93)(After 2014.09)		Air conditioning				Read Fault Code		Y		
408(T93)(After 2014.09)		Air conditioning				Erase Fault Code		Y		
408(T93)(After 2014.09)		Air conditioning				Live Data		Y		
408(T93)(After 2014.09)		Air conditioning				Actuation Test		Y		
408(T93)(After 2014.09)		Air conditioning				Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS			Read ECU Information		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS			Read Fault Code		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS			Erase Fault Code		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS			Live Data		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS			Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS_GP			Read ECU Information		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS_GP			Read Fault Code		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS_GP			Erase Fault Code		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS_GP			Live Data		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS_GP			Actuation Test		Y		
408(T93)(After 2014.09)		Touch screen	EMF_DGT_UDS_GP			Special Function	Configuration	Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA_CN			Read ECU Information		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA_CN			Read Fault Code		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA_CN			Erase Fault Code		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA_CN			Live Data		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA_CN			Actuation Test		Y		
408(T93)(After 2014.09)		Service module / Independent telematic unit	BTA_CN			Special Function	Pack Repair	Y		
408(T93)(After 2014.09)		Anti-theft alarm				Read ECU Information		Y		
408(T93)(After 2014.09)		Anti-theft alarm				Read Fault Code		Y		
408(T93)(After 2014.09)		Anti-theft alarm				Erase Fault Code		Y		
408(T93)(After 2014.09)		Anti-theft alarm				Live Data		Y		
408(T93)(After 2014.09)		Anti-theft alarm				Actuation Test		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	Yes			Actuation Test		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
408(T93)(After 2014.09)		Control on the steering wheel / integral controls steering wheel	No			Actuation Test		Y		
508		BSI(Built-in Systems Interface)				Read ECU Information		Y		
508		BSI(Built-in Systems Interface)				Read Fault Code		Y		
508		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
508		BSI(Built-in Systems Interface)				Live Data		Y		
508		BSI(Built-in Systems Interface)				Actuation Test		Y		
508		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
508		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
508		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
508		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Read ECU Information		Y		
508		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Read Fault Code		Y		
508		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Erase Fault Code		Y		
508		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Live Data		Y		
508		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Actuation Test		Y		
508		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Special Function	Configuration	Y		
508		Engine management ECU	Petrol	MED17_4_2	14 MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Live Data		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Configuration	Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RHH	Read ECU Information		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RHH	Read Fault Code		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RHH	Erase Fault Code		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RHH	Live Data		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RHH	Actuation Test		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RHH	Special Function	Configuration	Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP RHH	Special Function	Pack Repair	Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP R	Read ECU Information		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP R	Read Fault Code		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP R	Erase Fault Code		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP R	Live Data		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP R	Actuation Test		Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP R	Special Function	Configuration	Y		
508		Engine management ECU	Petrol	MM6KP	MM6KP R	Special Function	Pack Repair	Y		
508		Engine management ECU	Petrol	MED17_4_4		Read ECU Information		Y		
508		Engine management ECU	Petrol	MED17_4_4		Read Fault Code		Y		
508		Engine management ECU	Petrol	MED17_4_4		Erase Fault Code		Y		
508		Engine management ECU	Petrol	MED17_4_4		Live Data		Y		
508		Engine management ECU	Petrol	MED17_4_4		Actuation Test		Y		
508		Engine management ECU	Petrol	MED17_4_4		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
508		Engine management ECU	Petrol	MED17_4_4		Special Function	Work on the ancillaries battery	Y		
508		Engine management ECU	Petrol	MED17_4_4		Special Function	Initialisation of the autoadaptive values	Y		
508		Engine management ECU	Petrol	MED17_4_4		Special Function	Replacement parts	Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Read ECU Information		Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Read Fault Code		Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Erase Fault Code		Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Live Data		Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Actuation Test		Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Special Function	Work on the ancillaries battery	Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Special Function	Initialisation of the autoadaptive values	Y		
508		Engine management ECU	Petrol	MED17_4_4_EP8		Special Function	Replacement parts	Y		
508		Engine management ECU	Diesel	DCM6.2		Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM6.2		Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM6.2		Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM6.2		Live Data		Y		
508		Engine management ECU	Diesel	DCM6.2		Actuation Test		Y		
508		Engine management ECU	Diesel	DCM6.2		Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHR	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHR	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHR	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHR	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHR	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHR	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHR	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHF	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHF	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHF	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHF	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHF	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHF	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.4_P	DCM3.4_P RHF	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHD-DW10CTED4-136CV	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHD-DW10CTED4-136CV	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHD-DW10CTED4-136CV	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHD-DW10CTED4-136CV	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHD-DW10CTED4-136CV	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHD-DW10CTED4-136CV	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHD-DW10CTED4-136CV	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Read ECU Information		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Read Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Erase Fault Code		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Live Data		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Actuation Test		Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	DCM3.5_BR2	RHE-DW10CTED4-150CV	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HL-DV6CTED	Read ECU Information		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HL-DV6CTED	Read Fault Code		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HL-DV6CTED	Erase Fault Code		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HL-DV6CTED	Live Data		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HL-DV6CTED	Actuation Test		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HL-DV6CTED	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HL-DV6CTED	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HR-DV6CTED	Read ECU Information		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HR-DV6CTED	Read Fault Code		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HR-DV6CTED	Erase Fault Code		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HR-DV6CTED	Live Data		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HR-DV6CTED	Actuation Test		Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HR-DV6CTED	Special Function	Configuration	Y		
508		Engine management ECU	Diesel	HDI_SID_807_BR2	9HR-DV6CTED	Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	EDC17CP42		Read ECU Information		Y		
508		Engine management ECU	Diesel	EDC17CP42		Read Fault Code		Y		
508		Engine management ECU	Diesel	EDC17CP42		Erase Fault Code		Y		
508		Engine management ECU	Diesel	EDC17CP42		Live Data		Y		
508		Engine management ECU	Diesel	EDC17CP42		Actuation Test		Y		
508		Engine management ECU	Diesel	EDC17CP42		Special Function	Configuration	Y		
508		Engine management ECU	Diesel	EDC17CP42		Special Function	Pack Repair	Y		
508		Engine management ECU	Diesel	EDC17C60		Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508		Engine management ECU	Diesel	EDC17C60		Read Fault Code		Y		
508		Engine management ECU	Diesel	EDC17C60		Erase Fault Code		Y		
508		Engine management ECU	Diesel	EDC17C60		Live Data		Y		
508		Engine management ECU	Diesel	EDC17C60		Actuation Test		Y		
508		Engine management ECU	Diesel	EDC17C60		Special Function	Pack Repair	Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read ECU Information		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Erase Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Live Data		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Actuation Test		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Configuration	Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Pack Repair	Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
508		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
508		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Read ECU Information		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Read Fault Code		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Erase Fault Code		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Live Data		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Actuation Test		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Special Function	Configuration	Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Special Function	Pack Repair	Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
508		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
508		Air bags and pre-tensioners control unit				Read ECU Information		Y		
508		Air bags and pre-tensioners control unit				Read Fault Code		Y		
508		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
508		Air bags and pre-tensioners control unit				Live Data		Y		
508		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
508		Power steering				Read ECU Information		Y		
508		Power steering				Read Fault Code		Y		
508		Power steering				Erase Fault Code		Y		
508		Power steering				Live Data		Y		
508		Power steering				Actuation Test		Y		
508		Under inflation detection	DSG_UDS			Read ECU Information		Y		
508		Under inflation detection	DSG_UDS			Read Fault Code		Y		
508		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
508		Under inflation detection	DSG_UDS			Live Data		Y		
508		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
508		Under inflation detection	DSG			Read ECU Information		Y		
508		Under inflation detection	DSG			Read Fault Code		Y		
508		Under inflation detection	DSG			Erase Fault Code		Y		
508		Under inflation detection	DSG			Live Data		Y		
508		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
508		Active damper electronic unit				Read ECU Information		Y		
508		Active damper electronic unit				Read Fault Code		Y		
508		Active damper electronic unit				Erase Fault Code		Y		
508		Active damper electronic unit				Live Data		Y		
508		Active damper electronic unit				Actuation Test		Y		
508		Active damper electronic unit				Special Function	Configuration	Y		
508		Active damper electronic unit				Special Function	Pack repair	Y		
508		Battery charge status unit				Read ECU Information		Y		
508		Battery charge status unit				Read Fault Code		Y		
508		Battery charge status unit				Erase Fault Code		Y		
508		Battery charge status unit				Live Data		Y		
508		Battery charge status unit				Special Function	Configuration	Y		
508		Electric secondary brake				Read ECU Information		Y		
508		Electric secondary brake				Read Fault Code		Y		
508		Electric secondary brake				Erase Fault Code		Y		
508		Electric secondary brake				Live Data		Y		
508		Electric secondary brake				Actuation Test		Y		
508		Electric secondary brake				Special Function	Pack Repair	Y		
508		Dynamic headlamp height adjuster	BEMP			Read ECU Information		Y		
508		Dynamic headlamp height adjuster	BEMP			Read Fault Code		Y		
508		Dynamic headlamp height adjuster	BEMP			Erase Fault Code		Y		
508		Dynamic headlamp height adjuster	BEMP			Live Data		Y		
508		Dynamic headlamp height adjuster	BEMP			Actuation Test		Y		
508		Dynamic headlamp height adjuster	BEMP			Special Function	Configuration	Y		
508		Dynamic headlamp height adjuster	BEMP			Special Function	Pack Repair	Y		
508		Dynamic headlamp height adjuster	LADCT			Read ECU Information		Y		
508		Dynamic headlamp height adjuster	LADCT			Read Fault Code		Y		
508		Dynamic headlamp height adjuster	LADCT			Erase Fault Code		Y		
508		Dynamic headlamp height adjuster	LADCT			Live Data		Y		
508		Dynamic headlamp height adjuster	LADCT			Actuation Test		Y		
508		Dynamic headlamp height adjuster	LADCT			Special Function	Configuration	Y		
508		Dynamic headlamp height adjuster	LADCT			Special Function	Pack Repair	Y		
508		Additional heating				Read ECU Information		Y		
508		Additional heating				Read Fault Code		Y		
508		Additional heating				Erase Fault Code		Y		
508		Additional heating				Live Data		Y		
508		Additional heating				Actuation Test		Y		
508		Engine relay unit				Read ECU Information		Y		
508		Engine relay unit				Read Fault Code		Y		
508		Engine relay unit				Erase Fault Code		Y		
508		Engine relay unit				Live Data		Y		
508		Engine relay unit				Special Function	Configuration	Y		
508		Trailer relay unit				Read ECU Information		Y		
508		Trailer relay unit				Read Fault Code		Y		
508		Trailer relay unit				Erase Fault Code		Y		
508		Trailer relay unit				Live Data		Y		
508		Trailer relay unit				Actuation Test		Y		
508		Parking assistance	AAS_UDS			Read ECU Information		Y		
508		Parking assistance	AAS_UDS			Read Fault Code		Y		
508		Parking assistance	AAS_UDS			Erase Fault Code		Y		
508		Parking assistance	AAS_UDS			Live Data		Y		
508		Parking assistance	AAS_UDS			Actuation Test		Y		
508		Parking assistance	AAS_UDS			Special Function	Configuration	Y		
508		Anti-theft alarm	Alarm: China version			Read ECU Information		Y		
508		Anti-theft alarm	Alarm: China version			Read Fault Code		Y		
508		Anti-theft alarm	Alarm: China version			Erase Fault Code		Y		
508		Anti-theft alarm	Alarm: China version			Live Data		Y		
508		Anti-theft alarm	Alarm: China version			Actuation Test		Y		
508		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
508		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
508		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
508		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
508		Multifunction screen	EMF_C_UDS			Special Function	Configuration	Y		
508		Telematic unit(RTX) or audio-naviggation	MRN			Read ECU Information		Y		
508		Telematic unit(RTX) or audio-naviggation	MRN			Read Fault Code		Y		
508		Telematic unit(RTX) or audio-naviggation	MRN			Erase Fault Code		Y		
508		Telematic unit(RTX) or audio-naviggation	MRN			Live Data		Y		
508		Telematic unit(RTX) or audio-naviggation	MRN			Actuation Test		Y		
508		Telematic unit(RTX) or audio-naviggation	MRN			Special Function	Configuration	Y		
508		Telematic unit(RTX) or audio-naviggation	RNEG2010			Read ECU Information		Y		
508		Telematic unit(RTX) or audio-naviggation	RNEG2010			Read Fault Code		Y		
508		Telematic unit(RTX) or audio-naviggation	RNEG2010			Erase Fault Code		Y		
508		Telematic unit(RTX) or audio-naviggation	RNEG2010			Live Data		Y		
508		Telematic unit(RTX) or audio-naviggation	RNEG2010			Actuation Test		Y		
508		Telematic unit(RTX) or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
508		Telematic unit(RTX) or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
508		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Read ECU Information		Y		
508		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Read Fault Code		Y		
508		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Erase Fault Code		Y		
508		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Live Data		Y		
508		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Actuation Test		Y		
508		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Special Function	Configuration	Y		
508		Service module / Independent telematic unit				Read ECU Information		Y		
508		Service module / Independent telematic unit				Read Fault Code		Y		
508		Service module / Independent telematic unit				Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508		Service module / Independent telematic unit				Live Data		Y		
508		Service module / Independent telematic unit				Actuation Test		Y		
508		Service module / Independent telematic unit				Special Function	Configuration	Y		
508		Service module / Independent telematic unit				Special Function	Pack Repair	Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Read Fault Code		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Erase Fault Code		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Live Data		Y		
508		Multiplexed control panel	RD5 audio system and manual air conditioning			Actuation Test		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read ECU Information		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read Fault Code		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Erase Fault Code		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Live Data		Y		
508		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Actuation Test		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Read Fault Code		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Live Data		Y		
508		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Actuation Test		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read Fault Code		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Erase Fault Code		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Live Data		Y		
508		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Actuation Test		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Read ECU Information		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Read Fault Code		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Erase Fault Code		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Live Data		Y		
508		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Actuation Test		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Read Fault Code		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Erase Fault Code		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Live Data		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Actuation Test		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Actuation Test		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read Fault Code		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Live Data		Y		
508		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Actuation Test		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Read ECU Information		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Read Fault Code		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Erase Fault Code		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Live Data		Y		
508		Multiplexed control panel	SMEG+ audio-navigation			Actuation Test		Y		
508		Control panel dot matrix display	No			Read ECU Information		Y		
508		Control panel dot matrix display	No			Read Fault Code		Y		
508		Control panel dot matrix display	No			Erase Fault Code		Y		
508		Control panel dot matrix display	No			Actuation Test		Y		
508		Control panel dot matrix display	No			Special Function	Configuration	Y		
508		Control panel dot matrix display	Yes			Read ECU Information		Y		
508		Control panel dot matrix display	Yes			Read Fault Code		Y		
508		Control panel dot matrix display	Yes			Erase Fault Code		Y		
508		Control panel dot matrix display	Yes			Actuation Test		Y		
508		Control panel dot matrix display	Yes			Special Function	Configuration	Y		
508		Radio				Read ECU Information		Y		
508		Radio				Read Fault Code		Y		
508		Radio				Erase Fault Code		Y		
508		Radio				Live Data		Y		
508		Radio				Actuation Test		Y		
508		Radio				Special Function	Configuration	Y		
508		Hands-free control unit				Read ECU Information		Y		
508		Hands-free control unit				Read Fault Code		Y		
508		Hands-free control unit				Erase Fault Code		Y		
508		Hands-free control unit				Live Data		Y		
508		Hands-free control unit				Actuation Test		Y		
508		Hands-free control unit				Special Function	Configuration	Y		
508		Telematic navigator / separate control				Read ECU Information		Y		
508		Telematic navigator / separate control				Live Data		Y		
508		Telematic navigator / separate control				Actuation Test		Y		
508		Radio amplifier				Read ECU Information		Y		
508		Radio amplifier				Read Fault Code		Y		
508		Radio amplifier				Erase Fault Code		Y		
508		Radio amplifier				Actuation Test		Y		
508		Radio amplifier				Special Function	Configuration	Y		
508		Controls under the steering wheel				Read ECU Information		Y		
508		Controls under the steering wheel				Read Fault Code		Y		
508		Controls under the steering wheel				Erase Fault Code		Y		
508		Controls under the steering wheel				Live Data		Y		
508		Controls under the steering wheel				Actuation Test		Y		
508		Controls under the steering wheel				Special Function	Pack Repair	Y		
508		Seat belt not fastened warning lights unit				Read ECU Information		Y		
508		Seat belt not fastened warning lights unit				Actuation Test		Y		
508		Supply protection and management unit				Read ECU Information		Y		
508		Supply protection and management unit				Read Fault Code		Y		
508		Supply protection and management unit				Erase Fault Code		Y		
508		Supply protection and management unit				Live Data		Y		
508		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
508		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
508		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
508		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
508		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
508		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
508		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
508		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
508		Rain and light sensor				Read ECU Information		Y		
508		Rain and light sensor				Read Fault Code		Y		
508		Rain and light sensor				Erase Fault Code		Y		
508		Rain and light sensor				Live Data		Y		
508		Rain and light sensor				Special Function	Pack Repair	Y		
508		Air conditioning	RFTA Four-zone			Read ECU Information		Y		
508		Air conditioning	RFTA Four-zone			Read Fault Code		Y		
508		Air conditioning	RFTA Four-zone			Erase Fault Code		Y		
508		Air conditioning	RFTA Four-zone			Live Data		Y		
508		Air conditioning	RFTA Four-zone			Actuation Test		Y		
508		Air conditioning	RFTA Four-zone			Special Function	Pack Repair	Y		
508		Rear air conditioning				Read ECU Information		Y		
508		Rear air conditioning				Live Data		Y		
508		Rear air conditioning				Actuation Test		Y		
508		Motorised Boot ECU				Read ECU Information		Y		
508		Motorised Boot ECU				Read Fault Code		Y		
508		Motorised Boot ECU				Erase Fault Code		Y		
508		Motorised Boot ECU				Live Data		Y		
508		Motorised Boot ECU				Actuation Test		Y		
508		Motorised Boot ECU				Special Function	Configuration	Y		
508		Motorised Boot ECU				Special Function	Pack Repair	Y		
508		Motorised Boot ECU				Special Function	Maintenance	Y		
508		Seat driver position memory module	BDMC			Read ECU Information		Y		
508		Seat driver position memory module	BDMC			Read Fault Code		Y		
508		Seat driver position memory module	BDMC			Erase Fault Code		Y		
508		Seat driver position memory module	BDMC			Live Data		Y		
508		Seat driver position memory module	BDMC			Actuation Test		Y		
508		Seat driver position memory module	BDMC			Special Function	Configuration	Y		
508		Driver's door module	PDPC			Read ECU Information		Y		
508		Driver's door module	PDPC			Read Fault Code		Y		
508		Driver's door module	PDPC			Erase Fault Code		Y		
508		Driver's door module	PDPC			Live Data		Y		
508		Driver's door module	PDPC			Actuation Test		Y		
508		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
508		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
508		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
508		Electronic key reader				Read ECU Information		Y		
508		Electronic key reader				Read Fault Code		Y		
508		Electronic key reader				Erase Fault Code		Y		
508		Electronic key reader				Live Data		Y		
508		High Head Vision				Read ECU Information		Y		
508		High Head Vision				Read Fault Code		Y		
508		High Head Vision				Erase Fault Code		Y		
508		High Head Vision				Live Data		Y		
508		High Head Vision				Actuation Test		Y		
508		High Head Vision				Special Function	Configuration	Y		
508		Main beams assistant ECU				Read ECU Information		Y		
508		Main beams assistant ECU				Read Fault Code		Y		
508		Main beams assistant ECU				Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508		Main beams assistant ECU				Live Data		Y		
508		Main beams assistant ECU				Actuation Test		Y		
508		Main beams assistant ECU				Special Function	Configuration	Y		
508		Main beams assistant ECU				Special Function	Pack Repair	Y		
508		Left hand front wiper motor	MOTEV_UDS	Yes		Read ECU Information		Y		
508		Left hand front wiper motor	MOTEV_UDS	Yes		Read Fault Code		Y		
508		Left hand front wiper motor	MOTEV_UDS	Yes		Erase Fault Code		Y		
508		Left hand front wiper motor	MOTEV_UDS	Yes		Live Data		Y		
508		Left hand front wiper motor	MOTEV_UDS	Yes		Actuation Test		Y		
508		Left hand front wiper motor	MOTEV_UDS	No		Read ECU Information		Y		
508		Left hand front wiper motor	ESV_G	Yes		Read ECU Information		Y		
508		Left hand front wiper motor	ESV_G	Yes		Read Fault Code		Y		
508		Left hand front wiper motor	ESV_G	Yes		Erase Fault Code		Y		
508		Left hand front wiper motor	ESV_G	Yes		Live Data		Y		
508		Left hand front wiper motor	ESV_G	Yes		Actuation Test		Y		
508		Left hand front wiper motor	ESV_G	No		Read ECU Information		Y		
508		Right hand front wiper motor	MOTED_UDS	Yes		Read ECU Information		Y		
508		Right hand front wiper motor	MOTED_UDS	No		Read ECU Information		Y		
508		Right hand front wiper motor	MOTED_UDS	No		Read Fault Code		Y		
508		Right hand front wiper motor	MOTED_UDS	No		Erase Fault Code		Y		
508		Right hand front wiper motor	MOTED_UDS	No		Live Data		Y		
508		Right hand front wiper motor	MOTED_UDS	No		Actuation Test		Y		
508		Right hand front wiper motor	ESV_D	Yes		Read ECU Information		Y		
508		Right hand front wiper motor	ESV_D	No		Read ECU Information		Y		
508		Right hand front wiper motor	ESV_D	No		Read Fault Code		Y		
508		Right hand front wiper motor	ESV_D	No		Erase Fault Code		Y		
508		Right hand front wiper motor	ESV_D	No		Live Data		Y		
508		Right hand front wiper motor	ESV_D	No		Actuation Test		Y		
508		Electric steering lock				Read ECU Information		Y		
508		Electric steering lock				Read Fault Code		Y		
508		Electric steering lock				Erase Fault Code		Y		
508		Electric steering lock				Live Data		Y		
508		External CD player				Read ECU Information		Y		
508		External CD player				Read Fault Code		Y		
508		External CD player				Erase Fault Code		Y		
508		External CD player				Live Data		Y		
508		External CD player				Actuation Test		Y		
508		External CD player				Special Function	Configuration	Y		
508 HYbrid4		BSI(Built-in Systems Interface)				Read ECU Information		Y		
508 HYbrid4		BSI(Built-in Systems Interface)				Read Fault Code		Y		
508 HYbrid4		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
508 HYbrid4		BSI(Built-in Systems Interface)				Live Data		Y		
508 HYbrid4		BSI(Built-in Systems Interface)				Actuation Test		Y		
508 HYbrid4		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
508 HYbrid4		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
508 HYbrid4		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
508 HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Read ECU Information		Y		
508 HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Read Fault Code		Y		
508 HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Erase Fault Code		Y		
508 HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Live Data		Y		
508 HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Actuation Test		Y		
508 HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Special Function	Configuration	Y		
508 HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Special Function	Pack Repair	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Read ECU Information		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Read Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Erase Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Live Data		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Actuation Test		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Special Function	Configuration	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Special Function	Pack Repair	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Read ECU Information		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Read Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Erase Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Live Data		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Actuation Test		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Special Function	Configuration	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Special Function	Pack Repair	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Read ECU Information		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Read Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Erase Fault Code		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Live Data		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Actuation Test		Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Special Function	Configuration	Y		
508 HYbrid4		Engine management ECU	MM6KP	MM6KP R		Special Function	Pack Repair	Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Read ECU Information		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Read Fault Code		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Erase Fault Code		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Live Data		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Actuation Test		Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Programming operations	Y		
508 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Replacement parts	Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
508 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Read ECU Information		Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Read Fault Code		Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Live Data		Y		
508 HYbrid4		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
508 HYbrid4		Power steering				Read ECU Information		Y		
508 HYbrid4		Power steering				Read Fault Code		Y		
508 HYbrid4		Power steering				Erase Fault Code		Y		
508 HYbrid4		Power steering				Live Data		Y		
508 HYbrid4		Power steering				Actuation Test		Y		
508 HYbrid4		Under inflation detection	DSG_UDS			Read ECU Information		Y		
508 HYbrid4		Under inflation detection	DSG_UDS			Read Fault Code		Y		
508 HYbrid4		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
508 HYbrid4		Under inflation detection	DSG_UDS			Live Data		Y		
508 HYbrid4		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
508 HYbrid4		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
508 HYbrid4		Under inflation detection	DSG			Read ECU Information		Y		
508 HYbrid4		Under inflation detection	DSG			Read Fault Code		Y		
508 HYbrid4		Under inflation detection	DSG			Erase Fault Code		Y		
508 HYbrid4		Under inflation detection	DSG			Live Data		Y		
508 HYbrid4		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
508 HYbrid4		Battery charge status unit				Read ECU Information		Y		
508 HYbrid4		Battery charge status unit				Read Fault Code		Y		
508 HYbrid4		Battery charge status unit				Erase Fault Code		Y		
508 HYbrid4		Battery charge status unit				Live Data		Y		
508 HYbrid4		Battery charge status unit				Special Function	Configuration	Y		
508 HYbrid4		Battery charge status unit				Special Function	Pack Repair	Y		
508 HYbrid4		Electric secondary brake				Read ECU Information		Y		
508 HYbrid4		Electric secondary brake				Read Fault Code		Y		
508 HYbrid4		Electric secondary brake				Erase Fault Code		Y		
508 HYbrid4		Electric secondary brake				Live Data		Y		
508 HYbrid4		Electric secondary brake				Actuation Test		Y		
508 HYbrid4		Electric secondary brake				Special Function	Pack Repair	Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Read ECU Information		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Read Fault Code		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Erase Fault Code		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Live Data		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Actuation Test		Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Special Function	Configuration	Y		
508 HYbrid4		Dynamic headlamp height adjuster	BEMP			Special Function	Pack Repair	Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Read ECU Information		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Read Fault Code		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Erase Fault Code		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Live Data		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Actuation Test		Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Special Function	Configuration	Y		
508 HYbrid4		Dynamic headlamp height adjuster	LADCT			Special Function	Pack Repair	Y		
508 HYbrid4		Additional heating				Read ECU Information		Y		
508 HYbrid4		Additional heating				Read Fault Code		Y		
508 HYbrid4		Additional heating				Erase Fault Code		Y		
508 HYbrid4		Additional heating				Live Data		Y		
508 HYbrid4		Additional heating				Actuation Test		Y		
508 HYbrid4		Engine relay unit				Read ECU Information		Y		
508 HYbrid4		Engine relay unit				Read Fault Code		Y		
508 HYbrid4		Engine relay unit				Erase Fault Code		Y		
508 HYbrid4		Engine relay unit				Live Data		Y		
508 HYbrid4		Engine relay unit				Special Function	Configuration	Y		
508 HYbrid4		Trailer relay unit				Read ECU Information		Y		
508 HYbrid4		Trailer relay unit				Read Fault Code		Y		
508 HYbrid4		Trailer relay unit				Erase Fault Code		Y		
508 HYbrid4		Trailer relay unit				Live Data		Y		
508 HYbrid4		Trailer relay unit				Actuation Test		Y		
508 HYbrid4		Parking assistance	4 Parking assistance sensors			Read ECU Information		Y		
508 HYbrid4		Parking assistance	4 Parking assistance sensors			Read Fault Code		Y		
508 HYbrid4		Parking assistance	4 Parking assistance sensors			Erase Fault Code		Y		
508 HYbrid4		Parking assistance	4 Parking assistance sensors			Live Data		Y		
508 HYbrid4		Parking assistance	4 Parking assistance sensors			Actuation Test		Y		
508 HYbrid4		Parking assistance	4 Parking assistance sensors			Special Function	Configuration	Y		
508 HYbrid4		Parking assistance	10 Parking assistance sensors			Read ECU Information		Y		
508 HYbrid4		Parking assistance	10 Parking assistance sensors			Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508 HYbrid4		Parking assistance	10 Parking assistance sensors			Erase Fault Code		Y		
508 HYbrid4		Parking assistance	10 Parking assistance sensors			Live Data		Y		
508 HYbrid4		Parking assistance	10 Parking assistance sensors			Actuation Test		Y		
508 HYbrid4		Parking assistance	10 Parking assistance sensors			Special Function	Configuration	Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Read ECU Information		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Read Fault Code		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Erase Fault Code		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Live Data		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Actuation Test		Y		
508 HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Special Function	Configuration	Y		
508 HYbrid4		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
508 HYbrid4		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
508 HYbrid4		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
508 HYbrid4		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
508 HYbrid4		Multifunction screen	EMF_C_UDS			Special Function	Configuration	Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	RNEG2010			Read ECU Information		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	RNEG2010			Read Fault Code		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	RNEG2010			Erase Fault Code		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	RNEG2010			Live Data		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	RNEG2010			Actuation Test		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Read ECU Information		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Read Fault Code		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Erase Fault Code		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Live Data		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Actuation Test		Y		
508 HYbrid4		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Special Function	Configuration	Y		
508 HYbrid4		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA			Live Data		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA			Actuation Test		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
508 HYbrid4		Service module / Independent telematic unit	BTA_2			Read ECU Information		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA_2			Read Fault Code		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA_2			Erase Fault Code		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA_2			Live Data		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA_2			Actuation Test		Y		
508 HYbrid4		Service module / Independent telematic unit	BTA_2			Special Function	Configuration	Y		
508 HYbrid4		Service module / Independent telematic unit	BTA_2			Special Function	Pack Repair	Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Live Data		Y		
508 HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Live Data		Y		
508 HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Live Data		Y		
508 HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Actuation Test		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Read ECU Information		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Read Fault Code		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Erase Fault Code		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Live Data		Y		
508 HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Actuation Test		Y		
508 HYbrid4		Control panel dot matrix display	No			Read ECU Information		Y		
508 HYbrid4		Control panel dot matrix display	No			Read Fault Code		Y		
508 HYbrid4		Control panel dot matrix display	No			Erase Fault Code		Y		
508 HYbrid4		Control panel dot matrix display	No			Actuation Test		Y		
508 HYbrid4		Control panel dot matrix display	No			Special Function	Configuration	Y		
508 HYbrid4		Control panel dot matrix display	Yes			Read ECU Information		Y		
508 HYbrid4		Control panel dot matrix display	Yes			Read Fault Code		Y		
508 HYbrid4		Control panel dot matrix display	Yes			Erase Fault Code		Y		
508 HYbrid4		Control panel dot matrix display	Yes			Actuation Test		Y		
508 HYbrid4		Control panel dot matrix display	Yes			Special Function	Configuration	Y		
508 HYbrid4		Radio				Read ECU Information		Y		
508 HYbrid4		Radio				Read Fault Code		Y		
508 HYbrid4		Radio				Erase Fault Code		Y		
508 HYbrid4		Radio				Live Data		Y		
508 HYbrid4		Radio				Actuation Test		Y		
508 HYbrid4		Radio				Special Function	Configuration	Y		
508 HYbrid4		Hands-free control unit				Read ECU Information		Y		
508 HYbrid4		Hands-free control unit				Read Fault Code		Y		
508 HYbrid4		Hands-free control unit				Erase Fault Code		Y		
508 HYbrid4		Hands-free control unit				Live Data		Y		
508 HYbrid4		Hands-free control unit				Actuation Test		Y		
508 HYbrid4		Hands-free control unit				Special Function	Configuration	Y		
508 HYbrid4		Telematic navigator / separate control				Read ECU Information		Y		
508 HYbrid4		Telematic navigator / separate control				Live Data		Y		
508 HYbrid4		Telematic navigator / separate control				Actuation Test		Y		
508 HYbrid4		Radio amplifier				Read ECU Information		Y		
508 HYbrid4		Radio amplifier				Read Fault Code		Y		
508 HYbrid4		Radio amplifier				Erase Fault Code		Y		
508 HYbrid4		Radio amplifier				Actuation Test		Y		
508 HYbrid4		Radio amplifier				Special Function	Configuration	Y		
508 HYbrid4		Controls under the steering wheel				Read ECU Information		Y		
508 HYbrid4		Controls under the steering wheel				Read Fault Code		Y		
508 HYbrid4		Controls under the steering wheel				Erase Fault Code		Y		
508 HYbrid4		Controls under the steering wheel				Live Data		Y		
508 HYbrid4		Controls under the steering wheel				Actuation Test		Y		
508 HYbrid4		Controls under the steering wheel				Special Function	Pack Repair	Y		
508 HYbrid4		Seat belt not fastened warning lights unit				Read ECU Information		Y		
508 HYbrid4		Seat belt not fastened warning lights unit				Actuation Test		Y		
508 HYbrid4		Supply protection and management unit				Read ECU Information		Y		
508 HYbrid4		Supply protection and management unit				Read Fault Code		Y		
508 HYbrid4		Supply protection and management unit				Erase Fault Code		Y		
508 HYbrid4		Supply protection and management unit				Live Data		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
508 HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
508 HYbrid4		Rain and light sensor				Read ECU Information		Y		
508 HYbrid4		Rain and light sensor				Read Fault Code		Y		
508 HYbrid4		Rain and light sensor				Erase Fault Code		Y		
508 HYbrid4		Rain and light sensor				Live Data		Y		
508 HYbrid4		Rain and light sensor				Special Function	Pack Repair	Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Read ECU Information		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Read Fault Code		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Erase Fault Code		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Live Data		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Actuation Test		Y		
508 HYbrid4		Air conditioning	RFTA Four-zone			Special Function	Pack Repair	Y		
508 HYbrid4		Rear air conditioning				Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508 HYbrid4		Rear air conditioning				Live Data		Y		
508 HYbrid4		Rear air conditioning				Actuation Test		Y		
508 HYbrid4		Seat driver position memory module	BDMC			Read ECU Information		Y		
508 HYbrid4		Seat driver position memory module	BDMC			Read Fault Code		Y		
508 HYbrid4		Seat driver position memory module	BDMC			Erase Fault Code		Y		
508 HYbrid4		Seat driver position memory module	BDMC			Live Data		Y		
508 HYbrid4		Seat driver position memory module	BDMC			Actuation Test		Y		
508 HYbrid4		Seat driver position memory module	BDMC			Special Function	Configuration	Y		
508 HYbrid4		Driver's door module	PDPC			Read ECU Information		Y		
508 HYbrid4		Driver's door module	PDPC			Read Fault Code		Y		
508 HYbrid4		Driver's door module	PDPC			Erase Fault Code		Y		
508 HYbrid4		Driver's door module	PDPC			Live Data		Y		
508 HYbrid4		Driver's door module	PDPC			Actuation Test		Y		
508 HYbrid4		Electronic key reader				Read ECU Information		Y		
508 HYbrid4		Electronic key reader				Read Fault Code		Y		
508 HYbrid4		Electronic key reader				Erase Fault Code		Y		
508 HYbrid4		Electronic key reader				Live Data		Y		
508 HYbrid4		High Head Vision				Read ECU Information		Y		
508 HYbrid4		High Head Vision				Read Fault Code		Y		
508 HYbrid4		High Head Vision				Erase Fault Code		Y		
508 HYbrid4		High Head Vision				Live Data		Y		
508 HYbrid4		High Head Vision				Actuation Test		Y		
508 HYbrid4		High Head Vision				Special Function	Configuration	Y		
508 HYbrid4		Main beams assistant ECU				Read ECU Information		Y		
508 HYbrid4		Main beams assistant ECU				Read Fault Code		Y		
508 HYbrid4		Main beams assistant ECU				Erase Fault Code		Y		
508 HYbrid4		Main beams assistant ECU				Live Data		Y		
508 HYbrid4		Main beams assistant ECU				Actuation Test		Y		
508 HYbrid4		Main beams assistant ECU				Special Function	Configuration	Y		
508 HYbrid4		Main beams assistant ECU				Special Function	Pack Repair	Y		
508 HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Read ECU Information		Y		
508 HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Read Fault Code		Y		
508 HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Erase Fault Code		Y		
508 HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Live Data		Y		
508 HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Actuation Test		Y		
508 HYbrid4		Left hand front wiper motor	MOTEV_UDS	No		Read ECU Information		Y		
508 HYbrid4		Left hand front wiper motor	ESV_G	Yes		Read ECU Information		Y		
508 HYbrid4		Left hand front wiper motor	ESV_G	Yes		Read Fault Code		Y		
508 HYbrid4		Left hand front wiper motor	ESV_G	Yes		Erase Fault Code		Y		
508 HYbrid4		Left hand front wiper motor	ESV_G	Yes		Live Data		Y		
508 HYbrid4		Left hand front wiper motor	ESV_G	Yes		Actuation Test		Y		
508 HYbrid4		Left hand front wiper motor	ESV_G	No		Read ECU Information		Y		
508 HYbrid4		Right hand front wiper motor	MOTED_UDS	Yes		Read ECU Information		Y		
508 HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Read ECU Information		Y		
508 HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Read Fault Code		Y		
508 HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Erase Fault Code		Y		
508 HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Live Data		Y		
508 HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Actuation Test		Y		
508 HYbrid4		Right hand front wiper motor	ESV_D	Yes		Read ECU Information		Y		
508 HYbrid4		Right hand front wiper motor	ESV_D	No		Read ECU Information		Y		
508 HYbrid4		Right hand front wiper motor	ESV_D	No		Read Fault Code		Y		
508 HYbrid4		Right hand front wiper motor	ESV_D	No		Erase Fault Code		Y		
508 HYbrid4		Right hand front wiper motor	ESV_D	No		Live Data		Y		
508 HYbrid4		Right hand front wiper motor	ESV_D	No		Actuation Test		Y		
508 HYbrid4		Electric steering lock				Read ECU Information		Y		
508 HYbrid4		Electric steering lock				Read Fault Code		Y		
508 HYbrid4		Electric steering lock				Erase Fault Code		Y		
508 HYbrid4		Electric steering lock				Live Data		Y		
508 HYbrid4		External CD player				Read ECU Information		Y		
508 HYbrid4		External CD player				Read Fault Code		Y		
508 HYbrid4		External CD player				Erase Fault Code		Y		
508 HYbrid4		External CD player				Live Data		Y		
508 HYbrid4		External CD player				Actuation Test		Y		
508 HYbrid4		External CD player				Special Function	Configuration	Y		
508 HYbrid4		Hybrid control ECU 1				Read ECU Information		Y		
508 HYbrid4		Hybrid control ECU 1				Read Fault Code		Y		
508 HYbrid4		Hybrid control ECU 1				Erase Fault Code		Y		
508 HYbrid4		Hybrid control ECU 1				Live Data		Y		
508 HYbrid4		Hybrid control ECU 1				Actuation Test		Y		
508 HYbrid4		Hybrid control ECU 1				Special Function	Pack repair	Y		
508 HYbrid4		Hybrid control ECU 2				Read ECU Information		Y		
508 HYbrid4		Hybrid control ECU 2				Read Fault Code		Y		
508 HYbrid4		Hybrid control ECU 2				Erase Fault Code		Y		
508 HYbrid4		Hybrid control ECU 2				Live Data		Y		
508 HYbrid4		Traction battery ECU				Read ECU Information		Y		
508 HYbrid4		Traction battery ECU				Read Fault Code		Y		
508 HYbrid4		Traction battery ECU				Erase Fault Code		Y		
508 HYbrid4		Traction battery ECU				Live Data		Y		
508 HYbrid4		Traction battery ECU				Actuation Test		Y		
508 HYbrid4		Traction battery ECU				Special Function	Reactivation	Y		
508 HYbrid4		Traction battery ECU				Special Function	Replacement parts	Y		
508 HYbrid4		Hybrid mode selector				Read ECU Information		Y		
508 HYbrid4		Hybrid mode selector				Read Fault Code		Y		
508 HYbrid4		Hybrid mode selector				Live Data		Y		
508 HYbrid4		Hybrid mode selector				Actuation Test		Y		
508 RXH		BSI(Built-in Systems Interface)				Read ECU Information		Y		
508 RXH		BSI(Built-in Systems Interface)				Read Fault Code		Y		
508 RXH		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
508 RXH		BSI(Built-in Systems Interface)				Live Data		Y		
508 RXH		BSI(Built-in Systems Interface)				Actuation Test		Y		
508 RXH		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
508 RXH		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
508 RXH		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
508 RXH		Engine management ECU	DCM6.2			Read ECU Information		Y		
508 RXH		Engine management ECU	DCM6.2			Read Fault Code		Y		
508 RXH		Engine management ECU	DCM6.2			Erase Fault Code		Y		
508 RXH		Engine management ECU	DCM6.2			Live Data		Y		
508 RXH		Engine management ECU	DCM6.2			Actuation Test		Y		
508 RXH		Engine management ECU	DCM6.2			Special Function	Pack Repair	Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
508 RXH		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Read ECU Information		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Read Fault Code		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Erase Fault Code		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Live Data		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Special Function	Configuration	Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81			Special Function	Pack Repair	Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
508 RXH		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
508 RXH		Air bags and pre-tensioners control unit				Read ECU Information		Y		
508 RXH		Air bags and pre-tensioners control unit				Read Fault Code		Y		
508 RXH		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
508 RXH		Air bags and pre-tensioners control unit				Live Data		Y		
508 RXH		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
508 RXH		Power steering				Read ECU Information		Y		
508 RXH		Power steering				Read Fault Code		Y		
508 RXH		Power steering				Erase Fault Code		Y		
508 RXH		Power steering				Live Data		Y		
508 RXH		Power steering				Actuation Test		Y		
508 RXH		Under inflation detection	DSG_UDS			Read ECU Information		Y		
508 RXH		Under inflation detection	DSG_UDS			Read Fault Code		Y		
508 RXH		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
508 RXH		Under inflation detection	DSG_UDS			Live Data		Y		
508 RXH		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
508 RXH		Battery charge status unit				Read ECU Information		Y		
508 RXH		Battery charge status unit				Read Fault Code		Y		
508 RXH		Battery charge status unit				Erase Fault Code		Y		
508 RXH		Battery charge status unit				Live Data		Y		
508 RXH		Battery charge status unit				Special Function	Configuration	Y		
508 RXH		Battery charge status unit				Special Function	Pack Repair	Y		
508 RXH		Electric secondary brake				Read ECU Information		Y		
508 RXH		Electric secondary brake				Read Fault Code		Y		
508 RXH		Electric secondary brake				Erase Fault Code		Y		
508 RXH		Electric secondary brake				Live Data		Y		
508 RXH		Electric secondary brake				Actuation Test		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Read ECU Information		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Read Fault Code		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Erase Fault Code		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Live Data		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Actuation Test		Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Special Function	Configuration	Y		
508 RXH		Dynamic headlamp height adjuster	BEMP			Special Function	Pack Repair	Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Read ECU Information		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Read Fault Code		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Erase Fault Code		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508 RXH		Dynamic headlamp height adjuster	LADCT			Actuation Test		Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Special Function	Configuration	Y		
508 RXH		Dynamic headlamp height adjuster	LADCT			Special Function	Pack Repair	Y		
508 RXH		Additional heating				Read ECU Information		Y		
508 RXH		Additional heating				Read Fault Code		Y		
508 RXH		Additional heating				Erase Fault Code		Y		
508 RXH		Additional heating				Live Data		Y		
508 RXH		Additional heating				Actuation Test		Y		
508 RXH		Engine relay unit				Read ECU Information		Y		
508 RXH		Engine relay unit				Read Fault Code		Y		
508 RXH		Engine relay unit				Erase Fault Code		Y		
508 RXH		Engine relay unit				Live Data		Y		
508 RXH		Engine relay unit				Special Function	Configuration	Y		
508 RXH		Trailer relay unit				Read ECU Information		Y		
508 RXH		Trailer relay unit				Read Fault Code		Y		
508 RXH		Trailer relay unit				Erase Fault Code		Y		
508 RXH		Trailer relay unit				Live Data		Y		
508 RXH		Trailer relay unit				Actuation Test		Y		
508 RXH		Parking assistance	AAS_UDS			Read ECU Information		Y		
508 RXH		Parking assistance	AAS_UDS			Read Fault Code		Y		
508 RXH		Parking assistance	AAS_UDS			Erase Fault Code		Y		
508 RXH		Parking assistance	AAS_UDS			Live Data		Y		
508 RXH		Parking assistance	AAS_UDS			Actuation Test		Y		
508 RXH		Parking assistance	AAS_UDS			Special Function	Configuration	Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift module			Read ECU Information		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift module			Read Fault Code		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift module			Erase Fault Code		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift module			Live Data		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift module			Actuation Test		Y		
508 RXH		Anti-theft alarm	Alarm with anti-lift module			Special Function	Configuration	Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	RNEG2010			Read ECU Information		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	RNEG2010			Read Fault Code		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	RNEG2010			Erase Fault Code		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	RNEG2010			Live Data		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	RNEG2010			Actuation Test		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Read ECU Information		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Read Fault Code		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Erase Fault Code		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Live Data		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Actuation Test		Y		
508 RXH		Telematic unit(RTX) or audio-naviggation	SMEG_PLUS			Special Function	Configuration	Y		
508 RXH		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
508 RXH		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
508 RXH		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
508 RXH		Service module / Independent telematic unit	BTA			Live Data		Y		
508 RXH		Service module / Independent telematic unit	BTA			Actuation Test		Y		
508 RXH		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
508 RXH		Service module / Independent telematic unit	BTA_2			Read ECU Information		Y		
508 RXH		Service module / Independent telematic unit	BTA_2			Read Fault Code		Y		
508 RXH		Service module / Independent telematic unit	BTA_2			Erase Fault Code		Y		
508 RXH		Service module / Independent telematic unit	BTA_2			Live Data		Y		
508 RXH		Service module / Independent telematic unit	BTA_2			Actuation Test		Y		
508 RXH		Service module / Independent telematic unit	BTA_2			Special Function	Configuration	Y		
508 RXH		Service module / Independent telematic unit	BTA_2			Special Function	Pack Repair	Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Read ECU Information		Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Read Fault Code		Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Live Data		Y		
508 RXH		Multiplexed control panel	RD5 audio system and manual air conditioning			Actuation Test		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Live Data		Y		
508 RXH		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Actuation Test		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Live Data		Y		
508 RXH		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Actuation Test		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Live Data		Y		
508 RXH		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Actuation Test		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Read ECU Information		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Read Fault Code		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Live Data		Y		
508 RXH		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Actuation Test		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Live Data		Y		
508 RXH		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Actuation Test		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Live Data		Y		
508 RXH		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Actuation Test		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Read ECU Information		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Read Fault Code		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Erase Fault Code		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Live Data		Y		
508 RXH		Multiplexed control panel	SMEG+ audio-navigation			Actuation Test		Y		
508 RXH		Control panel dot matrix display	No			Read ECU Information		Y		
508 RXH		Control panel dot matrix display	No			Read Fault Code		Y		
508 RXH		Control panel dot matrix display	No			Erase Fault Code		Y		
508 RXH		Control panel dot matrix display	No			Actuation Test		Y		
508 RXH		Control panel dot matrix display	No			Special Function	Configuration	Y		
508 RXH		Control panel dot matrix display	Yes			Read ECU Information		Y		
508 RXH		Control panel dot matrix display	Yes			Read Fault Code		Y		
508 RXH		Control panel dot matrix display	Yes			Erase Fault Code		Y		
508 RXH		Control panel dot matrix display	Yes			Actuation Test		Y		
508 RXH		Control panel dot matrix display	Yes			Special Function	Configuration	Y		
508 RXH		Hands-free control unit				Read ECU Information		Y		
508 RXH		Hands-free control unit				Read Fault Code		Y		
508 RXH		Hands-free control unit				Erase Fault Code		Y		
508 RXH		Hands-free control unit				Live Data		Y		
508 RXH		Hands-free control unit				Actuation Test		Y		
508 RXH		Hands-free control unit				Special Function	Configuration	Y		
508 RXH		Radio amplifier				Read ECU Information		Y		
508 RXH		Radio amplifier				Read Fault Code		Y		
508 RXH		Radio amplifier				Erase Fault Code		Y		
508 RXH		Radio amplifier				Actuation Test		Y		
508 RXH		Radio amplifier				Special Function	Configuration	Y		
508 RXH		Controls under the steering wheel				Read ECU Information		Y		
508 RXH		Controls under the steering wheel				Read Fault Code		Y		
508 RXH		Controls under the steering wheel				Erase Fault Code		Y		
508 RXH		Controls under the steering wheel				Live Data		Y		
508 RXH		Controls under the steering wheel				Actuation Test		Y		
508 RXH		Controls under the steering wheel				Special Function	Pack Repair	Y		
508 RXH		Seat belt not fastened warning lights unit				Read ECU Information		Y		
508 RXH		Seat belt not fastened warning lights unit				Actuation Test		Y		
508 RXH		Supply protection and management unit				Read ECU Information		Y		
508 RXH		Supply protection and management unit				Read Fault Code		Y		
508 RXH		Supply protection and management unit				Erase Fault Code		Y		
508 RXH		Supply protection and management unit				Live Data		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
508 RXH		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
508 RXH		Rain and light sensor				Read ECU Information		Y		
508 RXH		Rain and light sensor				Read Fault Code		Y		
508 RXH		Rain and light sensor				Erase Fault Code		Y		
508 RXH		Rain and light sensor				Live Data		Y		
508 RXH		Rain and light sensor				Special Function	Pack Repair	Y		
508 RXH		Air conditioning	RFTA Four-zone			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508 RXH		Air conditioning	RFTA Four-zone			Read Fault Code		Y		
508 RXH		Air conditioning	RFTA Four-zone			Erase Fault Code		Y		
508 RXH		Air conditioning	RFTA Four-zone			Live Data		Y		
508 RXH		Air conditioning	RFTA Four-zone			Actuation Test		Y		
508 RXH		Air conditioning	RFTA Four-zone			Special Function	Pack Repair	Y		
508 RXH		Rear air conditioning				Read ECU Information		Y		
508 RXH		Rear air conditioning				Live Data		Y		
508 RXH		Rear air conditioning				Actuation Test		Y		
508 RXH		Motorised Boot ECU				Read ECU Information		Y		
508 RXH		Motorised Boot ECU				Read Fault Code		Y		
508 RXH		Motorised Boot ECU				Erase Fault Code		Y		
508 RXH		Motorised Boot ECU				Live Data		Y		
508 RXH		Motorised Boot ECU				Actuation Test		Y		
508 RXH		Motorised Boot ECU				Special Function	Configuration	Y		
508 RXH		Motorised Boot ECU				Special Function	Pack Repair	Y		
508 RXH		Motorised Boot ECU				Special Function	Maintenance	Y		
508 RXH		Seat driver position memory module	BDMC			Read ECU Information		Y		
508 RXH		Seat driver position memory module	BDMC			Read Fault Code		Y		
508 RXH		Seat driver position memory module	BDMC			Erase Fault Code		Y		
508 RXH		Seat driver position memory module	BDMC			Live Data		Y		
508 RXH		Seat driver position memory module	BDMC			Actuation Test		Y		
508 RXH		Seat driver position memory module	BDMC			Special Function	Configuration	Y		
508 RXH		Driver's door module	PDPC			Read ECU Information		Y		
508 RXH		Driver's door module	PDPC			Read Fault Code		Y		
508 RXH		Driver's door module	PDPC			Erase Fault Code		Y		
508 RXH		Driver's door module	PDPC			Live Data		Y		
508 RXH		Driver's door module	PDPC			Actuation Test		Y		
508 RXH		Electronic key reader				Read ECU Information		Y		
508 RXH		Electronic key reader				Read Fault Code		Y		
508 RXH		Electronic key reader				Erase Fault Code		Y		
508 RXH		Electronic key reader				Live Data		Y		
508 RXH		High Head Vision				Read ECU Information		Y		
508 RXH		High Head Vision				Read Fault Code		Y		
508 RXH		High Head Vision				Erase Fault Code		Y		
508 RXH		High Head Vision				Live Data		Y		
508 RXH		High Head Vision				Actuation Test		Y		
508 RXH		High Head Vision				Special Function	Configuration	Y		
508 RXH		Main beams assistant ECU				Read ECU Information		Y		
508 RXH		Main beams assistant ECU				Read Fault Code		Y		
508 RXH		Main beams assistant ECU				Erase Fault Code		Y		
508 RXH		Main beams assistant ECU				Live Data		Y		
508 RXH		Main beams assistant ECU				Actuation Test		Y		
508 RXH		Main beams assistant ECU				Special Function	Configuration	Y		
508 RXH		Main beams assistant ECU				Special Function	Pack Repair	Y		
508 RXH		Left hand front wiper motor	MOTEV_UDS	Yes		Read ECU Information		Y		
508 RXH		Left hand front wiper motor	MOTEV_UDS	Yes		Read Fault Code		Y		
508 RXH		Left hand front wiper motor	MOTEV_UDS	Yes		Erase Fault Code		Y		
508 RXH		Left hand front wiper motor	MOTEV_UDS	Yes		Live Data		Y		
508 RXH		Left hand front wiper motor	MOTEV_UDS	Yes		Actuation Test		Y		
508 RXH		Left hand front wiper motor	MOTEV_UDS	No		Read ECU Information		Y		
508 RXH		Left hand front wiper motor	ESV_G	Yes		Read ECU Information		Y		
508 RXH		Left hand front wiper motor	ESV_G	Yes		Read Fault Code		Y		
508 RXH		Left hand front wiper motor	ESV_G	Yes		Erase Fault Code		Y		
508 RXH		Left hand front wiper motor	ESV_G	Yes		Live Data		Y		
508 RXH		Left hand front wiper motor	ESV_G	Yes		Actuation Test		Y		
508 RXH		Left hand front wiper motor	ESV_G	No		Read ECU Information		Y		
508 RXH		Right hand front wiper motor	MOTED_UDS	Yes		Read ECU Information		Y		
508 RXH		Right hand front wiper motor	MOTED_UDS	No		Read ECU Information		Y		
508 RXH		Right hand front wiper motor	MOTED_UDS	No		Read Fault Code		Y		
508 RXH		Right hand front wiper motor	MOTED_UDS	No		Erase Fault Code		Y		
508 RXH		Right hand front wiper motor	MOTED_UDS	No		Live Data		Y		
508 RXH		Right hand front wiper motor	MOTED_UDS	No		Actuation Test		Y		
508 RXH		Right hand front wiper motor	ESV_D	Yes		Read ECU Information		Y		
508 RXH		Right hand front wiper motor	ESV_D	No		Read ECU Information		Y		
508 RXH		Right hand front wiper motor	ESV_D	No		Read Fault Code		Y		
508 RXH		Right hand front wiper motor	ESV_D	No		Erase Fault Code		Y		
508 RXH		Right hand front wiper motor	ESV_D	No		Live Data		Y		
508 RXH		Right hand front wiper motor	ESV_D	No		Actuation Test		Y		
508 RXH		Electric steering lock				Read ECU Information		Y		
508 RXH		Electric steering lock				Read Fault Code		Y		
508 RXH		Electric steering lock				Erase Fault Code		Y		
508 RXH		Electric steering lock				Live Data		Y		
508 RXH		External CD player				Read ECU Information		Y		
508 RXH		External CD player				Read Fault Code		Y		
508 RXH		External CD player				Erase Fault Code		Y		
508 RXH		External CD player				Live Data		Y		
508 RXH		External CD player				Actuation Test		Y		
508 RXH		External CD player				Special Function	Configuration	Y		
508 RXH		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
508 RXH		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
508 RXH		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
508 RXH HYbrid4		BSI(Built-in Systems Interface)				Read ECU Information		Y		
508 RXH HYbrid4		BSI(Built-in Systems Interface)				Read Fault Code		Y		
508 RXH HYbrid4		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
508 RXH HYbrid4		BSI(Built-in Systems Interface)				Live Data		Y		
508 RXH HYbrid4		BSI(Built-in Systems Interface)				Actuation Test		Y		
508 RXH HYbrid4		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
508 RXH HYbrid4		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
508 RXH HYbrid4		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
508 RXH HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Read ECU Information		Y		
508 RXH HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Read Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Special Function	Configuration	Y		
508 RXH HYbrid4		Engine management ECU	DCM35_HY	RHC-DW10CTED4-163CV		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Read ECU Information		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Read Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Special Function	Configuration	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RFJ		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Read ECU Information		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Read Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Special Function	Configuration	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP RHH		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Read ECU Information		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Read Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Special Function	Configuration	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Erase Fault Code		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Live Data		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Actuation Test		Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Special Function	Configuration	Y		
508 RXH HYbrid4		Engine management ECU	MM6KP	MM6KP R		Special Function	Pack Repair	Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Read ECU Information		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Read Fault Code		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Erase Fault Code		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Live Data		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Actuation Test		Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Programming operations	Y		
508 RXH HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Replacement parts	Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
508 RXH HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Read ECU Information		Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Read Fault Code		Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Live Data		Y		
508 RXH HYbrid4		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
508 RXH HYbrid4		Power steering				Read ECU Information		Y		
508 RXH HYbrid4		Power steering				Read Fault Code		Y		
508 RXH HYbrid4		Power steering				Erase Fault Code		Y		
508 RXH HYbrid4		Power steering				Live Data		Y		
508 RXH HYbrid4		Power steering				Actuation Test		Y		
508 RXH HYbrid4		Under inflation detection	DSG_UDS			Read ECU Information		Y		
508 RXH HYbrid4		Under inflation detection	DSG_UDS			Read Fault Code		Y		
508 RXH HYbrid4		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
508 RXH HYbrid4		Under inflation detection	DSG_UDS			Live Data		Y		
508 RXH HYbrid4		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
508 RXH HYbrid4		Under inflation detection	DSG			Read ECU Information		Y		
508 RXH HYbrid4		Under inflation detection	DSG			Read Fault Code		Y		
508 RXH HYbrid4		Under inflation detection	DSG			Erase Fault Code		Y		
508 RXH HYbrid4		Under inflation detection	DSG			Live Data		Y		
508 RXH HYbrid4		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
508 RXH HYbrid4		Battery charge status unit				Read ECU Information		Y		
508 RXH HYbrid4		Battery charge status unit				Read Fault Code		Y		
508 RXH HYbrid4		Battery charge status unit				Erase Fault Code		Y		
508 RXH HYbrid4		Battery charge status unit				Live Data		Y		
508 RXH HYbrid4		Battery charge status unit				Special Function	Configuration	Y		
508 RXH HYbrid4		Battery charge status unit				Special Function	Pack Repair	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508 RXH HYbrid4		Electric secondary brake				Read ECU Information		Y		
508 RXH HYbrid4		Electric secondary brake				Read Fault Code		Y		
508 RXH HYbrid4		Electric secondary brake				Erase Fault Code		Y		
508 RXH HYbrid4		Electric secondary brake				Live Data		Y		
508 RXH HYbrid4		Electric secondary brake				Actuation Test		Y		
508 RXH HYbrid4		Electric secondary brake				Special Function	Pack Repair	Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Read ECU Information		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Read Fault Code		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Erase Fault Code		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Live Data		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Actuation Test		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Special Function	Configuration	Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	BEMP			Special Function	Pack Repair	Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Read ECU Information		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Read Fault Code		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Erase Fault Code		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Live Data		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Actuation Test		Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Special Function	Configuration	Y		
508 RXH HYbrid4		Dynamic headlamp height adjuster	LADCT			Special Function	Pack Repair	Y		
508 RXH HYbrid4		Additional heating				Read ECU Information		Y		
508 RXH HYbrid4		Additional heating				Read Fault Code		Y		
508 RXH HYbrid4		Additional heating				Erase Fault Code		Y		
508 RXH HYbrid4		Additional heating				Live Data		Y		
508 RXH HYbrid4		Additional heating				Actuation Test		Y		
508 RXH HYbrid4		Engine relay unit				Read ECU Information		Y		
508 RXH HYbrid4		Engine relay unit				Read Fault Code		Y		
508 RXH HYbrid4		Engine relay unit				Erase Fault Code		Y		
508 RXH HYbrid4		Engine relay unit				Live Data		Y		
508 RXH HYbrid4		Engine relay unit				Special Function	Configuration	Y		
508 RXH HYbrid4		Trailer relay unit				Read ECU Information		Y		
508 RXH HYbrid4		Trailer relay unit				Read Fault Code		Y		
508 RXH HYbrid4		Trailer relay unit				Erase Fault Code		Y		
508 RXH HYbrid4		Trailer relay unit				Live Data		Y		
508 RXH HYbrid4		Trailer relay unit				Actuation Test		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Read ECU Information		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Read Fault Code		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Erase Fault Code		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Live Data		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Actuation Test		Y		
508 RXH HYbrid4		Parking assistance	AAS_UDS			Special Function	Configuration	Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Read ECU Information		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Read Fault Code		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Erase Fault Code		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Live Data		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Actuation Test		Y		
508 RXH HYbrid4		Anti-theft alarm	Alarm with anti-lift module			Special Function	Configuration	Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
508 RXH HYbrid4		Multifunction screen	EMF_C_UDS			Special Function	Configuration	Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	RNEG2010			Read ECU Information		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	RNEG2010			Read Fault Code		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	RNEG2010			Erase Fault Code		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	RNEG2010			Live Data		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	RNEG2010			Actuation Test		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	RNEG2010			Special Function	Configuration	Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	RNEG2010			Special Function	Pack repair	Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	SMEG_PLUS			Read ECU Information		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	SMEG_PLUS			Read Fault Code		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	SMEG_PLUS			Erase Fault Code		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	SMEG_PLUS			Live Data		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	SMEG_PLUS			Actuation Test		Y		
508 RXH HYbrid4		Telematic unit(RTX) or audio-navigation	SMEG_PLUS			Special Function	Configuration	Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA			Live Data		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA			Actuation Test		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA_2			Read ECU Information		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA_2			Read Fault Code		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA_2			Erase Fault Code		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA_2			Live Data		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA_2			Actuation Test		Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA_2			Special Function	Configuration	Y		
508 RXH HYbrid4		Service module / Independent telematic unit	BTA_2			Special Function	Pack Repair	Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	RD5 audio system and manual air conditioning			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and dual-zone automatic air			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Radio RD5 and quadrizonal automatic air conditioning			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Telematic unit RT6 and dual-zone automatic air conditioning			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	RT6 telematic unit and automatic air conditioning Four-zone			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and dual-zone automatic air conditioning			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	Accessory radio and quadrizonal automatic air conditioning			Actuation Test		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Read ECU Information		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Read Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Erase Fault Code		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Live Data		Y		
508 RXH HYbrid4		Multiplexed control panel	SMEG+ audio-navigation			Actuation Test		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Read ECU Information		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Read Fault Code		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Erase Fault Code		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Actuation Test		Y		
508 RXH HYbrid4		Control panel dot matrix display	No			Special Function	Configuration	Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Read ECU Information		Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Read Fault Code		Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Erase Fault Code		Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Actuation Test		Y		
508 RXH HYbrid4		Control panel dot matrix display	Yes			Special Function	Configuration	Y		
508 RXH HYbrid4		Radio				Read ECU Information		Y		
508 RXH HYbrid4		Radio				Read Fault Code		Y		
508 RXH HYbrid4		Radio				Erase Fault Code		Y		
508 RXH HYbrid4		Radio				Live Data		Y		
508 RXH HYbrid4		Radio				Actuation Test		Y		
508 RXH HYbrid4		Radio				Special Function	Configuration	Y		
508 RXH HYbrid4		Hands-free control unit				Read ECU Information		Y		
508 RXH HYbrid4		Hands-free control unit				Read Fault Code		Y		
508 RXH HYbrid4		Hands-free control unit				Erase Fault Code		Y		
508 RXH HYbrid4		Hands-free control unit				Live Data		Y		
508 RXH HYbrid4		Hands-free control unit				Actuation Test		Y		
508 RXH HYbrid4		Hands-free control unit				Special Function	Configuration	Y		
508 RXH HYbrid4		Telematic navigator / separate control				Read ECU Information		Y		
508 RXH HYbrid4		Telematic navigator / separate control				Live Data		Y		
508 RXH HYbrid4		Telematic navigator / separate control				Actuation Test		Y		
508 RXH HYbrid4		Radio amplifier				Read ECU Information		Y		
508 RXH HYbrid4		Radio amplifier				Read Fault Code		Y		
508 RXH HYbrid4		Radio amplifier				Erase Fault Code		Y		
508 RXH HYbrid4		Radio amplifier				Actuation Test		Y		
508 RXH HYbrid4		Radio amplifier				Special Function	Configuration	Y		
508 RXH HYbrid4		Controls under the steering wheel				Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
508 RXH HYbrid4		Controls under the steering wheel				Read Fault Code		Y		
508 RXH HYbrid4		Controls under the steering wheel				Erase Fault Code		Y		
508 RXH HYbrid4		Controls under the steering wheel				Live Data		Y		
508 RXH HYbrid4		Controls under the steering wheel				Actuation Test		Y		
508 RXH HYbrid4		Controls under the steering wheel				Special Function	Pack Repair	Y		
508 RXH HYbrid4		Seat belt not fastened warning lights unit				Read ECU Information		Y		
508 RXH HYbrid4		Seat belt not fastened warning lights unit				Actuation Test		Y		
508 RXH HYbrid4		Supply protection and management unit				Read ECU Information		Y		
508 RXH HYbrid4		Supply protection and management unit				Read Fault Code		Y		
508 RXH HYbrid4		Supply protection and management unit				Erase Fault Code		Y		
508 RXH HYbrid4		Supply protection and management unit				Live Data		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Read ECU Information		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Read Fault Code		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Erase Fault Code		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	No			Live Data		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Read ECU Information		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Read Fault Code		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Erase Fault Code		Y		
508 RXH HYbrid4		Control on the steering wheel / integral controls steering wheel	Yes			Live Data		Y		
508 RXH HYbrid4		Rain and light sensor				Read ECU Information		Y		
508 RXH HYbrid4		Rain and light sensor				Read Fault Code		Y		
508 RXH HYbrid4		Rain and light sensor				Erase Fault Code		Y		
508 RXH HYbrid4		Rain and light sensor				Live Data		Y		
508 RXH HYbrid4		Rain and light sensor				Special Function	Pack Repair	Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Read ECU Information		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Read Fault Code		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Erase Fault Code		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Live Data		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Actuation Test		Y		
508 RXH HYbrid4		Air conditioning	RFTA Two zone			Special Function	Pack Repair	Y		
508 RXH HYbrid4		Rear air conditioning				Read ECU Information		Y		
508 RXH HYbrid4		Rear air conditioning				Live Data		Y		
508 RXH HYbrid4		Rear air conditioning				Actuation Test		Y		
508 RXH HYbrid4		Motorised Boot ECU				Read ECU Information		Y		
508 RXH HYbrid4		Motorised Boot ECU				Read Fault Code		Y		
508 RXH HYbrid4		Motorised Boot ECU				Erase Fault Code		Y		
508 RXH HYbrid4		Motorised Boot ECU				Live Data		Y		
508 RXH HYbrid4		Motorised Boot ECU				Actuation Test		Y		
508 RXH HYbrid4		Motorised Boot ECU				Special Function	Configuration	Y		
508 RXH HYbrid4		Motorised Boot ECU				Special Function	Pack Repair	Y		
508 RXH HYbrid4		Motorised Boot ECU				Special Function	Maintenance	Y		
508 RXH HYbrid4		Seat driver position memory module	BDMC			Read ECU Information		Y		
508 RXH HYbrid4		Seat driver position memory module	BDMC			Read Fault Code		Y		
508 RXH HYbrid4		Seat driver position memory module	BDMC			Erase Fault Code		Y		
508 RXH HYbrid4		Seat driver position memory module	BDMC			Live Data		Y		
508 RXH HYbrid4		Seat driver position memory module	BDMC			Actuation Test		Y		
508 RXH HYbrid4		Seat driver position memory module	BDMC			Special Function	Configuration	Y		
508 RXH HYbrid4		Driver's door module	PDPC			Read ECU Information		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Read Fault Code		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Erase Fault Code		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Live Data		Y		
508 RXH HYbrid4		Driver's door module	PDPC			Actuation Test		Y		
508 RXH HYbrid4		Electronic key reader				Read ECU Information		Y		
508 RXH HYbrid4		Electronic key reader				Read Fault Code		Y		
508 RXH HYbrid4		Electronic key reader				Erase Fault Code		Y		
508 RXH HYbrid4		Electronic key reader				Live Data		Y		
508 RXH HYbrid4		High Head Vision				Read ECU Information		Y		
508 RXH HYbrid4		High Head Vision				Read Fault Code		Y		
508 RXH HYbrid4		High Head Vision				Erase Fault Code		Y		
508 RXH HYbrid4		High Head Vision				Live Data		Y		
508 RXH HYbrid4		High Head Vision				Actuation Test		Y		
508 RXH HYbrid4		High Head Vision				Special Function	Configuration	Y		
508 RXH HYbrid4		Main beams assistant ECU				Read ECU Information		Y		
508 RXH HYbrid4		Main beams assistant ECU				Read Fault Code		Y		
508 RXH HYbrid4		Main beams assistant ECU				Erase Fault Code		Y		
508 RXH HYbrid4		Main beams assistant ECU				Live Data		Y		
508 RXH HYbrid4		Main beams assistant ECU				Actuation Test		Y		
508 RXH HYbrid4		Main beams assistant ECU				Special Function	Configuration	Y		
508 RXH HYbrid4		Main beams assistant ECU				Special Function	Pack Repair	Y		
508 RXH HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Read ECU Information		Y		
508 RXH HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Read Fault Code		Y		
508 RXH HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Erase Fault Code		Y		
508 RXH HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Live Data		Y		
508 RXH HYbrid4		Left hand front wiper motor	MOTEV_UDS	Yes		Actuation Test		Y		
508 RXH HYbrid4		Left hand front wiper motor	MOTEV_UDS	No		Read ECU Information		Y		
508 RXH HYbrid4		Left hand front wiper motor	ESV_G	Yes		Read ECU Information		Y		
508 RXH HYbrid4		Left hand front wiper motor	ESV_G	Yes		Read Fault Code		Y		
508 RXH HYbrid4		Left hand front wiper motor	ESV_G	Yes		Erase Fault Code		Y		
508 RXH HYbrid4		Left hand front wiper motor	ESV_G	Yes		Live Data		Y		
508 RXH HYbrid4		Left hand front wiper motor	ESV_G	Yes		Actuation Test		Y		
508 RXH HYbrid4		Left hand front wiper motor	ESV_G	No		Read ECU Information		Y		
508 RXH HYbrid4		Right hand front wiper motor	MOTED_UDS	Yes		Read ECU Information		Y		
508 RXH HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Read ECU Information		Y		
508 RXH HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Read Fault Code		Y		
508 RXH HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Erase Fault Code		Y		
508 RXH HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Live Data		Y		
508 RXH HYbrid4		Right hand front wiper motor	MOTED_UDS	No		Actuation Test		Y		
508 RXH HYbrid4		Right hand front wiper motor	ESV_D	Yes		Read ECU Information		Y		
508 RXH HYbrid4		Right hand front wiper motor	ESV_D	No		Read ECU Information		Y		
508 RXH HYbrid4		Right hand front wiper motor	ESV_D	No		Read Fault Code		Y		
508 RXH HYbrid4		Right hand front wiper motor	ESV_D	No		Erase Fault Code		Y		
508 RXH HYbrid4		Right hand front wiper motor	ESV_D	No		Live Data		Y		
508 RXH HYbrid4		Right hand front wiper motor	ESV_D	No		Actuation Test		Y		
508 RXH HYbrid4		Electric steering lock				Read ECU Information		Y		
508 RXH HYbrid4		Electric steering lock				Read Fault Code		Y		
508 RXH HYbrid4		Electric steering lock				Erase Fault Code		Y		
508 RXH HYbrid4		Electric steering lock				Live Data		Y		
508 RXH HYbrid4		External CD player				Read ECU Information		Y		
508 RXH HYbrid4		External CD player				Read Fault Code		Y		
508 RXH HYbrid4		External CD player				Erase Fault Code		Y		
508 RXH HYbrid4		External CD player				Live Data		Y		
508 RXH HYbrid4		External CD player				Actuation Test		Y		
508 RXH HYbrid4		External CD player				Special Function	Configuration	Y		
508 RXH HYbrid4		Hybrid control ECU 1				Read ECU Information		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Read Fault Code		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Erase Fault Code		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Live Data		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Actuation Test		Y		
508 RXH HYbrid4		Hybrid control ECU 1				Special Function	Pack repair	Y		
508 RXH HYbrid4		Hybrid control ECU 2				Read ECU Information		Y		
508 RXH HYbrid4		Hybrid control ECU 2				Read Fault Code		Y		
508 RXH HYbrid4		Hybrid control ECU 2				Erase Fault Code		Y		
508 RXH HYbrid4		Hybrid control ECU 2				Live Data		Y		
508 RXH HYbrid4		Traction battery ECU				Read ECU Information		Y		
508 RXH HYbrid4		Traction battery ECU				Read Fault Code		Y		
508 RXH HYbrid4		Traction battery ECU				Erase Fault Code		Y		
508 RXH HYbrid4		Traction battery ECU				Live Data		Y		
508 RXH HYbrid4		Traction battery ECU				Actuation Test		Y		
508 RXH HYbrid4		Traction battery ECU				Special Function	Reactivation	Y		
508 RXH HYbrid4		Traction battery ECU				Special Function	Replacement parts	Y		
508 RXH HYbrid4		Hybrid mode selector				Read ECU Information		Y		
508 RXH HYbrid4		Hybrid mode selector				Read Fault Code		Y		
508 RXH HYbrid4		Hybrid mode selector				Live Data		Y		
508 RXH HYbrid4		Hybrid mode selector				Actuation Test		Y		
2008		BSI(Built-in Systems Interface)				Read ECU Information		Y		
2008		BSI(Built-in Systems Interface)				Read Fault Code		Y		
2008		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
2008		BSI(Built-in Systems Interface)				Live Data		Y		
2008		BSI(Built-in Systems Interface)				Actuation Test		Y		
2008		BSI(Built-in Systems Interface)				Special Function	Maintenance - BSI operating mode	Y		
2008		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
2008		BSI(Built-in Systems Interface)				Special Function	Pack Repair	Y		
2008		Engine management ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Read ECU Information		Y		
2008		Engine management ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Read Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Erase Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Live Data		Y		
2008		Engine management ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Actuation Test		Y		
2008		Engine management ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Special Function	Configuration	Y		
2008		Engine management ECU	EDC17C10_BR2	9HP-DV6DTED-92 CV		Special Function	Pack Repair	Y		
2008		Engine management ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Read ECU Information		Y		
2008		Engine management ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Read Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Erase Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Live Data		Y		
2008		Engine management ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Actuation Test		Y		
2008		Engine management ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Special Function	Configuration	Y		
2008		Engine management ECU	EDC17C10_BR2	9HJ-DV6DTEDM-90 CV		Special Function	Pack Repair	Y		
2008		Engine management ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Read ECU Information		Y		
2008		Engine management ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Read Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Erase Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Live Data		Y		
2008		Engine management ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Actuation Test		Y		
2008		Engine management ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Special Function	Configuration	Y		
2008		Engine management ECU	EDC17C10_BR2	9HK-DV6ETEDM-75 CV		Special Function	Pack Repair	Y		
2008		Engine management ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
2008		Engine management ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Live Data		Y		
2008		Engine management ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
2008		Engine management ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
2008		Engine management ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
2008		Engine management ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Read ECU Information		Y		
2008		Engine management ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
2008		Engine management ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Erase Fault Code		Y		
2008		Engine management ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Live Data		Y		
2008		Engine management ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Actuation Test		Y		
2008		Engine management ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Special Function	Configuration	Y		
2008		Engine management ECU	EDC17C10_BR2	8HP-DV4CTED-70 CV		Special Function	Pack Repair	Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read ECU Information		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Read Fault Code		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Erase Fault Code		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Live Data		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Actuation Test		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FP MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Read ECU Information		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Read Fault Code		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Erase Fault Code		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Live Data		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Actuation Test		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3C	8FR MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Read ECU Information		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Read Fault Code		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Erase Fault Code		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Live Data		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Actuation Test		Y		
2008		Engine management ECU	MEV17_4_2	MEV17_4_2 EP3CGAZ	8FN MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Read ECU Information		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Read Fault Code		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Erase Fault Code		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Live Data		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Actuation Test		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Special Function	Configuration	Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HD		Special Function	Pack Repair	Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read ECU Information		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read Fault Code		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Erase Fault Code		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Live Data		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Actuation Test		Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Configuration	Y		
2008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Pack Repair	Y		
2008		Engine management ECU	V46	Yes		Read ECU Information		Y		
2008		Engine management ECU	V46	Yes		Read Fault Code		Y		
2008		Engine management ECU	V46	Yes		Erase Fault Code		Y		
2008		Engine management ECU	V46	Yes		Live Data		Y		
2008		Engine management ECU	V46	Yes		Actuation Test		Y		
2008		Engine management ECU	V46	Yes		Special Function	Pack Repair	Y		
2008		Engine management ECU	V46	No	ZMZ	Read ECU Information		Y		
2008		Engine management ECU	V46	No	ZMZ	Read Fault Code		Y		
2008		Engine management ECU	V46	No	ZMZ	Erase Fault Code		Y		
2008		Engine management ECU	V46	No	ZMZ	Live Data		Y		
2008		Engine management ECU	V46	No	ZMZ	Actuation Test		Y		
2008		Engine management ECU	V46	No	ZMZ	Special Function	Pack Repair	Y		
2008		Engine management ECU	V46	No	HMW	Read ECU Information		Y		
2008		Engine management ECU	V46	No	HMW	Read Fault Code		Y		
2008		Engine management ECU	V46	No	HMW	Erase Fault Code		Y		
2008		Engine management ECU	V46	No	HMW	Live Data		Y		
2008		Engine management ECU	V46	No	HMW	Actuation Test		Y		
2008		Engine management ECU	V46	No	HMW	Special Function	Pack Repair	Y		
2008		Engine management ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Read ECU Information		Y		
2008		Engine management ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Read Fault Code		Y		
2008		Engine management ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Erase Fault Code		Y		
2008		Engine management ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Live Data		Y		
2008		Engine management ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Actuation Test		Y		
2008		Engine management ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Special Function	Configuration	Y		
2008		Engine management ECU	MED17_4_2	5FV MED 17.4.2 EURO 5		Special Function	Pack Repair	Y		
2008		Engine management ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Read ECU Information		Y		
2008		Engine management ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Read Fault Code		Y		
2008		Engine management ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Erase Fault Code		Y		
2008		Engine management ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Live Data		Y		
2008		Engine management ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Actuation Test		Y		
2008		Engine management ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Special Function	Configuration	Y		
2008		Engine management ECU	MED17_4_2	5FN MED 17.4.2 EURO 5		Special Function	Pack Repair	Y		
2008		Engine management ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Read ECU Information		Y		
2008		Engine management ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Read Fault Code		Y		
2008		Engine management ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Erase Fault Code		Y		
2008		Engine management ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Live Data		Y		
2008		Engine management ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Actuation Test		Y		
2008		Engine management ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Special Function	Initialising the autoadaptives	Y		
2008		Engine management ECU	MEVD17_4_2	5FU MEVD17.4.2 EURO 5		Special Function	Replacement parts	Y		
2008		Engine management ECU	VD46			Read ECU Information		Y		
2008		Engine management ECU	VD46			Read Fault Code		Y		
2008		Engine management ECU	VD46			Erase Fault Code		Y		
2008		Engine management ECU	VD46			Live Data		Y		
2008		Engine management ECU	VD46			Actuation Test		Y		
2008		Engine management ECU	VD46			Special Function	Pack Repair	Y		
2008		Engine management ECU	EDC17C60	Yes		Read ECU Information		Y		
2008		Engine management ECU	EDC17C60	Yes		Read Fault Code		Y		
2008		Engine management ECU	EDC17C60	Yes		Erase Fault Code		Y		
2008		Engine management ECU	EDC17C60	Yes		Live Data		Y		
2008		Engine management ECU	EDC17C60	Yes		Actuation Test		Y		
2008		Engine management ECU	EDC17C60	Yes		Special Function	Pack Repair	Y		
2008		Engine management ECU	EDC17C60	No	BHZ/BHX	Read ECU Information		Y		
2008		Engine management ECU	EDC17C60	No	BHZ/BHX	Read Fault Code		Y		
2008		Engine management ECU	EDC17C60	No	BHZ/BHX	Erase Fault Code		Y		
2008		Engine management ECU	EDC17C60	No	BHZ/BHX	Live Data		Y		
2008		Engine management ECU	EDC17C60	No	BHZ/BHX	Actuation Test		Y		
2008		Engine management ECU	EDC17C60	No	BHZ/BHX	Special Function	Pack Repair	Y		
2008		Engine management ECU	EDC17C60	No	BHY	Read ECU Information		Y		
2008		Engine management ECU	EDC17C60	No	BHY	Read Fault Code		Y		
2008		Engine management ECU	EDC17C60	No	BHY	Erase Fault Code		Y		
2008		Engine management ECU	EDC17C60	No	BHY	Live Data		Y		
2008		Engine management ECU	EDC17C60	No	BHY	Actuation Test		Y		
2008		Engine management ECU	EDC17C60	No	BHY	Special Function	Pack Repair	Y		
2008		Engine management ECU	MEVD17_4_4			Read ECU Information		Y		
2008		Engine management ECU	MEVD17_4_4			Read Fault Code		Y		
2008		Engine management ECU	MEVD17_4_4			Erase Fault Code		Y		
2008		Engine management ECU	MEVD17_4_4			Live Data		Y		
2008		Engine management ECU	MEVD17_4_4			Actuation Test		Y		
2008		Engine management ECU	MEVD17_4_4			Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
2008		Engine management ECU	MEVD17_4_4			Special Function	Work on the ancillaries battery	Y		
2008		Engine management ECU	MEVD17_4_4			Special Function	Initialisation of the autoadaptive values	Y		
2008		Engine management ECU	MEVD17_4_4			Special Function	Replacement parts	Y		
2008		Engine management ECU	ME745_EC5	ME745_EC5 NFP		Read ECU Information		Y		
2008		Engine management ECU	ME745_EC5	ME745_EC5 NFP		Read Fault Code		Y		
2008		Engine management ECU	ME745_EC5	ME745_EC5 NFP		Erase Fault Code		Y		
2008		Engine management ECU	ME745_EC5	ME745_EC5 NFP		Live Data		Y		
2008		Engine management ECU	ME745_EC5	ME745_EC5 NFP		Actuation Test		Y		
2008		Engine management ECU	ME745_EC5	ME745_EC5 NFP		Special Function	Configuration	Y		
2008		Engine management ECU	ME745_EC5	ME745_EC5 NFP		Special Function	Pack Repair	Y		
2008		Engine management ECU	MED17_4_4			Read ECU Information		Y		
2008		Engine management ECU	MED17_4_4			Read Fault Code		Y		
2008		Engine management ECU	MED17_4_4			Erase Fault Code		Y		
2008		Engine management ECU	MED17_4_4			Live Data		Y		
2008		Engine management ECU	MED17_4_4			Actuation Test		Y		
2008		Engine management ECU	MED17_4_4			Special Function	Pack Repair	Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFP		Read ECU Information		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFP		Read Fault Code		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFP		Erase Fault Code		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFP		Live Data		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFP		Actuation Test		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFP		Special Function	Initialising the autoadaptives	Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFP		Special Function	Replacement parts	Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFN		Read ECU Information		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFN		Read Fault Code		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFN		Erase Fault Code		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFN		Live Data		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFN		Actuation Test		Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFN		Special Function	Initialising the autoadaptives	Y		
2008		Engine management ECU	ME749_EC5	ME749_EC5 NFN		Special Function	Replacement parts	Y		
2008		Engine management ECU	V34.4	V34.4 ESSENCE		Read ECU Information		Y		
2008		Engine management ECU	V34.4	V34.4 ESSENCE		Read Fault Code		Y		
2008		Engine management ECU	V34.4	V34.4 ESSENCE		Erase Fault Code		Y		
2008		Engine management ECU	V34.4	V34.4 ESSENCE		Live Data		Y		
2008		Engine management ECU	V34.4	V34.4 ESSENCE		Actuation Test		Y		
2008		Engine management ECU	V34.4	V34.4 ESSENCE		Special Function	Initialising the autoadaptives	Y		
2008		Engine management ECU	V34.4	V34.4 ESSENCE		Special Function	Replacement parts	Y		
2008		Engine management ECU	V34.4	V34.4 FLEX FUEL		Read ECU Information		Y		
2008		Engine management ECU	V34.4	V34.4 FLEX FUEL		Read Fault Code		Y		
2008		Engine management ECU	V34.4	V34.4 FLEX FUEL		Erase Fault Code		Y		
2008		Engine management ECU	V34.4	V34.4 FLEX FUEL		Live Data		Y		
2008		Engine management ECU	V34.4	V34.4 FLEX FUEL		Actuation Test		Y		
2008		Engine management ECU	V34.4	V34.4 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
2008		Engine management ECU	V34.4	V34.4 FLEX FUEL		Special Function	Replacement parts	Y		
2008		Engine management ECU	V34.5	V34.5 ESSENCE		Read ECU Information		Y		
2008		Engine management ECU	V34.5	V34.5 ESSENCE		Read Fault Code		Y		
2008		Engine management ECU	V34.5	V34.5 ESSENCE		Erase Fault Code		Y		
2008		Engine management ECU	V34.5	V34.5 ESSENCE		Live Data		Y		
2008		Engine management ECU	V34.5	V34.5 ESSENCE		Actuation Test		Y		
2008		Engine management ECU	V34.5	V34.5 ESSENCE		Special Function	Initialising the autoadaptives	Y		
2008		Engine management ECU	V34.5	V34.5 ESSENCE		Special Function	Replacement parts	Y		
2008		Engine management ECU	V34.5	V34.5 FLEX FUEL		Read ECU Information		Y		
2008		Engine management ECU	V34.5	V34.5 FLEX FUEL		Read Fault Code		Y		
2008		Engine management ECU	V34.5	V34.5 FLEX FUEL		Erase Fault Code		Y		
2008		Engine management ECU	V34.5	V34.5 FLEX FUEL		Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
2008		Engine management ECU	V34.5	V34.5 FLEX FUEL		Actuation Test		Y		
2008		Engine management ECU	V34.5	V34.5 FLEX FUEL		Special Function	Initialising the autoadaptives	Y		
2008		Engine management ECU	V34.5	V34.5 FLEX FUEL		Special Function	Replacement parts	Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Read ECU Information		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Read Fault Code		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Erase Fault Code		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Live Data		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Actuation Test		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100			Special Function		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Read ECU Information		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Read Fault Code		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Erase Fault Code		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Live Data		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Actuation Test		Y		
2008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100			Special Function		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AL4			Read ECU Information		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AL4			Read Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AL4			Erase Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AL4			Live Data		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AL4			Actuation Test		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AL4			Special Function	Configuration	Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AL4			Special Function	Pack Repair	Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
2008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Configuration	Y		
2008		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
2008		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
2008		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
2008		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP			Read ECU Information		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP			Read Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP			Erase Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP			Live Data		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP			Actuation Test		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP			Special Function	Counters	Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP			Special Function	Pack Repair	Y		
2008		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Read ECU Information		Y		
2008		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Read Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Erase Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Live Data		Y		
2008		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Actuation Test		Y		
2008		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Special Function	Setting of the actuator	Y		
2008		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Special Function	Programming	Y		
2008		Automatic gearbox or controlled manual gearbox	MAPS_UDS			Special Function	Replacement parts	Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Read ECU Information		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Read Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Erase Fault Code		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Live Data		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Actuation Test		Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Special Function	Replacement parts	Y		
2008		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Special Function	Counters	Y		
2008		Air bags and pre-tensioners control unit				Read ECU Information		Y		
2008		Air bags and pre-tensioners control unit				Read Fault Code		Y		
2008		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
2008		Air bags and pre-tensioners control unit				Live Data		Y		
2008		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
2008		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
2008		Traction control mode selector				Read ECU Information		Y		
2008		Traction control mode selector				Read Fault Code		Y		
2008		Traction control mode selector				Live Data		Y		
2008		Traction control mode selector				Actuation Test		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG			Read ECU Information		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG			Read Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG			Erase Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG			Live Data		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG			Actuation Test		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG			Read ECU Information		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Read Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Erase Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Live Data		Y		
2008		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Actuation Test		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Read ECU Information		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Read Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Erase Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Live Data		Y		
2008		Telematic unit (RTx) or audio-navigation	MRN			Actuation Test		Y		
2008		Telematic unit (RTx) or audio-navigation	RCC			Read ECU Information		Y		
2008		Telematic unit (RTx) or audio-navigation	RCC			Read Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	RCC			Erase Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	RCC			Live Data		Y		
2008		Telematic unit (RTx) or audio-navigation	RCC			Actuation Test		Y		
2008		Telematic unit (RTx) or audio-navigation	RCC			Special Function	Configuration	Y		
2008		Telematic unit (RTx) or audio-navigation	NAC			Read ECU Information		Y		
2008		Telematic unit (RTx) or audio-navigation	NAC			Read Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	NAC			Erase Fault Code		Y		
2008		Telematic unit (RTx) or audio-navigation	NAC			Live Data		Y		
2008		Telematic unit (RTx) or audio-navigation	NAC			Actuation Test		Y		
2008		Telematic unit (RTx) or audio-navigation	NAC			Special Function	Configuration	Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Read ECU Information		Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Read Fault Code		Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Erase Fault Code		Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Actuation Test		Y		
2008		Control panel dot matrix display	Yes	Colour matrix screen		Special Function	Configuration	Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Read ECU Information		Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Read Fault Code		Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Erase Fault Code		Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Actuation Test		Y		
2008		Control panel dot matrix display	No	Monochrome matrix screen		Special Function	Configuration	Y		
2008		Parking assistance	AAS_UDS			Read ECU Information		Y		
2008		Parking assistance	AAS_UDS			Read Fault Code		Y		
2008		Parking assistance	AAS_UDS			Erase Fault Code		Y		
2008		Parking assistance	AAS_UDS			Live Data		Y		
2008		Parking assistance	AAS_UDS			Actuation Test		Y		
2008		Controls under the steering wheel				Read ECU Information		Y		
2008		Controls under the steering wheel				Read Fault Code		Y		
2008		Controls under the steering wheel				Erase Fault Code		Y		
2008		Controls under the steering wheel				Live Data		Y		
2008		Controls under the steering wheel				Actuation Test		Y		
2008		Power steering	DAE			Read ECU Information		Y		
2008		Power steering	DAE			Read Fault Code		Y		
2008		Power steering	DAE			Erase Fault Code		Y		
2008		Power steering	DAE			Live Data		Y		
2008		Power steering	DAE_A515			Read ECU Information		Y		
2008		Power steering	DAE_A515			Read Fault Code		Y		
2008		Power steering	DAE_A515			Erase Fault Code		Y		
2008		Power steering	DAE_A515			Live Data		Y		
2008		Power steering	DAE_A515			Actuation Test		Y		
2008		Rain and brightness sensor				Read ECU Information		Y		
2008		Rain and brightness sensor				Read Fault Code		Y		
2008		Rain and brightness sensor				Erase Fault Code		Y		
2008		Rain and brightness sensor				Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
2008		Rain and brightness sensor				Special Function	Pack Repair	Y		
2008		Hands-free control unit				Read ECU Information		Y		
2008		Hands-free control unit				Read Fault Code		Y		
2008		Hands-free control unit				Erase Fault Code		Y		
2008		Hands-free control unit				Live Data		Y		
2008		Hands-free control unit				Special Function	Configuration	Y		
2008		Electric steering lock				Read ECU Information		Y		
2008		Electric steering lock				Read Fault Code		Y		
2008		Electric steering lock				Erase Fault Code		Y		
2008		Electric steering lock				Live Data		Y		
2008		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
2008		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
2008		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
2008		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
2008		Control on the steering wheel / integral controls steering wheel				Actuation Test		Y		
2008		Electronic key reader				Read ECU Information		Y		
2008		Electronic key reader				Read Fault Code		Y		
2008		Electronic key reader				Erase Fault Code		Y		
2008		Electronic key reader				Live Data		Y		
2008		Air conditioning	TDC_RFTA_MUX			Read ECU Information		Y		
2008		Air conditioning	TDC_RFTA_MUX			Read Fault Code		Y		
2008		Air conditioning	TDC_RFTA_MUX			Erase Fault Code		Y		
2008		Air conditioning	TDC_RFTA_MUX			Live Data		Y		
2008		Air conditioning	TDC_RFTA_MUX			Actuation Test		Y		
2008		Air conditioning	TDC_RFTA_MUX			Special Function	Configuration	Y		
2008		Air conditioning	TDC_RFTA_MUX			Special Function	Pack Repair	Y		
2008		Air conditioning	TDC_CH_MUX			Read ECU Information		Y		
2008		Air conditioning	TDC_CH_MUX			Read Fault Code		Y		
2008		Air conditioning	TDC_CH_MUX			Erase Fault Code		Y		
2008		Air conditioning	TDC_CH_MUX			Live Data		Y		
2008		Air conditioning	TDC_CH_MUX			Actuation Test		Y		
2008		Air conditioning	TDC_CH_MUX			Special Function	Pack Repair	Y		
2008		Air conditioning	TDC_RF_MUX			Read ECU Information		Y		
2008		Air conditioning	TDC_RF_MUX			Read Fault Code		Y		
2008		Air conditioning	TDC_RF_MUX			Erase Fault Code		Y		
2008		Air conditioning	TDC_RF_MUX			Live Data		Y		
2008		Air conditioning	TDC_RF_MUX			Actuation Test		Y		
2008		Air conditioning	TDC_RF_MUX			Special Function	Pack Repair	Y		
2008		Instrument panel				Read ECU Information		Y		
2008		Instrument panel				Read Fault Code		Y		
2008		Instrument panel				Erase Fault Code		Y		
2008		Instrument panel				Live Data		Y		
2008		Instrument panel				Actuation Test		Y		
2008		Instrument panel				Special Function	Configuration	Y		
2008		Instrument panel				Special Function	Pack Repair	Y		
2008		Multiplexed control panel				Read ECU Information		Y		
2008		Multiplexed control panel				Read Fault Code		Y		
2008		Multiplexed control panel				Erase Fault Code		Y		
2008		Multiplexed control panel				Live Data		Y		
2008		Multiplexed control panel				Actuation Test		Y		
2008		Voltage retaining device	DMTC			Read ECU Information		Y		
2008		Voltage retaining device	DMTR			Read ECU Information		Y		
2008		Voltage retaining device	DMTR			Read Fault Code		Y		
2008		Voltage retaining device	DMTR			Erase Fault Code		Y		
2008		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
2008		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
2008		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
2008		Battery charge status unit				Read ECU Information		Y		
2008		Battery charge status unit				Read Fault Code		Y		
2008		Battery charge status unit				Erase Fault Code		Y		
2008		Battery charge status unit				Live Data		Y		
2008		Intrusion alarm siren				Read ECU Information		Y		
2008		Intrusion alarm siren				Read Fault Code		Y		
2008		Intrusion alarm siren				Erase Fault Code		Y		
2008		Intrusion alarm siren				Live Data		Y		
2008		Intrusion alarm siren				Actuation Test		Y		
2008		Anti-theft alarm				Read ECU Information		Y		
2008		Anti-theft alarm				Read Fault Code		Y		
2008		Anti-theft alarm				Erase Fault Code		Y		
2008		Anti-theft alarm				Live Data		Y		
2008		Anti-theft alarm				Actuation Test		Y		
2008		Audio amplifier				Read ECU Information		Y		
2008		Audio amplifier				Read Fault Code		Y		
2008		Audio amplifier				Erase Fault Code		Y		
2008		Audio amplifier				Actuation Test		Y		
2008		External CD player				Read ECU Information		Y		
2008		External CD player				Read Fault Code		Y		
2008		External CD player				Erase Fault Code		Y		
2008		External CD player				Live Data		Y		
2008		External CD player				Actuation Test		Y		
2008		Trailer relay unit				Read ECU Information		Y		
2008		Trailer relay unit				Read Fault Code		Y		
2008		Trailer relay unit				Erase Fault Code		Y		
2008		Trailer relay unit				Live Data		Y		
2008		Trailer relay unit				Actuation Test		Y		
2008		Radio				Read ECU Information		Y		
2008		Radio				Read Fault Code		Y		
2008		Radio				Erase Fault Code		Y		
2008		Radio				Live Data		Y		
2008		Radio				Actuation Test		Y		
2008		Service module/Independent telematic unit	BTA			Read ECU Information		Y		
2008		Service module/Independent telematic unit	BTA			Read Fault Code		Y		
2008		Service module/Independent telematic unit	BTA			Erase Fault Code		Y		
2008		Service module/Independent telematic unit	BTA			Live Data		Y		
2008		Service module/Independent telematic unit	BTA			Actuation Test		Y		
2008		Service module/Independent telematic unit	BTA			Special Function	Configuration	Y		
2008		Service module/Independent telematic unit	BTA			Special Function	Pack Repair	Y		
2008		Service module/Independent telematic unit	BTA_2			Read ECU Information		Y		
2008		Service module/Independent telematic unit	BTA_2			Read Fault Code		Y		
2008		Service module/Independent telematic unit	BTA_2			Erase Fault Code		Y		
2008		Service module/Independent telematic unit	BTA_2			Live Data		Y		
2008		Service module/Independent telematic unit	BTA_2			Actuation Test		Y		
2008		Service module/Independent telematic unit	BTA_2			Special Function	Configuration	Y		
2008		Service module/Independent telematic unit	BTA_2			Special Function	Pack Repair	Y		
2008		Service module/Independent telematic unit	BTA_3R			Read ECU Information		Y		
2008		Service module/Independent telematic unit	BTA_3R			Read Fault Code		Y		
2008		Service module/Independent telematic unit	BTA_3R			Erase Fault Code		Y		
2008		Service module/Independent telematic unit	BTA_3R			Live Data		Y		
2008		Service module/Independent telematic unit	BTA_3R			Actuation Test		Y		
2008		Diesel additive pump	PADDGO			Read ECU Information		Y		
2008		Diesel additive pump	PADDGO			Read Fault Code		Y		
2008		Diesel additive pump	PADDGO			Erase Fault Code		Y		
2008		Diesel additive pump	PADDGO			Live Data		Y		
2008		Diesel additive pump	PADDGO			Actuation Test		Y		
2008		Diesel additive pump	PADDGO			Special Function	Configuration	Y		
2008		Diesel additive pump	PADDGO			Special Function	Pack repair	Y		
2008		Diesel additive pump	PADDGO_TI_E6			Read ECU Information		Y		
2008		Diesel additive pump	PADDGO_TI_E6			Read Fault Code		Y		
2008		Diesel additive pump	PADDGO_TI_E6			Erase Fault Code		Y		
2008		Diesel additive pump	PADDGO_TI_E6			Live Data		Y		
2008		Diesel additive pump	PADDGO_TI_E6			Special Function	Configuration	Y		
3008		BSI(Built-in Systems Interface)				Read ECU Information		Y		
3008		BSI(Built-in Systems Interface)				Read Fault Code		Y		
3008		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
3008		BSI(Built-in Systems Interface)				Live Data		Y		
3008		BSI(Built-in Systems Interface)				Actuation Test		Y		
3008		BSI(Built-in Systems Interface)				Special Function	Changing the mode Electrical	Y		
3008		BSI(Built-in Systems Interface)				Special Function	Learning	Y		
3008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
3008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
3008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
3008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
3008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
3008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Special Function	Configuration	Y		
3008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Read ECU Information		Y		
3008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Read Fault Code		Y		
3008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Live Data		Y		
3008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Actuation Test		Y		
3008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Special Function	Configuration	Y		
3008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Read ECU Information		Y		
3008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Read Fault Code		Y		
3008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Live Data		Y		
3008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Actuation Test		Y		
3008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Special Function	Configuration	Y		
3008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Read ECU Information		Y		
3008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Read Fault Code		Y		
3008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Live Data		Y		
3008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Actuation Test		Y		
3008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Special Function	Configuration	Y		
3008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Read ECU Information		Y		
3008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Read Fault Code		Y		
3008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Live Data		Y		
3008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Actuation Test		Y		
3008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Special Function	Configuration	Y		
3008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_4			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
3008		Engine management ECU	MED17_4_4			Read Fault Code		Y		
3008		Engine management ECU	MED17_4_4			Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_4			Live Data		Y		
3008		Engine management ECU	MED17_4_4			Actuation Test		Y		
3008		Engine management ECU	MED17_4_4			Special Function	Pack Repair	Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Read ECU Information		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Read Fault Code		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Erase Fault Code		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Live Data		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Actuation Test		Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Special Function	Configuration	Y		
3008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Read ECU Information		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Read Fault Code		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Live Data		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Actuation Test		Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Special Function	Configuration	Y		
3008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Special Function	Pack Repair	Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Read ECU Information		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Read Fault Code		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Erase Fault Code		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Live Data		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Actuation Test		Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Special Function	Configuration	Y		
3008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Special Function	Pack Repair	Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Read ECU Information		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Read Fault Code		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Erase Fault Code		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Live Data		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Actuation Test		Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Special Function	Configuration	Y		
3008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Special Function	Pack Repair	Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Read ECU Information		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Read Fault Code		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Erase Fault Code		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Live Data		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Actuation Test		Y		
3008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Special Function	Pack Repair	Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Read ECU Information		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Read Fault Code		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Erase Fault Code		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Live Data		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Actuation Test		Y		
3008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Special Function	Pack Repair	Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read ECU Information		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read Fault Code		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Erase Fault Code		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Live Data		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Actuation Test		Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Configuration	Y		
3008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Pack Repair	Y		
3008		Engine management ECU	EDC17C60			Read ECU Information		Y		
3008		Engine management ECU	EDC17C60			Read Fault Code		Y		
3008		Engine management ECU	EDC17C60			Erase Fault Code		Y		
3008		Engine management ECU	EDC17C60			Live Data		Y		
3008		Engine management ECU	EDC17C60			Actuation Test		Y		
3008		Engine management ECU	EDC17C60			Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Read ECU Information		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Read Fault Code		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Erase Fault Code		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Live Data		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Actuation Test		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Read ECU Information		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Read Fault Code		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Erase Fault Code		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Live Data		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Actuation Test		Y		
3008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Read ECU Information		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Read Fault Code		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Erase Fault Code		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Live Data		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Actuation Test		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Special Function	Configuration	Y		
3008		Engine management ECU	DCM3.5	DCM35 RHE		Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Read ECU Information		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Read Fault Code		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Erase Fault Code		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Live Data		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Actuation Test		Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Special Function	Configuration	Y		
3008		Engine management ECU	DCM3.5	DCM35 RHH		Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Read ECU Information		Y		
3008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Read Fault Code		Y		
3008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Erase Fault Code		Y		
3008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Live Data		Y		
3008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Actuation Test		Y		
3008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Special Function	Configuration	Y		
3008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Special Function	Pack Repair	Y		
3008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Read ECU Information		Y		
3008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Read Fault Code		Y		
3008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Erase Fault Code		Y		
3008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Live Data		Y		
3008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Actuation Test		Y		
3008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Special Function	Configuration	Y		
3008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Special Function	Pack Repair	Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Read ECU Information		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Read Fault Code		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Erase Fault Code		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Live Data		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Actuation Test		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Special Function	Configuration	Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Special Function	Pack Repair	Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Read ECU Information		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Read Fault Code		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Erase Fault Code		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Live Data		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Actuation Test		Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Special Function	Configuration	Y		
3008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Special Function	Pack Repair	Y		
3008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read ECU Information		Y		
3008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read Fault Code		Y		
3008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Erase Fault Code		Y		
3008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Live Data		Y		
3008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Actuation Test		Y		
3008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Configuration	Y		
3008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Pack Repair	Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
3008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read ECU Information		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Erase Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Live Data		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Actuation Test		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Configuration	Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Pack Repair	Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
3008		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
3008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
3008		Air bags and pre-tensioners control unit				Read ECU Information		Y		
3008		Air bags and pre-tensioners control unit				Read Fault Code		Y		
3008		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
3008		Air bags and pre-tensioners control unit				Live Data		Y		
3008		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
3008		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
3008		Power steering				Read ECU Information		Y		
3008		Power steering				Read Fault Code		Y		
3008		Power steering				Erase Fault Code		Y		
3008		Power steering				Live Data		Y		
3008		Power steering				Actuation Test		Y		
3008		Diesel additive function	PADDGO			Read ECU Information		Y		
3008		Diesel additive function	PADDGO			Read Fault Code		Y		
3008		Diesel additive function	PADDGO			Erase Fault Code		Y		
3008		Diesel additive function	PADDGO			Live Data		Y		
3008		Diesel additive function	PADDGO			Actuation Test		Y		
3008		Diesel additive function	PADDGO			Special Function	Configuration	Y		
3008		Diesel additive function	PUMP_MUX_TI			Read ECU Information		Y		
3008		Diesel additive function	PUMP_MUX_TI			Read Fault Code		Y		
3008		Diesel additive function	PUMP_MUX_TI			Erase Fault Code		Y		
3008		Diesel additive function	PUMP_MUX_TI			Live Data		Y		
3008		Diesel additive function	PUMP_MUX_TI			Actuation Test		Y		
3008		Diesel additive function	PUMP_MUX_TI			Special Function	Configuration	Y		
3008		Diesel additive function	PADDGO_TI_E6			Read ECU Information		Y		
3008		Diesel additive function	PADDGO_TI_E6			Read Fault Code		Y		
3008		Diesel additive function	PADDGO_TI_E6			Erase Fault Code		Y		
3008		Diesel additive function	PADDGO_TI_E6			Live Data		Y		
3008		Diesel additive function	PADDGO_TI_E6			Special Function	Configuration	Y		
3008		Under inflation detection	DSG_UDS			Read ECU Information		Y		
3008		Under inflation detection	DSG_UDS			Read Fault Code		Y		
3008		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
3008		Under inflation detection	DSG_UDS			Live Data		Y		
3008		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
3008		Under inflation detection	DSG			Read ECU Information		Y		
3008		Under inflation detection	DSG			Read Fault Code		Y		
3008		Under inflation detection	DSG			Erase Fault Code		Y		
3008		Under inflation detection	DSG			Live Data		Y		
3008		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
3008		Dynamic headlamp height adjuster				Read ECU Information		Y		
3008		Dynamic headlamp height adjuster				Read Fault Code		Y		
3008		Dynamic headlamp height adjuster				Erase Fault Code		Y		
3008		Dynamic headlamp height adjuster				Live Data		Y		
3008		Dynamic headlamp height adjuster				Actuation Test		Y		
3008		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
3008		Dynamic headlamp height adjuster				Special Function	Pack repair	Y		
3008		Dynamic headlamp height adjuster				Live Data		Y		
3008		Dynamic headlamp height adjuster				Actuation Test		Y		
3008		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
3008		Dynamic headlamp height adjuster				Special Function	Pack repair	Y		
3008		Battery charge status unit	BECB			Read ECU Information		Y		
3008		Battery charge status unit	BECB			Read Fault Code		Y		
3008		Battery charge status unit	BECB			Erase Fault Code		Y		
3008		Battery charge status unit	BECB			Live Data		Y		
3008		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
3008		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
3008		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
3008		Battery charge status unit	BECB_GEN2			Live Data		Y		
3008		Battery charge status unit	BECB_GEN2			Special Function	Configuration	Y		
3008		Battery charge status unit	BECB_GEN2			Special Function	Pack Repair	Y		
3008		Vehicle Distance Assistance				Read ECU Information		Y		
3008		Vehicle Distance Assistance				Read Fault Code		Y		
3008		Vehicle Distance Assistance				Erase Fault Code		Y		
3008		Vehicle Distance Assistance				Live Data		Y		
3008		Vehicle Distance Assistance				Special Function	Configuration	Y		
3008		Vehicle Distance Assistance				Special Function	Pack repair	Y		
3008		Electric secondary brake				Read ECU Information		Y		
3008		Electric secondary brake				Read Fault Code		Y		
3008		Electric secondary brake				Erase Fault Code		Y		
3008		Electric secondary brake				Live Data		Y		
3008		Electric secondary brake				Actuation Test		Y		
3008		Electric secondary brake				Special Function	Pack Repair	Y		
3008		Trailer relay unit				Read ECU Information		Y		
3008		Trailer relay unit				Read Fault Code		Y		
3008		Trailer relay unit				Erase Fault Code		Y		
3008		Engine relay unit				Read ECU Information		Y		
3008		Engine relay unit				Read Fault Code		Y		
3008		Engine relay unit				Erase Fault Code		Y		
3008		Engine relay unit				Actuation Test		Y		
3008		Air conditioning				Read ECU Information		Y		
3008		Air conditioning				Read Fault Code		Y		
3008		Air conditioning				Erase Fault Code		Y		
3008		Air conditioning				Live Data		Y		
3008		Air conditioning				Actuation Test		Y		
3008		Air conditioning				Special Function	Configuration	Y		
3008		Air conditioning				Special Function	Pack Repair	Y		
3008		Controls under the steering wheel	HDC			Read ECU Information		Y		
3008		Controls under the steering wheel	HDC			Read Fault Code		Y		
3008		Controls under the steering wheel	HDC			Erase Fault Code		Y		
3008		Controls under the steering wheel	HDC			Live Data		Y		
3008		Controls under the steering wheel	HDC			Actuation Test		Y		
3008		Controls under the steering wheel	HDC			Special Function	Pack Repair	Y		
3008		Controls under the steering wheel	COM2008P			Read ECU Information		Y		
3008		Controls under the steering wheel	COM2008P			Read Fault Code		Y		
3008		Controls under the steering wheel	COM2008P			Erase Fault Code		Y		
3008		Controls under the steering wheel	COM2008P			Live Data		Y		
3008		Controls under the steering wheel	COM2008P			Actuation Test		Y		
3008		Multifunction screen	Type "A" (segments) with buttons			Read ECU Information		Y		
3008		Multifunction screen	Type "A" (segments) with buttons			Read Fault Code		Y		
3008		Multifunction screen	Type "A" (segments) with buttons			Erase Fault Code		Y		
3008		Multifunction screen	Type "A" (segments) with buttons			Live Data		Y		
3008		Multifunction screen	Type "A" (segments) with buttons			Actuation Test		Y		
3008		Multifunction screen	Type "A" (segments) with buttons			Special Function	Configuration	Y		
3008		Multifunction screen	Type "A" (segments) with buttons			Special Function	Pack repair	Y		
3008		Multifunction screen	Type "A" (segments) without buttons			Read ECU Information		Y		
3008		Multifunction screen	Type "A" (segments) without buttons			Read Fault Code		Y		
3008		Multifunction screen	Type "A" (segments) without buttons			Erase Fault Code		Y		
3008		Multifunction screen	Type "A" (segments) without buttons			Live Data		Y		
3008		Multifunction screen	Type "A" (segments) without buttons			Actuation Test		Y		
3008		Multifunction screen	Type "A" (segments) without buttons			Special Function	Configuration	Y		
3008		Multifunction screen	Type "A" (segments) without buttons			Special Function	Pack repair	Y		
3008		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
3008		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
3008		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack repair	Y		
3008		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
3008		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
3008		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
3008		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
3008		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
3008		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
3008		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack repair	Y		
3008		Instrument panel				Read ECU Information		Y		
3008		Instrument panel				Read Fault Code		Y		
3008		Instrument panel				Erase Fault Code		Y		
3008		Instrument panel				Live Data		Y		
3008		Instrument panel				Actuation Test		Y		
3008		Windscreen wiper				Read ECU Information		Y		
3008		Windscreen wiper				Actuation Test		Y		
3008		Windscreen wiper				Special Function	Configuration	Y		
3008		Windscreen wiper				Special Function	Pack Repair	Y		
3008		Parking assistance				Read ECU Information		Y		
3008		Parking assistance				Read Fault Code		Y		
3008		Parking assistance				Erase Fault Code		Y		
3008		Parking assistance				Live Data		Y		
3008		Parking assistance				Special Function	Configuration	Y		
3008		Parking assistance				Special Function	Pack Repair	Y		
3008		Radio	RD4			Read ECU Information		Y		
3008		Radio	RD4			Read Fault Code		Y		
3008		Radio	RD4			Erase Fault Code		Y		
3008		Radio	RD4			Live Data		Y		
3008		Radio	RD4			Actuation Test		Y		
3008		Radio	RD4			Special Function	Configuration	Y		
3008		Radio	RD4			Special Function	Replacement parts	Y		
3008		Radio	RD45			Read ECU Information		Y		
3008		Radio	RD45			Read Fault Code		Y		
3008		Radio	RD45			Erase Fault Code		Y		
3008		Radio	RD45			Live Data		Y		
3008		Radio	RD45			Actuation Test		Y		
3008		Radio	RD45			Special Function	Configuration	Y		
3008		Radio	RD45			Special Function	Pack Repair	Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Read ECU Information		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Read Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Erase Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Live Data		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Actuation Test		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Special Function	Configuration	Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Read ECU Information		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Read Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Erase Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Live Data		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Actuation Test		Y		
3008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Special Function	Configuration	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
3008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
3008		Audio amplifier				Read ECU Information		Y		
3008		Audio amplifier				Read Fault Code		Y		
3008		Audio amplifier				Erase Fault Code		Y		
3008		Audio amplifier				Actuation Test		Y		
3008		Audio amplifier				Special Function	Configuration	Y		
3008		Audio amplifier				Special Function	Pack Repair	Y		
3008		CD player / External CD player				Read ECU Information		Y		
3008		CD player / External CD player				Read Fault Code		Y		
3008		CD player / External CD player				Erase Fault Code		Y		
3008		CD player / External CD player				Actuation Test		Y		
3008		CD player / External CD player				Special Function	Configuration	Y		
3008		Hands-free kit / Portable Unit				Read ECU Information		Y		
3008		Hands-free kit / Portable Unit				Read Fault Code		Y		
3008		Hands-free kit / Portable Unit				Erase Fault Code		Y		
3008		Hands-free kit / Portable Unit				Live Data		Y		
3008		Hands-free kit / Portable Unit				Actuation Test		Y		
3008		Hands-free kit / Portable Unit				Special Function	Configuration	Y		
3008		Hands-free kit / Portable Unit				Special Function	Pack repair	Y		
3008		Anti-theft alarm				Read ECU Information		Y		
3008		Anti-theft alarm				Read Fault Code		Y		
3008		Anti-theft alarm				Erase Fault Code		Y		
3008		Anti-theft alarm				Live Data		Y		
3008		Anti-theft alarm				Actuation Test		Y		
3008		Anti-theft alarm				Special Function	Configuration	Y		
3008		Anti-theft alarm				Special Function	Pack repair	Y		
3008		Traction control mode selector				Read ECU Information		Y		
3008		Traction control mode selector				Read Fault Code		Y		
3008		Traction control mode selector				Live Data		Y		
3008		Traction control mode selector				Actuation Test		Y		
3008		Driver's door module	Driver's door module			Read ECU Information		Y		
3008		Driver's door module	Driver's door module			Read Fault Code		Y		
3008		Driver's door module	Driver's door module			Erase Fault Code		Y		
3008		Driver's door module	Driver's door module			Live Data		Y		
3008		Driver's door module	Driver's door module			Actuation Test		Y		
3008		Control panel dot matrix display				Read ECU Information		Y		
3008		Control panel dot matrix display				Read Fault Code		Y		
3008		Control panel dot matrix display				Erase Fault Code		Y		
3008		Control panel dot matrix display				Live Data		Y		
3008		Control panel dot matrix display				Actuation Test		Y		
3008		Control panel dot matrix display				Special Function	Configuration	Y		
3008		Service module /Independent telematic unit	MD_SERV			Read ECU Information		Y		
3008		Service module /Independent telematic unit	MD_SERV			Read Fault Code		Y		
3008		Service module /Independent telematic unit	MD_SERV			Erase Fault Code		Y		
3008		Service module /Independent telematic unit	MD_SERV			Live Data		Y		
3008		Service module /Independent telematic unit	MD_SERV			Actuation Test		Y		
3008		Service module /Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
3008		Service module /Independent telematic unit	MD_SERV			Special Function	Pack Repair	Y		
3008		Service module /Independent telematic unit	BTA			Read ECU Information		Y		
3008		Service module /Independent telematic unit	BTA			Read Fault Code		Y		
3008		Service module /Independent telematic unit	BTA			Erase Fault Code		Y		
3008		Service module /Independent telematic unit	BTA			Live Data		Y		
3008		Service module /Independent telematic unit	BTA			Actuation Test		Y		
3008		Service module /Independent telematic unit	BTA			Special Function	Configuration	Y		
3008		Service module /Independent telematic unit	BTA			Special Function	Pack Repair	Y		
3008		Network isolation control unit				Read ECU Information		Y		
3008		Network isolation control unit				Live Data		Y		
3008		Rain and brightness sensor				Read ECU Information		Y		
3008		Rain and brightness sensor				Read Fault Code		Y		
3008		Rain and brightness sensor				Erase Fault Code		Y		
3008		Voltage retaining device	DMTC			Read ECU Information		Y		
3008		Voltage retaining device	DMTR			Read ECU Information		Y		
3008		Voltage retaining device	DMTR			Read Fault Code		Y		
3008		Voltage retaining device	DMTR			Erase Fault Code		Y		
3008		High Head Vision	VTH			Read ECU Information		Y		
3008		High Head Vision	VTH			Read Fault Code		Y		
3008		High Head Vision	VTH			Erase Fault Code		Y		
3008		High Head Vision	VTH			Live Data		Y		
3008		High Head Vision	VTH			Actuation Test		Y		
3008		High Head Vision	VTH			Special Function	Configuration	Y		
3008		High Head Vision	VTH_UDS			Read ECU Information		Y		
3008		High Head Vision	VTH_UDS			Read Fault Code		Y		
3008		High Head Vision	VTH_UDS			Erase Fault Code		Y		
3008		High Head Vision	VTH_UDS			Live Data		Y		
3008		High Head Vision	VTH_UDS			Actuation Test		Y		
3008		High Head Vision	VTH_UDS			Special Function	Configuration	Y		
3008		High Head Vision	VTH_UDS			Special Function	Pack repair	Y		
3008		High frequency receiver				Read ECU Information		Y		
3008		High frequency receiver				Read Fault Code		Y		
3008		High frequency receiver				Erase Fault Code		Y		
3008		High frequency receiver				Live Data		Y		
3008		Seat belts not fastened LED unit				Read ECU Information		Y		
3008		Seat belts not fastened LED unit				Actuation Test		Y		
3008 HYbrid4		BSI(Built-in Systems Interface)				Read ECU Information		Y		
3008 HYbrid4		BSI(Built-in Systems Interface)				Read Fault Code		Y		
3008 HYbrid4		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
3008 HYbrid4		BSI(Built-in Systems Interface)				Live Data		Y		
3008 HYbrid4		BSI(Built-in Systems Interface)				Actuation Test		Y		
3008 HYbrid4		BSI(Built-in Systems Interface)				Special Function	Changing the mode Electrical	Y		
3008 HYbrid4		BSI(Built-in Systems Interface)				Special Function	Learning	Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Read ECU Information		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Read Fault Code		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Erase Fault Code		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Live Data		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Actuation Test		Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Special Function	Configuration	Y		
3008 HYbrid4		Engine management ECU	DCM35_HY	RHC_DW10CTED4-163CV		Special Function	Pack Repair	Y		
3008 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Read ECU Information		Y		
3008 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Read Fault Code		Y		
3008 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Erase Fault Code		Y		
3008 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Live Data		Y		
3008 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Actuation Test		Y		
3008 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Counters	Y		
3008 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Programming operations	Y		
3008 HYbrid4		Automatic gearbox or controlled manual gearbox	CFC300P_HY			Special Function	Replacement parts	Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
3008 HYbrid4		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Read ECU Information		Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Read Fault Code		Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Live Data		Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
3008 HYbrid4		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
3008 HYbrid4		Power steering				Read ECU Information		Y		
3008 HYbrid4		Power steering				Read Fault Code		Y		
3008 HYbrid4		Power steering				Erase Fault Code		Y		
3008 HYbrid4		Power steering				Live Data		Y		
3008 HYbrid4		Power steering				Actuation Test		Y		
3008 HYbrid4		Under inflation detection	DSG_UDS			Read ECU Information		Y		
3008 HYbrid4		Under inflation detection	DSG_UDS			Read Fault Code		Y		
3008 HYbrid4		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
3008 HYbrid4		Under inflation detection	DSG_UDS			Live Data		Y		
3008 HYbrid4		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
3008 HYbrid4		Under inflation detection	DSG			Read ECU Information		Y		
3008 HYbrid4		Under inflation detection	DSG			Read Fault Code		Y		
3008 HYbrid4		Under inflation detection	DSG			Erase Fault Code		Y		
3008 HYbrid4		Under inflation detection	DSG			Live Data		Y		
3008 HYbrid4		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
3008 HYbrid4		Electric secondary brake				Read ECU Information		Y		
3008 HYbrid4		Electric secondary brake				Read Fault Code		Y		
3008 HYbrid4		Electric secondary brake				Erase Fault Code		Y		
3008 HYbrid4		Electric secondary brake				Live Data		Y		
3008 HYbrid4		Electric secondary brake				Actuation Test		Y		
3008 HYbrid4		Electric secondary brake				Special Function	Pack Repair	Y		
3008 HYbrid4		Trailer relay unit				Read ECU Information		Y		
3008 HYbrid4		Trailer relay unit				Read Fault Code		Y		
3008 HYbrid4		Trailer relay unit				Erase Fault Code		Y		
3008 HYbrid4		Engine relay unit				Read ECU Information		Y		
3008 HYbrid4		Engine relay unit				Read Fault Code		Y		
3008 HYbrid4		Engine relay unit				Erase Fault Code		Y		
3008 HYbrid4		Engine relay unit				Actuation Test		Y		
3008 HYbrid4		Air conditioning				Read ECU Information		Y		
3008 HYbrid4		Air conditioning				Read Fault Code		Y		
3008 HYbrid4		Air conditioning				Erase Fault Code		Y		
3008 HYbrid4		Air conditioning				Live Data		Y		
3008 HYbrid4		Air conditioning				Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
3008 HYbrid4		Air conditioning				Special Function	Configuration	Y		
3008 HYbrid4		Air conditioning				Special Function	Pack Repair	Y		
3008 HYbrid4		Controls under the steering wheel	HDC			Read ECU Information		Y		
3008 HYbrid4		Controls under the steering wheel	HDC			Read Fault Code		Y		
3008 HYbrid4		Controls under the steering wheel	HDC			Erase Fault Code		Y		
3008 HYbrid4		Controls under the steering wheel	HDC			Live Data		Y		
3008 HYbrid4		Controls under the steering wheel	HDC			Actuation Test		Y		
3008 HYbrid4		Controls under the steering wheel	HDC			Special Function	Pack Repair	Y		
3008 HYbrid4		Controls under the steering wheel	COM2008P			Read ECU Information		Y		
3008 HYbrid4		Controls under the steering wheel	COM2008P			Read Fault Code		Y		
3008 HYbrid4		Controls under the steering wheel	COM2008P			Erase Fault Code		Y		
3008 HYbrid4		Controls under the steering wheel	COM2008P			Live Data		Y		
3008 HYbrid4		Controls under the steering wheel	COM2008P			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) with buttons			Read ECU Information		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) with buttons			Read Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) with buttons			Erase Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) with buttons			Live Data		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) with buttons			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) with buttons			Special Function	Configuration	Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) with buttons			Special Function	Pack repair	Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) without buttons			Read ECU Information		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) without buttons			Read Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) without buttons			Erase Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) without buttons			Live Data		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) without buttons			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) without buttons			Special Function	Configuration	Y		
3008 HYbrid4		Multifunction screen	Type "A" (segments) without buttons			Special Function	Pack repair	Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
3008 HYbrid4		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack repair	Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
3008 HYbrid4		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack repair	Y		
3008 HYbrid4		Instrument panel				Read ECU Information		Y		
3008 HYbrid4		Instrument panel				Read Fault Code		Y		
3008 HYbrid4		Instrument panel				Erase Fault Code		Y		
3008 HYbrid4		Instrument panel				Live Data		Y		
3008 HYbrid4		Instrument panel				Actuation Test		Y		
3008 HYbrid4		Windscreen wiper				Read ECU Information		Y		
3008 HYbrid4		Windscreen wiper				Actuation Test		Y		
3008 HYbrid4		Windscreen wiper				Special Function	Configuration	Y		
3008 HYbrid4		Windscreen wiper				Special Function	Pack Repair	Y		
3008 HYbrid4		Parking assistance				Read ECU Information		Y		
3008 HYbrid4		Parking assistance				Read Fault Code		Y		
3008 HYbrid4		Parking assistance				Erase Fault Code		Y		
3008 HYbrid4		Parking assistance				Live Data		Y		
3008 HYbrid4		Parking assistance				Special Function	Configuration	Y		
3008 HYbrid4		Parking assistance				Special Function	Pack Repair	Y		
3008 HYbrid4		Radio	RD4			Read ECU Information		Y		
3008 HYbrid4		Radio	RD4			Read Fault Code		Y		
3008 HYbrid4		Radio	RD4			Erase Fault Code		Y		
3008 HYbrid4		Radio	RD4			Live Data		Y		
3008 HYbrid4		Radio	RD4			Actuation Test		Y		
3008 HYbrid4		Radio	RD4			Special Function	Configuration	Y		
3008 HYbrid4		Radio	RD4			Special Function	Replacement parts	Y		
3008 HYbrid4		Radio	RD45			Read ECU Information		Y		
3008 HYbrid4		Radio	RD45			Read Fault Code		Y		
3008 HYbrid4		Radio	RD45			Erase Fault Code		Y		
3008 HYbrid4		Radio	RD45			Live Data		Y		
3008 HYbrid4		Radio	RD45			Actuation Test		Y		
3008 HYbrid4		Radio	RD45			Special Function	Configuration	Y		
3008 HYbrid4		Radio	RD45			Special Function	Pack Repair	Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Read ECU Information		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Read Fault Code		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Erase Fault Code		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Live Data		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Actuation Test		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Special Function	Configuration	Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
3008 HYbrid4		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
3008 HYbrid4		Audio amplifier				Read ECU Information		Y		
3008 HYbrid4		Audio amplifier				Read Fault Code		Y		
3008 HYbrid4		Audio amplifier				Erase Fault Code		Y		
3008 HYbrid4		Audio amplifier				Actuation Test		Y		
3008 HYbrid4		Audio amplifier				Special Function	Configuration	Y		
3008 HYbrid4		Audio amplifier				Special Function	Pack Repair	Y		
3008 HYbrid4		CD player / External CD player				Read ECU Information		Y		
3008 HYbrid4		CD player / External CD player				Read Fault Code		Y		
3008 HYbrid4		CD player / External CD player				Erase Fault Code		Y		
3008 HYbrid4		CD player / External CD player				Actuation Test		Y		
3008 HYbrid4		CD player / External CD player				Special Function	Configuration	Y		
3008 HYbrid4		Hands-free kit / Portable Unit				Read ECU Information		Y		
3008 HYbrid4		Hands-free kit / Portable Unit				Read Fault Code		Y		
3008 HYbrid4		Hands-free kit / Portable Unit				Erase Fault Code		Y		
3008 HYbrid4		Hands-free kit / Portable Unit				Live Data		Y		
3008 HYbrid4		Hands-free kit / Portable Unit				Actuation Test		Y		
3008 HYbrid4		Hands-free kit / Portable Unit				Special Function	Configuration	Y		
3008 HYbrid4		Hands-free kit / Portable Unit				Special Function	Pack repair	Y		
3008 HYbrid4		Anti-theft alarm				Read ECU Information		Y		
3008 HYbrid4		Anti-theft alarm				Read Fault Code		Y		
3008 HYbrid4		Anti-theft alarm				Erase Fault Code		Y		
3008 HYbrid4		Anti-theft alarm				Live Data		Y		
3008 HYbrid4		Anti-theft alarm				Actuation Test		Y		
3008 HYbrid4		Anti-theft alarm				Special Function	Configuration	Y		
3008 HYbrid4		Anti-theft alarm				Special Function	Pack repair	Y		
3008 HYbrid4		Driver's door module	Driver's door module			Read ECU Information		Y		
3008 HYbrid4		Driver's door module	Driver's door module			Read Fault Code		Y		
3008 HYbrid4		Driver's door module	Driver's door module			Erase Fault Code		Y		
3008 HYbrid4		Driver's door module	Driver's door module			Live Data		Y		
3008 HYbrid4		Driver's door module	Driver's door module			Actuation Test		Y		
3008 HYbrid4		Control panel dot matrix display				Read ECU Information		Y		
3008 HYbrid4		Control panel dot matrix display				Read Fault Code		Y		
3008 HYbrid4		Control panel dot matrix display				Erase Fault Code		Y		
3008 HYbrid4		Control panel dot matrix display				Live Data		Y		
3008 HYbrid4		Control panel dot matrix display				Actuation Test		Y		
3008 HYbrid4		Control panel dot matrix display				Special Function	Configuration	Y		
3008 HYbrid4		Service module /Independent telematic unit	MD_SERV			Read ECU Information		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD_SERV			Read Fault Code		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD_SERV			Erase Fault Code		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD_SERV			Live Data		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD_SERV			Actuation Test		Y		
3008 HYbrid4		Service module /Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
3008 HYbrid4		Service module /Independent telematic unit	MD_SERV			Special Function	Pack Repair	Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Read ECU Information		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Read Fault Code		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Erase Fault Code		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Live Data		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Actuation Test		Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Special Function	Configuration	Y		
3008 HYbrid4		Service module /Independent telematic unit	BTA			Special Function	Pack Repair	Y		
3008 HYbrid4		Rain and brightness sensor				Read ECU Information		Y		
3008 HYbrid4		Rain and brightness sensor				Read Fault Code		Y		
3008 HYbrid4		Rain and brightness sensor				Erase Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH			Read ECU Information		Y		
3008 HYbrid4		High Head Vision	VTH			Read Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH			Erase Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH			Live Data		Y		
3008 HYbrid4		High Head Vision	VTH			Actuation Test		Y		
3008 HYbrid4		High Head Vision	VTH			Special Function	Configuration	Y		
3008 HYbrid4		High Head Vision	VTH_UDS			Read ECU Information		Y		
3008 HYbrid4		High Head Vision	VTH_UDS			Read Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH_UDS			Erase Fault Code		Y		
3008 HYbrid4		High Head Vision	VTH_UDS			Live Data		Y		
3008 HYbrid4		High Head Vision	VTH_UDS			Actuation Test		Y		
3008 HYbrid4		High Head Vision	VTH_UDS			Special Function	Configuration	Y		
3008 HYbrid4		High Head Vision	VTH_UDS			Special Function	Pack repair	Y		
3008 HYbrid4		Hybrid mode selector				Read ECU Information		Y		
3008 HYbrid4		Hybrid mode selector				Read Fault Code		Y		
3008 HYbrid4		Hybrid mode selector				Live Data		Y		
3008 HYbrid4		Hybrid mode selector				Actuation Test		Y		
3008 HYbrid4		Traction battery ECU				Read ECU Information		Y		
3008 HYbrid4		Traction battery ECU				Read Fault Code		Y		
3008 HYbrid4		Traction battery ECU				Erase Fault Code		Y		
3008 HYbrid4		Traction battery ECU				Live Data		Y		
3008 HYbrid4		Traction battery ECU				Actuation Test		Y		
3008 HYbrid4		Hybrid control ECU 1				Read ECU Information		Y		
3008 HYbrid4		Hybrid control ECU 1				Read Fault Code		Y		
3008 HYbrid4		Hybrid control ECU 1				Erase Fault Code		Y		
3008 HYbrid4		Hybrid control ECU 1				Live Data		Y		
3008 HYbrid4		Hybrid control ECU 1				Actuation Test		Y		
3008 HYbrid4		Hybrid control ECU 1				Special Function	Pack repair	Y		
3008 HYbrid4		Hybrid control ECU 2				Read ECU Information		Y		
3008 HYbrid4		Hybrid control ECU 2				Read Fault Code		Y		
3008 HYbrid4		Hybrid control ECU 2				Erase Fault Code		Y		
3008 HYbrid4		Hybrid control ECU 2				Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
3008 HYbrid4		Battery charge status unit				Read ECU Information		Y		
3008 HYbrid4		Battery charge status unit				Read Fault Code		Y		
3008 HYbrid4		Battery charge status unit				Erase Fault Code		Y		
3008 HYbrid4		Battery charge status unit				Live Data		Y		
3008 HYbrid4		Battery charge status unit				Special Function	Configuration	Y		
3008 HYbrid4		Battery charge status unit				Special Function	Pack Repair	Y		
3008 HYbrid4		Diesel additive function				Read ECU Information		Y		
3008 HYbrid4		Diesel additive function				Read Fault Code		Y		
3008 HYbrid4		Diesel additive function				Erase Fault Code		Y		
3008 HYbrid4		Diesel additive function				Live Data		Y		
3008 HYbrid4		Diesel additive function				Actuation Test		Y		
3008 HYbrid4		Diesel additive function				Special Function	Configuration	Y		
3008 Chine		BSI(Built-in Systems Interface)				Read ECU Information		Y		
3008 Chine		BSI(Built-in Systems Interface)				Read Fault Code		Y		
3008 Chine		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
3008 Chine		BSI(Built-in Systems Interface)				Live Data		Y		
3008 Chine		BSI(Built-in Systems Interface)				Actuation Test		Y		
3008 Chine		BSI(Built-in Systems Interface)				Special Function	Changing the mode Electrical	Y		
3008 Chine		BSI(Built-in Systems Interface)				Special Function	Learning	Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_2	14 MED17.4.2 EURO 5	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_2	14 MED17.4.2 EURO 5	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_2	14 MED17.4.2 EURO 5	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_2	14 MED17.4.2 EURO 5	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_2	14 MED17.4.2 EURO 5	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_2	14 MED17.4.2 EURO 5	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_2	14 MED17.4.2 EURO 5	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_4		Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_4		Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_4		Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_4		Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_4		Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_4		Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO4	MEV17_4_EURO4 5FW	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO4	MED17_4_EURO4 5FX	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MEV17_4_EURO5	MEV17_4_EURO5 5FS	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MED17_4_EURO5	MED17_4_EURO5 5FV	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read ECU Information		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Read Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Live Data		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Actuation Test		Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Petrol	MM6KP	MM6KP RFJ	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP-110CV	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHE	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	DCM35	DCM35 RHH	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HR	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HR	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HR	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HR	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HR	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HR	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HR	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Pack Repair	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HR	Read ECU Information		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HR	Read Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HR	Erase Fault Code		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HR	Live Data		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HR	Actuation Test		Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HR	Special Function	Configuration	Y		
3008 Chine		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HR	Special Function	Pack Repair	Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read ECU Information		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read Fault Code		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Erase Fault Code		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Live Data		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Actuation Test		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Configuration	Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Pack Repair	Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
3008 Chine		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
3008 Chine		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
3008 Chine		Air bags and pre-tensioners control unit				Read ECU Information		Y		
3008 Chine		Air bags and pre-tensioners control unit				Read Fault Code		Y		
3008 Chine		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
3008 Chine		Air bags and pre-tensioners control unit				Live Data		Y		
3008 Chine		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
3008 Chine		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
3008 Chine		Power steering				Read ECU Information		Y		
3008 Chine		Power steering				Read Fault Code		Y		
3008 Chine		Power steering				Erase Fault Code		Y		
3008 Chine		Power steering				Live Data		Y		
3008 Chine		Power steering				Actuation Test		Y		
3008 Chine		Under inflation detection	DSG_UDS			Read ECU Information		Y		
3008 Chine		Under inflation detection	DSG_UDS			Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
3008 Chine		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
3008 Chine		Under inflation detection	DSG_UDS			Live Data		Y		
3008 Chine		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
3008 Chine		Under inflation detection	DSG			Read ECU Information		Y		
3008 Chine		Under inflation detection	DSG			Read Fault Code		Y		
3008 Chine		Under inflation detection	DSG			Erase Fault Code		Y		
3008 Chine		Under inflation detection	DSG			Live Data		Y		
3008 Chine		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
3008 Chine		Battery charge status unit				Read ECU Information		Y		
3008 Chine		Battery charge status unit				Read Fault Code		Y		
3008 Chine		Battery charge status unit				Erase Fault Code		Y		
3008 Chine		Battery charge status unit				Live Data		Y		
3008 Chine		Electric secondary brake				Read ECU Information		Y		
3008 Chine		Electric secondary brake				Read Fault Code		Y		
3008 Chine		Electric secondary brake				Erase Fault Code		Y		
3008 Chine		Electric secondary brake				Live Data		Y		
3008 Chine		Electric secondary brake				Actuation Test		Y		
3008 Chine		Electric secondary brake				Special Function	Pack Repair	Y		
3008 Chine		Engine relay unit				Read ECU Information		Y		
3008 Chine		Engine relay unit				Read Fault Code		Y		
3008 Chine		Engine relay unit				Erase Fault Code		Y		
3008 Chine		Engine relay unit				Actuation Test		Y		
3008 Chine		Air conditioning				Read ECU Information		Y		
3008 Chine		Air conditioning				Read Fault Code		Y		
3008 Chine		Air conditioning				Erase Fault Code		Y		
3008 Chine		Air conditioning				Live Data		Y		
3008 Chine		Air conditioning				Actuation Test		Y		
3008 Chine		Air conditioning				Special Function	Configuration	Y		
3008 Chine		Air conditioning				Special Function	Pack Repair	Y		
3008 Chine		Multifunction screen	Type "A" (segments) with buttons			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "A" (segments) with buttons			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "A" (segments) with buttons			Erase Fault Code		Y		
3008 Chine		Multifunction screen	Type "A" (segments) with buttons			Live Data		Y		
3008 Chine		Multifunction screen	Type "A" (segments) with buttons			Actuation Test		Y		
3008 Chine		Multifunction screen	Type "A" (segments) with buttons			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "A" (segments) with buttons			Special Function	Pack repair	Y		
3008 Chine		Multifunction screen	Type "A" (segments) without buttons			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "A" (segments) without buttons			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "A" (segments) without buttons			Erase Fault Code		Y		
3008 Chine		Multifunction screen	Type "A" (segments) without buttons			Live Data		Y		
3008 Chine		Multifunction screen	Type "A" (segments) without buttons			Actuation Test		Y		
3008 Chine		Multifunction screen	Type "A" (segments) without buttons			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "A" (segments) without buttons			Special Function	Pack repair	Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack repair	Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack repair	Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
3008 Chine		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack repair	Y		
3008 Chine		Instrument panel				Read ECU Information		Y		
3008 Chine		Instrument panel				Read Fault Code		Y		
3008 Chine		Instrument panel				Erase Fault Code		Y		
3008 Chine		Instrument panel				Live Data		Y		
3008 Chine		Instrument panel				Actuation Test		Y		
3008 Chine		Radio	RD43			Read ECU Information		Y		
3008 Chine		Radio	RD43			Read Fault Code		Y		
3008 Chine		Radio	RD43			Erase Fault Code		Y		
3008 Chine		Radio	RD43			Live Data		Y		
3008 Chine		Radio	RD43			Actuation Test		Y		
3008 Chine		Radio	RD43			Special Function	Configuration	Y		
3008 Chine		Radio	RD43			Special Function	Replacement parts	Y		
3008 Chine		Radio	RD45			Read ECU Information		Y		
3008 Chine		Radio	RD45			Read Fault Code		Y		
3008 Chine		Radio	RD45			Erase Fault Code		Y		
3008 Chine		Radio	RD45			Live Data		Y		
3008 Chine		Radio	RD45			Actuation Test		Y		
3008 Chine		Radio	RD45			Special Function	Configuration	Y		
3008 Chine		Radio	RD45			Special Function	Pack Repair	Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEGC			Read ECU Information		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEGC			Read Fault Code		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEGC			Erase Fault Code		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEGC			Live Data		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEGC			Actuation Test		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEGC			Special Function	Configuration	Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEGC			Special Function	Pack repair	Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Read ECU Information		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Read Fault Code		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Erase Fault Code		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Live Data		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Actuation Test		Y		
3008 Chine		Telematic unit(RTX)or audio-naviggation	MRN			Special Function	Configuration	Y		
3008 Chine		Anti-theft alarm				Read ECU Information		Y		
3008 Chine		Anti-theft alarm				Read Fault Code		Y		
3008 Chine		Anti-theft alarm				Erase Fault Code		Y		
3008 Chine		Anti-theft alarm				Live Data		Y		
3008 Chine		Anti-theft alarm				Actuation Test		Y		
3008 Chine		Traction control mode selector				Read ECU Information		Y		
3008 Chine		Traction control mode selector				Read Fault Code		Y		
3008 Chine		Traction control mode selector				Live Data		Y		
3008 Chine		Traction control mode selector				Actuation Test		Y		
3008 Chine		Driver's door module	Driver's door module			Read ECU Information		Y		
3008 Chine		Driver's door module	Driver's door module			Read Fault Code		Y		
3008 Chine		Driver's door module	Driver's door module			Erase Fault Code		Y		
3008 Chine		Driver's door module	Driver's door module			Live Data		Y		
3008 Chine		Driver's door module	Driver's door module			Actuation Test		Y		
3008 Chine		Control panel dot matrix display				Read ECU Information		Y		
3008 Chine		Control panel dot matrix display				Read Fault Code		Y		
3008 Chine		Control panel dot matrix display				Erase Fault Code		Y		
3008 Chine		Control panel dot matrix display				Live Data		Y		
3008 Chine		Control panel dot matrix display				Actuation Test		Y		
3008 Chine		Control panel dot matrix display				Special Function	Configuration	Y		
3008 Chine		Rain and brightness sensor				Read ECU Information		Y		
3008 Chine		Rain and brightness sensor				Read Fault Code		Y		
3008 Chine		Rain and brightness sensor				Erase Fault Code		Y		
3008 Chine		Voltage retaining device	DMTC			Read ECU Information		Y		
3008 Chine		Voltage retaining device	DMTR			Read ECU Information		Y		
3008 Chine		Voltage retaining device	DMTR			Read Fault Code		Y		
3008 Chine		Voltage retaining device	DMTR			Erase Fault Code		Y		
3008 Chine		Controls under the steering wheel	HDC			Read ECU Information		Y		
3008 Chine		Controls under the steering wheel	HDC			Read Fault Code		Y		
3008 Chine		Controls under the steering wheel	HDC			Erase Fault Code		Y		
3008 Chine		Controls under the steering wheel	HDC			Live Data		Y		
3008 Chine		Controls under the steering wheel	HDC			Actuation Test		Y		
3008 Chine		Controls under the steering wheel	HDC			Special Function	Pack Repair	Y		
3008 Chine		Controls under the steering wheel	COM2008P			Read ECU Information		Y		
3008 Chine		Controls under the steering wheel	COM2008P			Read Fault Code		Y		
3008 Chine		Controls under the steering wheel	COM2008P			Erase Fault Code		Y		
3008 Chine		Controls under the steering wheel	COM2008P			Live Data		Y		
3008 Chine		Controls under the steering wheel	COM2008P			Actuation Test		Y		
3008 Chine		Windscreen wiper				Read ECU Information		Y		
3008 Chine		Windscreen wiper				Actuation Test		Y		
3008 Chine		High Head Vision	VTH			Read ECU Information		Y		
3008 Chine		High Head Vision	VTH			Read Fault Code		Y		
3008 Chine		High Head Vision	VTH			Erase Fault Code		Y		
3008 Chine		High Head Vision	VTH			Live Data		Y		
3008 Chine		High Head Vision	VTH			Actuation Test		Y		
3008 Chine		High Head Vision	VTH			Special Function	Configuration	Y		
3008 Chine		High Head Vision	VTH_UDS			Read ECU Information		Y		
3008 Chine		High Head Vision	VTH_UDS			Read Fault Code		Y		
3008 Chine		High Head Vision	VTH_UDS			Erase Fault Code		Y		
3008 Chine		High Head Vision	VTH_UDS			Live Data		Y		
3008 Chine		High Head Vision	VTH_UDS			Actuation Test		Y		
3008 Chine		High Head Vision	VTH_UDS			Special Function	Configuration	Y		
3008 Chine		High Head Vision	VTH_UDS			Special Function	Pack repair	Y		
3008 Chine		Parking assistance				Read ECU Information		Y		
3008 Chine		Parking assistance				Read Fault Code		Y		
3008 Chine		Parking assistance				Erase Fault Code		Y		
3008 Chine		Parking assistance				Live Data		Y		
3008 Chine		Parking assistance				Special Function	Configuration	Y		
3008 Chine		Parking assistance				Special Function	Pack Repair	Y		
3008 Chine		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
3008 Chine		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
3008 Chine		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
3008 Chine		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
3008 Chine		Multifunction video camera(CMF)				Read ECU Information		Y		
3008 Chine		Multifunction video camera(CMF)				Read Fault Code		Y		
3008 Chine		Multifunction video camera(CMF)				Erase Fault Code		Y		
3008 Chine		Multifunction video camera(CMF)				Live Data		Y		
3008 Chine		Multifunction video camera(CMF)				Actuation Test		Y		
3008 Chine		Panoramic vision assistance ECU				Read ECU Information		Y		
3008 Chine		Panoramic vision assistance ECU				Read Fault Code		Y		
3008 Chine		Panoramic vision assistance ECU				Erase Fault Code		Y		
3008 Chine		Panoramic vision assistance ECU				Live Data		Y		
3008 Chine		Panoramic vision assistance ECU				Actuation Test		Y		
3008 Chine		Panoramic vision assistance ECU				Special Function	Pack Repair	Y		
3008 Chine		Panoramic vision assistance ECU				Special Function	Learning	Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
3008(P84)		Engine management ECU	Petrol Engine	VD46		Read Fault Code		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Live Data		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Actuation Test		Y		
3008(P84)		Engine management ECU	Petrol Engine	VD46		Special Function	Pack Repair	Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17_4_4		Read ECU Information		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17_4_4		Read Fault Code		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17_4_4		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17_4_4		Live Data		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17_4_4		Actuation Test		Y		
3008(P84)		Engine management ECU	Petrol Engine	MED17_4_4		Special Function	Pack Repair	Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Read ECU Information		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Read Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Live Data		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Actuation Test		Y		
3008(P84)		Engine management ECU	Diesel Engine	EDC17C60		Special Function	Pack Repair	Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Read ECU Information		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Read Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Live Data		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Actuation Test		Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Special Function	Pack Repair	Y		
3008(P84)		Engine management ECU	Diesel Engine	DCM6.2		Special Function	Configuration	Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM_DCM71		Read ECU Information		Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM_DCM71		Read Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM_DCM71		Erase Fault Code		Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM_DCM71		Live Data		Y		
3008(P84)		Engine management ECU	Diesel Engine	CMM_DCM71		Actuation Test		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
3008(P84)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
3008(P84)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
3008(P84)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
3008(P84)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
3008(P84)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
3008(P84)		Air bags and pre-tensioners control unit				Live Data		Y		
3008(P84)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
3008(P84)		Engine relay unit				Read ECU Information		Y		
3008(P84)		Engine relay unit				Read Fault Code		Y		
3008(P84)		Engine relay unit				Erase Fault Code		Y		
3008(P84)		Intrusion alarm siren				Read ECU Information		Y		
3008(P84)		Intrusion alarm siren				Read Fault Code		Y		
3008(P84)		Intrusion alarm siren				Erase Fault Code		Y		
3008(P84)		Intrusion alarm siren				Live Data		Y		
3008(P84)		Intrusion alarm siren				Actuation Test		Y		
3008(P84)		Intrusion alarm siren				Special Function	Configuration	Y		
3008(P84)		Intrusion alarm siren				Special Function	Pack Repair	Y		
3008(P84)		Driver's door module	Yes			Read ECU Information		Y		
3008(P84)		Driver's door module	Yes			Read Fault Code		Y		
3008(P84)		Driver's door module	Yes			Erase Fault Code		Y		
3008(P84)		Driver's door module	Yes			Live Data		Y		
3008(P84)		Driver's door module	Yes			Actuation Test		Y		
3008(P84)		Driver's door module	No			Read ECU Information		Y		
3008(P84)		Driver's door module	No			Read Fault Code		Y		
3008(P84)		Driver's door module	No			Erase Fault Code		Y		
3008(P84)		Driver's door module	No			Live Data		Y		
3008(P84)		Driver's door module	No			Actuation Test		Y		
3008(P84)		Dynamic headlamp height adjuster				Read ECU Information		Y		
3008(P84)		Dynamic headlamp height adjuster				Read Fault Code		Y		
3008(P84)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
3008(P84)		Dynamic headlamp height adjuster				Live Data		Y		
3008(P84)		Dynamic headlamp height adjuster				Actuation Test		Y		
3008(P84)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
3008(P84)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
3008(P84)		Seat belt not fastened warning lights unit				Read ECU Information		Y		
3008(P84)		Seat belt not fastened warning lights unit				Actuation Test		Y		
3008(P84)		Battery charge status unit				Read ECU Information		Y		
3008(P84)		Battery charge status unit				Read Fault Code		Y		
3008(P84)		Battery charge status unit				Erase Fault Code		Y		
3008(P84)		Battery charge status unit				Live Data		Y		
3008(P84)		Battery charge status unit				Special Function	Configuration	Y		
3008(P84)		Battery charge status unit				Special Function	Pack Repair	Y		
3008(P84)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
3008(P84)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		
3008(P84)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
3008(P84)		Parking assistance	4 parking assistance sensors			Live Data		Y		
3008(P84)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
3008(P84)		Parking assistance	8 parking assistance sensors			Read ECU Information		Y		
3008(P84)		Parking assistance	8 parking assistance sensors			Read Fault Code		Y		
3008(P84)		Parking assistance	8 parking assistance sensors			Erase Fault Code		Y		
3008(P84)		Parking assistance	8 parking assistance sensors			Live Data		Y		
3008(P84)		Parking assistance	8 parking assistance sensors			Actuation Test		Y		
3008(P84)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
3008(P84)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
3008(P84)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
3008(P84)		Parking assistance	10 parking assistance sensors			Live Data		Y		
3008(P84)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
3008(P84)		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
3008(P84)		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
3008(P84)		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
3008(P84)		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
3008(P84)		Air conditioning				Read ECU Information		Y		
3008(P84)		Air conditioning				Read Fault Code		Y		
3008(P84)		Air conditioning				Erase Fault Code		Y		
3008(P84)		Air conditioning				Live Data		Y		
3008(P84)		Air conditioning				Actuation Test		Y		
3008(P84)		Air conditioning				Special Function	Pack Repair	Y		
3008(P84)		Panoramic vision assistance ECU				Read ECU Information		Y		
3008(P84)		Panoramic vision assistance ECU				Read Fault Code		Y		
3008(P84)		Panoramic vision assistance ECU				Erase Fault Code		Y		
3008(P84)		Panoramic vision assistance ECU				Live Data		Y		
3008(P84)		Panoramic vision assistance ECU				Actuation Test		Y		
3008(P84)		Panoramic vision assistance ECU				Special Function	Pack Repair	Y		
3008(P84)		Hands full access ECU, right-hand side or rear				Read ECU Information		Y		
3008(P84)		Hands full access ECU, right-hand side or rear				Read Fault Code		Y		
3008(P84)		Controls under the steering wheel				Read ECU Information		Y		
3008(P84)		Controls under the steering wheel				Read Fault Code		Y		
3008(P84)		Controls under the steering wheel				Erase Fault Code		Y		
3008(P84)		Controls under the steering wheel				Live Data		Y		
3008(P84)		Controls under the steering wheel				Actuation Test		Y		
3008(P84)		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
3008(P84)		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
3008(P84)		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
3008(P84)		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
3008(P84)		Supply protection and management unit				Read ECU Information		Y		
3008(P84)		Supply protection and management unit				Read Fault Code		Y		
3008(P84)		Supply protection and management unit				Erase Fault Code		Y		
3008(P84)		Supply protection and management unit				Live Data		Y		
3008(P84)		Voltage retaining device	DMTC			Read ECU Information		Y		
3008(P84)		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
3008(P84)		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
3008(P84)		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
3008(P84)		Diesel additive pump				Read ECU Information		Y		
3008(P84)		Diesel additive pump				Read Fault Code		Y		
3008(P84)		Diesel additive pump				Erase Fault Code		Y		
3008(P84)		Diesel additive pump				Live Data		Y		
3008(P84)		Diesel additive pump				Actuation Test		Y		
3008(P84)		Traction control mode selector				Read ECU Information		Y		
3008(P84)		Traction control mode selector				Read Fault Code		Y		
3008(P84)		Traction control mode selector				Live Data		Y		
3008(P84)		Traction control mode selector				Actuation Test		Y		
3008(P84)		Electric steering lock				Read ECU Information		Y		
3008(P84)		Electric steering lock				Read Fault Code		Y		
3008(P84)		Electric steering lock				Erase Fault Code		Y		
3008(P84)		Electric steering lock				Live Data		Y		
3008(P84)		Trailer relay unit				Read ECU Information		Y		
3008(P84)		Trailer relay unit				Read Fault Code		Y		
3008(P84)		Trailer relay unit				Erase Fault Code		Y		
3008(P84)		Trailer relay unit				Live Data		Y		
3008(P84)		Trailer relay unit				Actuation Test		Y		
3008(P84)		Power steering				Read ECU Information		Y		
3008(P84)		Power steering				Read Fault Code		Y		
3008(P84)		Power steering				Erase Fault Code		Y		
3008(P84)		Power steering				Live Data		Y		
3008(P84)		Front left seat heated pads and ventilation regulation ECU				Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
3008(P84)		Front left seat heated pads and ventilation regulation ECU				Read Fault Code		Y		
3008(P84)		Front left seat heated pads and ventilation regulation ECU				Live Data		Y		
3008(P84)		Front left seat heated pads and ventilation regulation ECU				Actuation Test		Y		
3008(P84)		Front right seat heated pads and ventilation regulation ECU				Read ECU Information		Y		
3008(P84)		Front right seat heated pads and ventilation regulation ECU				Read Fault Code		Y		
3008(P84)		Front right seat heated pads and ventilation regulation ECU				Live Data		Y		
3008(P84)		Front right seat heated pads and ventilation regulation ECU				Actuation Test		Y		
3008(P84)		Automatic gearbox electric control				Read ECU Information		Y		
3008(P84)		Automatic gearbox electric control				Read Fault Code		Y		
3008(P84)		Automatic gearbox electric control				Erase Fault Code		Y		
3008(P84)		Automatic gearbox electric control				Live Data		Y		
3008(P84)		Automatic gearbox electric control				Actuation Test		Y		
3008(P84)		Automatic gearbox electric control				Special Function	Programming	Y		
3008(P84)		Automatic gearbox electric control				Special Function	Replacement parts	Y		
3008(P84)		Motorised Boot ECU				Read ECU Information		Y		
3008(P84)		Motorised Boot ECU				Read Fault Code		Y		
3008(P84)		Motorised Boot ECU				Erase Fault Code		Y		
3008(P84)		Motorised Boot ECU				Live Data		Y		
3008(P84)		Motorised Boot ECU				Actuation Test		Y		
3008(P84)		External CD player				Read ECU Information		Y		
3008(P84)		External CD player				Read Fault Code		Y		
3008(P84)		External CD player				Erase Fault Code		Y		
3008(P84)		External CD player				Live Data		Y		
3008(P84)		External CD player				Actuation Test		Y		
3008(P84)		Anti-theft alarm				Read ECU Information		Y		
3008(P84)		Anti-theft alarm				Read Fault Code		Y		
3008(P84)		Anti-theft alarm				Erase Fault Code		Y		
3008(P84)		Anti-theft alarm				Live Data		Y		
3008(P84)		Anti-theft alarm				Special Function	Configuration	Y		
3008(P84)		Anti-theft alarm				Special Function	Pack Repair	Y		
3008(P84)		Radio amplifier				Read ECU Information		Y		
3008(P84)		Radio amplifier				Read Fault Code		Y		
3008(P84)		Radio amplifier				Erase Fault Code		Y		
3008(P84)		Radio amplifier				Actuation Test		Y		
3008(P84)		Vehicle Distance Assistance				Read ECU Information		Y		
3008(P84)		Vehicle Distance Assistance				Read Fault Code		Y		
3008(P84)		Vehicle Distance Assistance				Erase Fault Code		Y		
3008(P84)		Vehicle Distance Assistance				Live Data		Y		
3008(P84)		Vehicle Distance Assistance				Actuation Test		Y		
3008(P84)		Radio				Read ECU Information		Y		
3008(P84)		Radio				Read Fault Code		Y		
3008(P84)		Radio				Erase Fault Code		Y		
3008(P84)		Radio				Live Data		Y		
3008(P84)		Radio				Actuation Test		Y		
3008(P84)		Rain and brightness sensor				Read ECU Information		Y		
3008(P84)		Rain and brightness sensor				Read Fault Code		Y		
3008(P84)		Rain and brightness sensor				Erase Fault Code		Y		
3008(P84)		Rain and brightness sensor				Live Data		Y		
3008(P84)		Rain and brightness sensor				Special Function	Pack Repair	Y		
3008(P84)		Multifunction video camera(CMF)				Read ECU Information		Y		
3008(P84)		Multifunction video camera(CMF)				Read Fault Code		Y		
3008(P84)		Multifunction video camera(CMF)				Erase Fault Code		Y		
3008(P84)		Multifunction video camera(CMF)				Live Data		Y		
3008(P84)		Multifunction video camera(CMF)				Actuation Test		Y		
3008(P84)		Push gear lever				Read ECU Information		Y		
3008(P84)		Push gear lever				Read Fault Code		Y		
3008(P84)		Push gear lever				Erase Fault Code		Y		
3008(P84)		Push gear lever				Live Data		Y		
3008(P84)		Push gear lever				Actuation Test		Y		
3008(P84)		Service module / Independent telematic unit	BTA_2			Read ECU Information		Y		
3008(P84)		Service module / Independent telematic unit	BTA_2			Read Fault Code		Y		
3008(P84)		Service module / Independent telematic unit	BTA_2			Erase Fault Code		Y		
3008(P84)		Service module / Independent telematic unit	BTA_2			Live Data		Y		
3008(P84)		Service module / Independent telematic unit	BTA_2			Actuation Test		Y		
3008(P84)		Service module / Independent telematic unit	BTA_2			Special Function	Pack Repair	Y		
3008(P84)		Service module / Independent telematic unit	BTA_3R			Read ECU Information		Y		
3008(P84)		Service module / Independent telematic unit	BTA_3R			Read Fault Code		Y		
3008(P84)		Service module / Independent telematic unit	BTA_3R			Erase Fault Code		Y		
3008(P84)		Service module / Independent telematic unit	BTA_3R			Live Data		Y		
3008(P84)		Service module / Independent telematic unit	BTA_3R			Actuation Test		Y		
3008(P84)		Windscreen wiper				Read ECU Information		Y		
3008(P84)		Windscreen wiper				Read Fault Code		Y		
3008(P84)		Windscreen wiper				Erase Fault Code		Y		
3008(P84)		Windscreen wiper				Live Data		Y		
3008(P84)		Windscreen wiper				Actuation Test		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Read ECU Information		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Read Fault Code		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Erase Fault Code		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Live Data		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	NAC			Actuation Test		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Read ECU Information		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Read Fault Code		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Erase Fault Code		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Live Data		Y		
3008(P84)		Audio-navigation/telematic unit/connected audio system	RCC			Actuation Test		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Read ECU Information		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Read Fault Code		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Erase Fault Code		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Live Data		Y		
3008(P84)		Multiplexed control panel	RD6 audio system without air conditioning			Actuation Test		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Read ECU Information		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Read Fault Code		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Erase Fault Code		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Live Data		Y		
3008(P84)		Multiplexed control panel	RD6 audio system and manual air conditioning			Actuation Test		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Read ECU Information		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Read Fault Code		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Erase Fault Code		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Live Data		Y		
3008(P84)		Multiplexed control panel	Audio/Navigation NAC			Actuation Test		Y		
3008(P84)		Touch screen				Read ECU Information		Y		
3008(P84)		Touch screen				Read Fault Code		Y		
3008(P84)		Touch screen				Erase Fault Code		Y		
3008(P84)		Touch screen				Live Data		Y		
3008(P84)		Touch screen				Actuation Test		Y		
3008(P84)		Rear air conditioning ECU				Read ECU Information		Y		
3008(P84)		Rear air conditioning ECU				Read Fault Code		Y		
3008(P84)		Rear air conditioning ECU				Erase Fault Code		Y		
3008(P84)		Rear air conditioning ECU				Live Data		Y		
3008(P84)		Rear air conditioning ECU				Actuation Test		Y		
3008(P84)		Rear air conditioning ECU				Special Function	Pack Repair	Y		
3008(P84)		Driver's seat comfort ECU				Read ECU Information		Y		
3008(P84)		Driver's seat comfort ECU				Read Fault Code		Y		
3008(P84)		Driver's seat comfort ECU				Erase Fault Code		Y		
3008(P84)		Driver's seat comfort ECU				Live Data		Y		
3008(P84)		Driver's seat comfort ECU				Actuation Test		Y		
3008(P84)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read ECU Information		Y		
3008(P84)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read Fault Code		Y		
3008(P84)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Live Data		Y		
3008(P84)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Actuation Test		Y		
3008(P84)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read ECU Information		Y		
3008(P84)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read Fault Code		Y		
3008(P84)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Live Data		Y		
3008(P84)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Actuation Test		Y		
4007		BSI(Built-in Systems Interface)				Read ECU Information		Y		
4007		BSI(Built-in Systems Interface)				Read Fault Code		Y		
4007		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
4007		BSI(Built-in Systems Interface)				Live Data		Y		
4007		BSI(Built-in Systems Interface)				Actuation Test		Y		
4007		Engine ECU	Petrol	SFZ 4B12 MIVEC EURO4.		Read ECU Information		Y		
4007		Engine ECU	Petrol	SFZ 4B12 MIVEC EURO4.		Read Fault Code		Y		
4007		Engine ECU	Petrol	SFZ 4B12 MIVEC EURO4.		Erase Fault Code		Y		
4007		Engine ECU	Petrol	SFZ 4B12 MIVEC EURO4.		Live Data		Y		
4007		Engine ECU	Petrol	SFZ 4B12 MIVEC EURO4.		Actuation Test		Y		
4007		Engine ECU	Petrol	SFZ 4B12 MIVEC EURO4.		Special Function	Pack Repair	Y		
4007		Engine ECU	Petrol	AFZ 4B11 MIVEC EURO4.		Read ECU Information		Y		
4007		Engine ECU	Petrol	AFZ 4B11 MIVEC EURO4.		Read Fault Code		Y		
4007		Engine ECU	Petrol	AFZ 4B11 MIVEC EURO4.		Erase Fault Code		Y		
4007		Engine ECU	Petrol	AFZ 4B11 MIVEC EURO4.		Live Data		Y		
4007		Engine ECU	Petrol	AFZ 4B11 MIVEC EURO4.		Actuation Test		Y		
4007		Engine ECU	Petrol	AFZ 4B11 MIVEC EURO4.		Special Function	Pack Repair	Y		
4007		Engine ECU	Petrol	SFY 4B12 MIVEC EURO5.		Read ECU Information		Y		
4007		Engine ECU	Petrol	SFY 4B12 MIVEC EURO5.		Read Fault Code		Y		
4007		Engine ECU	Petrol	SFY 4B12 MIVEC EURO5.		Erase Fault Code		Y		
4007		Engine ECU	Petrol	SFY 4B12 MIVEC EURO5.		Live Data		Y		
4007		Engine ECU	Petrol	SFY 4B12 MIVEC EURO5.		Actuation Test		Y		
4007		Engine ECU	Petrol	SFY 4B12 MIVEC EURO5.		Special Function	Pack Repair	Y		
4007		Engine ECU	Diesel	4HN EDC16CP39.		Read ECU Information		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39.		Read Fault Code		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39.		Erase Fault Code		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39.		Live Data		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39.		Actuation Test		Y		
4007		Engine ECU	Diesel	4HN EDC16CP39.		Special Function	Pack Repair	Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5.		Read ECU Information		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5.		Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5.		Erase Fault Code		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5.		Live Data		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5.		Actuation Test		Y		
4007		Engine ECU	Diesel	4HK EDC16CP39 EURO5.		Special Function	Pack Repair	Y		
4007		ABS or ESP ECU	ABS.			Read ECU Information		Y		
4007		ABS or ESP ECU	ABS.			Read Fault Code		Y		
4007		ABS or ESP ECU	ABS.			Erase Fault Code		Y		
4007		ABS or ESP ECU	ABS.			Live Data		Y		
4007		ABS or ESP ECU	ABS.			Actuation Test		Y		
4007		ABS or ESP ECU	ABS.			Special Function	Pack Repair	Y		
4007		ABS or ESP ECU	ESP.			Read ECU Information		Y		
4007		ABS or ESP ECU	ESP.			Read Fault Code		Y		
4007		ABS or ESP ECU	ESP.			Erase Fault Code		Y		
4007		ABS or ESP ECU	ESP.			Live Data		Y		
4007		ABS or ESP ECU	ESP.			Actuation Test		Y		
4007		ABS or ESP ECU	ESP.			Special Function	Pack Repair	Y		
4007		Air bag				Read ECU Information		Y		
4007		Air bag				Read Fault Code		Y		
4007		Air bag				Erase Fault Code		Y		
4007		Air bag				Live Data		Y		
4007		Air bag				Actuation Test		Y		
4007		Heating/ventilation				Read ECU Information		Y		
4007		Heating/ventilation				Read Fault Code		Y		
4007		Heating/ventilation				Erase Fault Code		Y		
4007		Heating/ventilation				Live Data		Y		
4007		Heating/ventilation				Actuation Test		Y		
4007		Radio				Read ECU Information		Y		
4007		Radio				Read Fault Code		Y		
4007		Radio				Erase Fault Code		Y		
4007		Radio				Live Data		Y		
4007		Radio				Actuation Test		Y		
4007		Navigation				Read ECU Information		Y		
4007		Navigation				Read Fault Code		Y		
4007		Navigation				Erase Fault Code		Y		
4007		Instrument panel				Read ECU Information		Y		
4007		Instrument panel				Read Fault Code		Y		
4007		Instrument panel				Erase Fault Code		Y		
4007		Instrument panel				Live Data		Y		
4007		Instrument panel				Actuation Test		Y		
4007		Instrument panel				Special Function	Pack Repair	Y		
4007		Hands Free Kit				Read ECU Information		Y		
4007		Hands Free Kit				Read Fault Code		Y		
4007		Hands Free Kit				Erase Fault Code		Y		
4007		Hands Free Kit				Live Data		Y		
4007		Hands Free Kit				Actuation Test		Y		
4007		LEVIER GETRAG				Read ECU Information		Y		
4007		LEVIER GETRAG				Read Fault Code		Y		
4007		LEVIER GETRAG				Erase Fault Code		Y		
4007		LEVIER GETRAG				Live Data		Y		
4007		LEVIER GETRAG				Actuation Test		Y		
4007		Coded anti-start				Read ECU Information		Y		
4007		Coded anti-start				Read Fault Code		Y		
4007		Coded anti-start				Erase Fault Code		Y		
4007		Coded anti-start				Live Data		Y		
4007		Driver's door control pad				Read ECU Information		Y		
4007		Driver's door control pad				Read Fault Code		Y		
4007		Driver's door control pad				Erase Fault Code		Y		
4007		Driver's door control pad				Live Data		Y		
4007		Passenger's door control panel				Read ECU Information		Y		
4007		Passenger's door control panel				Read Fault Code		Y		
4007		Passenger's door control panel				Erase Fault Code		Y		
4007		Passenger's door control panel				Live Data		Y		
4007		Rear LH door switch panel				Read ECU Information		Y		
4007		Rear LH door switch panel				Read Fault Code		Y		
4007		Rear LH door switch panel				Erase Fault Code		Y		
4007		Rear LH door switch panel				Live Data		Y		
4007		Rear RH door switch panel				Read ECU Information		Y		
4007		Rear RH door switch panel				Read Fault Code		Y		
4007		Rear RH door switch panel				Erase Fault Code		Y		
4007		Rear RH door switch panel				Live Data		Y		
4007		Sun roof				Read ECU Information		Y		
4007		Sun roof				Read Fault Code		Y		
4007		Sun roof				Erase Fault Code		Y		
4007		Sun roof				Live Data		Y		
4007		Steering wheel angle sensor				Read ECU Information		Y		
4007		Steering wheel angle sensor				Read Fault Code		Y		
4007		Steering wheel angle sensor				Erase Fault Code		Y		
4007		Steering wheel angle sensor				Special Function	Pack Repair	Y		
4007		Static AFS				Read ECU Information		Y		
4007		Static AFS				Read Fault Code		Y		
4007		Static AFS				Erase Fault Code		Y		
4007		Static AFS				Live Data		Y		
4007		Static AFS				Actuation Test		Y		
4007		Rain and brightness sensor				Read ECU Information		Y		
4007		Rain and brightness sensor				Read Fault Code		Y		
4007		Rain and brightness sensor				Erase Fault Code		Y		
4007		Rain and brightness sensor				Live Data		Y		
4007		Rain and brightness sensor				Special Function	Replacement Parts	Y		
4007		Directional headlamps				Read ECU Information		Y		
4007		Directional headlamps				Read Fault Code		Y		
4007		Directional headlamps				Erase Fault Code		Y		
4007		Directional headlamps				Live Data		Y		
4007		Directional headlamps				Actuation Test		Y		
4007		Directional headlamps				Special Function	Calibration	Y		
4008		BSI(Built-in Systems Interface)				Read ECU Information		Y		
4008		BSI(Built-in Systems Interface)				Read Fault Code		Y		
4008		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
4008		BSI(Built-in Systems Interface)				Live Data		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Read ECU Information		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Read Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Erase Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Actuation Test		Y		
4008		Engine ECU	MIVEC	MIVEC SFZ		Special Function	Pack Repair	Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Read ECU Information		Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Read Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Erase Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Actuation Test		Y		
4008		Engine ECU	MIVEC	MIVEC SFY		Special Function	Pack Repair	Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Read ECU Information		Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Read Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Erase Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Actuation Test		Y		
4008		Engine ECU	MIVEC	MIVEC AFZ		Special Function	Pack Repair	Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Read ECU Information		Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Read Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Erase Fault Code		Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Actuation Test		Y		
4008		Engine ECU	MIVEC	MIVEC AFY		Special Function	Pack Repair	Y		
4008		Engine ECU	CMM_4A92			Read ECU Information		Y		
4008		Engine ECU	CMM_4A92			Read Fault Code		Y		
4008		Engine ECU	CMM_4A92			Erase Fault Code		Y		
4008		Engine ECU	CMM_4A92			Live Data		Y		
4008		Engine ECU	CMM_4A92			Actuation Test		Y		
4008		Engine ECU	CMM_4A92			Special Function	Pack Repair	Y		
4008		Engine ECU	HDI_4N13	HDI_4N13		Read ECU Information		Y		
4008		Engine ECU	HDI_4N13	HDI_4N13		Read Fault Code		Y		
4008		Engine ECU	HDI_4N13	HDI_4N13		Erase Fault Code		Y		
4008		Engine ECU	HDI_4N13	HDI_4N13		Live Data		Y		
4008		Engine ECU	HDI_4N13	HDI_4N13		Special Function	Pack Repair	Y		
4008		Engine ECU	HDI_4N13	HDI_4N13_STT		Read ECU Information		Y		
4008		Engine ECU	HDI_4N13	HDI_4N13_STT		Read Fault Code		Y		
4008		Engine ECU	HDI_4N13	HDI_4N13_STT		Erase Fault Code		Y		
4008		Engine ECU	HDI_4N13	HDI_4N13_STT		Live Data		Y		
4008		Engine ECU	HDI_4N13	HDI_4N13_STT		Special Function	Pack Repair	Y		
4008		Engine ECU	HDI_SID807_J3J4			Read ECU Information		Y		
4008		Engine ECU	HDI_SID807_J3J4			Read Fault Code		Y		
4008		Engine ECU	HDI_SID807_J3J4			Erase Fault Code		Y		
4008		Engine ECU	HDI_SID807_J3J4			Live Data		Y		
4008		Engine ECU	HDI_SID807_J3J4			Actuation Test		Y		
4008		Engine ECU	HDI_SID807_J3J4			Special Function	Pack Repair	Y		
4008		Gearbox				Read ECU Information		Y		
4008		Gearbox				Read Fault Code		Y		
4008		Gearbox				Erase Fault Code		Y		
4008		Gearbox				Live Data		Y		
4008		Gearbox				Special Function	Pack Repair	Y		
4008		ABS/traction control	ABS			Read ECU Information		Y		
4008		ABS/traction control	ABS			Read Fault Code		Y		
4008		ABS/traction control	ABS			Erase Fault Code		Y		
4008		ABS/traction control	ABS			Live Data		Y		
4008		ABS/traction control	ABS			Actuation Test		Y		
4008		ABS/traction control	ESP			Read ECU Information		Y		
4008		ABS/traction control	ESP			Read Fault Code		Y		
4008		ABS/traction control	ESP			Erase Fault Code		Y		
4008		ABS/traction control	ESP			Live Data		Y		
4008		ABS/traction control	ESP			Actuation Test		Y		
4008		ABS/traction control	ESP			Special Function	Pack Repair	Y		
4008		Rear final drive piloted clutch				Read ECU Information		Y		
4008		Rear final drive piloted clutch				Read Fault Code		Y		
4008		Rear final drive piloted clutch				Erase Fault Code		Y		
4008		Rear final drive piloted clutch				Live Data		Y		
4008		Rear final drive piloted clutch				Actuation Test		Y		
4008		Coded anti-start / Hands free starting access electronic module.	WCM			Read ECU Information		Y		
4008		Coded anti-start / Hands free starting access electronic module.	WCM			Read Fault Code		Y		
4008		Coded anti-start / Hands free starting access electronic module.	WCM			Erase Fault Code		Y		
4008		Coded anti-start / Hands free starting access electronic module.	WCM			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Read ECU Information		Y		
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Read Fault Code		Y		
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Erase Fault Code		Y		
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Live Data		Y		
4008		Coded anti-start / Hands free starting access electronic module.	KOS			Actuation Test		Y		
4008		Driver and passenger airbags				Read ECU Information		Y		
4008		Driver and passenger airbags				Read Fault Code		Y		
4008		Driver and passenger airbags				Erase Fault Code		Y		
4008		Driver and passenger airbags				Live Data		Y		
4008		Anti-theft alarm				Read Fault Code		Y		
4008		Anti-theft alarm				Erase Fault Code		Y		
4008		Anti-theft alarm				Live Data		Y		
4008		Starting authorisation ECU				Read ECU Information		Y		
4008		Starting authorisation ECU				Read Fault Code		Y		
4008		Starting authorisation ECU				Erase Fault Code		Y		
4008		Starting authorisation ECU				Live Data		Y		
4008		Calculateur stop and start				Read ECU Information		Y		
4008		Calculateur stop and start				Read Fault Code		Y		
4008		Calculateur stop and start				Erase Fault Code		Y		
4008		Calculateur stop and start				Live Data		Y		
4008		Steering wheel angle sensor				Read ECU Information		Y		
4008		Steering wheel angle sensor				Read Fault Code		Y		
4008		Steering wheel angle sensor				Erase Fault Code		Y		
4008		Steering wheel angle sensor				Special Function	Pack Repair	Y		
4008		Parking aid				Read ECU Information		Y		
4008		Parking aid				Read Fault Code		Y		
4008		Parking aid				Erase Fault Code		Y		
4008		Parking aid				Live Data		Y		
4008		Instrument panel				Read ECU Information		Y		
4008		Instrument panel				Read Fault Code		Y		
4008		Instrument panel				Erase Fault Code		Y		
4008		Instrument panel				Live Data		Y		
4008		Instrument panel				Actuation Test		Y		
4008		Instrument panel				Special Function	Pack Repair	Y		
4008		Heating/ventilation				Read ECU Information		Y		
4008		Heating/ventilation				Read Fault Code		Y		
4008		Heating/ventilation				Erase Fault Code		Y		
4008		Heating/ventilation				Live Data		Y		
4008		Heating/ventilation				Actuation Test		Y		
4008		Directional headlamps				Read ECU Information		Y		
4008		Directional headlamps				Read Fault Code		Y		
4008		Directional headlamps				Erase Fault Code		Y		
4008		Directional headlamps				Live Data		Y		
4008		Directional headlamps				Actuation Test		Y		
4008		Directional headlamps				Special Function	Calibration	Y		
4008		Power steering				Read ECU Information		Y		
4008		Power steering				Read Fault Code		Y		
4008		Power steering				Erase Fault Code		Y		
4008		Power steering				Live Data		Y		
4008		Radio or radiotelephone(radio part)				Read ECU Information		Y		
4008		Radio or radiotelephone(radio part)				Read Fault Code		Y		
4008		Radio or radiotelephone(radio part)				Erase Fault Code		Y		
4008		Radio or radiotelephone(radio part)				Live Data		Y		
4008		Radio or radiotelephone(radio part)				Actuation Test		Y		
4008		Navigation				Read ECU Information		Y		
4008		Navigation				Read Fault Code		Y		
4008		Navigation				Erase Fault Code		Y		
4008		Rain and brightness sensor				Read ECU Information		Y		
4008		Rain and brightness sensor				Read Fault Code		Y		
4008		Rain and brightness sensor				Erase Fault Code		Y		
4008		Rain and brightness sensor				Live Data		Y		
4008		Rain and brightness sensor				Special Function	Replacement Parts	Y		
4008(P84C)		Engine management ECU	MED17_4_4			Read ECU Information		Y		
4008(P84C)		Engine management ECU	MED17_4_4			Read Fault Code		Y		
4008(P84C)		Engine management ECU	MED17_4_4			Erase Fault Code		Y		
4008(P84C)		Engine management ECU	MED17_4_4			Live Data		Y		
4008(P84C)		Engine management ECU	MED17_4_4			Actuation Test		Y		
4008(P84C)		Engine management ECU	MED17_4_4			Special Function	Pack Repair	Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Read ECU Information		Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Read Fault Code		Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Erase Fault Code		Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Live Data		Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Actuation Test		Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Special Function	Temporary reactivation of the Stop and Start function(for a maximum distance of 10 km)	Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Special Function	Work on the ancillaries battery	Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Special Function	Initialisation of the autoadaptive values	Y		
4008(P84C)		Engine management ECU	MED17_4_4_EP8			Special Function	Replacement parts	Y		
4008(P84C)		Engine management ECU	VD46			Read ECU Information		Y		
4008(P84C)		Engine management ECU	VD46			Read Fault Code		Y		
4008(P84C)		Engine management ECU	VD46			Erase Fault Code		Y		
4008(P84C)		Engine management ECU	VD46			Live Data		Y		
4008(P84C)		Engine management ECU	VD46			Actuation Test		Y		
4008(P84C)		Engine management ECU	VD46			Special Function	Pack Repair	Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
4008(P84C)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
4008(P84C)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
4008(P84C)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
4008(P84C)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
4008(P84C)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
4008(P84C)		Air bags and pre-tensioners control unit				Live Data		Y		
4008(P84C)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
4008(P84C)		Dynamic headlamp height adjuster				Read ECU Information		Y		
4008(P84C)		Dynamic headlamp height adjuster				Read Fault Code		Y		
4008(P84C)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
4008(P84C)		Dynamic headlamp height adjuster				Live Data		Y		
4008(P84C)		Dynamic headlamp height adjuster				Actuation Test		Y		
4008(P84C)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
4008(P84C)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
4008(P84C)		Battery charge status unit				Read ECU Information		Y		
4008(P84C)		Battery charge status unit				Read Fault Code		Y		
4008(P84C)		Battery charge status unit				Erase Fault Code		Y		
4008(P84C)		Battery charge status unit				Live Data		Y		
4008(P84C)		Battery charge status unit				Special Function	Configuration	Y		
4008(P84C)		Battery charge status unit				Special Function	Pack Repair	Y		
4008(P84C)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
4008(P84C)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		
4008(P84C)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
4008(P84C)		Parking assistance	4 parking assistance sensors			Live Data		Y		
4008(P84C)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
4008(P84C)		Parking assistance	8 parking assistance sensors			Read ECU Information		Y		
4008(P84C)		Parking assistance	8 parking assistance sensors			Read Fault Code		Y		
4008(P84C)		Parking assistance	8 parking assistance sensors			Erase Fault Code		Y		
4008(P84C)		Parking assistance	8 parking assistance sensors			Live Data		Y		
4008(P84C)		Parking assistance	8 parking assistance sensors			Actuation Test		Y		
4008(P84C)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
4008(P84C)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
4008(P84C)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
4008(P84C)		Parking assistance	10 parking assistance sensors			Live Data		Y		
4008(P84C)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
4008(P84C)		Air conditioning				Read ECU Information		Y		
4008(P84C)		Air conditioning				Read Fault Code		Y		
4008(P84C)		Air conditioning				Erase Fault Code		Y		
4008(P84C)		Air conditioning				Live Data		Y		
4008(P84C)		Air conditioning				Actuation Test		Y		
4008(P84C)		Air conditioning				Special Function	Pack Repair	Y		
4008(P84C)		Panoramic vision assistance ECU				Read ECU Information		Y		
4008(P84C)		Panoramic vision assistance ECU				Read Fault Code		Y		
4008(P84C)		Panoramic vision assistance ECU				Erase Fault Code		Y		
4008(P84C)		Panoramic vision assistance ECU				Live Data		Y		
4008(P84C)		Panoramic vision assistance ECU				Actuation Test		Y		
4008(P84C)		Panoramic vision assistance ECU				Special Function	Pack Repair	Y		
4008(P84C)		Hands full access ECU, right-hand side or rear				Read ECU Information		Y		
4008(P84C)		Hands full access ECU, right-hand side or rear				Read Fault Code		Y		
4008(P84C)		Controls under the steering wheel				Read ECU Information		Y		
4008(P84C)		Controls under the steering wheel				Read Fault Code		Y		
4008(P84C)		Controls under the steering wheel				Erase Fault Code		Y		
4008(P84C)		Controls under the steering wheel				Live Data		Y		
4008(P84C)		Controls under the steering wheel				Actuation Test		Y		
4008(P84C)		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
4008(P84C)		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
4008(P84C)		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
4008(P84C)		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
4008(P84C)		Voltage retaining device	DMTC			Read ECU Information		Y		
4008(P84C)		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
4008(P84C)		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
4008(P84C)		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
4008(P84C)		Front left seat heated pads and ventilation regulation ECU				Read ECU Information		Y		
4008(P84C)		Front left seat heated pads and ventilation regulation ECU				Read Fault Code		Y		
4008(P84C)		Front left seat heated pads and ventilation regulation ECU				Live Data		Y		
4008(P84C)		Front left seat heated pads and ventilation regulation ECU				Actuation Test		Y		
4008(P84C)		Front right seat heated pads and ventilation regulation ECU				Read ECU Information		Y		
4008(P84C)		Front right seat heated pads and ventilation regulation ECU				Read Fault Code		Y		
4008(P84C)		Front right seat heated pads and ventilation regulation ECU				Live Data		Y		
4008(P84C)		Front right seat heated pads and ventilation regulation ECU				Actuation Test		Y		
4008(P84C)		Automatic gearbox electric control				Read ECU Information		Y		
4008(P84C)		Automatic gearbox electric control				Read Fault Code		Y		
4008(P84C)		Automatic gearbox electric control				Erase Fault Code		Y		
4008(P84C)		Automatic gearbox electric control				Live Data		Y		
4008(P84C)		Automatic gearbox electric control				Actuation Test		Y		
4008(P84C)		Automatic gearbox electric control				Special Function	Programming	Y		
4008(P84C)		Automatic gearbox electric control				Special Function	Replacement parts	Y		
4008(P84C)		Motorised Boot ECU				Read ECU Information		Y		
4008(P84C)		Motorised Boot ECU				Read Fault Code		Y		
4008(P84C)		Motorised Boot ECU				Erase Fault Code		Y		
4008(P84C)		Motorised Boot ECU				Live Data		Y		
4008(P84C)		Motorised Boot ECU				Actuation Test		Y		
4008(P84C)		Driver's door module	PDPC			Read ECU Information		Y		
4008(P84C)		Driver's door module	PDPC			Read Fault Code		Y		
4008(P84C)		Driver's door module	PDPC			Erase Fault Code		Y		
4008(P84C)		Driver's door module	PDPC			Live Data		Y		
4008(P84C)		Driver's door module	PDPC			Actuation Test		Y		
4008(P84C)		Driver's door module	PDPC_UDS			Read ECU Information		Y		
4008(P84C)		Driver's door module	PDPC_UDS			Read Fault Code		Y		
4008(P84C)		Driver's door module	PDPC_UDS			Erase Fault Code		Y		
4008(P84C)		Driver's door module	PDPC_UDS			Live Data		Y		
4008(P84C)		Driver's door module	PDPC_UDS			Actuation Test		Y		
4008(P84C)		Vehicle Distance Assistance				Read ECU Information		Y		
4008(P84C)		Vehicle Distance Assistance				Read Fault Code		Y		
4008(P84C)		Vehicle Distance Assistance				Erase Fault Code		Y		
4008(P84C)		Vehicle Distance Assistance				Live Data		Y		
4008(P84C)		Vehicle Distance Assistance				Actuation Test		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Read ECU Information		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Read Fault Code		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Erase Fault Code		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Live Data		Y		
4008(P84C)		Multiplexed control panel	Audio/Navigation NAC			Actuation Test		Y		
4008(P84C)		Rear air conditioning ECU				Read ECU Information		Y		
4008(P84C)		Rear air conditioning ECU				Read Fault Code		Y		
4008(P84C)		Rear air conditioning ECU				Erase Fault Code		Y		
4008(P84C)		Rear air conditioning ECU				Live Data		Y		
4008(P84C)		Rear air conditioning ECU				Actuation Test		Y		
4008(P84C)		Rear air conditioning ECU				Special Function	Pack Repair	Y		
4008(P84C)		Electric steering lock				Read ECU Information		Y		
4008(P84C)		Electric steering lock				Read Fault Code		Y		
4008(P84C)		Electric steering lock				Erase Fault Code		Y		
4008(P84C)		Electric steering lock				Live Data		Y		
4008(P84C)		Rain and brightness sensor				Read ECU Information		Y		
4008(P84C)		Rain and brightness sensor				Read Fault Code		Y		
4008(P84C)		Rain and brightness sensor				Erase Fault Code		Y		
4008(P84C)		Rain and brightness sensor				Live Data		Y		
4008(P84C)		Rain and brightness sensor				Special Function	Pack Repair	Y		
4008(P84C)		Radio amplifier				Read ECU Information		Y		
4008(P84C)		Radio amplifier				Read Fault Code		Y		
4008(P84C)		Radio amplifier				Erase Fault Code		Y		
4008(P84C)		Radio amplifier				Actuation Test		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Read ECU Information		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Read Fault Code		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Erase Fault Code		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Live Data		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Actuation Test		Y		
4008(P84C)		Service module / Independent telematic unit	BTA_CN			Special Function	Pack Repair	Y		
4008(P84C)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read ECU Information		Y		
4008(P84C)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read Fault Code		Y		
4008(P84C)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Live Data		Y		
4008(P84C)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Actuation Test		Y		
4008(P84C)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read ECU Information		Y		
4008(P84C)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read Fault Code		Y		
4008(P84C)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Live Data		Y		
4008(P84C)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Actuation Test		Y		
4008(P84C)		Traction control mode selector				Read ECU Information		Y		
4008(P84C)		Traction control mode selector				Read Fault Code		Y		
4008(P84C)		Traction control mode selector				Live Data		Y		
4008(P84C)		Traction control mode selector				Actuation Test		Y		
4008(P84C)		Power steering				Read ECU Information		Y		
4008(P84C)		Power steering				Read Fault Code		Y		
4008(P84C)		Power steering				Erase Fault Code		Y		
4008(P84C)		Power steering				Live Data		Y		
4008(P84C)		Multifunction video camera(CMF)				Read ECU Information		Y		
4008(P84C)		Multifunction video camera(CMF)				Read Fault Code		Y		
4008(P84C)		Multifunction video camera(CMF)				Erase Fault Code		Y		
4008(P84C)		Multifunction video camera(CMF)				Live Data		Y		
4008(P84C)		Multifunction video camera(CMF)				Actuation Test		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Read ECU Information		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Read Fault Code		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Erase Fault Code		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Live Data		Y		
4008(P84C)		Audio-navigation/telematic unit/connected audio system	NAC			Actuation Test		Y		
4008(P84C)		Touch screen				Read ECU Information		Y		
4008(P84C)		Touch screen				Read Fault Code		Y		
4008(P84C)		Touch screen				Erase Fault Code		Y		
4008(P84C)		Touch screen				Live Data		Y		
4008(P84C)		Touch screen				Actuation Test		Y		
4008(P84C)		Driver's seat comfort ECU				Read ECU Information		Y		
4008(P84C)		Driver's seat comfort ECU				Read Fault Code		Y		
4008(P84C)		Driver's seat comfort ECU				Erase Fault Code		Y		
4008(P84C)		Driver's seat comfort ECU				Live Data		Y		
4008(P84C)		Driver's seat comfort ECU				Actuation Test		Y		
4008(P84C)		Push gear lever				Read ECU Information		Y		
4008(P84C)		Push gear lever				Read Fault Code		Y		
4008(P84C)		Push gear lever				Erase Fault Code		Y		
4008(P84C)		Push gear lever				Live Data		Y		
4008(P84C)		Push gear lever				Actuation Test		Y		
4008(P84C)		Windscreen wiper				Read ECU Information		Y		
4008(P84C)		Windscreen wiper				Read Fault Code		Y		
4008(P84C)		Windscreen wiper				Erase Fault Code		Y		
4008(P84C)		Windscreen wiper				Live Data		Y		
4008(P84C)		Windscreen wiper				Actuation Test		Y		
5008		BSI(Built-in Systems Interface)				Read ECU Information		Y		
5008		BSI(Built-in Systems Interface)				Read Fault Code		Y		
5008		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
5008		BSI(Built-in Systems Interface)				Live Data		Y		
5008		BSI(Built-in Systems Interface)				Actuation Test		Y		
5008		BSI(Built-in Systems Interface)				Special Function	Changing the mode Electrical	Y		
5008		BSI(Built-in Systems Interface)				Special Function	Learning	Y		
5008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Read ECU Information		Y		
5008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Read Fault Code		Y		
5008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Erase Fault Code		Y		
5008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Live Data		Y		
5008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Actuation Test		Y		
5008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Special Function	Configuration	Y		
5008		Engine management ECU	MEV17_4_2	MEV17_4_2EP6C	5FS MEV17.4.2 EURO 5	Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Read ECU Information		Y		
5008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Read Fault Code		Y		
5008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Erase Fault Code		Y		
5008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Live Data		Y		
5008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Actuation Test		Y		
5008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Special Function	Configuration	Y		
5008		Engine management ECU	MED17_4_2	5FV MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Read ECU Information		Y		
5008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Read Fault Code		Y		
5008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Erase Fault Code		Y		
5008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Live Data		Y		
5008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Actuation Test		Y		
5008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Special Function	Configuration	Y		
5008		Engine management ECU	MED17_4_2	5FN MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Read ECU Information		Y		
5008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Read Fault Code		Y		
5008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Erase Fault Code		Y		
5008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Live Data		Y		
5008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Actuation Test		Y		
5008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Special Function	Configuration	Y		
5008		Engine management ECU	MED17_4_2	5FM MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Read ECU Information		Y		
5008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Read Fault Code		Y		
5008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Erase Fault Code		Y		
5008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Live Data		Y		
5008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Actuation Test		Y		
5008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Special Function	Configuration	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
5008		Engine management ECU	MED17_4_2	5FE MED17.4.2 EURO 5		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17_4_4			Read ECU Information		Y		
5008		Engine management ECU	MED17_4_4			Read Fault Code		Y		
5008		Engine management ECU	MED17_4_4			Erase Fault Code		Y		
5008		Engine management ECU	MED17_4_4			Live Data		Y		
5008		Engine management ECU	MED17_4_4			Actuation Test		Y		
5008		Engine management ECU	MED17_4_4			Special Function	Pack Repair	Y		
5008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Read ECU Information		Y		
5008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Read Fault Code		Y		
5008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Erase Fault Code		Y		
5008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Live Data		Y		
5008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Actuation Test		Y		
5008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Special Function	Configuration	Y		
5008		Engine management ECU	MEV17_4_EURO4	MEV17_4_EURO4 5FW		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Read ECU Information		Y		
5008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Read Fault Code		Y		
5008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Erase Fault Code		Y		
5008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Live Data		Y		
5008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Actuation Test		Y		
5008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Special Function	Configuration	Y		
5008		Engine management ECU	MED17_4_EURO4	MED17_4_EURO4 5FX		Special Function	Pack Repair	Y		
5008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Read ECU Information		Y		
5008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Read Fault Code		Y		
5008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Erase Fault Code		Y		
5008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Live Data		Y		
5008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Actuation Test		Y		
5008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Special Function	Configuration	Y		
5008		Engine management ECU	MEV17_4_EURO5	MEV17_4_EURO5 5FS		Special Function	Pack Repair	Y		
5008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Read ECU Information		Y		
5008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Read Fault Code		Y		
5008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Erase Fault Code		Y		
5008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Live Data		Y		
5008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Actuation Test		Y		
5008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Special Function	Configuration	Y		
5008		Engine management ECU	MED17_4_EURO5	MED17_4_EURO5 5FV		Special Function	Pack Repair	Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Read ECU Information		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Read Fault Code		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Erase Fault Code		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Live Data		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Actuation Test		Y		
5008		Engine management ECU	VD46	Engine type 42: EB2DTS Engine with 5-speed manual gearbox		Special Function	Pack Repair	Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Read ECU Information		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Read Fault Code		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Erase Fault Code		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Live Data		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Actuation Test		Y		
5008		Engine management ECU	VD46	Engine type 44: EB2DTS Engine with 6-speed manual gearboX		Special Function	Pack Repair	Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read ECU Information		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Read Fault Code		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Erase Fault Code		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Live Data		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Actuation Test		Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Configuration	Y		
5008		Engine management ECU	EDC16C3	9HZ-DV6TED4 FAP-110CV		Special Function	Pack Repair	Y		
5008		Engine management ECU	EDC17C60			Read ECU Information		Y		
5008		Engine management ECU	EDC17C60			Read Fault Code		Y		
5008		Engine management ECU	EDC17C60			Erase Fault Code		Y		
5008		Engine management ECU	EDC17C60			Live Data		Y		
5008		Engine management ECU	EDC17C60			Actuation Test		Y		
5008		Engine management ECU	EDC17C60			Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Read ECU Information		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Read Fault Code		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Erase Fault Code		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Live Data		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Actuation Test		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FD TED4-150CV	AHX DCM6.2	Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Read ECU Information		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Read Fault Code		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Erase Fault Code		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Live Data		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Actuation Test		Y		
5008		Engine management ECU	DCM6.2	DCM6.2 DW10FDD TED4-136CV	AHV DCM6.2	Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Read ECU Information		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Read Fault Code		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Erase Fault Code		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Live Data		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Actuation Test		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Special Function	Configuration	Y		
5008		Engine management ECU	DCM3.5	DCM35 RHE		Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Read ECU Information		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Read Fault Code		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Erase Fault Code		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Live Data		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Actuation Test		Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Special Function	Configuration	Y		
5008		Engine management ECU	DCM3.5	DCM35 RHH		Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Read ECU Information		Y		
5008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Read Fault Code		Y		
5008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Erase Fault Code		Y		
5008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Live Data		Y		
5008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Actuation Test		Y		
5008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Special Function	Configuration	Y		
5008		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Special Function	Pack Repair	Y		
5008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Read ECU Information		Y		
5008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Read Fault Code		Y		
5008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Erase Fault Code		Y		
5008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Live Data		Y		
5008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Actuation Test		Y		
5008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Special Function	Configuration	Y		
5008		Engine management ECU	DCM3.5_BR2	RHE-DW10CTED4-150CV		Special Function	Pack Repair	Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Read ECU Information		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Read Fault Code		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Erase Fault Code		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Live Data		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Actuation Test		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Special Function	Configuration	Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HR		Special Function	Pack Repair	Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Read ECU Information		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Read Fault Code		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Erase Fault Code		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Live Data		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Actuation Test		Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Special Function	Configuration	Y		
5008		Engine management ECU	HDI_SID807	HDI_SID807 9HL		Special Function	Pack Repair	Y		
5008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read ECU Information		Y		
5008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Read Fault Code		Y		
5008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Erase Fault Code		Y		
5008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Live Data		Y		
5008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Actuation Test		Y		
5008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Configuration	Y		
5008		Engine management ECU	HDI_SID807_BR2	HDI_SID807_BR2 9HR		Special Function	Pack Repair	Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read ECU Information		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Read Fault Code		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Erase Fault Code		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Live Data		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Actuation Test		Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Configuration	Y		
5008		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81			Special Function	Pack Repair	Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read ECU Information		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Erase Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Live Data		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Actuation Test		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Configuration	Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Pack Repair	Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
5008		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
5008		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
5008		Air bags and pre-tensioners control unit				Read ECU Information		Y		
5008		Air bags and pre-tensioners control unit				Read Fault Code		Y		
5008		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
5008		Air bags and pre-tensioners control unit				Live Data		Y		
5008		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
5008		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
5008		Power steering				Read ECU Information		Y		
5008		Power steering				Read Fault Code		Y		
5008		Power steering				Erase Fault Code		Y		
5008		Power steering				Live Data		Y		
5008		Power steering				Actuation Test		Y		
5008		Diesel additive function	PADDGO			Read ECU Information		Y		
5008		Diesel additive function	PADDGO			Read Fault Code		Y		
5008		Diesel additive function	PADDGO			Erase Fault Code		Y		
5008		Diesel additive function	PADDGO			Live Data		Y		
5008		Diesel additive function	PADDGO			Actuation Test		Y		
5008		Diesel additive function	PADDGO			Special Function	Configuration	Y		
5008		Diesel additive function	PUMP_MUX_TI			Read ECU Information		Y		
5008		Diesel additive function	PUMP_MUX_TI			Read Fault Code		Y		
5008		Diesel additive function	PUMP_MUX_TI			Erase Fault Code		Y		
5008		Diesel additive function	PUMP_MUX_TI			Live Data		Y		
5008		Diesel additive function	PUMP_MUX_TI			Actuation Test		Y		
5008		Diesel additive function	PUMP_MUX_TI			Special Function	Configuration	Y		
5008		Diesel additive function	PADDGO_TI_E6			Read ECU Information		Y		
5008		Diesel additive function	PADDGO_TI_E6			Read Fault Code		Y		
5008		Diesel additive function	PADDGO_TI_E6			Erase Fault Code		Y		
5008		Diesel additive function	PADDGO_TI_E6			Live Data		Y		
5008		Diesel additive function	PADDGO_TI_E6			Special Function	Configuration	Y		
5008		Under inflation detection	DSG_UDS			Read ECU Information		Y		
5008		Under inflation detection	DSG_UDS			Read Fault Code		Y		
5008		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
5008		Under inflation detection	DSG_UDS			Live Data		Y		
5008		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
5008		Under inflation detection	DSG			Read ECU Information		Y		
5008		Under inflation detection	DSG			Read Fault Code		Y		
5008		Under inflation detection	DSG			Erase Fault Code		Y		
5008		Under inflation detection	DSG			Live Data		Y		
5008		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
5008		Dynamic headlamp height adjuster				Read ECU Information		Y		
5008		Dynamic headlamp height adjuster				Read Fault Code		Y		
5008		Dynamic headlamp height adjuster				Erase Fault Code		Y		
5008		Dynamic headlamp height adjuster				Live Data		Y		
5008		Dynamic headlamp height adjuster				Actuation Test		Y		
5008		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
5008		Dynamic headlamp height adjuster				Special Function	Pack repair	Y		
5008		Battery charge status unit	BECB			Read ECU Information		Y		
5008		Battery charge status unit	BECB			Read Fault Code		Y		
5008		Battery charge status unit	BECB			Erase Fault Code		Y		
5008		Battery charge status unit	BECB			Live Data		Y		
5008		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
5008		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
5008		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
5008		Battery charge status unit	BECB_GEN2			Live Data		Y		
5008		Battery charge status unit	BECB_GEN2			Special Function	Configuration	Y		
5008		Battery charge status unit	BECB_GEN2			Special Function	Pack Repair	Y		
5008		Vehicle Distance Assistance				Read ECU Information		Y		
5008		Vehicle Distance Assistance				Read Fault Code		Y		
5008		Vehicle Distance Assistance				Erase Fault Code		Y		
5008		Vehicle Distance Assistance				Live Data		Y		
5008		Vehicle Distance Assistance				Special Function	Configuration	Y		
5008		Vehicle Distance Assistance				Special Function	Pack repair	Y		
5008		Electric secondary brake				Read ECU Information		Y		
5008		Electric secondary brake				Read Fault Code		Y		
5008		Electric secondary brake				Erase Fault Code		Y		
5008		Electric secondary brake				Live Data		Y		
5008		Electric secondary brake				Actuation Test		Y		
5008		Electric secondary brake				Special Function	Pack Repair	Y		
5008		Trailer relay unit				Read ECU Information		Y		
5008		Trailer relay unit				Read Fault Code		Y		
5008		Trailer relay unit				Erase Fault Code		Y		
5008		Engine relay unit				Read ECU Information		Y		
5008		Engine relay unit				Read Fault Code		Y		
5008		Engine relay unit				Erase Fault Code		Y		
5008		Engine relay unit				Actuation Test		Y		
5008		Air conditioning				Read ECU Information		Y		
5008		Air conditioning				Read Fault Code		Y		
5008		Air conditioning				Erase Fault Code		Y		
5008		Air conditioning				Live Data		Y		
5008		Air conditioning				Actuation Test		Y		
5008		Air conditioning				Special Function	Configuration	Y		
5008		Air conditioning				Special Function	Pack Repair	Y		
5008		Controls under the steering wheel	HDC			Read ECU Information		Y		
5008		Controls under the steering wheel	HDC			Read Fault Code		Y		
5008		Controls under the steering wheel	HDC			Erase Fault Code		Y		
5008		Controls under the steering wheel	HDC			Live Data		Y		
5008		Controls under the steering wheel	HDC			Actuation Test		Y		
5008		Controls under the steering wheel	HDC			Special Function	Pack Repair	Y		
5008		Controls under the steering wheel	COM2008P			Read ECU Information		Y		
5008		Controls under the steering wheel	COM2008P			Read Fault Code		Y		
5008		Controls under the steering wheel	COM2008P			Erase Fault Code		Y		
5008		Controls under the steering wheel	COM2008P			Live Data		Y		
5008		Controls under the steering wheel	COM2008P			Actuation Test		Y		
5008		Multifunction screen	Type "A" (segments) with buttons			Read ECU Information		Y		
5008		Multifunction screen	Type "A" (segments) with buttons			Read Fault Code		Y		
5008		Multifunction screen	Type "A" (segments) with buttons			Erase Fault Code		Y		
5008		Multifunction screen	Type "A" (segments) with buttons			Live Data		Y		
5008		Multifunction screen	Type "A" (segments) with buttons			Actuation Test		Y		
5008		Multifunction screen	Type "A" (segments) with buttons			Special Function	Configuration	Y		
5008		Multifunction screen	Type "A" (segments) with buttons			Special Function	Pack repair	Y		
5008		Multifunction screen	Type "A" (segments) without buttons			Read ECU Information		Y		
5008		Multifunction screen	Type "A" (segments) without buttons			Read Fault Code		Y		
5008		Multifunction screen	Type "A" (segments) without buttons			Erase Fault Code		Y		
5008		Multifunction screen	Type "A" (segments) without buttons			Live Data		Y		
5008		Multifunction screen	Type "A" (segments) without buttons			Actuation Test		Y		
5008		Multifunction screen	Type "A" (segments) without buttons			Special Function	Configuration	Y		
5008		Multifunction screen	Type "A" (segments) without buttons			Special Function	Pack repair	Y		
5008		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
5008		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
5008		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack repair	Y		
5008		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
5008		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
5008		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
5008		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
5008		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
5008		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
5008		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack repair	Y		
5008		Instrument panel				Read ECU Information		Y		
5008		Instrument panel				Read Fault Code		Y		
5008		Instrument panel				Erase Fault Code		Y		
5008		Instrument panel				Live Data		Y		
5008		Instrument panel				Actuation Test		Y		
5008		Windscreen wiper				Read ECU Information		Y		
5008		Windscreen wiper				Actuation Test		Y		
5008		Windscreen wiper				Special Function	Configuration	Y		
5008		Windscreen wiper				Special Function	Pack Repair	Y		
5008		Parking assistance				Read ECU Information		Y		
5008		Parking assistance				Read Fault Code		Y		
5008		Parking assistance				Erase Fault Code		Y		
5008		Parking assistance				Live Data		Y		
5008		Parking assistance				Special Function	Configuration	Y		
5008		Parking assistance				Special Function	Pack Repair	Y		
5008		Radio	RD4			Read ECU Information		Y		
5008		Radio	RD4			Read Fault Code		Y		
5008		Radio	RD4			Erase Fault Code		Y		
5008		Radio	RD4			Live Data		Y		
5008		Radio	RD4			Actuation Test		Y		
5008		Radio	RD4			Special Function	Configuration	Y		
5008		Radio	RD4			Special Function	Replacement parts	Y		
5008		Radio	RD45			Read ECU Information		Y		
5008		Radio	RD45			Read Fault Code		Y		
5008		Radio	RD45			Erase Fault Code		Y		
5008		Radio	RD45			Live Data		Y		
5008		Radio	RD45			Actuation Test		Y		
5008		Radio	RD45			Special Function	Configuration	Y		
5008		Radio	RD45			Special Function	Pack Repair	Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Read ECU Information		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Read Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Erase Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Live Data		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Actuation Test		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_RNEG			Special Function	Configuration	Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Read ECU Information		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Read Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Erase Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Actuation Test		Y		
5008		Telematic unit(RTX)or audio-naviggation	RADIONAV_NG4			Special Function	Configuration	Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read ECU Information		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Read Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Erase Fault Code		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Live Data		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Actuation Test		Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Configuration	Y		
5008		Telematic unit(RTX)or audio-naviggation	RNEG2010			Special Function	Pack repair	Y		
5008		Audio amplifier				Read ECU Information		Y		
5008		Audio amplifier				Read Fault Code		Y		
5008		Audio amplifier				Erase Fault Code		Y		
5008		Audio amplifier				Actuation Test		Y		
5008		Audio amplifier				Special Function	Configuration	Y		
5008		Audio amplifier				Special Function	Pack Repair	Y		
5008		CD player / External CD player				Read ECU Information		Y		
5008		CD player / External CD player				Read Fault Code		Y		
5008		CD player / External CD player				Erase Fault Code		Y		
5008		CD player / External CD player				Actuation Test		Y		
5008		CD player / External CD player				Special Function	Configuration	Y		
5008		Hands-free kit / Portable Unit				Read ECU Information		Y		
5008		Hands-free kit / Portable Unit				Read Fault Code		Y		
5008		Hands-free kit / Portable Unit				Erase Fault Code		Y		
5008		Hands-free kit / Portable Unit				Live Data		Y		
5008		Hands-free kit / Portable Unit				Actuation Test		Y		
5008		Hands-free kit / Portable Unit				Special Function	Configuration	Y		
5008		Hands-free kit / Portable Unit				Special Function	Pack repair	Y		
5008		Anti-theft alarm				Read ECU Information		Y		
5008		Anti-theft alarm				Read Fault Code		Y		
5008		Anti-theft alarm				Erase Fault Code		Y		
5008		Anti-theft alarm				Live Data		Y		
5008		Anti-theft alarm				Actuation Test		Y		
5008		Anti-theft alarm				Special Function	Configuration	Y		
5008		Anti-theft alarm				Special Function	Pack repair	Y		
5008		Driver's door module	Driver's door module			Read ECU Information		Y		
5008		Driver's door module	Driver's door module			Read Fault Code		Y		
5008		Driver's door module	Driver's door module			Erase Fault Code		Y		
5008		Driver's door module	Driver's door module			Live Data		Y		
5008		Driver's door module	Driver's door module			Actuation Test		Y		
5008		Control panel dot matrix display				Read ECU Information		Y		
5008		Control panel dot matrix display				Read Fault Code		Y		
5008		Control panel dot matrix display				Erase Fault Code		Y		
5008		Control panel dot matrix display				Live Data		Y		
5008		Control panel dot matrix display				Actuation Test		Y		
5008		Control panel dot matrix display				Special Function	Configuration	Y		
5008		Service module /Independent telematic unit	MD_SERV			Read ECU Information		Y		
5008		Service module /Independent telematic unit	MD_SERV			Read Fault Code		Y		
5008		Service module /Independent telematic unit	MD_SERV			Erase Fault Code		Y		
5008		Service module /Independent telematic unit	MD_SERV			Live Data		Y		
5008		Service module /Independent telematic unit	MD_SERV			Actuation Test		Y		
5008		Service module /Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
5008		Service module /Independent telematic unit	MD_SERV			Special Function	Pack Repair	Y		
5008		Service module /Independent telematic unit	BTA			Read ECU Information		Y		
5008		Service module /Independent telematic unit	BTA			Read Fault Code		Y		
5008		Service module /Independent telematic unit	BTA			Erase Fault Code		Y		
5008		Service module /Independent telematic unit	BTA			Live Data		Y		
5008		Service module /Independent telematic unit	BTA			Actuation Test		Y		
5008		Service module /Independent telematic unit	BTA			Special Function	Configuration	Y		
5008		Service module /Independent telematic unit	BTA			Special Function	Pack Repair	Y		
5008		Network isolation control unit				Read ECU Information		Y		
5008		Network isolation control unit				Live Data		Y		
5008		Rain and brightness sensor				Read ECU Information		Y		
5008		Rain and brightness sensor				Read Fault Code		Y		
5008		Rain and brightness sensor				Erase Fault Code		Y		
5008		Voltage retaining device	DMTC			Read ECU Information		Y		
5008		Voltage retaining device	DMTR			Read ECU Information		Y		
5008		Voltage retaining device	DMTR			Read Fault Code		Y		
5008		Voltage retaining device	DMTR			Erase Fault Code		Y		
5008		High Head Vision	VTH			Read ECU Information		Y		
5008		High Head Vision	VTH			Read Fault Code		Y		
5008		High Head Vision	VTH			Erase Fault Code		Y		
5008		High Head Vision	VTH			Live Data		Y		
5008		High Head Vision	VTH			Actuation Test		Y		
5008		High Head Vision	VTH			Special Function	Configuration	Y		
5008		High Head Vision	VTH_UDS			Read ECU Information		Y		
5008		High Head Vision	VTH_UDS			Read Fault Code		Y		
5008		High Head Vision	VTH_UDS			Erase Fault Code		Y		
5008		High Head Vision	VTH_UDS			Live Data		Y		
5008		High Head Vision	VTH_UDS			Actuation Test		Y		
5008		High Head Vision	VTH_UDS			Special Function	Configuration	Y		
5008		High Head Vision	VTH_UDS			Special Function	Pack repair	Y		
5008		High frequency receiver				Read ECU Information		Y		
5008		High frequency receiver				Read Fault Code		Y		
5008		High frequency receiver				Erase Fault Code		Y		
5008		High frequency receiver				Live Data		Y		
5008		Seat belts not fastened LED unit				Read ECU Information		Y		
5008		Seat belts not fastened LED unit				Actuation Test		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Read ECU Information		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Read Fault Code		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Live Data		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Actuation Test		Y		
5008(P87)		Engine management ECU	Petrol Engine	VD46		Special Function	Pack Repair	Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17_4_4		Read ECU Information		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17_4_4		Read Fault Code		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17_4_4		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17_4_4		Live Data		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17_4_4		Actuation Test		Y		
5008(P87)		Engine management ECU	Petrol Engine	MED17_4_4		Special Function	Pack Repair	Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Read ECU Information		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Read Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Live Data		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Actuation Test		Y		
5008(P87)		Engine management ECU	Diesel Engine	EDC17C60		Special Function	Pack Repair	Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Read ECU Information		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Read Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Live Data		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Actuation Test		Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Special Function	Pack Repair	Y		
5008(P87)		Engine management ECU	Diesel Engine	DCM6.2		Special Function	Configuration	Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Read ECU Information		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Read Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Live Data		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Actuation Test		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Read ECU Information		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Read Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Erase Fault Code		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Live Data		Y		
5008(P87)		Engine management ECU	Diesel Engine	CMM_DCM71		Actuation Test		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read ECU Information		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Read Fault Code		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Erase Fault Code		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Live Data		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Actuation Test		Y		
5008(P87)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90			Special Function	Pack Repair	Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read ECU Information		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Read Fault Code		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Erase Fault Code		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Live Data		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Actuation Test		Y		
5008(P87)		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_UDS			Special Function	Pack Repair	Y		
5008(P87)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
5008(P87)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
5008(P87)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
5008(P87)		Air bags and pre-tensioners control unit				Live Data		Y		
5008(P87)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
5008(P87)		Engine relay unit				Read ECU Information		Y		
5008(P87)		Engine relay unit				Read Fault Code		Y		
5008(P87)		Engine relay unit				Erase Fault Code		Y		
5008(P87)		Intrusion alarm siren				Read ECU Information		Y		
5008(P87)		Intrusion alarm siren				Read Fault Code		Y		
5008(P87)		Intrusion alarm siren				Erase Fault Code		Y		
5008(P87)		Intrusion alarm siren				Live Data		Y		
5008(P87)		Intrusion alarm siren				Actuation Test		Y		
5008(P87)		Intrusion alarm siren				Special Function	Configuration	Y		
5008(P87)		Intrusion alarm siren				Special Function	Pack Repair	Y		
5008(P87)		Driver's door module	Yes			Read ECU Information		Y		
5008(P87)		Driver's door module	Yes			Read Fault Code		Y		
5008(P87)		Driver's door module	Yes			Erase Fault Code		Y		
5008(P87)		Driver's door module	Yes			Live Data		Y		
5008(P87)		Driver's door module	Yes			Actuation Test		Y		
5008(P87)		Driver's door module	No			Read ECU Information		Y		
5008(P87)		Driver's door module	No			Read Fault Code		Y		
5008(P87)		Driver's door module	No			Erase Fault Code		Y		
5008(P87)		Driver's door module	No			Live Data		Y		
5008(P87)		Driver's door module	No			Actuation Test		Y		
5008(P87)		Dynamic headlamp height adjuster				Read ECU Information		Y		
5008(P87)		Dynamic headlamp height adjuster				Read Fault Code		Y		
5008(P87)		Dynamic headlamp height adjuster				Erase Fault Code		Y		
5008(P87)		Dynamic headlamp height adjuster				Live Data		Y		
5008(P87)		Dynamic headlamp height adjuster				Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
5008(P87)		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
5008(P87)		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
5008(P87)		Seat belt not fastened warning lights unit				Read ECU Information		Y		
5008(P87)		Seat belt not fastened warning lights unit				Actuation Test		Y		
5008(P87)		Battery charge status unit				Read ECU Information		Y		
5008(P87)		Battery charge status unit				Read Fault Code		Y		
5008(P87)		Battery charge status unit				Erase Fault Code		Y		
5008(P87)		Battery charge status unit				Live Data		Y		
5008(P87)		Battery charge status unit				Special Function	Configuration	Y		
5008(P87)		Battery charge status unit				Special Function	Pack Repair	Y		
5008(P87)		Parking assistance	4 parking assistance sensors			Read ECU Information		Y		
5008(P87)		Parking assistance	4 parking assistance sensors			Read Fault Code		Y		
5008(P87)		Parking assistance	4 parking assistance sensors			Erase Fault Code		Y		
5008(P87)		Parking assistance	4 parking assistance sensors			Live Data		Y		
5008(P87)		Parking assistance	4 parking assistance sensors			Actuation Test		Y		
5008(P87)		Parking assistance	8 parking assistance sensors			Read ECU Information		Y		
5008(P87)		Parking assistance	8 parking assistance sensors			Read Fault Code		Y		
5008(P87)		Parking assistance	8 parking assistance sensors			Erase Fault Code		Y		
5008(P87)		Parking assistance	8 parking assistance sensors			Live Data		Y		
5008(P87)		Parking assistance	8 parking assistance sensors			Actuation Test		Y		
5008(P87)		Parking assistance	10 parking assistance sensors			Read ECU Information		Y		
5008(P87)		Parking assistance	10 parking assistance sensors			Read Fault Code		Y		
5008(P87)		Parking assistance	10 parking assistance sensors			Erase Fault Code		Y		
5008(P87)		Parking assistance	10 parking assistance sensors			Live Data		Y		
5008(P87)		Parking assistance	10 parking assistance sensors			Actuation Test		Y		
5008(P87)		Multifunction screen	EMF_C_UDS			Read ECU Information		Y		
5008(P87)		Multifunction screen	EMF_C_UDS			Read Fault Code		Y		
5008(P87)		Multifunction screen	EMF_C_UDS			Erase Fault Code		Y		
5008(P87)		Multifunction screen	EMF_C_UDS			Actuation Test		Y		
5008(P87)		Air conditioning				Read ECU Information		Y		
5008(P87)		Air conditioning				Read Fault Code		Y		
5008(P87)		Air conditioning				Erase Fault Code		Y		
5008(P87)		Air conditioning				Live Data		Y		
5008(P87)		Air conditioning				Actuation Test		Y		
5008(P87)		Air conditioning				Special Function	Pack Repair	Y		
5008(P87)		Panoramic vision assistance ECU				Read ECU Information		Y		
5008(P87)		Panoramic vision assistance ECU				Read Fault Code		Y		
5008(P87)		Panoramic vision assistance ECU				Erase Fault Code		Y		
5008(P87)		Panoramic vision assistance ECU				Live Data		Y		
5008(P87)		Panoramic vision assistance ECU				Actuation Test		Y		
5008(P87)		Panoramic vision assistance ECU				Special Function	Pack Repair	Y		
5008(P87)		Hands full access ECU, right-hand side or rear				Read ECU Information		Y		
5008(P87)		Hands full access ECU, right-hand side or rear				Read Fault Code		Y		
5008(P87)		Controls under the steering wheel				Read ECU Information		Y		
5008(P87)		Controls under the steering wheel				Read Fault Code		Y		
5008(P87)		Controls under the steering wheel				Erase Fault Code		Y		
5008(P87)		Controls under the steering wheel				Live Data		Y		
5008(P87)		Controls under the steering wheel				Actuation Test		Y		
5008(P87)		Control on the steering wheel / integral controls steering wheel				Read ECU Information		Y		
5008(P87)		Control on the steering wheel / integral controls steering wheel				Read Fault Code		Y		
5008(P87)		Control on the steering wheel / integral controls steering wheel				Erase Fault Code		Y		
5008(P87)		Control on the steering wheel / integral controls steering wheel				Live Data		Y		
5008(P87)		Supply protection and management unit				Read ECU Information		Y		
5008(P87)		Supply protection and management unit				Read Fault Code		Y		
5008(P87)		Supply protection and management unit				Erase Fault Code		Y		
5008(P87)		Supply protection and management unit				Live Data		Y		
5008(P87)		Voltage retaining device	DMTC			Read ECU Information		Y		
5008(P87)		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
5008(P87)		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
5008(P87)		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
5008(P87)		Diesel additive pump				Read ECU Information		Y		
5008(P87)		Diesel additive pump				Read Fault Code		Y		
5008(P87)		Diesel additive pump				Erase Fault Code		Y		
5008(P87)		Diesel additive pump				Live Data		Y		
5008(P87)		Diesel additive pump				Actuation Test		Y		
5008(P87)		Traction control mode selector				Read ECU Information		Y		
5008(P87)		Traction control mode selector				Read Fault Code		Y		
5008(P87)		Traction control mode selector				Live Data		Y		
5008(P87)		Traction control mode selector				Actuation Test		Y		
5008(P87)		Front left seat heated pads and ventilation regulation ECU				Read ECU Information		Y		
5008(P87)		Front left seat heated pads and ventilation regulation ECU				Read Fault Code		Y		
5008(P87)		Front left seat heated pads and ventilation regulation ECU				Live Data		Y		
5008(P87)		Front left seat heated pads and ventilation regulation ECU				Actuation Test		Y		
5008(P87)		Front right seat heated pads and ventilation regulation ECU				Read ECU Information		Y		
5008(P87)		Front right seat heated pads and ventilation regulation ECU				Read Fault Code		Y		
5008(P87)		Front right seat heated pads and ventilation regulation ECU				Live Data		Y		
5008(P87)		Front right seat heated pads and ventilation regulation ECU				Actuation Test		Y		
5008(P87)		Automatic gearbox electric control				Read ECU Information		Y		
5008(P87)		Automatic gearbox electric control				Read Fault Code		Y		
5008(P87)		Automatic gearbox electric control				Erase Fault Code		Y		
5008(P87)		Automatic gearbox electric control				Live Data		Y		
5008(P87)		Automatic gearbox electric control				Actuation Test		Y		
5008(P87)		Automatic gearbox electric control				Special Function	Programming	Y		
5008(P87)		Automatic gearbox electric control				Special Function	Replacement parts	Y		
5008(P87)		Motorised Boot ECU				Read ECU Information		Y		
5008(P87)		Motorised Boot ECU				Read Fault Code		Y		
5008(P87)		Motorised Boot ECU				Erase Fault Code		Y		
5008(P87)		Motorised Boot ECU				Live Data		Y		
5008(P87)		Motorised Boot ECU				Actuation Test		Y		
5008(P87)		Vehicle Distance Assistance				Read ECU Information		Y		
5008(P87)		Vehicle Distance Assistance				Read Fault Code		Y		
5008(P87)		Vehicle Distance Assistance				Erase Fault Code		Y		
5008(P87)		Vehicle Distance Assistance				Live Data		Y		
5008(P87)		Vehicle Distance Assistance				Actuation Test		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Read ECU Information		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Read Fault Code		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Erase Fault Code		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Live Data		Y		
5008(P87)		Multiplexed control panel	RD6 audio system without air conditioning			Actuation Test		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Read ECU Information		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Read Fault Code		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Erase Fault Code		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Live Data		Y		
5008(P87)		Multiplexed control panel	RD6 audio system and manual air conditioning			Actuation Test		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Read ECU Information		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Read Fault Code		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Erase Fault Code		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Live Data		Y		
5008(P87)		Multiplexed control panel	Audio/Navigation NAC			Actuation Test		Y		
5008(P87)		Rear air conditioning ECU				Read ECU Information		Y		
5008(P87)		Rear air conditioning ECU				Read Fault Code		Y		
5008(P87)		Rear air conditioning ECU				Erase Fault Code		Y		
5008(P87)		Rear air conditioning ECU				Live Data		Y		
5008(P87)		Rear air conditioning ECU				Actuation Test		Y		
5008(P87)		Rear air conditioning ECU				Special Function	Pack Repair	Y		
5008(P87)		Electric steering lock				Read ECU Information		Y		
5008(P87)		Electric steering lock				Read Fault Code		Y		
5008(P87)		Electric steering lock				Erase Fault Code		Y		
5008(P87)		Electric steering lock				Live Data		Y		
5008(P87)		Trailer relay unit				Read ECU Information		Y		
5008(P87)		Trailer relay unit				Read Fault Code		Y		
5008(P87)		Trailer relay unit				Erase Fault Code		Y		
5008(P87)		Trailer relay unit				Live Data		Y		
5008(P87)		Trailer relay unit				Actuation Test		Y		
5008(P87)		Radio amplifier				Read ECU Information		Y		
5008(P87)		Radio amplifier				Read Fault Code		Y		
5008(P87)		Radio amplifier				Erase Fault Code		Y		
5008(P87)		Radio amplifier				Actuation Test		Y		
5008(P87)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read ECU Information		Y		
5008(P87)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Read Fault Code		Y		
5008(P87)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Live Data		Y		
5008(P87)		Driver's seat pneumatic functions ECU	Driver's seat pneumatic functions ECU			Actuation Test		Y		
5008(P87)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read ECU Information		Y		
5008(P87)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Read Fault Code		Y		
5008(P87)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Live Data		Y		
5008(P87)		Passenger's seat pneumatic functions ECU	Passenger's seat pneumatic functions ECU			Actuation Test		Y		
5008(P87)		Radio				Read ECU Information		Y		
5008(P87)		Radio				Read Fault Code		Y		
5008(P87)		Radio				Erase Fault Code		Y		
5008(P87)		Radio				Live Data		Y		
5008(P87)		Radio				Actuation Test		Y		
5008(P87)		Rain and brightness sensor				Read ECU Information		Y		
5008(P87)		Rain and brightness sensor				Read Fault Code		Y		
5008(P87)		Rain and brightness sensor				Erase Fault Code		Y		
5008(P87)		Rain and brightness sensor				Live Data		Y		
5008(P87)		Rain and brightness sensor				Special Function	Pack Repair	Y		
5008(P87)		External CD player				Read ECU Information		Y		
5008(P87)		External CD player				Read Fault Code		Y		
5008(P87)		External CD player				Erase Fault Code		Y		
5008(P87)		External CD player				Live Data		Y		
5008(P87)		External CD player				Actuation Test		Y		
5008(P87)		Power steering				Read ECU Information		Y		
5008(P87)		Power steering				Read Fault Code		Y		
5008(P87)		Power steering				Erase Fault Code		Y		
5008(P87)		Power steering				Live Data		Y		
5008(P87)		Multifunction video camera(CMF)				Read ECU Information		Y		
5008(P87)		Multifunction video camera(CMF)				Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
5008(P87)		Multifunction video camera(CMF)				Erase Fault Code		Y		
5008(P87)		Multifunction video camera(CMF)				Live Data		Y		
5008(P87)		Multifunction video camera(CMF)				Actuation Test		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Read ECU Information		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Read Fault Code		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Erase Fault Code		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Live Data		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	NAC			Actuation Test		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Read ECU Information		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Read Fault Code		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Erase Fault Code		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Live Data		Y		
5008(P87)		Audio-navigation/telematic unit/connected audio system	RCC			Actuation Test		Y		
5008(P87)		Touch screen				Read ECU Information		Y		
5008(P87)		Touch screen				Read Fault Code		Y		
5008(P87)		Touch screen				Erase Fault Code		Y		
5008(P87)		Touch screen				Live Data		Y		
5008(P87)		Touch screen				Actuation Test		Y		
5008(P87)		Driver's seat comfort ECU				Read ECU Information		Y		
5008(P87)		Driver's seat comfort ECU				Read Fault Code		Y		
5008(P87)		Driver's seat comfort ECU				Erase Fault Code		Y		
5008(P87)		Driver's seat comfort ECU				Live Data		Y		
5008(P87)		Driver's seat comfort ECU				Actuation Test		Y		
5008(P87)		Push gear lever				Read ECU Information		Y		
5008(P87)		Push gear lever				Read Fault Code		Y		
5008(P87)		Push gear lever				Erase Fault Code		Y		
5008(P87)		Push gear lever				Live Data		Y		
5008(P87)		Push gear lever				Actuation Test		Y		
5008(P87)		Windscreen wiper				Read ECU Information		Y		
5008(P87)		Windscreen wiper				Read Fault Code		Y		
5008(P87)		Windscreen wiper				Erase Fault Code		Y		
5008(P87)		Windscreen wiper				Live Data		Y		
5008(P87)		Windscreen wiper				Actuation Test		Y		
5008(P87)		Service module / Independent telematic unit	BTA_2			Read ECU Information		Y		
5008(P87)		Service module / Independent telematic unit	BTA_2			Read Fault Code		Y		
5008(P87)		Service module / Independent telematic unit	BTA_2			Erase Fault Code		Y		
5008(P87)		Service module / Independent telematic unit	BTA_2			Live Data		Y		
5008(P87)		Service module / Independent telematic unit	BTA_2			Actuation Test		Y		
5008(P87)		Service module / Independent telematic unit	BTA_2			Special Function	Pack Repair	Y		
5008(P87)		Service module / Independent telematic unit	BTA_3R			Read ECU Information		Y		
5008(P87)		Service module / Independent telematic unit	BTA_3R			Read Fault Code		Y		
5008(P87)		Service module / Independent telematic unit	BTA_3R			Erase Fault Code		Y		
5008(P87)		Service module / Independent telematic unit	BTA_3R			Live Data		Y		
5008(P87)		Service module / Independent telematic unit	BTA_3R			Actuation Test		Y		
5008(P87)		Service module / Independent telematic unit	BTA_3R			Special Function	Pack Repair	Y		
5008(P87)		Anti-theft alarm				Read ECU Information		Y		
5008(P87)		Anti-theft alarm				Read Fault Code		Y		
5008(P87)		Anti-theft alarm				Erase Fault Code		Y		
5008(P87)		Anti-theft alarm				Live Data		Y		
5008(P87)		Anti-theft alarm				Special Function	Configuration	Y		
5008(P87)		Anti-theft alarm				Special Function	Pack Repair	Y		
BIPPER		Built-in Systems Interface	BCM			Read ECU Information		Y		
BIPPER		Built-in Systems Interface	BCM			Read Fault Code		Y		
BIPPER		Built-in Systems Interface	BCM			Erase Fault Code		Y		
BIPPER		Built-in Systems Interface	BCM			Live Data		Y		
BIPPER		Built-in Systems Interface	BCM			Actuation Test		Y		
BIPPER		Built-in Systems Interface	BCM			Special Function	Configuration	Y		
BIPPER		Built-in Systems Interface	BCM			Special Function	Pack repair	Y		
BIPPER		Engine ECU	EDC16C34	EDC16C34 8HS		Read ECU Information		Y		
BIPPER		Engine ECU	EDC16C34	EDC16C34 8HS		Read Fault Code		Y		
BIPPER		Engine ECU	EDC16C34	EDC16C34 8HS		Erase Fault Code		Y		
BIPPER		Engine ECU	EDC16C34	EDC16C34 8HS		Live Data		Y		
BIPPER		Engine ECU	EDC16C34	EDC16C34 8HS		Actuation Test		Y		
BIPPER		Engine ECU	EDC16C34	EDC16C34 8HS		Special Function	Pack Repair	Y		
BIPPER		Engine ECU	V34P	V34P KFV		Read ECU Information		Y		
BIPPER		Engine ECU	V34P	V34P KFV		Read Fault Code		Y		
BIPPER		Engine ECU	V34P	V34P KFV		Erase Fault Code		Y		
BIPPER		Engine ECU	V34P	V34P KFV		Live Data		Y		
BIPPER		Engine ECU	V34P	V34P KFV		Actuation Test		Y		
BIPPER		Engine ECU	V34P	V34P KFV		Special Function	Pack Repair	Y		
BIPPER		Engine ECU	V34.2	V34.2 KFT		Read ECU Information		Y		
BIPPER		Engine ECU	V34.2	V34.2 KFT		Read Fault Code		Y		
BIPPER		Engine ECU	V34.2	V34.2 KFT		Erase Fault Code		Y		
BIPPER		Engine ECU	V34.2	V34.2 KFT		Live Data		Y		
BIPPER		Engine ECU	V34.2	V34.2 KFT		Actuation Test		Y		
BIPPER		Engine ECU	V34.2	V34.2 KFT		Special Function	Pack Repair	Y		
BIPPER		Engine ECU	HDI_8DF2			Read ECU Information		Y		
BIPPER		Engine ECU	HDI_8DF2			Read Fault Code		Y		
BIPPER		Engine ECU	HDI_8DF2			Erase Fault Code		Y		
BIPPER		Engine ECU	HDI_8DF2			Live Data		Y		
BIPPER		Engine ECU	HDI_8DF2			Actuation Test		Y		
BIPPER		Engine ECU	HDI_8DF2			Special Function	Pack Repair	Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3		Read ECU Information		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3		Read Fault Code		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3		Erase Fault Code		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3		Live Data		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3		Actuation Test		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3		Special Function	Configuration	Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3		Special Function	Pack Repair	Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3_STT		Read ECU Information		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3_STT		Read Fault Code		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3_STT		Erase Fault Code		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3_STT		Live Data		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3_STT		Actuation Test		Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3_STT		Special Function	Configuration	Y		
BIPPER		Engine ECU	HDI_8DF3	HDI_8DF3_STT		Special Function	Pack Repair	Y		
BIPPER		Gearbox	Manual gearbox			Read ECU Information		Y		
BIPPER		Gearbox	Manual gearbox			Read Fault Code		Y		
BIPPER		Gearbox	Manual gearbox			Erase Fault Code		Y		
BIPPER		Gearbox	Manual gearbox			Live Data		Y		
BIPPER		Gearbox	Manual gearbox			Actuation Test		Y		
BIPPER		Gearbox	Manual gearbox			Special Function	Pack Repair	Y		
BIPPER		Gearbox	BVMP_MTA			Read ECU Information		Y		
BIPPER		Gearbox	BVMP_MTA			Read Fault Code		Y		
BIPPER		Gearbox	BVMP_MTA			Erase Fault Code		Y		
BIPPER		Gearbox	BVMP_MTA			Live Data		Y		
BIPPER		Gearbox	BVMP_MTA			Actuation Test		Y		
BIPPER		Gearbox	BVMP_MTA			Special Function	Configuration	Y		
BIPPER		Gearbox	BVMP_MTA			Special Function	Pack Repair	Y		
BIPPER		ABS/ASR	ABS 81			Read ECU Information		Y		
BIPPER		ABS/ASR	ABS 81			Read Fault Code		Y		
BIPPER		ABS/ASR	ABS 81			Erase Fault Code		Y		
BIPPER		ABS/ASR	ABS 81			Live Data		Y		
BIPPER		ABS/ASR	ABS 81			Actuation Test		Y		
BIPPER		ABS/ASR	ESP 81			Read ECU Information		Y		
BIPPER		ABS/ASR	ESP 81			Read Fault Code		Y		
BIPPER		ABS/ASR	ESP 81			Erase Fault Code		Y		
BIPPER		ABS/ASR	ESP 81			Live Data		Y		
BIPPER		ABS/ASR	ESP 81			Actuation Test		Y		
BIPPER		ABS/ASR	ESP 81			Special Function	Pack Repair	Y		
BIPPER		Driver and passenger airbags				Read ECU Information		Y		
BIPPER		Driver and passenger airbags				Read Fault Code		Y		
BIPPER		Driver and passenger airbags				Erase Fault Code		Y		
BIPPER		Driver and passenger airbags				Live Data		Y		
BIPPER		Driver and passenger airbags				Actuation Test		Y		
BIPPER		Instrument panel				Read ECU Information		Y		
BIPPER		Instrument panel				Read Fault Code		Y		
BIPPER		Instrument panel				Erase Fault Code		Y		
BIPPER		Instrument panel				Live Data		Y		
BIPPER		Instrument panel				Actuation Test		Y		
BIPPER		Instrument panel				Special Function	Pack Repair	Y		
BIPPER		Parking aid				Read ECU Information		Y		
BIPPER		Parking aid				Read Fault Code		Y		
BIPPER		Parking aid				Erase Fault Code		Y		
BIPPER		Parking aid				Live Data		Y		
BIPPER		Parking aid				Special Function	Configuration	Y		
BIPPER		Parking aid				Special Function	Pack Repair	Y		
BIPPER		Telematics unit				Read ECU Information		Y		
BIPPER		Telematics unit				Read Fault Code		Y		
BIPPER		Telematics unit				Erase Fault Code		Y		
BIPPER		Telematics unit				Live Data		Y		
BIPPER		Telematics unit				Actuation Test		Y		
BIPPER		Telematics unit				Special Function	Test of the microphone	Y		
BOXER		Engine	Petrol	MM4.8P 2L Unleaded petrol		Read ECU Information		Y		
BOXER		Engine	Petrol	MM4.8P 2L Unleaded petrol		Read Fault Code		Y		
BOXER		Engine	Petrol	MM4.8P 2L Unleaded petrol		Erase Fault Code		Y		
BOXER		Engine	Petrol	MM4.8P 2L Unleaded petrol		Live Data		Y		
BOXER		Engine	Petrol	MM4.8P 2L Unleaded petrol		Actuation Test		Y		
BOXER		Engine	Petrol	MM4.8P 2L Unleaded petrol		Special Function	Injection ECU initialisation procedure	Y		
BOXER		Engine	Petrol	MM4.8P 2L Unleaded petrol		Special Function	Initialising the autoadaptives	Y		
BOXER		Engine	Petrol	MM48P 2L Leaded petrol		Read ECU Information		Y		
BOXER		Engine	Petrol	MM48P 2L Leaded petrol		Read Fault Code		Y		
BOXER		Engine	Petrol	MM48P 2L Leaded petrol		Erase Fault Code		Y		
BOXER		Engine	Petrol	MM48P 2L Leaded petrol		Live Data		Y		
BOXER		Engine	Petrol	MM48P 2L Leaded petrol		Actuation Test		Y		
BOXER		Engine	Petrol	MM48P 2L Leaded petrol		Special Function	Injection ECU initialisation procedure	Y		
BOXER		Engine	Petrol	MM48P 2L Leaded petrol		Special Function	Initialising the autoadaptives	Y		
BOXER		Engine	Petrol	MM48P 2L dual fuel(LPG)		Read ECU Information		Y		
BOXER		Engine	Petrol	MM48P 2L dual fuel(LPG)		Read Fault Code		Y		
BOXER		Engine	Petrol	MM48P 2L dual fuel(LPG)		Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
BOXER		Engine	Petrol	MM48P 2L dual fuel(LPG)		Live Data		Y		
BOXER		Engine	Petrol	MM48P 2L dual fuel(LPG)		Actuation Test		Y		
BOXER		Engine	Petrol	MM48P 2L dual fuel(LPG)		Special Function	Injection ECU initialisation procedure	Y		
BOXER		Engine	Petrol	MM48P 2L dual fuel(LPG)		Special Function	Initialising the autoadaptives	Y		
BOXER		Engine	Diesel	2.0L HDI Bosch EDC15C7		Read ECU Information		Y		
BOXER		Engine	Diesel	2.0L HDI Bosch EDC15C7		Read Fault Code		Y		
BOXER		Engine	Diesel	2.0L HDI Bosch EDC15C7		Erase Fault Code		Y		
BOXER		Engine	Diesel	2.0L HDI Bosch EDC15C7		Live Data		Y		
BOXER		Engine	Diesel	2.2L HDI Bosch EDC15C7		Read ECU Information		Y		
BOXER		Engine	Diesel	2.2L HDI Bosch EDC15C7		Read Fault Code		Y		
BOXER		Engine	Diesel	2.2L HDI Bosch EDC15C7		Erase Fault Code		Y		
BOXER		Engine	Diesel	2.2L HDI Bosch EDC15C7		Live Data		Y		
BOXER		Engine	Diesel	2.8L HDI Bosch EDC15C7		Read ECU Information		Y		
BOXER		Engine	Diesel	2.8L HDI Bosch EDC15C7		Read Fault Code		Y		
BOXER		Engine	Diesel	2.8L HDI Bosch EDC15C7		Erase Fault Code		Y		
BOXER		Engine	Diesel	2.8L HDI Bosch EDC15C7		Live Data		Y		
BOXER		Engine	Diesel	TUB EDC16C39		Read ECU Information		Y		
BOXER		Engine	Diesel	TUB EDC16C39		Read Fault Code		Y		
BOXER		Engine	Diesel	TUB EDC16C39		Erase Fault Code		Y		
BOXER		4HP20 automatic gearbox				Read ECU Information		Y		
BOXER		4HP20 automatic gearbox				Read Fault Code		Y		
BOXER		4HP20 automatic gearbox				Erase Fault Code		Y		
BOXER		4HP20 automatic gearbox				Live Data		Y		
BOXER 3		Built-in Systems Interface				Read ECU Information		Y		
BOXER 3		Built-in Systems Interface				Read Fault Code		Y		
BOXER 3		Built-in Systems Interface				Erase Fault Code		Y		
BOXER 3		Built-in Systems Interface				Live Data		Y		
BOXER 3		Built-in Systems Interface				Actuation Test		Y		
BOXER 3		Built-in Systems Interface				Special Function	Configuration	Y		
BOXER 3		Built-in Systems Interface				Special Function	Pack repair	Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HV		Read ECU Information		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HV		Read Fault Code		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HV		Erase Fault Code		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HV		Live Data		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HV		Actuation Test		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HV		Special Function	Configuration	Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HV		Special Function	Pack repair	Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HU		Read ECU Information		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HU		Read Fault Code		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HU		Erase Fault Code		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HU		Live Data		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HU		Actuation Test		Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HU		Special Function	Configuration	Y		
BOXER 3		Engine management ECU	PUMA	PUMA 4HU		Special Function	Pack repair	Y		
BOXER 3		Engine management ECU	EDC17CP52	Sofim euro5		Read ECU Information		Y		
BOXER 3		Engine management ECU	EDC17CP52	Sofim euro5		Read Fault Code		Y		
BOXER 3		Engine management ECU	EDC17CP52	Sofim euro5		Erase Fault Code		Y		
BOXER 3		Engine management ECU	EDC17CP52	Sofim euro5		Live Data		Y		
BOXER 3		Engine management ECU	EDC17CP52	Sofim euro5		Actuation Test		Y		
BOXER 3		Engine management ECU	EDC17CP52	Sofim euro5		Special Function	Configuration	Y		
BOXER 3		Engine management ECU	EDC17CP52	Sofim euro5		Special Function	Pack repair	Y		
BOXER 3		Engine management ECU	EDC16C39	EDC16C39 TUB		Read ECU Information		Y		
BOXER 3		Engine management ECU	EDC16C39	EDC16C39 TUB		Read Fault Code		Y		
BOXER 3		Engine management ECU	EDC16C39	EDC16C39 TUB		Erase Fault Code		Y		
BOXER 3		Engine management ECU	EDC16C39	EDC16C39 TUB		Live Data		Y		
BOXER 3		Engine management ECU	EDC16C39	EDC16C39 TUB		Actuation Test		Y		
BOXER 3		Engine management ECU	EDC16C39	EDC16C39 TUB		Special Function	Configuration	Y		
BOXER 3		Engine management ECU	EDC16C39	EDC16C39 TUB		Special Function	Pack repair	Y		
BOXER 3		Air bags and pre-tensioners control unit 1				Read ECU Information		Y		
BOXER 3		Air bags and pre-tensioners control unit 1				Read Fault Code		Y		
BOXER 3		Air bags and pre-tensioners control unit 1				Erase Fault Code		Y		
BOXER 3		Air bags and pre-tensioners control unit 1				Live Data		Y		
BOXER 3		Air bags and pre-tensioners control unit 1				Actuation Test		Y		
BOXER 3		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Read ECU Information		Y		
BOXER 3		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Read Fault Code		Y		
BOXER 3		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Erase Fault Code		Y		
BOXER 3		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Live Data		Y		
BOXER 3		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Actuation Test		Y		
BOXER 3		Power steering				Read ECU Information		Y		
BOXER 3		Power steering				Read Fault Code		Y		
BOXER 3		Power steering				Erase Fault Code		Y		
BOXER 3		Power steering				Live Data		Y		
BOXER 3		Electronically managed suspension				Read ECU Information		Y		
BOXER 3		Electronically managed suspension				Read Fault Code		Y		
BOXER 3		Electronically managed suspension				Erase Fault Code		Y		
BOXER 3		Electronically managed suspension				Live Data		Y		
BOXER 3		Electronically managed suspension				Special Function	Pack repair	Y		
BOXER 3		Additional heating				Read ECU Information		Y		
BOXER 3		Additional heating				Read Fault Code		Y		
BOXER 3		Additional heating				Erase Fault Code		Y		
BOXER 3		Additional heating				Live Data		Y		
BOXER 3		Additional heating				Actuation Test		Y		
BOXER 3		Additional heating				Special Function	Pack Repair	Y		
BOXER 3		Parking assistance				Read ECU Information		Y		
BOXER 3		Parking assistance				Read Fault Code		Y		
BOXER 3		Parking assistance				Erase Fault Code		Y		
BOXER 3		Parking assistance				Live Data		Y		
BOXER 3		Parking assistance				Special Function	Configuration	Y		
BOXER 3		Parking assistance				Special Function	Pack Repair	Y		
BOXER 3		Instrument panel				Read ECU Information		Y		
BOXER 3		Instrument panel				Read Fault Code		Y		
BOXER 3		Instrument panel				Erase Fault Code		Y		
BOXER 3		Instrument panel				Live Data		Y		
BOXER 3		Instrument panel				Actuation Test		Y		
BOXER 3		Instrument panel				Special Function	Pack Repair	Y		
BOXER 3		Instrument panel				Special Function	Replacement parts	Y		
BOXER 3		Air conditioning				Read ECU Information		Y		
BOXER 3		Air conditioning				Read Fault Code		Y		
BOXER 3		Air conditioning				Erase Fault Code		Y		
BOXER 3		Air conditioning				Live Data		Y		
BOXER 3		Air conditioning				Actuation Test		Y		
BOXER 3		Air conditioning				Special Function	Learning	Y		
BOXER 3		Air conditioning				Special Function	Pack Repair	Y		
BOXER 3		Telematic unit(RTX) or audio-navigation				Read ECU Information		Y		
BOXER 3		Telematic unit(RTX) or audio-navigation				Read Fault Code		Y		
BOXER 3		Telematic unit(RTX) or audio-navigation				Erase Fault Code		Y		
BOXER 3		Telematic unit(RTX) or audio-navigation				Live Data		Y		
BOXER 3		Telematic unit(RTX) or audio-navigation				Actuation Test		Y		
BOXER 3		Tachograph	Tachograph			Read ECU Information		Y		
BOXER 3		Tachograph	Tachograph			Read Fault Code		Y		
BOXER 3		Tachograph	Tachograph			Erase Fault Code		Y		
BOXER 3		Tachograph	Tachograph			Live Data		Y		
BOXER 3		Tachograph	Tachograph			Actuation Test		Y		
BOXER 3		Tachograph	Tachograph			Special Function	Configuration	Y		
BOXER 3		Tachograph	Tachograph			Special Function	Pack repair	Y		
BOXER 3 minibus		BSI(Built-in Systems Interface)				Read ECU Information		Y		
BOXER 3 minibus		BSI(Built-in Systems Interface)				Read Fault Code		Y		
BOXER 3 minibus		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
BOXER 3 minibus		BSI(Built-in Systems Interface)				Live Data		Y		
BOXER 3 minibus		BSI(Built-in Systems Interface)				Actuation Test		Y		
BOXER 3 minibus		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
BOXER 3 minibus		BSI(Built-in Systems Interface)				Special Function	Pack repair	Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HV		Read ECU Information		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HV		Read Fault Code		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HV		Erase Fault Code		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HV		Live Data		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HV		Actuation Test		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HV		Special Function	Configuration	Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HV		Special Function	Pack repair	Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HU		Read ECU Information		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HU		Read Fault Code		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HU		Erase Fault Code		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HU		Live Data		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HU		Actuation Test		Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HU		Special Function	Configuration	Y		
BOXER 3 minibus		Engine management ECU	PUMA	PUMA 4HU		Special Function	Pack repair	Y		
BOXER 3 minibus		Engine management ECU	EDC16C39	EDC16C39 TUB		Read ECU Information		Y		
BOXER 3 minibus		Engine management ECU	EDC16C39	EDC16C39 TUB		Read Fault Code		Y		
BOXER 3 minibus		Engine management ECU	EDC16C39	EDC16C39 TUB		Erase Fault Code		Y		
BOXER 3 minibus		Engine management ECU	EDC16C39	EDC16C39 TUB		Live Data		Y		
BOXER 3 minibus		Engine management ECU	EDC16C39	EDC16C39 TUB		Actuation Test		Y		
BOXER 3 minibus		Engine management ECU	EDC16C39	EDC16C39 TUB		Special Function	Configuration	Y		
BOXER 3 minibus		Engine management ECU	EDC16C39	EDC16C39 TUB		Special Function	Pack repair	Y		
BOXER 3 minibus		Engine management ECU	EDC17CP52	Sofim euro5		Read ECU Information		Y		
BOXER 3 minibus		Engine management ECU	EDC17CP52	Sofim euro5		Read Fault Code		Y		
BOXER 3 minibus		Engine management ECU	EDC17CP52	Sofim euro5		Erase Fault Code		Y		
BOXER 3 minibus		Engine management ECU	EDC17CP52	Sofim euro5		Live Data		Y		
BOXER 3 minibus		Engine management ECU	EDC17CP52	Sofim euro5		Actuation Test		Y		
BOXER 3 minibus		Engine management ECU	EDC17CP52	Sofim euro5		Special Function	Configuration	Y		
BOXER 3 minibus		Engine management ECU	EDC17CP52	Sofim euro5		Special Function	Pack repair	Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 80			Read ECU Information		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 80			Read Fault Code		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 80			Erase Fault Code		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 80			Live Data		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 80			Actuation Test		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 80			Special Function	Pack repair	Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 80			Read ECU Information		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 80			Read Fault Code		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 80			Erase Fault Code		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 80			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 80			Actuation Test		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 80			Special Function	Pack repair	Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ASR 80			Read ECU Information		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ASR 80			Read Fault Code		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ASR 80			Erase Fault Code		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ASR 80			Live Data		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ASR 80			Actuation Test		Y		
BOXER 3 minibus		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ASR 80			Special Function	Pack repair	Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 1				Read ECU Information		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 1				Read Fault Code		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 1				Erase Fault Code		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 1				Live Data		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 1				Actuation Test		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Read ECU Information		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Read Fault Code		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Erase Fault Code		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Live Data		Y		
BOXER 3 minibus		Air bags and pre-tensioners control unit 2	Air bags and pre-tensioners control unit			Actuation Test		Y		
BOXER 3 minibus		Power steering				Read ECU Information		Y		
BOXER 3 minibus		Power steering				Read Fault Code		Y		
BOXER 3 minibus		Power steering				Erase Fault Code		Y		
BOXER 3 minibus		Power steering				Live Data		Y		
BOXER 3 minibus		Electronically managed suspension				Read ECU Information		Y		
BOXER 3 minibus		Electronically managed suspension				Read Fault Code		Y		
BOXER 3 minibus		Electronically managed suspension				Erase Fault Code		Y		
BOXER 3 minibus		Electronically managed suspension				Live Data		Y		
BOXER 3 minibus		Electronically managed suspension				Special Function	Pack repair	Y		
BOXER 3 minibus		Additional heating				Read ECU Information		Y		
BOXER 3 minibus		Additional heating				Read Fault Code		Y		
BOXER 3 minibus		Additional heating				Erase Fault Code		Y		
BOXER 3 minibus		Additional heating				Live Data		Y		
BOXER 3 minibus		Additional heating				Actuation Test		Y		
BOXER 3 minibus		Additional heating				Special Function	Pack Repair	Y		
BOXER 3 minibus		Parking assistance				Read ECU Information		Y		
BOXER 3 minibus		Parking assistance				Read Fault Code		Y		
BOXER 3 minibus		Parking assistance				Erase Fault Code		Y		
BOXER 3 minibus		Parking assistance				Live Data		Y		
BOXER 3 minibus		Parking assistance				Special Function	Configuration	Y		
BOXER 3 minibus		Parking assistance				Special Function	Pack Repair	Y		
BOXER 3 minibus		Instrument panel				Read ECU Information		Y		
BOXER 3 minibus		Instrument panel				Read Fault Code		Y		
BOXER 3 minibus		Instrument panel				Erase Fault Code		Y		
BOXER 3 minibus		Instrument panel				Live Data		Y		
BOXER 3 minibus		Instrument panel				Actuation Test		Y		
BOXER 3 minibus		Instrument panel				Special Function	Pack Repair	Y		
BOXER 3 minibus		Air conditioning				Read ECU Information		Y		
BOXER 3 minibus		Air conditioning				Read Fault Code		Y		
BOXER 3 minibus		Air conditioning				Erase Fault Code		Y		
BOXER 3 minibus		Air conditioning				Live Data		Y		
BOXER 3 minibus		Air conditioning				Actuation Test		Y		
BOXER 3 minibus		Air conditioning				Special Function	Learning	Y		
BOXER 3 minibus		Air conditioning				Special Function	Pack Repair	Y		
BOXER 3 minibus		Telematic unit(RTX) or audio-naviggation				Read ECU Information		Y		
BOXER 3 minibus		Telematic unit(RTX) or audio-naviggation				Read Fault Code		Y		
BOXER 3 minibus		Telematic unit(RTX) or audio-naviggation				Erase Fault Code		Y		
BOXER 3 minibus		Telematic unit(RTX) or audio-naviggation				Live Data		Y		
BOXER 3 minibus		Telematic unit(RTX) or audio-naviggation				Actuation Test		Y		
BOXER 3 minibus		Telematic unit(RTX) or audio-naviggation				Special Function	Configuration	Y		
BOXER 3 minibus		Tachograph				Read ECU Information		Y		
BOXER 3 minibus		Tachograph				Read Fault Code		Y		
BOXER 3 minibus		Tachograph				Erase Fault Code		Y		
BOXER 3 minibus		Tachograph				Live Data		Y		
BOXER 3 minibus		Tachograph				Actuation Test		Y		
BOXER 3 minibus		Tachograph				Special Function	Configuration	Y		
BOXER 3 Euro 5/Euro 6		Built-in Systems Interface	Built-in Systems Interface			Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Built-in Systems Interface	Built-in Systems Interface			Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Built-in Systems Interface	Built-in Systems Interface			Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Built-in Systems Interface	Built-in Systems Interface			Live Data		Y		
BOXER 3 Euro 5/Euro 6		Built-in Systems Interface	Built-in Systems Interface			Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Built-in Systems Interface	Built-in Systems Interface			Special Function	Configuration	Y		
BOXER 3 Euro 5/Euro 6		Built-in Systems Interface	Built-in Systems Interface			Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	EDC17CP52_UDS	EDC17CP52_UDS 3.0 HDI 180CV E5		Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	EDC17CP52_UDS	EDC17CP52_UDS 3.0 HDI 180CV E5		Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	EDC17CP52_UDS	EDC17CP52_UDS 3.0 HDI 180CV E5		Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	EDC17CP52_UDS	EDC17CP52_UDS 3.0 HDI 180CV E5		Live Data		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	EDC17CP52_UDS	EDC17CP52_UDS 3.0 HDI 180CV E5		Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	EDC17CP52_UDS	EDC17CP52_UDS 3.0 HDI 180CV E5		Special Function	Configuration	Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	EDC17CP52_UDS	EDC17CP52_UDS 3.0 HDI 180CV E5		Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	SID208	SID208 2.2 HDI 180CV E5		Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	SID208	SID208 2.2 HDI 180CV E5		Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	SID208	SID208 2.2 HDI 180CV E5		Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	SID208	SID208 2.2 HDI 180CV E5		Live Data		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	SID208	SID208 2.2 HDI 180CV E5		Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	SID208	SID208 2.2 HDI 180CV E5		Special Function	Configuration	Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	SID208	SID208 2.2 HDI 180CV E5		Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHM		Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHM		Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHM		Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHM		Live Data		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHM		Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHM		Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHN		Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHN		Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHN		Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHN		Live Data		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHN		Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHN		Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHP		Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHP		Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHP		Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHP		Live Data		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHP		Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Engine management ECU	DCM62_F	DCM62_F AHP		Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS90_F			Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS90_F			Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS90_F			Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS90_F			Live Data		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS90_F			Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS90_F			Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90_F			Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90_F			Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90_F			Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90_F			Live Data		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90_F			Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90_F			Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Air bags and pre-tensioners control unit	Air bags and pre-tensioners control unit			Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Air bags and pre-tensioners control unit	Air bags and pre-tensioners control unit			Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Air bags and pre-tensioners control unit	Air bags and pre-tensioners control unit			Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Air bags and pre-tensioners control unit	Air bags and pre-tensioners control unit			Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
BOXER 3 Euro 5/Euro 6		Air bags and pre-tensioners control unit	Air bags and pre-tensioners control unit			Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Trailer relay unit				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Trailer relay unit				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Trailer relay unit				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Trailer relay unit				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Trailer relay unit				Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Additional heating				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Additional heating				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Additional heating				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Additional heating				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Additional heating				Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Additional heating				Special Function	Pack Repair	Y		
BOXER 3 Euro 5/Euro 6		Power steering				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Power steering				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Power steering				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Power steering				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Telematic unit(RTX) or audio-navigation				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Telematic unit(RTX) or audio-navigation				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Telematic unit(RTX) or audio-navigation				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Telematic unit(RTX) or audio-navigation				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Telematic unit(RTX) or audio-navigation				Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Telematic unit(RTX) or audio-navigation				Special Function	Test of the microphone	Y		
BOXER 3 Euro 5/Euro 6		Audio/navigation ITM				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Audio/navigation ITM				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Audio/navigation ITM				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Audio/navigation ITM				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Audio/navigation ITM				Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Audio/navigation ITM				Special Function	Pack Repair	Y		
BOXER 3 Euro 5/Euro 6		Air conditioning				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Air conditioning				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Air conditioning				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Air conditioning				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Air conditioning				Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Air conditioning				Special Function	Replacement parts	Y		
BOXER 3 Euro 5/Euro 6		Parking assistance				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Parking assistance				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Parking assistance				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Parking assistance				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Parking assistance				Special Function	Configuration	Y		
BOXER 3 Euro 5/Euro 6		Parking assistance				Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Tachograph				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Tachograph				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Tachograph				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Tachograph				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Tachograph				Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Tachograph				Special Function	Configuration	Y		
BOXER 3 Euro 5/Euro 6		Tachograph				Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Electronically managed suspension				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Electronically managed suspension				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Electronically managed suspension				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Electronically managed suspension				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Electronically managed suspension				Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Electronically managed suspension				Special Function	Pack repair	Y		
BOXER 3 Euro 5/Euro 6		Under-inflation detection				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Under-inflation detection				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Under-inflation detection				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Under-inflation detection				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Under-inflation detection				Special Function	Spare part	Y		
BOXER 3 Euro 5/Euro 6		Radio				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Radio				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Radio				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Radio				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Radio				Actuation Test		Y		
BOXER 3 Euro 5/Euro 6		Radio				Special Function	Test routines	Y		
BOXER 3 Euro 5/Euro 6		Lane departure warning system				Read ECU Information		Y		
BOXER 3 Euro 5/Euro 6		Lane departure warning system				Read Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Lane departure warning system				Erase Fault Code		Y		
BOXER 3 Euro 5/Euro 6		Lane departure warning system				Live Data		Y		
BOXER 3 Euro 5/Euro 6		Lane departure warning system				Special Function	Pack repair	Y		
EXPERT		Engine	Petrol	R6F MM4.8P		Read ECU Information		Y		
EXPERT		Engine	Petrol	R6F MM4.8P		Read Fault Code		Y		
EXPERT		Engine	Petrol	R6F MM4.8P		Erase Fault Code		Y		
EXPERT		Engine	Petrol	R6F MM4.8P		Live Data		Y		
EXPERT		Engine	Petrol	R6F MM4.8P		Actuation Test		Y		
EXPERT		Engine	Petrol	R6F MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
EXPERT		Engine	Petrol	R6F MM4.8P		Special Function	Initialising the autoadaptives	Y		
EXPERT		Engine	Petrol	RFN MM4.8P		Read ECU Information		Y		
EXPERT		Engine	Petrol	RFN MM4.8P		Read Fault Code		Y		
EXPERT		Engine	Petrol	RFN MM4.8P		Erase Fault Code		Y		
EXPERT		Engine	Petrol	RFN MM4.8P		Live Data		Y		
EXPERT		Engine	Petrol	RFN MM4.8P		Actuation Test		Y		
EXPERT		Engine	Petrol	RFN MM4.8P		Special Function	Injection ECU initialisation procedure	Y		
EXPERT		Engine	Petrol	RFN MM4.8P		Special Function	Initialising the autoadaptives	Y		
EXPERT		Engine	Diesel	RHW BOSCH EDC15C2		Read ECU Information		Y		
EXPERT		Engine	Diesel	RHW BOSCH EDC15C2		Read Fault Code		Y		
EXPERT		Engine	Diesel	RHW BOSCH EDC15C2		Erase Fault Code		Y		
EXPERT		Engine	Diesel	RHW BOSCH EDC15C2		Live Data		Y		
EXPERT		Engine	Diesel	RHW BOSCH EDC15C2		Actuation Test		Y		
EXPERT		Engine	Diesel	RHX BOSCH EDC15C2		Read ECU Information		Y		
EXPERT		Engine	Diesel	RHX BOSCH EDC15C2		Read Fault Code		Y		
EXPERT		Engine	Diesel	RHX BOSCH EDC15C2		Erase Fault Code		Y		
EXPERT		Engine	Diesel	RHX BOSCH EDC15C2		Live Data		Y		
EXPERT		Engine	Diesel	RHX BOSCH EDC15C2		Actuation Test		Y		
EXPERT		Engine	Diesel	RHZ BOSCH EDC15C2		Read ECU Information		Y		
EXPERT		Engine	Diesel	RHZ BOSCH EDC15C2		Read Fault Code		Y		
EXPERT		Engine	Diesel	RHZ BOSCH EDC15C2		Erase Fault Code		Y		
EXPERT		Engine	Diesel	RHZ BOSCH EDC15C2		Live Data		Y		
EXPERT		Engine	Diesel	RHZ BOSCH EDC15C2		Actuation Test		Y		
EXPERT		Engine	Diesel	WJY LUCAS DCN2		Read ECU Information		Y		
EXPERT		Engine	Diesel	WJY LUCAS DCN2		Read Fault Code		Y		
EXPERT		Engine	Diesel	WJY LUCAS DCN2		Erase Fault Code		Y		
EXPERT		Engine	Diesel	WJY LUCAS DCN2		Live Data		Y		
EXPERT		Engine	Diesel	WJY LUCAS DCN2		Actuation Test		Y		
EXPERT		BOSCH ABS53				Read ECU Information		Y		
EXPERT		BOSCH ABS53				Read Fault Code		Y		
EXPERT		BOSCH ABS53				Erase Fault Code		Y		
EXPERT		BOSCH ABS53				Live Data		Y		
EXPERT		BOSCH ABS53				Actuation Test		Y		
EXPERT		BOSCH ABS53				Special Function	Bleeding	Y		
EXPERT		Air bag and seat belt				Read ECU Information		Y		
EXPERT		Air bag and seat belt				Read Fault Code		Y		
EXPERT		Air bag and seat belt				Erase Fault Code		Y		
EXPERT		Additional heating				Read ECU Information		Y		
EXPERT		Additional heating				Read Fault Code		Y		
EXPERT		Additional heating				Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
EXPERT		Additional heating				Live Data		Y		
EXPERT		Additional heating				Actuation Test		Y		
EXPERT 2		BSI(Built-in Systems Interface)				Read ECU Information		Y		
EXPERT 2		BSI(Built-in Systems Interface)				Read Fault Code		Y		
EXPERT 2		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
EXPERT 2		BSI(Built-in Systems Interface)				Live Data		Y		
EXPERT 2		BSI(Built-in Systems Interface)				Actuation Test		Y		
EXPERT 2		BSI(Built-in Systems Interface)				Special Function	Changing the mode Electrical	Y		
EXPERT 2		BSI(Built-in Systems Interface)				Special Function	Learning	Y		
EXPERT 2		Engine ECU	Petrol	RFH MM6KP (EW10A).		Read ECU Information		Y		
EXPERT 2		Engine ECU	Petrol	RFH MM6KP (EW10A).		Read Fault Code		Y		
EXPERT 2		Engine ECU	Petrol	RFH MM6KP (EW10A).		Erase Fault Code		Y		
EXPERT 2		Engine ECU	Petrol	RFH MM6KP (EW10A).		Live Data		Y		
EXPERT 2		Engine ECU	Petrol	RFH MM6KP (EW10A).		Actuation Test		Y		
EXPERT 2		Engine ECU	Petrol	RFH MM6KP (EW10A).		Special Function	Initialising the autoadaptives	Y		
EXPERT 2		Engine ECU	Petrol	RFH MM6KP (EW10A).		Special Function	Replacement parts	Y		
EXPERT 2		Engine ECU	Diesel	9HU BOSCH EDC16C3-EDC16C34.		Read ECU Information		Y		
EXPERT 2		Engine ECU	Diesel	9HU BOSCH EDC16C3-EDC16C34.		Read Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	9HU BOSCH EDC16C3-EDC16C34.		Erase Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	9HU BOSCH EDC16C3-EDC16C34.		Live Data		Y		
EXPERT 2		Engine ECU	Diesel	9HU BOSCH EDC16C3-EDC16C34.		Actuation Test		Y		
EXPERT 2		Engine ECU	Diesel	RHR SIEMENS SID 803.		Read ECU Information		Y		
EXPERT 2		Engine ECU	Diesel	RHR SIEMENS SID 803.		Read Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHR SIEMENS SID 803.		Erase Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHR SIEMENS SID 803.		Live Data		Y		
EXPERT 2		Engine ECU	Diesel	RHR SIEMENS SID 803.		Actuation Test		Y		
EXPERT 2		Engine ECU	Diesel	RHL SIEMENS SID 803.		Read ECU Information		Y		
EXPERT 2		Engine ECU	Diesel	RHL SIEMENS SID 803.		Read Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHL SIEMENS SID 803.		Erase Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHL SIEMENS SID 803.		Live Data		Y		
EXPERT 2		Engine ECU	Diesel	RHL SIEMENS SID 803.		Actuation Test		Y		
EXPERT 2		Engine ECU	Diesel	RHK SIEMENS SID 803.		Read ECU Information		Y		
EXPERT 2		Engine ECU	Diesel	RHK SIEMENS SID 803.		Read Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHK SIEMENS SID 803.		Erase Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHK SIEMENS SID 803.		Live Data		Y		
EXPERT 2		Engine ECU	Diesel	RHK SIEMENS SID 803.		Actuation Test		Y		
EXPERT 2		Engine ECU	Diesel	RHG SIEMENS SID 803.		Read ECU Information		Y		
EXPERT 2		Engine ECU	Diesel	RHG SIEMENS SID 803.		Read Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHG SIEMENS SID 803.		Erase Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHG SIEMENS SID 803.		Live Data		Y		
EXPERT 2		Engine ECU	Diesel	RHG SIEMENS SID 803.		Actuation Test		Y		
EXPERT 2		Engine ECU	Diesel	9HT BOSCH EDC16C3.		Read ECU Information		Y		
EXPERT 2		Engine ECU	Diesel	9HT BOSCH EDC16C3.		Read Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	9HT BOSCH EDC16C3.		Erase Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	9HT BOSCH EDC16C3.		Live Data		Y		
EXPERT 2		Engine ECU	Diesel	9HT BOSCH EDC16C3.		Actuation Test		Y		
EXPERT 2		Engine ECU	Diesel	RHH DCM3.5.		Read ECU Information		Y		
EXPERT 2		Engine ECU	Diesel	RHH DCM3.5.		Read Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHH DCM3.5.		Erase Fault Code		Y		
EXPERT 2		Engine ECU	Diesel	RHH DCM3.5.		Live Data		Y		
EXPERT 2		Engine ECU	Diesel	RHH DCM3.5.		Actuation Test		Y		
EXPERT 2		Engine ECU	Diesel	RHH DCM3.5.		Special Function	Particulate filter after sales operation	Y		
EXPERT 2		Engine ECU	Diesel	RHH DCM3.5.		Special Function	Replacement parts	Y		
EXPERT 2		ABS or ESP ECU	ABS8_BOSCH			Read ECU Information		Y		
EXPERT 2		ABS or ESP ECU	ABS8_BOSCH			Read Fault Code		Y		
EXPERT 2		ABS or ESP ECU	ABS8_BOSCH			Erase Fault Code		Y		
EXPERT 2		ABS or ESP ECU	ABS8_BOSCH			Live Data		Y		
EXPERT 2		ABS or ESP ECU	ABS8_BOSCH			Actuation Test		Y		
EXPERT 2		ABS or ESP ECU	ABS8_BOSCH			Special Function	Bleeding	Y		
EXPERT 2		ABS or ESP ECU	ESP_BOSCH8			Read ECU Information		Y		
EXPERT 2		ABS or ESP ECU	ESP_BOSCH8			Read Fault Code		Y		
EXPERT 2		ABS or ESP ECU	ESP_BOSCH8			Erase Fault Code		Y		
EXPERT 2		ABS or ESP ECU	ESP_BOSCH8			Live Data		Y		
EXPERT 2		ABS or ESP ECU	ESP_BOSCH8			Actuation Test		Y		
EXPERT 2		ABS or ESP ECU	ESP_BOSCH8			Special Function	Bleeding	Y		
EXPERT 2		ABS or ESP ECU	ESP_BOSCH8			Special Function	Steering wheel angle sensor calibration	Y		
EXPERT 2		ABS or ESP ECU	ABS 8.1			Read ECU Information		Y		
EXPERT 2		ABS or ESP ECU	ABS 8.1			Read Fault Code		Y		
EXPERT 2		ABS or ESP ECU	ABS 8.1			Erase Fault Code		Y		
EXPERT 2		ABS or ESP ECU	ABS 8.1			Live Data		Y		
EXPERT 2		ABS or ESP ECU	ABS 8.1			Actuation Test		Y		
EXPERT 2		ABS or ESP ECU	ABS 8.1			Special Function	Bleeding	Y		
EXPERT 2		ABS or ESP ECU	ESP 8.1			Read ECU Information		Y		
EXPERT 2		ABS or ESP ECU	ESP 8.1			Read Fault Code		Y		
EXPERT 2		ABS or ESP ECU	ESP 8.1			Erase Fault Code		Y		
EXPERT 2		ABS or ESP ECU	ESP 8.1			Live Data		Y		
EXPERT 2		ABS or ESP ECU	ESP 8.1			Actuation Test		Y		
EXPERT 2		ABS or ESP ECU	ESP 8.1			Special Function	Bleeding	Y		
EXPERT 2		Airbag ECU				Read ECU Information		Y		
EXPERT 2		Airbag ECU				Read Fault Code		Y		
EXPERT 2		Airbag ECU				Erase Fault Code		Y		
EXPERT 2		Airbag ECU				Live Data		Y		
EXPERT 2		Parking aid				Read ECU Information		Y		
EXPERT 2		Parking aid				Read Fault Code		Y		
EXPERT 2		Parking aid				Erase Fault Code		Y		
EXPERT 2		Parking aid				Live Data		Y		
EXPERT 2		Parking aid				Actuation Test		Y		
EXPERT 2		Additional heating				Read ECU Information		Y		
EXPERT 2		Additional heating				Read Fault Code		Y		
EXPERT 2		Additional heating				Erase Fault Code		Y		
EXPERT 2		Additional heating				Live Data		Y		
EXPERT 2		Additional heating				Actuation Test		Y		
EXPERT 2		Power steering				Read ECU Information		Y		
EXPERT 2		Power steering				Read Fault Code		Y		
EXPERT 2		Power steering				Erase Fault Code		Y		
EXPERT 2		Power steering				Live Data		Y		
EXPERT 2		Power steering				Actuation Test		Y		
EXPERT 2		Pneumatic suspension				Read ECU Information		Y		
EXPERT 2		Pneumatic suspension				Read Fault Code		Y		
EXPERT 2		Pneumatic suspension				Erase Fault Code		Y		
EXPERT 2		Pneumatic suspension				Live Data		Y		
EXPERT 2		Pneumatic suspension				Actuation Test		Y		
EXPERT 2		Multifunction display				Read ECU Information		Y		
EXPERT 2		Multifunction display				Read Fault Code		Y		
EXPERT 2		Multifunction display				Erase Fault Code		Y		
EXPERT 2		Multifunction display				Live Data		Y		
EXPERT 2		Multifunction display				Actuation Test		Y		
EXPERT 2		Radio				Read ECU Information		Y		
EXPERT 2		Radio				Read Fault Code		Y		
EXPERT 2		Radio				Erase Fault Code		Y		
EXPERT 2		Radio				Live Data		Y		
EXPERT 2		Radio				Actuation Test		Y		
EXPERT 2		CD player				Read ECU Information		Y		
EXPERT 2		CD player				Read Fault Code		Y		
EXPERT 2		CD player				Erase Fault Code		Y		
EXPERT 2		CD player				Actuation Test		Y		
EXPERT 2		Instrument panel				Read ECU Information		Y		
EXPERT 2		Instrument panel				Read Fault Code		Y		
EXPERT 2		Instrument panel				Erase Fault Code		Y		
EXPERT 2		Instrument panel				Live Data		Y		
EXPERT 2		Hands Free Kit	KML			Read ECU Information		Y		
EXPERT 2		Hands Free Kit	KML			Read Fault Code		Y		
EXPERT 2		Hands Free Kit	KML			Erase Fault Code		Y		
EXPERT 2		Hands Free Kit	KML			Live Data		Y		
EXPERT 2		Hands Free Kit	KML			Actuation Test		Y		
EXPERT 2		Hands Free Kit	BOITIER_NOMADE			Read ECU Information		Y		
EXPERT 2		Hands Free Kit	BOITIER_NOMADE			Read Fault Code		Y		
EXPERT 2		Hands Free Kit	BOITIER_NOMADE			Erase Fault Code		Y		
EXPERT 2		Hands Free Kit	BOITIER_NOMADE			Live Data		Y		
EXPERT 2		Hands Free Kit	BOITIER_NOMADE			Actuation Test		Y		
EXPERT 2		Switch module at the steering wheel				Read ECU Information		Y		
EXPERT 2		Switch module at the steering wheel				Read Fault Code		Y		
EXPERT 2		Switch module at the steering wheel				Erase Fault Code		Y		
EXPERT 2		Switch module at the steering wheel				Live Data		Y		
EXPERT 2		Switch module at the steering wheel				Actuation Test		Y		
EXPERT 2		Telematics	Data communication ECU			Read ECU Information		Y		
EXPERT 2		Telematics	Data communication ECU			Read Fault Code		Y		
EXPERT 2		Telematics	Data communication ECU			Erase Fault Code		Y		
EXPERT 2		Telematics	Data communication ECU			Live Data		Y		
EXPERT 2		Telematics	Data communication ECU			Actuation Test		Y		
EXPERT 2		Telematics	RNEG radio navigation			Read ECU Information		Y		
EXPERT 2		Telematics	RNEG radio navigation			Read Fault Code		Y		
EXPERT 2		Telematics	RNEG radio navigation			Erase Fault Code		Y		
EXPERT 2		Telematics	RNEG radio navigation			Live Data		Y		
EXPERT 2		Telematics	RNEG radio navigation			Actuation Test		Y		
EXPERT 2		Alarm				Read ECU Information		Y		
EXPERT 2		Alarm				Read Fault Code		Y		
EXPERT 2		Alarm				Erase Fault Code		Y		
EXPERT 2		Alarm				Live Data		Y		
EXPERT 2		Alarm				Actuation Test		Y		
EXPERT 2		Rain/sunlight sensor				Read ECU Information		Y		
EXPERT 2		Rain/sunlight sensor				Read Fault Code		Y		
EXPERT 2		Rain/sunlight sensor				Erase Fault Code		Y		
EXPERT 3		BSI(Built-in Systems Interface)				Read ECU Information		Y		
EXPERT 3		BSI(Built-in Systems Interface)				Read Fault Code		Y		
EXPERT 3		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
EXPERT 3		BSI(Built-in Systems Interface)				Live Data		Y		
EXPERT 3		BSI(Built-in Systems Interface)				Actuation Test		Y		
EXPERT 3		Engine management ECU	EDC16C3	9HU-DV6UTED4 - 90CV		Read ECU Information		Y		
EXPERT 3		Engine management ECU	EDC16C3	9HU-DV6UTED4 - 90CV		Read Fault Code		Y		
EXPERT 3		Engine management ECU	EDC16C3	9HU-DV6UTED4 - 90CV		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	EDC16C3	9HU-DV6UTED4 - 90CV		Live Data		Y		
EXPERT 3		Engine management ECU	EDC16C3	9HU-DV6UTED4 - 90CV		Actuation Test		Y		
EXPERT 3		Engine management ECU	EDC16C3	9HU-DV6UTED4 - 90CV		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	EDC16C3	9HU-DV6UTED4 - 90CV		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HM - DV6UC		Read ECU Information		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HM - DV6UC		Read Fault Code		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HM - DV6UC		Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HM - DV6UC		Live Data		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HM - DV6UC		Actuation Test		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HM - DV6UC		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HM - DV6UC		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HH - DV6UM		Read ECU Information		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HH - DV6UM		Read Fault Code		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HH - DV6UM		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HH - DV6UM		Live Data		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HH - DV6UM		Actuation Test		Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HH - DV6UM		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	EDC17C10_BR2	9HH - DV6UM		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHR		Read ECU Information		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHR		Read Fault Code		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHR		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHR		Live Data		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHR		Actuation Test		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHR		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHR		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHK		Read ECU Information		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHK		Read Fault Code		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHK		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHK		Live Data		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHK		Actuation Test		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHK		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHK		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHG		Read ECU Information		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHG		Read Fault Code		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHG		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHG		Live Data		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHG		Actuation Test		Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHG		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	HDI_SID803A	HDI_SID803A RHG		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	MM6KP	MM6KP RFH		Read ECU Information		Y		
EXPERT 3		Engine management ECU	MM6KP	MM6KP RFH		Read Fault Code		Y		
EXPERT 3		Engine management ECU	MM6KP	MM6KP RFH		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	MM6KP	MM6KP RFH		Live Data		Y		
EXPERT 3		Engine management ECU	MM6KP	MM6KP RFH		Actuation Test		Y		
EXPERT 3		Engine management ECU	MM6KP	MM6KP RFH		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	MM6KP	MM6KP RFH		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	DCM3.5	DCM3.5 RHE/RHH		Read ECU Information		Y		
EXPERT 3		Engine management ECU	DCM3.5	DCM3.5 RHE/RHH		Read Fault Code		Y		
EXPERT 3		Engine management ECU	DCM3.5	DCM3.5 RHE/RHH		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	DCM3.5	DCM3.5 RHE/RHH		Live Data		Y		
EXPERT 3		Engine management ECU	DCM3.5	DCM3.5 RHE/RHH		Actuation Test		Y		
EXPERT 3		Engine management ECU	DCM3.5	DCM3.5 RHE/RHH		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	DCM3.5	DCM3.5 RHE/RHH		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Read ECU Information		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Read Fault Code		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Live Data		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Actuation Test		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	RHH-DW10CTED4-163CV		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHY-DW10CE-98CV		Read ECU Information		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHY-DW10CE-98CV		Read Fault Code		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHY-DW10CE-98CV		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHY-DW10CE-98CV		Live Data		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHY-DW10CE-98CV		Actuation Test		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHY-DW10CE-98CV		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHY-DW10CE-98CV		Special Function	Pack Repair	Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHZ-DW10CD-128CV		Read ECU Information		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHZ-DW10CD-128CV		Read Fault Code		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHZ-DW10CD-128CV		Erase Fault Code		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHZ-DW10CD-128CV		Live Data		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHZ-DW10CD-128CV		Actuation Test		Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHZ-DW10CD-128CV		Special Function	Configuration	Y		
EXPERT 3		Engine management ECU	DCM3.5_BR2	AHZ-DW10CD-128CV		Special Function	Pack Repair	Y		
EXPERT 3		Automatic gearbox or controlled manual gearbox				Read ECU Information		Y		
EXPERT 3		Automatic gearbox or controlled manual gearbox				Read Fault Code		Y		
EXPERT 3		Automatic gearbox or controlled manual gearbox				Erase Fault Code		Y		
EXPERT 3		Automatic gearbox or controlled manual gearbox				Live Data		Y		
EXPERT 3		Automatic gearbox or controlled manual gearbox				Actuation Test		Y		
EXPERT 3		Automatic gearbox or controlled manual gearbox				Special Function	Configuration	Y		
EXPERT 3		Automatic gearbox or controlled manual gearbox				Special Function	Pack Repair	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Read ECU Information		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Read Fault Code		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Erase Fault Code		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Live Data		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Actuation Test		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Special Function	Configuration	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Actuation Test		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Special Function	Configuration	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8_BOSCH			Special Function	Pack Repair	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 8_BOSCH			Read ECU Information		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 8_BOSCH			Read Fault Code		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 8_BOSCH			Erase Fault Code		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 8_BOSCH			Live Data		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 8_BOSCH			Actuation Test		Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 8_BOSCH			Special Function	Configuration	Y		
EXPERT 3		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 8_BOSCH			Special Function	Pack Repair	Y		
EXPERT 3		Air bags and pre-tensioners control unit				Read ECU Information		Y		
EXPERT 3		Air bags and pre-tensioners control unit				Read Fault Code		Y		
EXPERT 3		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
EXPERT 3		Air bags and pre-tensioners control unit				Live Data		Y		
EXPERT 3		Power steering				Read ECU Information		Y		
EXPERT 3		Power steering				Read Fault Code		Y		
EXPERT 3		Power steering				Erase Fault Code		Y		
EXPERT 3		Power steering				Live Data		Y		
EXPERT 3		Under-inflation detection	DSG_UDS			Read ECU Information		Y		
EXPERT 3		Under-inflation detection	DSG_UDS			Read Fault Code		Y		
EXPERT 3		Under-inflation detection	DSG_UDS			Erase Fault Code		Y		
EXPERT 3		Under-inflation detection	DSG_UDS			Live Data		Y		
EXPERT 3		Under-inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
EXPERT 3		Under-inflation detection	DSG			Read ECU Information		Y		
EXPERT 3		Under-inflation detection	DSG			Read Fault Code		Y		
EXPERT 3		Under-inflation detection	DSG			Erase Fault Code		Y		
EXPERT 3		Under-inflation detection	DSG			Live Data		Y		
EXPERT 3		Under-inflation detection	DSG			Special Function	Pack Reparation	Y		
EXPERT 3		Pneumatic suspension				Read ECU Information		Y		
EXPERT 3		Pneumatic suspension				Read Fault Code		Y		
EXPERT 3		Pneumatic suspension				Erase Fault Code		Y		
EXPERT 3		Pneumatic suspension				Live Data		Y		
EXPERT 3		Pneumatic suspension				Actuation Test		Y		
EXPERT 3		Additional heating				Read ECU Information		Y		
EXPERT 3		Additional heating				Read Fault Code		Y		
EXPERT 3		Additional heating				Erase Fault Code		Y		
EXPERT 3		Additional heating				Live Data		Y		
EXPERT 3		Additional heating				Actuation Test		Y		
EXPERT 3		Trailer relay unit				Read ECU Information		Y		
EXPERT 3		Trailer relay unit				Read Fault Code		Y		
EXPERT 3		Trailer relay unit				Erase Fault Code		Y		
EXPERT 3		Trailer relay unit				Live Data		Y		
EXPERT 3		Trailer relay unit				Actuation Test		Y		
EXPERT 3		Bodywork Conversion Unit				Read ECU Information		Y		
EXPERT 3		Bodywork Conversion Unit				Read Fault Code		Y		
EXPERT 3		Bodywork Conversion Unit				Erase Fault Code		Y		
EXPERT 3		Bodywork Conversion Unit				Live Data		Y		
EXPERT 3		Bodywork Conversion Unit				Actuation Test		Y		
EXPERT 3		Engine relay unit				Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
EXPERT 3		Engine relay unit				Read Fault Code		Y		
EXPERT 3		Engine relay unit				Erase Fault Code		Y		
EXPERT 3		Engine relay unit				Live Data		Y		
EXPERT 3		Engine relay unit				Actuation Test		Y		
EXPERT 3		Instrument panel				Read ECU Information		Y		
EXPERT 3		Instrument panel				Read Fault Code		Y		
EXPERT 3		Instrument panel				Erase Fault Code		Y		
EXPERT 3		Instrument panel				Live Data		Y		
EXPERT 3		Parking assistance				Read ECU Information		Y		
EXPERT 3		Parking assistance				Read Fault Code		Y		
EXPERT 3		Parking assistance				Erase Fault Code		Y		
EXPERT 3		Parking assistance				Live Data		Y		
EXPERT 3		Controls under the steering wheel				Read ECU Information		Y		
EXPERT 3		Controls under the steering wheel				Read Fault Code		Y		
EXPERT 3		Controls under the steering wheel				Erase Fault Code		Y		
EXPERT 3		Controls under the steering wheel				Live Data		Y		
EXPERT 3		Controls under the steering wheel				Actuation Test		Y		
EXPERT 3		Controls under the steering wheel				Special Function	Pack Repair	Y		
EXPERT 3		Multifunction screen	Type "A" (segments) with buttons			Read ECU Information		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) with buttons			Read Fault Code		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) with buttons			Erase Fault Code		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) with buttons			Live Data		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) with buttons			Actuation Test		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) with buttons			Special Function	Configuration	Y		
EXPERT 3		Multifunction screen	Type "A" (segments) with buttons			Special Function	Pack Repair	Y		
EXPERT 3		Multifunction screen	Type "A" (segments) without buttons			Read ECU Information		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) without buttons			Read Fault Code		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) without buttons			Erase Fault Code		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) without buttons			Live Data		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) without buttons			Actuation Test		Y		
EXPERT 3		Multifunction screen	Type "A" (segments) without buttons			Special Function	Configuration	Y		
EXPERT 3		Multifunction screen	Type "A" (segments) without buttons			Special Function	Pack Repair	Y		
EXPERT 3		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
EXPERT 3		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
EXPERT 3		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
EXPERT 3		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
EXPERT 3		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
EXPERT 3		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
EXPERT 3		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack Repair	Y		
EXPERT 3		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
EXPERT 3		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
EXPERT 3		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
EXPERT 3		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
EXPERT 3		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
EXPERT 3		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
EXPERT 3		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack Repair	Y		
EXPERT 3		Air conditioning				Read ECU Information		Y		
EXPERT 3		Air conditioning				Read Fault Code		Y		
EXPERT 3		Air conditioning				Erase Fault Code		Y		
EXPERT 3		Air conditioning				Live Data		Y		
EXPERT 3		Air conditioning				Actuation Test		Y		
EXPERT 3		Air conditioning				Special Function	Configuration	Y		
EXPERT 3		Air conditioning				Special Function	Pack repair	Y		
EXPERT 3		CD player/External CD player				Read ECU Information		Y		
EXPERT 3		CD player/External CD player				Read Fault Code		Y		
EXPERT 3		CD player/External CD player				Erase Fault Code		Y		
EXPERT 3		CD player/External CD player				Actuation Test		Y		
EXPERT 3		CD player/External CD player				Special Function	Configuration	Y		
EXPERT 3		Hands-free Kit/Portable Unit	KML			Read ECU Information		Y		
EXPERT 3		Hands-free Kit/Portable Unit	KML			Read Fault Code		Y		
EXPERT 3		Hands-free Kit/Portable Unit	KML			Erase Fault Code		Y		
EXPERT 3		Hands-free Kit/Portable Unit	KML			Live Data		Y		
EXPERT 3		Hands-free Kit/Portable Unit	KML			Actuation Test		Y		
EXPERT 3		Hands-free Kit/Portable Unit	KML			Special Function	Configuration	Y		
EXPERT 3		Hands-free Kit/Portable Unit	KML			Special Function	Spare part	Y		
EXPERT 3		Hands-free Kit/Portable Unit	BOITIER_NOMADE			Read ECU Information		Y		
EXPERT 3		Hands-free Kit/Portable Unit	BOITIER_NOMADE			Read Fault Code		Y		
EXPERT 3		Hands-free Kit/Portable Unit	BOITIER_NOMADE			Erase Fault Code		Y		
EXPERT 3		Hands-free Kit/Portable Unit	BOITIER_NOMADE			Live Data		Y		
EXPERT 3		Hands-free Kit/Portable Unit	BOITIER_NOMADE			Actuation Test		Y		
EXPERT 3		Hands-free Kit/Portable Unit	BOITIER_NOMADE			Special Function	Configuration	Y		
EXPERT 3		Hands-free Kit/Portable Unit	BOITIER_NOMADE			Special Function	Replacement parts	Y		
EXPERT 3		Radio	RD4			Read ECU Information		Y		
EXPERT 3		Radio	RD4			Read Fault Code		Y		
EXPERT 3		Radio	RD4			Erase Fault Code		Y		
EXPERT 3		Radio	RD4			Live Data		Y		
EXPERT 3		Radio	RD4			Actuation Test		Y		
EXPERT 3		Radio	RD4			Special Function	Configuration	Y		
EXPERT 3		Radio	RD4			Special Function	Replacement parts	Y		
EXPERT 3		Radio	RD45			Read ECU Information		Y		
EXPERT 3		Radio	RD45			Read Fault Code		Y		
EXPERT 3		Radio	RD45			Erase Fault Code		Y		
EXPERT 3		Radio	RD45			Live Data		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read ECU Information		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read Fault Code		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	BOITIER_TELEMATIQUE			Erase Fault Code		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	BOITIER_TELEMATIQUE			Live Data		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	BOITIER_TELEMATIQUE			Actuation Test		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Configuration	Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Pack Repair	Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RADIOAV_RNEG			Read ECU Information		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RADIOAV_RNEG			Read Fault Code		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RADIOAV_RNEG			Erase Fault Code		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RADIOAV_RNEG			Live Data		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RADIOAV_RNEG			Actuation Test		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RADIOAV_RNEG			Special Function	Configuration	Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RNEG2010			Live Data		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RNEG2010			Special Function	Configuration	Y		
EXPERT 3		Telematic unit(RTx) or audio-navigation	RNEG2010			Special Function	Pack repair	Y		
EXPERT 3		Anti-theft alarm				Read ECU Information		Y		
EXPERT 3		Anti-theft alarm				Read Fault Code		Y		
EXPERT 3		Anti-theft alarm				Erase Fault Code		Y		
EXPERT 3		Anti-theft alarm				Live Data		Y		
EXPERT 3		Anti-theft alarm				Actuation Test		Y		
EXPERT 3		Anti-theft alarm				Special Function	Configuration	Y		
EXPERT 3		Traction control mode selector				Read ECU Information		Y		
EXPERT 3		Traction control mode selector				Read Fault Code		Y		
EXPERT 3		Traction control mode selector				Live Data		Y		
EXPERT 3		Traction control mode selector				Actuation Test		Y		
EXPERT 3		Rear air conditioning table				Read ECU Information		Y		
EXPERT 3		Rear air conditioning table				Read Fault Code		Y		
EXPERT 3		Rear air conditioning table				Erase Fault Code		Y		
EXPERT 3		Rear air conditioning table				Live Data		Y		
EXPERT 3		Rear air conditioning table				Actuation Test		Y		
EXPERT 3		Rear air conditioning table				Special Function	Pack repair	Y		
EXPERT 3		Rain and light sensor				Read ECU Information		Y		
EXPERT 3		Rain and light sensor				Read Fault Code		Y		
EXPERT 3		Rain and light sensor				Erase Fault Code		Y		
EXPERT 3		High frequency receiver				Read ECU Information		Y		
EXPERT 3		High frequency receiver				Read Fault Code		Y		
EXPERT 3		High frequency receiver				Erase Fault Code		Y		
EXPERT 3		High frequency receiver				Live Data		Y		
EXPERT 3		Battery charge status unit				Read ECU Information		Y		
EXPERT 3		Battery charge status unit				Read Fault Code		Y		
EXPERT 3		Battery charge status unit				Erase Fault Code		Y		
EXPERT 3		Battery charge status unit				Live Data		Y		
EXPERT 3		Battery charge status unit				Special Function	Configuration with displaying of the parameters	Y		
EXPERT 3		Battery charge status unit				Special Function	Pack repair	Y		
HOGGAR		Engine ECU	EDC15C2			Read ECU Information		Y		
HOGGAR		Engine ECU	EDC15C2			Read Fault Code		Y		
HOGGAR		Engine ECU	EDC15C2			Erase Fault Code		Y		
HOGGAR		Engine ECU	EDC15C2			Live Data		Y		
HOGGAR		Engine ECU	EDC15C2			Actuation Test		Y		
HOGGAR		Engine ECU	EDC15C2			Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 NFU	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 N6A	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 N6B	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 KFW	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 NON FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Read ECU Information		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Read Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Erase Fault Code		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Live Data		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Actuation Test		Y		
HOGGAR		Engine ECU	ME749	ME749 KFS	ME749 FLEX FUEL	Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Read ECU Information		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Read Fault Code		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Erase Fault Code		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Live Data		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Actuation Test		Y		
HOGGAR		Engine ECU	J34P	J34P KFW		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Read ECU Information		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Read Fault Code		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Erase Fault Code		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Live Data		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Actuation Test		Y		
HOGGAR		Engine ECU	J34P	J34P HFX		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Read ECU Information		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Read Fault Code		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Erase Fault Code		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Live Data		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Actuation Test		Y		
HOGGAR		Engine ECU	DCN2	DCN2 WJY		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Read ECU Information		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Read Fault Code		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Erase Fault Code		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Live Data		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Actuation Test		Y		
HOGGAR		Engine ECU	DCN2	DCN2 HFX		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Read ECU Information		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Read Fault Code		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Erase Fault Code		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Live Data		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Actuation Test		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HX - DV4TD		Special Function	Pairing	Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Read ECU Information		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Read Fault Code		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Erase Fault Code		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Live Data		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Actuation Test		Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Special Function	Pack Repair	Y		
HOGGAR		Engine ECU	EDC16C3DV4	8HZ - DV4TD		Special Function	Pairing	Y		
HOGGAR		Engine ECU	V343	V343 HFV		Read ECU Information		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Read Fault Code		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Erase Fault Code		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Live Data		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Actuation Test		Y		
HOGGAR		Engine ECU	V343	V343 HFV		Special Function	Initialisation of the auto-adaptive components	Y		
HOGGAR		Engine ECU	V343	V343 KFT		Read ECU Information		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Read Fault Code		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Erase Fault Code		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Live Data		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Actuation Test		Y		
HOGGAR		Engine ECU	V343	V343 KFT		Special Function	Initialisation of the auto-adaptive components	Y		
HOGGAR		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read ECU Information		Y		
HOGGAR		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Read Fault Code		Y		
HOGGAR		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Erase Fault Code		Y		
HOGGAR		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Live Data		Y		
HOGGAR		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Actuation Test		Y		
HOGGAR		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Configuration	Y		
HOGGAR		Engine ECU	EDC17C10_BR2	8HR-DV4CTED-70 CV		Special Function	Pack Repair	Y		
HOGGAR		Gearbox				Read ECU Information		Y		
HOGGAR		Gearbox				Read Fault Code		Y		
HOGGAR		Gearbox				Erase Fault Code		Y		
HOGGAR		Gearbox				Live Data		Y		
HOGGAR		Gearbox				Actuation Test		Y		
HOGGAR		Gearbox				Special Function	Configuration	Y		
HOGGAR		Gearbox				Special Function	Pack Repair	Y		
HOGGAR		ABS/traction control	ABS MK70			Read ECU Information		Y		
HOGGAR		ABS/traction control	ABS MK70			Read Fault Code		Y		
HOGGAR		ABS/traction control	ABS MK70			Erase Fault Code		Y		
HOGGAR		ABS/traction control	ABS MK70			Live Data		Y		
HOGGAR		ABS/traction control	ABS MK70			Actuation Test		Y		
HOGGAR		ABS/traction control	ABS MK70			Special Function	Replacement parts	Y		
HOGGAR		ABS/traction control	ESP MK60			Read ECU Information		Y		
HOGGAR		ABS/traction control	ESP MK60			Read Fault Code		Y		
HOGGAR		ABS/traction control	ESP MK60			Erase Fault Code		Y		
HOGGAR		ABS/traction control	ESP MK60			Live Data		Y		
HOGGAR		ABS/traction control	ESP MK60			Actuation Test		Y		
HOGGAR		ABS/traction control	ESP MK60			Special Function	Replacement parts	Y		
HOGGAR		Driver and passenger airbags				Read ECU Information		Y		
HOGGAR		Driver and passenger airbags				Read Fault Code		Y		
HOGGAR		Driver and passenger airbags				Erase Fault Code		Y		
HOGGAR		Driver and passenger airbags				Special Function	Replacement parts	Y		
HOGGAR		Multifunction display	RT3			Read ECU Information		Y		
HOGGAR		Multifunction display	RT3			Read Fault Code		Y		
HOGGAR		Multifunction display	RT3			Erase Fault Code		Y		
HOGGAR		Multifunction display	RT3			Actuation Test		Y		
HOGGAR		Multifunction display	Display			Read ECU Information		Y		
HOGGAR		Multifunction display	Display			Read Fault Code		Y		
HOGGAR		Multifunction display	Display			Erase Fault Code		Y		
HOGGAR		Multifunction display	Display			Live Data		Y		
HOGGAR		Multifunction display	Display			Actuation Test		Y		
HOGGAR		Anti-theft alarm				Read ECU Information		Y		
HOGGAR		Anti-theft alarm				Read Fault Code		Y		
HOGGAR		Anti-theft alarm				Erase Fault Code		Y		
HOGGAR		Anti-theft alarm				Actuation Test		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Read ECU Information		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Read Fault Code		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Erase Fault Code		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Live Data		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio			Actuation Test		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Read ECU Information		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Read Fault Code		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Erase Fault Code		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Live Data		Y		
HOGGAR		Radio or radiotelephone(radio part)	Radio. RDE filament			Actuation Test		Y		
HOGGAR		BSI				Read ECU Information		Y		
HOGGAR		BSI				Read Fault Code		Y		
HOGGAR		BSI				Erase Fault Code		Y		
HOGGAR		BSI				Live Data		Y		
HOGGAR		BSI				Actuation Test		Y		
HOGGAR		CD player				Read ECU Information		Y		
HOGGAR		CD player				Read Fault Code		Y		
HOGGAR		CD player				Erase Fault Code		Y		
HOGGAR		CD player				Live Data		Y		
HOGGAR		CD player				Actuation Test		Y		
HOGGAR		Heating/ventilation				Read ECU Information		Y		
HOGGAR		Heating/ventilation				Read Fault Code		Y		
HOGGAR		Heating/ventilation				Erase Fault Code		Y		
HOGGAR		Heating/ventilation				Live Data		Y		
HOGGAR		Instrument panel				Read ECU Information		Y		
HOGGAR		Instrument panel				Read Fault Code		Y		
HOGGAR		Instrument panel				Erase Fault Code		Y		
HOGGAR		Instrument panel				Live Data		Y		
HOGGAR		Instrument panel				Actuation Test		Y		
HOGGAR		Rain and brightness sensor				Read ECU Information		Y		
HOGGAR		Rain and brightness sensor				Read Fault Code		Y		
HOGGAR		Rain and brightness sensor				Erase Fault Code		Y		
HOGGAR		Switch module at the steering wheel				Read ECU Information		Y		
HOGGAR		Switch module at the steering wheel				Read Fault Code		Y		
HOGGAR		Switch module at the steering wheel				Erase Fault Code		Y		
HOGGAR		Switch module at the steering wheel				Live Data		Y		
HOGGAR		Power steering electric pump unit				Read ECU Information		Y		
HOGGAR		Power steering electric pump unit				Read Fault Code		Y		
HOGGAR		Power steering electric pump unit				Erase Fault Code		Y		
HOGGAR		Power steering electric pump unit				Live Data		Y		
HOGGAR		Services module				Read ECU Information		Y		
HOGGAR		Services module				Read Fault Code		Y		
HOGGAR		Services module				Erase Fault Code		Y		
HOGGAR		Services module				Live Data		Y		
HOGGAR		Services module				Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
ION		BSI(Built-in Systems Interface)				Read ECU Information		Y		
ION		BSI(Built-in Systems Interface)				Read Fault Code		Y		
ION		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
ION		BSI(Built-in Systems Interface)				Live Data		Y		
ION		Electric machine management ECU	Electric machine management ECU			Read ECU Information		Y		
ION		Electric machine management ECU	Electric machine management ECU			Read Fault Code		Y		
ION		Electric machine management ECU	Electric machine management ECU			Erase Fault Code		Y		
ION		Electric machine management ECU	Electric machine management ECU			Live Data		Y		
ION		Electric machine management ECU	Electric machine management ECU			Special Function	Pack Repair	Y		
ION		Traction battery ECU				Read ECU Information		Y		
ION		Traction battery ECU				Read Fault Code		Y		
ION		Traction battery ECU				Erase Fault Code		Y		
ION		Traction battery ECU				Live Data		Y		
ION		Traction battery ECU				Actuation Test		Y		
ION		Power steering				Read ECU Information		Y		
ION		Power steering				Read Fault Code		Y		
ION		Power steering				Erase Fault Code		Y		
ION		Power steering				Live Data		Y		
ION		Airbag	SRS			Read ECU Information		Y		
ION		Airbag	SRS			Read Fault Code		Y		
ION		Airbag	SRS			Erase Fault Code		Y		
ION		Airbag	SRS			Live Data		Y		
ION		Airbag	SRS			Actuation Test		Y		
ION		Airbag	ORC			Read ECU Information		Y		
ION		Airbag	ORC			Read Fault Code		Y		
ION		Airbag	ORC			Erase Fault Code		Y		
ION		Airbag	ORC			Live Data		Y		
ION		Airbag	ORC			Actuation Test		Y		
ION		Electric vehicle management ECU				Read ECU Information		Y		
ION		Electric vehicle management ECU				Read Fault Code		Y		
ION		Electric vehicle management ECU				Erase Fault Code		Y		
ION		Electric vehicle management ECU				Live Data		Y		
ION		Electric vehicle management ECU				Actuation Test		Y		
ION		ESP				Read ECU Information		Y		
ION		ESP				Read Fault Code		Y		
ION		ESP				Erase Fault Code		Y		
ION		ESP				Live Data		Y		
ION		ESP				Actuation Test		Y		
ION		Steering wheel angle sensor				Read ECU Information		Y		
ION		Steering wheel angle sensor				Read Fault Code		Y		
ION		Steering wheel angle sensor				Erase Fault Code		Y		
ION		Steering wheel angle sensor				Live Data		Y		
ION		Steering wheel angle sensor				Special Function	Pack repair	Y		
ION		Gateway wiring housing				Read ECU Information		Y		
ION		Gateway wiring housing				Read Fault Code		Y		
ION		Gateway wiring housing				Erase Fault Code		Y		
ION		Gateway wiring housing				Live Data		Y		
ION		Gateway wiring housing				Special Function	View and print all Configuration parameters	Y		
ION		Gateway wiring housing				Special Function	Configuration	Y		
ION		Independent telematic unit (BTA)				Read ECU Information		Y		
ION		Independent telematic unit (BTA)				Read Fault Code		Y		
ION		Independent telematic unit (BTA)				Erase Fault Code		Y		
ION		Independent telematic unit (BTA)				Live Data		Y		
ION		Independent telematic unit (BTA)				Actuation Test		Y		
ION		Independent telematic unit (BTA)				Special Function	Configuration	Y		
ION		Instrument panel				Read ECU Information		Y		
ION		Instrument panel				Read Fault Code		Y		
ION		Instrument panel				Erase Fault Code		Y		
ION		Instrument panel				Live Data		Y		
ION		Instrument panel				Actuation Test		Y		
ION		Radio				Read ECU Information		Y		
ION		Radio				Read Fault Code		Y		
ION		Radio				Erase Fault Code		Y		
ION		Radio				Live Data		Y		
ION		Radio				Actuation Test		Y		
ION		Radio				Special Function	Configuration	Y		
ION		Air conditioning				Read ECU Information		Y		
ION		Air conditioning				Read Fault Code		Y		
ION		Air conditioning				Erase Fault Code		Y		
ION		Air conditioning				Live Data		Y		
ION		Air conditioning				Actuation Test		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Read ECU Information		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Read Fault Code		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Erase Fault Code		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Live Data		Y		
ION		Air conditioning compressor and passenger compartment heating control module				Actuation Test		Y		
ION		Onboard charger of the traction battery				Read ECU Information		Y		
ION		Onboard charger of the traction battery				Read Fault Code		Y		
ION		Onboard charger of the traction battery				Erase Fault Code		Y		
ION		Onboard charger of the traction battery				Live Data		Y		
ION		Direct voltage (DC/DC) transformer				Read ECU Information		Y		
ION		Direct voltage (DC/DC) transformer				Read Fault Code		Y		
ION		Direct voltage (DC/DC) transformer				Erase Fault Code		Y		
ION		Direct voltage (DC/DC) transformer				Live Data		Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type LFX	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type KFXBOSCH MP7.3 system	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type KFXMM1AP system	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type LFXSAGEM SL 96 system	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type HDY	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type HDZ	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type HFX	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type KFW	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type N6A	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type NFU	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type RHYSIEMENS SID801 system	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type RHYBOSCH EDC15C2 system	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type A9A	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type WJZ	Y		
PARTNER	Production date before 30 September 2002	BSI(Built-in Systems Interface)				Special Function	Engine type WJY	Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HDY BOSCH MA3.1.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HDY BOSCH MA3.1.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HDY BOSCH MA3.1.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HDY BOSCH MA3.1.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HDZ BOSCH MA3.1.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HDZ BOSCH MA3.1.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HDZ BOSCH MA3.1.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HDZ BOSCH MA3.1.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HFX BOSCH M7.4.4.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HFX BOSCH M7.4.4.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HFX BOSCH M7.4.4.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HFX BOSCH M7.4.4.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	HFX BOSCH M7.4.4.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFW SAGEM S2000.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFW SAGEM S2000.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFW SAGEM S2000.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFW SAGEM S2000.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFW SAGEM S2000.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	K6D SAGEM S2000.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	K6D SAGEM S2000.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	K6D SAGEM S2000.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	K6D SAGEM S2000.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	K6D SAGEM S2000.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX BOSCH MP7.3.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX BOSCH MP7.3.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX BOSCH MP7.3.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX BOSCH MP7.3.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX BOSCH MP7.3.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX MM1AP.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX MM1AP.		Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX MM1AP.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX MM1AP.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX SAGEM SL 96.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX SAGEM SL 96.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX SAGEM SL 96.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX SAGEM SL 96.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	KFX SAGEM SL 96.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	LFX MM1AP.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	LFX MM1AP.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	LFX MM1AP.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	LFX MM1AP.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY SIEMENS SID801.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY SIEMENS SID801.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY SIEMENS SID801.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY SIEMENS SID801.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY SIEMENS SID801.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY BOSCH EDC15C2.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY BOSCH EDC15C2.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY BOSCH EDC15C2.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY BOSCH EDC15C2.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	RHY BOSCH EDC15C2.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJY LUCAS DCN2.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJY LUCAS DCN2.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJY LUCAS DCN2.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJY LUCAS DCN2.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJY LUCAS DCN2.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJZ LUCAS DCN2.		Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJZ LUCAS DCN2.		Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJZ LUCAS DCN2.		Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJZ LUCAS DCN2.		Live Data		Y		
PARTNER	Production date before 30 September 2002	Engine	Diesel	WJZ LUCAS DCN2.		Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Live Data		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.			Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Live Data		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Active safety	BOSCH ABS5.3.			Special Function	Bleeding	Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Live Data		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio PHILIPS			Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Live Data		Y		
PARTNER	Production date before 30 September 2002	Radio	Radio CLARION			Actuation Test		Y		
PARTNER	Production date before 30 September 2002	CD player				Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	CD player				Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	CD player				Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	CD player				Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Live Data		Y		
PARTNER	Production date before 30 September 2002	Instrument panel				Actuation Test		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Read ECU Information		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Read Fault Code		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Erase Fault Code		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Live Data		Y		
PARTNER	Production date before 30 September 2002	Additional heating				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	BSI(Built-in Systems Interface)				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	BSI(Built-in Systems Interface)				Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER	Production date between 30 September 2002 and 27 October 2002	BSI(Built-in Systems Interface)				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	BSI(Built-in Systems Interface)				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	HFX MM4.8P.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	HFX MM4.8P.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	HFX MM4.8P.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	HFX MM4.8P.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	HFX MM4.8P.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM1.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM1.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM1.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM1.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM1.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM2.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM2.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM2.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM2.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW SAGEM S2000PM2.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.4.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.4.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME7.4.5.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6B BOSCH ME7.4.5.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU BOSCH ME7.4.5.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU Or N6A BOSCH ME749.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU Or N6A BOSCH ME749.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU Or N6A BOSCH ME749.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU Or N6A BOSCH ME749.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	NFU Or N6A BOSCH ME749.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME749 BIO FLEX.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME749 BIO FLEX.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME749 BIO FLEX.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME749 BIO FLEX.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	N6A BOSCH ME749 BIO FLEX.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749 BIO FLEX.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749 BIO FLEX.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749 BIO FLEX.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749 BIO FLEX.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW BOSCH ME749 BIO FLEX.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW J34P.		Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW J34P.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW J34P.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW J34P.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Petrol	KFW J34P.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	RHY SIEMENS SID801.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	WJY LUCAS DCN2.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	WJY LUCAS DCN2.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	WJY LUCAS DCN2.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	WJY LUCAS DCN2.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	WJY LUCAS DCN2.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HW BOSCH EDC16C3.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HW BOSCH EDC16C3.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HW BOSCH EDC16C3.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HW BOSCH EDC16C3.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HW BOSCH EDC16C3.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HX BOSCH EDC16C3.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HX BOSCH EDC16C3.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HX BOSCH EDC16C3.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HX BOSCH EDC16C3.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HX BOSCH EDC16C3.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HT BOSCH EDC16C3.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HT BOSCH EDC16C3.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HT BOSCH EDC16C3.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HT BOSCH EDC16C3.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HT BOSCH EDC16C3.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HJ EDC17C10_BR2 - DV6DTEDM - 92 CV.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HK EDC17C10_BR2 - DV6ETEDM - 75 CV.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV.		Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV.		Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV.		Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV.		Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Engine	Diesel	9HE EDC17C10_BR2 - DV6DBM - 89 CV.		Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	BOSCH ABS5.3			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS BOSCH 8			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Read Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Special Function	Steering wheel angle sensor calibration	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 5.7			Special Function	De-calibration of the steering wheel angle sensor	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Special Function	Steering wheel angle sensor calibration	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Special Function	De-calibration of the steering wheel angle sensor	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP BOSCH 8			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ABS 8.1			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Active safety	ESP 8.1			Special Function	Bleeding	Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Airbags				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Airbags				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Airbags				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	LPG / GNV	SAGEM SAX500			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	LPG / GNV	SAGEM SAX500			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	LPG / GNV	SAGEM SAX500			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	LPG / GNV	SAGEM SAX500			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Parking aid				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Additional heating				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Alarm				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Alarm				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Alarm				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Alarm				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Alarm				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Service module				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	AMF			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Display / Telematics	RT3			Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	CD player				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Instrument panel				Actuation Test		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Switching module below steering wheel (COM 2000)				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Switching module below steering wheel (COM 2000)				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Switching module below steering wheel (COM 2000)				Erase Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Switching module below steering wheel (COM 2000)				Live Data		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Rain/sunlight sensor				Read ECU Information		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Rain/sunlight sensor				Read Fault Code		Y		
PARTNER	Production date between 30 September 2002 and 27 October 2002	Rain/sunlight sensor				Erase Fault Code		Y		
PARTNER B9		BSI(Built-in Systems Interface)				Read ECU Information		Y		
PARTNER B9		BSI(Built-in Systems Interface)				Read Fault Code		Y		
PARTNER B9		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
PARTNER B9		BSI(Built-in Systems Interface)				Live Data		Y		
PARTNER B9		BSI(Built-in Systems Interface)				Actuation Test		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6B	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6B	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6B	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6B	Live Data		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6B	Actuation Test		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6A	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6A	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6A	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6A	Live Data		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6A	Actuation Test		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFR	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFR	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFR	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFR	Live Data		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFR	Actuation Test		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFR	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFR	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFU	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFU	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFU	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFU	Live Data		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFU	Actuation Test		Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FS	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FS	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FS	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FS	Live Data		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FS	Actuation Test		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FS	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FS	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FK	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FK	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FK	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FK	Live Data		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FK	Actuation Test		Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FK	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Petrol	MEV17_4_EUR05	MEV17_4_EUR05 5FK	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Petrol	VD46		Read ECU Information		Y		
PARTNER B9		Engine management ECU	Petrol	VD46		Read Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	VD46		Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Petrol	VD46		Live Data		Y		
PARTNER B9		Engine management ECU	Petrol	VD46		Actuation Test		Y		
PARTNER B9		Engine management ECU	Petrol	VD46		Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HT DV6BUTED4 - 75CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HT DV6BUTED4 - 75CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HT DV6BUTED4 - 75CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HT DV6BUTED4 - 75CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HT DV6BUTED4 - 75CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HT DV6BUTED4 - 75CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HT DV6BUTED4 - 75CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HW DV6BUTED4 - 75CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HW DV6BUTED4 - 75CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HW DV6BUTED4 - 75CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HW DV6BUTED4 - 75CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HW DV6BUTED4 - 75CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HW DV6BUTED4 - 75CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HW DV6BUTED4 - 75CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX DV6AUTED4 - 90CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX DV6AUTED4 - 90CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX DV6AUTED4 - 90CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX DV6AUTED4 - 90CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX DV6AUTED4 - 90CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX DV6AUTED4 - 90CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX DV6AUTED4 - 90CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX-DV6ATED4 - 90CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX-DV6ATED4 - 90CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX-DV6ATED4 - 90CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX-DV6ATED4 - 90CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX-DV6ATED4 - 90CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX-DV6ATED4 - 90CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HX-DV6ATED4 - 90CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HS-DV6TED4BU FAP -	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HS-DV6TED4BU FAP -	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HS-DV6TED4BU FAP -	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HS-DV6TED4BU FAP -	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HS-DV6TED4BU FAP -	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HS-DV6TED4BU FAP -	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HS-DV6TED4BU FAP -	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HV-DV6TED4B FAP - 90CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HV-DV6TED4B FAP - 90CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HV-DV6TED4B FAP - 90CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HV-DV6TED4B FAP - 90CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HV-DV6TED4B FAP - 90CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HV-DV6TED4B FAP - 90CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HV-DV6TED4B FAP - 90CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP - 110CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP - 110CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP - 110CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP - 110CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP - 110CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP - 110CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC16C3	9HZ-DV6TED4 FAP - 110CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HP - DV6DTED - 92 CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HP - DV6DTED - 92 CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HP - DV6DTED - 92 CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HP - DV6DTED - 92 CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HP - DV6DTED - 92 CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HP - DV6DTED - 92 CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HP - DV6DTED - 92 CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HF - DV6DTED - 89 CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HF - DV6DTED - 89 CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HF - DV6DTED - 89 CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HF - DV6DTED - 89 CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HF - DV6DTED - 89 CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HF - DV6DTED - 89 CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HF - DV6DTED - 89 CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HN - DV6ETED	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HN - DV6ETED	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HN - DV6ETED	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HN - DV6ETED	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HN - DV6ETED	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HN - DV6ETED	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HN - DV6ETED	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HJ - DV6DTEDM - 90 CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HJ - DV6DTEDM - 90 CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HJ - DV6DTEDM - 90 CV	Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HJ - DV6DTEDM - 90 CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HJ - DV6DTEDM - 90 CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HJ - DV6DTEDM - 90 CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HJ - DV6DTEDM - 90 CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HK - DV6ETEDM - 75 CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HK - DV6ETEDM - 75 CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HK - DV6ETEDM - 75 CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HK - DV6ETEDM - 75 CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HK - DV6ETEDM - 75 CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HK - DV6ETEDM - 75 CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HK - DV6ETEDM - 75 CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HE - DV6DBM - 89 CV	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HE - DV6DBM - 89 CV	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HE - DV6DBM - 89 CV	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HE - DV6DBM - 89 CV	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HE - DV6DBM - 89 CV	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HE - DV6DBM - 89 CV	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C10_BR2	9HE - DV6DBM - 89 CV	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HL	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HL	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HL	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HL	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HL	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HL	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HL	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Configuration	Y		
PARTNER B9		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Pack Repair	Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C60		Read ECU Information		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C60		Read Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C60		Erase Fault Code		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C60		Live Data		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C60		Actuation Test		Y		
PARTNER B9		Engine management ECU	Diesel	EDC17C60		Special Function	Pack Repair	Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	90 ESP			Read ECU Information		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	90 ESP			Read Fault Code		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	90 ESP			Erase Fault Code		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	90 ESP			Live Data		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	90 ESP			Actuation Test		Y		
PARTNER B9		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	90 ESP			Special Function	Pack Repair	Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Read ECU Information		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Read Fault Code		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Erase Fault Code		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Live Data		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Actuation Test		Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Special Function	Replacement parts	Y		
PARTNER B9		Automatic gearbox or controlled manual gearbox	BVMP_MCP_UDS			Special Function	Counters	Y		
PARTNER B9		Air bags and pre-tensioners control unit				Read ECU Information		Y		
PARTNER B9		Air bags and pre-tensioners control unit				Read Fault Code		Y		
PARTNER B9		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
PARTNER B9		Air bags and pre-tensioners control unit				Live Data		Y		
PARTNER B9		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
PARTNER B9		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
PARTNER B9		Power steering				Read ECU Information		Y		
PARTNER B9		Power steering				Read Fault Code		Y		
PARTNER B9		Power steering				Erase Fault Code		Y		
PARTNER B9		Power steering				Live Data		Y		
PARTNER B9		Power steering				Actuation Test		Y		
PARTNER B9		Diesel additive pump	PADDGO			Read ECU Information		Y		
PARTNER B9		Diesel additive pump	PADDGO			Read Fault Code		Y		
PARTNER B9		Diesel additive pump	PADDGO			Erase Fault Code		Y		
PARTNER B9		Diesel additive pump	PADDGO			Live Data		Y		
PARTNER B9		Diesel additive pump	PADDGO			Actuation Test		Y		
PARTNER B9		Diesel additive pump	PADDGO			Special Function	Configuration	Y		
PARTNER B9		Diesel additive pump	PADDGO			Special Function	Pack repair	Y		
PARTNER B9		Diesel additive pump	POMPE_MUX_TI			Read ECU Information		Y		
PARTNER B9		Diesel additive pump	POMPE_MUX_TI			Read Fault Code		Y		
PARTNER B9		Diesel additive pump	POMPE_MUX_TI			Erase Fault Code		Y		
PARTNER B9		Diesel additive pump	POMPE_MUX_TI			Live Data		Y		
PARTNER B9		Diesel additive pump	POMPE_MUX_TI			Actuation Test		Y		
PARTNER B9		Diesel additive pump	POMPE_MUX_TI			Special Function	Configuration	Y		
PARTNER B9		Diesel additive pump	PADDGO_TI_E6			Read ECU Information		Y		
PARTNER B9		Diesel additive pump	PADDGO_TI_E6			Read Fault Code		Y		
PARTNER B9		Diesel additive pump	PADDGO_TI_E6			Erase Fault Code		Y		
PARTNER B9		Diesel additive pump	PADDGO_TI_E6			Live Data		Y		
PARTNER B9		Diesel additive pump	PADDGO_TI_E6			Special Function	Configuration	Y		
PARTNER B9		Under inflation detection	DSG_UDS			Read ECU Information		Y		
PARTNER B9		Under inflation detection	DSG_UDS			Read Fault Code		Y		
PARTNER B9		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
PARTNER B9		Under inflation detection	DSG_UDS			Live Data		Y		
PARTNER B9		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
PARTNER B9		Under inflation detection	DSG			Read ECU Information		Y		
PARTNER B9		Under inflation detection	DSG			Read Fault Code		Y		
PARTNER B9		Under inflation detection	DSG			Erase Fault Code		Y		
PARTNER B9		Under inflation detection	DSG			Live Data		Y		
PARTNER B9		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
PARTNER B9		Battery charge status unit	BECB			Read ECU Information		Y		
PARTNER B9		Battery charge status unit	BECB			Read Fault Code		Y		
PARTNER B9		Battery charge status unit	BECB			Erase Fault Code		Y		
PARTNER B9		Battery charge status unit	BECB			Live Data		Y		
PARTNER B9		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
PARTNER B9		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
PARTNER B9		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
PARTNER B9		Battery charge status unit	BECB_GEN2			Live Data		Y		
PARTNER B9		Battery charge status unit	BECB_GEN2			Special Function	Configuration with displaying of the parameters	Y		
PARTNER B9		Battery charge status unit	BECB_GEN2			Special Function	Pack repair	Y		
PARTNER B9		Engine relay unit				Read ECU Information		Y		
PARTNER B9		Engine relay unit				Read Fault Code		Y		
PARTNER B9		Engine relay unit				Erase Fault Code		Y		
PARTNER B9		Engine relay unit				Live Data		Y		
PARTNER B9		Engine relay unit				Actuation Test		Y		
PARTNER B9		Bodywork Conversion Unit				Read ECU Information		Y		
PARTNER B9		Bodywork Conversion Unit				Read Fault Code		Y		
PARTNER B9		Bodywork Conversion Unit				Erase Fault Code		Y		
PARTNER B9		Bodywork Conversion Unit				Live Data		Y		
PARTNER B9		Bodywork Conversion Unit				Actuation Test		Y		
PARTNER B9		Trailer relay unit				Read ECU Information		Y		
PARTNER B9		Trailer relay unit				Read Fault Code		Y		
PARTNER B9		Trailer relay unit				Erase Fault Code		Y		
PARTNER B9		Trailer relay unit				Live Data		Y		
PARTNER B9		Trailer relay unit				Actuation Test		Y		
PARTNER B9		Air conditioning				Read ECU Information		Y		
PARTNER B9		Air conditioning				Read Fault Code		Y		
PARTNER B9		Air conditioning				Erase Fault Code		Y		
PARTNER B9		Air conditioning				Live Data		Y		
PARTNER B9		Air conditioning				Actuation Test		Y		
PARTNER B9		Air conditioning				Special Function	Configuration	Y		
PARTNER B9		Air conditioning				Special Function	Pack repair	Y		
PARTNER B9		Multifunction screen	Type "A" (segments) With buttons			Read ECU Information		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER B9		Multifunction screen	Type "A" (segments) With buttons			Read Fault Code		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) With buttons			Erase Fault Code		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) With buttons			Live Data		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) With buttons			Actuation Test		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) With buttons			Special Function	Configuration	Y		
PARTNER B9		Multifunction screen	Type "A" (segments) With buttons			Special Function	Pack Repair	Y		
PARTNER B9		Multifunction screen	Type "A" (segments) Without button			Read ECU Information		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) Without button			Read Fault Code		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) Without button			Erase Fault Code		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) Without button			Live Data		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) Without button			Actuation Test		Y		
PARTNER B9		Multifunction screen	Type "A" (segments) Without button			Special Function	Configuration	Y		
PARTNER B9		Multifunction screen	Type "A" (segments) Without button			Special Function	Pack Repair	Y		
PARTNER B9		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
PARTNER B9		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
PARTNER B9		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
PARTNER B9		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
PARTNER B9		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
PARTNER B9		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
PARTNER B9		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack Repair	Y		
PARTNER B9		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
PARTNER B9		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
PARTNER B9		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
PARTNER B9		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
PARTNER B9		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
PARTNER B9		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
PARTNER B9		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack Repair	Y		
PARTNER B9		Instrument panel				Read ECU Information		Y		
PARTNER B9		Instrument panel				Read Fault Code		Y		
PARTNER B9		Instrument panel				Erase Fault Code		Y		
PARTNER B9		Instrument panel				Live Data		Y		
PARTNER B9		Instrument panel				Actuation Test		Y		
PARTNER B9		Instrument panel				Special Function	Configuration	Y		
PARTNER B9		Parking assistance	AAS			Read ECU Information		Y		
PARTNER B9		Parking assistance	AAS			Read Fault Code		Y		
PARTNER B9		Parking assistance	AAS			Erase Fault Code		Y		
PARTNER B9		Parking assistance	AAS			Live Data		Y		
PARTNER B9		Parking assistance	AAS			Special Function	Configuration	Y		
PARTNER B9		Parking assistance	AAS			Special Function	Pack repair	Y		
PARTNER B9		Parking assistance	AAS_UDS	4 parking assistance sensors		Read ECU Information		Y		
PARTNER B9		Parking assistance	AAS_UDS	4 parking assistance sensors		Read Fault Code		Y		
PARTNER B9		Parking assistance	AAS_UDS	4 parking assistance sensors		Erase Fault Code		Y		
PARTNER B9		Parking assistance	AAS_UDS	4 parking assistance sensors		Live Data		Y		
PARTNER B9		Parking assistance	AAS_UDS	4 parking assistance sensors		Actuation Test		Y		
PARTNER B9		Parking assistance	AAS_UDS	8 parking assistance sensors		Read ECU Information		Y		
PARTNER B9		Parking assistance	AAS_UDS	8 parking assistance sensors		Read Fault Code		Y		
PARTNER B9		Parking assistance	AAS_UDS	8 parking assistance sensors		Erase Fault Code		Y		
PARTNER B9		Parking assistance	AAS_UDS	8 parking assistance sensors		Live Data		Y		
PARTNER B9		Parking assistance	AAS_UDS	8 parking assistance sensors		Actuation Test		Y		
PARTNER B9		Controls under the steering wheel				Read ECU Information		Y		
PARTNER B9		Controls under the steering wheel				Read Fault Code		Y		
PARTNER B9		Controls under the steering wheel				Erase Fault Code		Y		
PARTNER B9		Controls under the steering wheel				Live Data		Y		
PARTNER B9		Controls under the steering wheel				Actuation Test		Y		
PARTNER B9		Controls under the steering wheel				Special Function	Pack Repair	Y		
PARTNER B9		Hands-free Kit / Portable Unit	KML			Read ECU Information		Y		
PARTNER B9		Hands-free Kit / Portable Unit	KML			Read Fault Code		Y		
PARTNER B9		Hands-free Kit / Portable Unit	KML			Erase Fault Code		Y		
PARTNER B9		Hands-free Kit / Portable Unit	KML			Live Data		Y		
PARTNER B9		Hands-free Kit / Portable Unit	KML			Actuation Test		Y		
PARTNER B9		Hands-free Kit / Portable Unit	KML			Special Function	Configuration	Y		
PARTNER B9		Hands-free Kit / Portable Unit	KML			Special Function	Spare part	Y		
PARTNER B9		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read ECU Information		Y		
PARTNER B9		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read Fault Code		Y		
PARTNER B9		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Erase Fault Code		Y		
PARTNER B9		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Live Data		Y		
PARTNER B9		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Actuation Test		Y		
PARTNER B9		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Special Function	Configuration	Y		
PARTNER B9		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Special Function	Replacement parts	Y		
PARTNER B9		Radio	RD4			Read ECU Information		Y		
PARTNER B9		Radio	RD4			Read Fault Code		Y		
PARTNER B9		Radio	RD4			Erase Fault Code		Y		
PARTNER B9		Radio	RD4			Live Data		Y		
PARTNER B9		Radio	RD4			Actuation Test		Y		
PARTNER B9		Radio	RD4			Special Function	Configuration	Y		
PARTNER B9		Radio	RD4			Special Function	Replacement parts	Y		
PARTNER B9		Radio	RD45			Read ECU Information		Y		
PARTNER B9		Radio	RD45			Read Fault Code		Y		
PARTNER B9		Radio	RD45			Erase Fault Code		Y		
PARTNER B9		Radio	RD45			Live Data		Y		
PARTNER B9		Radio	RD45			Actuation Test		Y		
PARTNER B9		Radio	RD45			Special Function	Configuration	Y		
PARTNER B9		Radio	RD45			Special Function	Pack Repair	Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read ECU Information		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read Fault Code		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Erase Fault Code		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Live Data		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Actuation Test		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Special Function	Configuration	Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Configuration	Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Pack repair	Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Read ECU Information		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Read Fault Code		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Erase Fault Code		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Live Data		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Actuation Test		Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Special Function	Configuration	Y		
PARTNER B9		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Special Function	Pack repair	Y		
PARTNER B9		CD changer / external CD player				Read ECU Information		Y		
PARTNER B9		CD changer / external CD player				Read Fault Code		Y		
PARTNER B9		CD changer / external CD player				Erase Fault Code		Y		
PARTNER B9		CD changer / external CD player				Actuation Test		Y		
PARTNER B9		CD changer / external CD player				Special Function	Configuration	Y		
PARTNER B9		Anti-theft alarm				Read ECU Information		Y		
PARTNER B9		Anti-theft alarm				Read Fault Code		Y		
PARTNER B9		Anti-theft alarm				Erase Fault Code		Y		
PARTNER B9		Anti-theft alarm				Live Data		Y		
PARTNER B9		Anti-theft alarm				Actuation Test		Y		
PARTNER B9		Anti-theft alarm				Special Function	Configuration	Y		
PARTNER B9		Anti-theft alarm				Special Function	Pack repair	Y		
PARTNER B9		Traction control mode selector				Read ECU Information		Y		
PARTNER B9		Traction control mode selector				Read Fault Code		Y		
PARTNER B9		Traction control mode selector				Live Data		Y		
PARTNER B9		Traction control mode selector				Actuation Test		Y		
PARTNER B9		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
PARTNER B9		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
PARTNER B9		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
PARTNER B9		Service module / Independent telematic unit	BTA			Live Data		Y		
PARTNER B9		Service module / Independent telematic unit	BTA			Actuation Test		Y		
PARTNER B9		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
PARTNER B9		Service module / Independent telematic unit	BTA			Special Function	Pack repair	Y		
PARTNER B9		Service module / Independent telematic unit	BTA_3R			Read ECU Information		Y		
PARTNER B9		Service module / Independent telematic unit	BTA_3R			Read Fault Code		Y		
PARTNER B9		Service module / Independent telematic unit	BTA_3R			Erase Fault Code		Y		
PARTNER B9		Service module / Independent telematic unit	BTA_3R			Live Data		Y		
PARTNER B9		Service module / Independent telematic unit	BTA_3R			Actuation Test		Y		
PARTNER B9		Rain and light sensor				Read ECU Information		Y		
PARTNER B9		Rain and light sensor				Read Fault Code		Y		
PARTNER B9		Rain and light sensor				Erase Fault Code		Y		
PARTNER B9		High frequency receiver				Read ECU Information		Y		
PARTNER B9		High frequency receiver				Read Fault Code		Y		
PARTNER B9		High frequency receiver				Erase Fault Code		Y		
PARTNER B9		High frequency receiver				Live Data		Y		
PARTNER B9		Voltage retaining device	DMTC			Read ECU Information		Y		
PARTNER B9		Voltage retaining device	DMTR			Read ECU Information		Y		
PARTNER B9		Voltage retaining device	DMTR			Read Fault Code		Y		
PARTNER B9		Voltage retaining device	DMTR			Erase Fault Code		Y		
PARTNER B9		Voltage retaining device	DMTR_DTC3B			Read ECU Information		Y		
PARTNER B9		Voltage retaining device	DMTR_DTC3B			Read Fault Code		Y		
PARTNER B9		Voltage retaining device	DMTR_DTC3B			Erase Fault Code		Y		
PARTNER B9		Vehicle Distance Assistance				Read ECU Information		Y		
PARTNER B9		Vehicle Distance Assistance				Read Fault Code		Y		
PARTNER B9		Vehicle Distance Assistance				Erase Fault Code		Y		
PARTNER B9		Vehicle Distance Assistance				Live Data		Y		
PARTNER B9		Vehicle Distance Assistance				Actuation Test		Y		
PARTNER B9		Vehicle Distance Assistance				Special Function	Pack repair	Y		
PARTNER Electric(B9e)		Built-in Systems Interface (BSI)				Read ECU Information		Y		
PARTNER Electric(B9e)		Built-in Systems Interface (BSI)				Read Fault Code		Y		
PARTNER Electric(B9e)		Built-in Systems Interface (BSI)				Erase Fault Code		Y		
PARTNER Electric(B9e)		Built-in Systems Interface (BSI)				Live Data		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER Electric(B9e)		Built-in Systems Interface (BSI)				Actuation Test		Y		
PARTNER Electric(B9e)		Built-in Systems Interface (BSI)				Special Function	Maintenance - BSI operating mode	Y		
PARTNER Electric(B9e)		Built-in Systems Interface (BSI)				Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
PARTNER Electric(B9e)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
PARTNER Electric(B9e)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
PARTNER Electric(B9e)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
PARTNER Electric(B9e)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
PARTNER Electric(B9e)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Air bags and pre-tensioners control unit				Read ECU Information		Y		
PARTNER Electric(B9e)		Air bags and pre-tensioners control unit				Read Fault Code		Y		
PARTNER Electric(B9e)		Air bags and pre-tensioners control unit				Erase Fault Code		Y		
PARTNER Electric(B9e)		Air bags and pre-tensioners control unit				Live Data		Y		
PARTNER Electric(B9e)		Air bags and pre-tensioners control unit				Special Function	Configuration	Y		
PARTNER Electric(B9e)		Air bags and pre-tensioners control unit				Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Radio	RD4			Read ECU Information		Y		
PARTNER Electric(B9e)		Radio	RD4			Read Fault Code		Y		
PARTNER Electric(B9e)		Radio	RD4			Erase Fault Code		Y		
PARTNER Electric(B9e)		Radio	RD4			Live Data		Y		
PARTNER Electric(B9e)		Radio	RD4			Actuation Test		Y		
PARTNER Electric(B9e)		Radio	RD4			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Radio	RD4			Special Function	Replacement parts	Y		
PARTNER Electric(B9e)		Radio	RD45			Read ECU Information		Y		
PARTNER Electric(B9e)		Radio	RD45			Read Fault Code		Y		
PARTNER Electric(B9e)		Radio	RD45			Erase Fault Code		Y		
PARTNER Electric(B9e)		Radio	RD45			Live Data		Y		
PARTNER Electric(B9e)		Radio	RD45			Actuation Test		Y		
PARTNER Electric(B9e)		Radio	RD45			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Radio	RD45			Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Parking assistance				Read ECU Information		Y		
PARTNER Electric(B9e)		Parking assistance				Read Fault Code		Y		
PARTNER Electric(B9e)		Parking assistance				Erase Fault Code		Y		
PARTNER Electric(B9e)		Parking assistance				Live Data		Y		
PARTNER Electric(B9e)		Parking assistance				Special Function	Configuration	Y		
PARTNER Electric(B9e)		Parking assistance				Special Function	Pack repair	Y		
PARTNER Electric(B9e)		Onboard charger of the traction battery				Read ECU Information		Y		
PARTNER Electric(B9e)		Onboard charger of the traction battery				Read Fault Code		Y		
PARTNER Electric(B9e)		Onboard charger of the traction battery				Erase Fault Code		Y		
PARTNER Electric(B9e)		Onboard charger of the traction battery				Live Data		Y		
PARTNER Electric(B9e)		Traction battery ECU				Read ECU Information		Y		
PARTNER Electric(B9e)		Traction battery ECU				Read Fault Code		Y		
PARTNER Electric(B9e)		Traction battery ECU				Erase Fault Code		Y		
PARTNER Electric(B9e)		Traction battery ECU				Live Data		Y		
PARTNER Electric(B9e)		Traction battery ECU				Special Function	Replacement parts	Y		
PARTNER Electric(B9e)		Air conditioning	Air conditioning			Read ECU Information		Y		
PARTNER Electric(B9e)		Air conditioning	Air conditioning			Read Fault Code		Y		
PARTNER Electric(B9e)		Air conditioning	Air conditioning			Erase Fault Code		Y		
PARTNER Electric(B9e)		Air conditioning	Air conditioning			Live Data		Y		
PARTNER Electric(B9e)		Air conditioning	Air conditioning			Actuation Test		Y		
PARTNER Electric(B9e)		Air conditioning	Air conditioning			Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Instrument panel				Read ECU Information		Y		
PARTNER Electric(B9e)		Instrument panel				Read Fault Code		Y		
PARTNER Electric(B9e)		Instrument panel				Erase Fault Code		Y		
PARTNER Electric(B9e)		Instrument panel				Live Data		Y		
PARTNER Electric(B9e)		Instrument panel				Actuation Test		Y		
PARTNER Electric(B9e)		Passenger compartment air heating resistor				Read ECU Information		Y		
PARTNER Electric(B9e)		Passenger compartment air heating resistor				Read Fault Code		Y		
PARTNER Electric(B9e)		Passenger compartment air heating resistor				Erase Fault Code		Y		
PARTNER Electric(B9e)		Passenger compartment air heating resistor				Live Data		Y		
PARTNER Electric(B9e)		Passenger compartment air heating resistor				Actuation Test		Y		
PARTNER Electric(B9e)		Air conditioning compressor				Read ECU Information		Y		
PARTNER Electric(B9e)		Air conditioning compressor				Read Fault Code		Y		
PARTNER Electric(B9e)		Air conditioning compressor				Erase Fault Code		Y		
PARTNER Electric(B9e)		Air conditioning compressor				Live Data		Y		
PARTNER Electric(B9e)		Air conditioning compressor				Actuation Test		Y		
PARTNER Electric(B9e)		Electric vehicle ECU				Read ECU Information		Y		
PARTNER Electric(B9e)		Electric vehicle ECU				Read Fault Code		Y		
PARTNER Electric(B9e)		Electric vehicle ECU				Erase Fault Code		Y		
PARTNER Electric(B9e)		Electric vehicle ECU				Live Data		Y		
PARTNER Electric(B9e)		Electric vehicle ECU				Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Service module / Independent telematic unit				Read ECU Information		Y		
PARTNER Electric(B9e)		Service module / Independent telematic unit				Read Fault Code		Y		
PARTNER Electric(B9e)		Service module / Independent telematic unit				Erase Fault Code		Y		
PARTNER Electric(B9e)		Service module / Independent telematic unit				Live Data		Y		
PARTNER Electric(B9e)		Service module / Independent telematic unit				Actuation Test		Y		
PARTNER Electric(B9e)		Service module / Independent telematic unit				Special Function	Configuration	Y		
PARTNER Electric(B9e)		Service module / Independent telematic unit				Special Function	Pack repair	Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) with buttons			Read ECU Information		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) with buttons			Read Fault Code		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) with buttons			Erase Fault Code		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) with buttons			Live Data		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) with buttons			Actuation Test		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) with buttons			Special Function	Configuration	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) with buttons			Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) without buttons			Read ECU Information		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) without buttons			Read Fault Code		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) without buttons			Erase Fault Code		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) without buttons			Live Data		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) without buttons			Actuation Test		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) without buttons			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Multifunction screen	Type "A" (segments) without buttons			Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Drive train interface ECU				Read ECU Information		Y		
PARTNER Electric(B9e)		Drive train interface ECU				Read Fault Code		Y		
PARTNER Electric(B9e)		Drive train interface ECU				Erase Fault Code		Y		
PARTNER Electric(B9e)		Drive train interface ECU				Live Data		Y		
PARTNER Electric(B9e)		Drive train interface ECU				Actuation Test		Y		
PARTNER Electric(B9e)		Drive train interface ECU				Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Anti-theft alarm				Read ECU Information		Y		
PARTNER Electric(B9e)		Anti-theft alarm				Read Fault Code		Y		
PARTNER Electric(B9e)		Anti-theft alarm				Erase Fault Code		Y		
PARTNER Electric(B9e)		Anti-theft alarm				Live Data		Y		
PARTNER Electric(B9e)		Anti-theft alarm				Actuation Test		Y		
PARTNER Electric(B9e)		Anti-theft alarm				Special Function	Configuration	Y		
PARTNER Electric(B9e)		Anti-theft alarm				Special Function	Pack repair	Y		
PARTNER Electric(B9e)		Rain and light sensor				Read ECU Information		Y		
PARTNER Electric(B9e)		Rain and light sensor				Read Fault Code		Y		
PARTNER Electric(B9e)		Rain and light sensor				Erase Fault Code		Y		
PARTNER Electric(B9e)		Power steering				Read ECU Information		Y		
PARTNER Electric(B9e)		Power steering				Read Fault Code		Y		
PARTNER Electric(B9e)		Power steering				Erase Fault Code		Y		
PARTNER Electric(B9e)		Power steering				Live Data		Y		
PARTNER Electric(B9e)		Power steering				Actuation Test		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read ECU Information		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read Fault Code		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Erase Fault Code		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Live Data		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Actuation Test		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Pack repair	Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Read ECU Information		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Read Fault Code		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Erase Fault Code		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Live Data		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Actuation Test		Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Special Function	Configuration	Y		
PARTNER Electric(B9e)		Telematic unit (RTx) or audio-navigation	SMEG_PLUS			Special Function	Pack repair	Y		
PARTNER Electric(B9e)		Electric machine management ECU				Read ECU Information		Y		
PARTNER Electric(B9e)		Electric machine management ECU				Read Fault Code		Y		
PARTNER Electric(B9e)		Electric machine management ECU				Erase Fault Code		Y		
PARTNER Electric(B9e)		Electric machine management ECU				Live Data		Y		
PARTNER Electric(B9e)		Electric machine management ECU				Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Battery charge status unit				Read ECU Information		Y		
PARTNER Electric(B9e)		Battery charge status unit				Read Fault Code		Y		
PARTNER Electric(B9e)		Battery charge status unit				Erase Fault Code		Y		
PARTNER Electric(B9e)		Battery charge status unit				Live Data		Y		
PARTNER Electric(B9e)		Battery charge status unit				Special Function	Configuration	Y		
PARTNER Electric(B9e)		Battery charge status unit				Special Function	Pack Repair	Y		
PARTNER Electric(B9e)		Engine relay unit				Read ECU Information		Y		
PARTNER Electric(B9e)		Engine relay unit				Read Fault Code		Y		
PARTNER Electric(B9e)		Engine relay unit				Erase Fault Code		Y		
PARTNER Electric(B9e)		Engine relay unit				Live Data		Y		
PARTNER Electric(B9e)		Engine relay unit				Actuation Test		Y		
PARTNER Electric(B9e)		Controls under the steering wheel				Read ECU Information		Y		
PARTNER Electric(B9e)		Controls under the steering wheel				Read Fault Code		Y		
PARTNER Electric(B9e)		Controls under the steering wheel				Erase Fault Code		Y		
PARTNER Electric(B9e)		Controls under the steering wheel				Live Data		Y		
PARTNER Electric(B9e)		Controls under the steering wheel				Actuation Test		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
PARTNER Electric(B9e)		Controls under the steering wheel				Special Function	Pack Repair	Y		
RCZ		BSI(Built-in Systems Interface)				Read ECU Information		Y		
RCZ		BSI(Built-in Systems Interface)				Read Fault Code		Y		
RCZ		BSI(Built-in Systems Interface)				Erase Fault Code		Y		
RCZ		BSI(Built-in Systems Interface)				Live Data		Y		
RCZ		BSI(Built-in Systems Interface)				Actuation Test		Y		
RCZ		BSI(Built-in Systems Interface)				Special Function	Changing the mode Electrical	Y		
RCZ		BSI(Built-in Systems Interface)				Special Function	Learning	Y		
RCZ		BSI(Built-in Systems Interface)				Special Function	Configuration	Y		
RCZ		BSI(Built-in Systems Interface)				Special Function	Activate Start/Stop function(New Car)	Y		
RCZ		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Live Data		Y		
RCZ		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	MM6LPB	MM6LPB RFJ	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6B	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6B	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6B	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6B	Live Data		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6B	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6B	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6A	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6A	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6A	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6A	Live Data		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6A	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 N6A	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 NFU	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 NFU	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 NFU	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 NFU	Live Data		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 NFU	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	ME745	ME745 NFU	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6A	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6A	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6A	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6A	Live Data		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6A	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6A	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6A	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 NFU	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 NFU	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 NFU	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 NFU	Live Data		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 NFU	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 NFU	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 NFU	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6B	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6B	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6B	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6B	Live Data		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6B	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6B	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	ME749	ME749 N6B	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	MM6KP		Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	MM6KP		Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	MM6KP		Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	MM6KP		Live Data		Y		
RCZ		Engine management ECU	Petrol	MM6KP		Actuation Test		Y		
RCZ		Engine management ECU	Petrol	MM6KP		Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	MM6KP		Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	MED17_4_EUR05	MED17_4_EUR05 5FV	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FV	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FV	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FV	Live Data		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FV	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	MED17_4_EUR05	MED17_4_EUR05 5FN	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FN	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	MED17_4_EUR05	MED17_4_EUR05 5FN	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FN	Live Data		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FN	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FN	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	MED17 4 EUR05	MED17 4 EUR05 5FN	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Live Data		Y		
RCZ		Engine management ECU	Petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	MED17.4.2	14 MED 17.4.2 EURO 5	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17_4_2 EP6C	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6C	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6C	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6C	Live Data		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6C	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6C	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6C	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17_4_2 EP6CM	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6CM	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6CM	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17_4_2 EP6CM	Live Data		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6CM	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6CM	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP6CM	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17_4_2 EP3C	Read ECU Information		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP3C	Read Fault Code		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP3C	Erase Fault Code		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17_4_2 EP3C	Live Data		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP3C	Actuation Test		Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP3C	Special Function	Configuration	Y		
RCZ		Engine management ECU	Petrol	MEV17.4.2	MEV17 4 2 EP3C	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHR	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.4	DCM3.4 RHF	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHE	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.5	DCM3.5 RHH	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	DCM3.5_BR2	RHH-DW10CTED4-163CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	DCM3.5 BR2	RHH-DW10CTED4-163CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX_DV6TED4_90CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HX DV6TED4 90CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HV_DV6TED4B_FAP_90CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HZ_DV6TED4_FAP_110CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC16C3	9HY_DV6ATED4_110CV	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Live Data		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	HDI_SID807	HDI_SID807 9HL	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Live Data		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	EDC17C10	EDC17C10 9HP	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Live Data		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HD	Special Function	Pack Repair	Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Read ECU Information		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Read Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Erase Fault Code		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Live Data		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Actuation Test		Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Special Function	Configuration	Y		
RCZ		Engine management ECU	Diesel	HDI_SID807_BR2	HDI_SID807_BR2 9HG	Special Function	Pack Repair	Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read ECU Information		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Read Fault Code		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Erase Fault Code		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Live Data		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Actuation Test		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Configuration	Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 81			Special Function	Pack Repair	Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read ECU Information		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Read Fault Code		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Erase Fault Code		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Live Data		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Actuation Test		Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Configuration	Y		
RCZ		Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	81 ESP			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read ECU Information		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Read Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Erase Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Live Data		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Actuation Test		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Configuration	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6_AT6_EURO5			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read ECU Information		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Read Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Erase Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Live Data		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Actuation Test		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Configuration	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Configuration	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AT8			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6			Read ECU Information		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6			Read Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6			Erase Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6			Live Data		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6			Actuation Test		Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6			Special Function	Configuration	Y		
RCZ		Automatic gearbox or controlled manual gearbox	BVA_AM6			Special Function	Pack Repair	Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Read ECU Information		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Read Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Erase Fault Code		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Live Data		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Actuation Test		Y		
RCZ		Automatic gearbox or controlled manual gearbox	CFC300P			Special Function	Replacement parts	Y		
RCZ		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Read ECU Information		Y		
RCZ		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Read Fault Code		Y		
RCZ		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Erase Fault Code		Y		
RCZ		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Live Data		Y		
RCZ		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Special Function	Configuration	Y		
RCZ		Air bags and pre-tensioners control unit	SAC_AUTOLIV			Special Function	Pack Repair	Y		
RCZ		Hands-free Kit / Portable Unit	KML			Read ECU Information		Y		
RCZ		Hands-free Kit / Portable Unit	KML			Read Fault Code		Y		
RCZ		Hands-free Kit / Portable Unit	KML			Erase Fault Code		Y		
RCZ		Hands-free Kit / Portable Unit	KML			Live Data		Y		
RCZ		Hands-free Kit / Portable Unit	KML			Actuation Test		Y		
RCZ		Hands-free Kit / Portable Unit	KML			Special Function	Configuration	Y		
RCZ		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read ECU Information		Y		
RCZ		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Read Fault Code		Y		
RCZ		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Erase Fault Code		Y		
RCZ		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Live Data		Y		
RCZ		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Actuation Test		Y		
RCZ		Hands-free Kit / Portable Unit	BOITIER_NOMADE			Special Function	Configuration	Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
RCZ		Power steering				Read ECU Information		Y		
RCZ		Power steering				Read Fault Code		Y		
RCZ		Power steering				Erase Fault Code		Y		
RCZ		Power steering				Live Data		Y		
RCZ		Power steering				Actuation Test		Y		
RCZ		Under inflation detection	DSG_UDS			Read ECU Information		Y		
RCZ		Under inflation detection	DSG_UDS			Read Fault Code		Y		
RCZ		Under inflation detection	DSG_UDS			Erase Fault Code		Y		
RCZ		Under inflation detection	DSG_UDS			Live Data		Y		
RCZ		Under inflation detection	DSG_UDS			Special Function	Pack Reparation	Y		
RCZ		Under inflation detection	DSG			Read ECU Information		Y		
RCZ		Under inflation detection	DSG			Read Fault Code		Y		
RCZ		Under inflation detection	DSG			Erase Fault Code		Y		
RCZ		Under inflation detection	DSG			Live Data		Y		
RCZ		Under inflation detection	DSG			Special Function	Pack Reparation	Y		
RCZ		Dynamic headlamp height adjuster				Read ECU Information		Y		
RCZ		Dynamic headlamp height adjuster				Read Fault Code		Y		
RCZ		Dynamic headlamp height adjuster				Erase Fault Code		Y		
RCZ		Dynamic headlamp height adjuster				Live Data		Y		
RCZ		Dynamic headlamp height adjuster				Actuation Test		Y		
RCZ		Dynamic headlamp height adjuster				Special Function	Configuration	Y		
RCZ		Dynamic headlamp height adjuster				Special Function	Pack Repair	Y		
RCZ		Battery charge status unit	BECB			Read ECU Information		Y		
RCZ		Battery charge status unit	BECB			Read Fault Code		Y		
RCZ		Battery charge status unit	BECB			Erase Fault Code		Y		
RCZ		Battery charge status unit	BECB			Live Data		Y		
RCZ		Battery charge status unit	BECB_GEN2			Read ECU Information		Y		
RCZ		Battery charge status unit	BECB_GEN2			Read Fault Code		Y		
RCZ		Battery charge status unit	BECB_GEN2			Erase Fault Code		Y		
RCZ		Battery charge status unit	BECB_GEN2			Live Data		Y		
RCZ		Battery charge status unit	BECB_GEN2			Special Function	Configuration	Y		
RCZ		Battery charge status unit	BECB_GEN2			Special Function	Pack repair	Y		
RCZ		Lane departure warning system				Read ECU Information		Y		
RCZ		Lane departure warning system				Read Fault Code		Y		
RCZ		Lane departure warning system				Erase Fault Code		Y		
RCZ		Lane departure warning system				Live Data		Y		
RCZ		Lane departure warning system				Actuation Test		Y		
RCZ		Lane departure warning system				Special Function	Configuration	Y		
RCZ		Lane departure warning system				Special Function	Pack repair	Y		
RCZ		Engine relay unit				Read ECU Information		Y		
RCZ		Engine relay unit				Read Fault Code		Y		
RCZ		Engine relay unit				Erase Fault Code		Y		
RCZ		Engine relay unit				Actuation Test		Y		
RCZ		Trailer relay unit				Read ECU Information		Y		
RCZ		Trailer relay unit				Read Fault Code		Y		
RCZ		Trailer relay unit				Erase Fault Code		Y		
RCZ		Multifunction screen	Type "A" (segments) With buttons			Read ECU Information		Y		
RCZ		Multifunction screen	Type "A" (segments) With buttons			Read Fault Code		Y		
RCZ		Multifunction screen	Type "A" (segments) With buttons			Erase Fault Code		Y		
RCZ		Multifunction screen	Type "A" (segments) With buttons			Live Data		Y		
RCZ		Multifunction screen	Type "A" (segments) With buttons			Actuation Test		Y		
RCZ		Multifunction screen	Type "A" (segments) With buttons			Special Function	Configuration	Y		
RCZ		Multifunction screen	Type "A" (segments) With buttons			Special Function	Pack Repair	Y		
RCZ		Multifunction screen	Type "A" (segments) Without button			Read ECU Information		Y		
RCZ		Multifunction screen	Type "A" (segments) Without button			Read Fault Code		Y		
RCZ		Multifunction screen	Type "A" (segments) Without button			Erase Fault Code		Y		
RCZ		Multifunction screen	Type "A" (segments) Without button			Live Data		Y		
RCZ		Multifunction screen	Type "A" (segments) Without button			Actuation Test		Y		
RCZ		Multifunction screen	Type "A" (segments) Without button			Special Function	Configuration	Y		
RCZ		Multifunction screen	Type "A" (segments) Without button			Special Function	Pack Repair	Y		
RCZ		Multifunction screen	Type "C" (dot matrix)			Read ECU Information		Y		
RCZ		Multifunction screen	Type "C" (dot matrix)			Read Fault Code		Y		
RCZ		Multifunction screen	Type "C" (dot matrix)			Erase Fault Code		Y		
RCZ		Multifunction screen	Type "C" (dot matrix)			Live Data		Y		
RCZ		Multifunction screen	Type "C" (dot matrix)			Actuation Test		Y		
RCZ		Multifunction screen	Type "C" (dot matrix)			Special Function	Configuration	Y		
RCZ		Multifunction screen	Type "C" (dot matrix)			Special Function	Pack Repair	Y		
RCZ		Multifunction screen	Type "C colour" (dot matrix)			Read ECU Information		Y		
RCZ		Multifunction screen	Type "C colour" (dot matrix)			Read Fault Code		Y		
RCZ		Multifunction screen	Type "C colour" (dot matrix)			Erase Fault Code		Y		
RCZ		Multifunction screen	Type "C colour" (dot matrix)			Live Data		Y		
RCZ		Multifunction screen	Type "C colour" (dot matrix)			Actuation Test		Y		
RCZ		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Configuration	Y		
RCZ		Multifunction screen	Type "C colour" (dot matrix)			Special Function	Pack Repair	Y		
RCZ		Windscreen wiper				Read ECU Information		Y		
RCZ		Windscreen wiper				Actuation Test		Y		
RCZ		Windscreen wiper				Special Function	Configuration	Y		
RCZ		Parking assistance	Parking aid			Read ECU Information		Y		
RCZ		Parking assistance	Parking aid			Read Fault Code		Y		
RCZ		Parking assistance	Parking aid			Erase Fault Code		Y		
RCZ		Parking assistance	Parking aid			Live Data		Y		
RCZ		Parking assistance	Parking aid			Special Function	Pack repair	Y		
RCZ		Parking assistance	Parking aid			Special Function	Configuration	Y		
RCZ		Air conditioning				Read ECU Information		Y		
RCZ		Air conditioning				Read Fault Code		Y		
RCZ		Air conditioning				Erase Fault Code		Y		
RCZ		Air conditioning				Live Data		Y		
RCZ		Air conditioning				Actuation Test		Y		
RCZ		Controls under the steering wheel				Read ECU Information		Y		
RCZ		Controls under the steering wheel				Read Fault Code		Y		
RCZ		Controls under the steering wheel				Erase Fault Code		Y		
RCZ		Controls under the steering wheel				Live Data		Y		
RCZ		Controls under the steering wheel				Actuation Test		Y		
RCZ		Controls under the steering wheel				Special Function	Pack Repair	Y		
RCZ		Instrument panel				Read ECU Information		Y		
RCZ		Instrument panel				Read Fault Code		Y		
RCZ		Instrument panel				Erase Fault Code		Y		
RCZ		Instrument panel				Live Data		Y		
RCZ		Instrument panel				Actuation Test		Y		
RCZ		Instrument panel				Special Function	Configuration	Y		
RCZ		CD changer / external CD player				Read ECU Information		Y		
RCZ		CD changer / external CD player				Read Fault Code		Y		
RCZ		CD changer / external CD player				Erase Fault Code		Y		
RCZ		CD changer / external CD player				Actuation Test		Y		
RCZ		CD changer / external CD player				Special Function	Configuration	Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG			Special Function	Configuration	Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_NG4			Special Function	Configuration	Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Configuration	Y		
RCZ		Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE			Special Function	Pack repair	Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC			Special Function	Configuration	Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_CEO			Special Function	Configuration	Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Configuration	Y		
RCZ		Telematic unit (RTx) or audio-navigation	RNEG2010			Special Function	Pack repair	Y		
RCZ		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Read ECU Information		Y		
RCZ		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Read Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Erase Fault Code		Y		
RCZ		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Live Data		Y		
RCZ		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Actuation Test		Y		
RCZ		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Special Function	Configuration	Y		
RCZ		Telematic unit (RTx) or audio-navigation	SMEG + audio/navigation			Special Function	Pack repair	Y		
RCZ		Radio amplifier				Read ECU Information		Y		
RCZ		Radio amplifier				Read Fault Code		Y		
RCZ		Radio amplifier				Erase Fault Code		Y		
RCZ		Radio amplifier				Actuation Test		Y		
RCZ		Radio amplifier				Special Function	Configuration	Y		
RCZ		Radio amplifier				Special Function	Pack Repair	Y		
RCZ		Radio	RD4			Read ECU Information		Y		
RCZ		Radio	RD4			Read Fault Code		Y		
RCZ		Radio	RD4			Erase Fault Code		Y		
RCZ		Radio	RD4			Live Data		Y		
RCZ		Radio	RD4			Actuation Test		Y		
RCZ		Radio	RD4			Special Function	Configuration	Y		
RCZ		Radio	RD4			Special Function	Spare part	Y		
RCZ		Radio	RD45			Read ECU Information		Y		
RCZ		Radio	RD45			Read Fault Code		Y		
RCZ		Radio	RD45			Erase Fault Code		Y		
RCZ		Radio	RD45			Live Data		Y		
RCZ		Radio	RD45			Actuation Test		Y		
RCZ		Radio	RD45			Special Function	Configuration	Y		
RCZ		Radio	RD45			Special Function	Pack Repair	Y		
RCZ		Seat driver position memory module				Read ECU Information		Y		
RCZ		Seat driver position memory module				Read Fault Code		Y		
RCZ		Seat driver position memory module				Erase Fault Code		Y		
RCZ		Seat driver position memory module				Live Data		Y		
RCZ		Seat driver position memory module				Actuation Test		Y		
RCZ		Seat driver position memory module				Special Function	Configuration	Y		
RCZ		Seat driver position memory module				Special Function	Pack repair	Y		
RCZ		Anti-theft alarm	Alarm with anti-lift module			Read ECU Information		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift module			Read Fault Code		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift module			Erase Fault Code		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift module			Live Data		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift module			Actuation Test		Y		
RCZ		Anti-theft alarm	Alarm with anti-lift module			Special Function	Configuration	Y		
RCZ		Anti-theft alarm	Alarm with anti-lift module			Special Function	Pack repair	Y		
RCZ		Seat passenger position memory module				Read ECU Information		Y		
RCZ		Seat passenger position memory module				Read Fault Code		Y		
RCZ		Seat passenger position memory module				Erase Fault Code		Y		
RCZ		Seat passenger position memory module				Live Data		Y		
RCZ		Seat passenger position memory module				Actuation Test		Y		
RCZ		Seat passenger position memory module				Special Function	Configuration	Y		
RCZ		Seat passenger position memory module				Special Function	Pack repair	Y		
RCZ		Driver's door module	Driver's door module			Read ECU Information		Y		
RCZ		Driver's door module	Driver's door module			Read Fault Code		Y		
RCZ		Driver's door module	Driver's door module			Erase Fault Code		Y		
RCZ		Driver's door module	Driver's door module			Live Data		Y		
RCZ		Driver's door module	Driver's door module			Actuation Test		Y		
RCZ		Sunroof				Read ECU Information		Y		
RCZ		Sunroof				Read Fault Code		Y		
RCZ		Sunroof				Erase Fault Code		Y		
RCZ		Sunroof				Live Data		Y		
RCZ		Sunroof				Actuation Test		Y		
RCZ		Sunroof				Special Function	Pack repair	Y		
RCZ		Moving panel deflector				Read ECU Information		Y		
RCZ		Moving panel deflector				Read Fault Code		Y		
RCZ		Moving panel deflector				Erase Fault Code		Y		
RCZ		Moving panel deflector				Live Data		Y		
RCZ		Moving panel deflector				Actuation Test		Y		
RCZ		Moving panel deflector				Special Function	Pack repair	Y		
RCZ		Folding roof				Read ECU Information		Y		
RCZ		Folding roof				Read Fault Code		Y		
RCZ		Folding roof				Erase Fault Code		Y		
RCZ		Folding roof				Live Data		Y		
RCZ		Folding roof				Actuation Test		Y		
RCZ		Folding roof				Special Function	Pack Repair	Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Read ECU Information		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Read Fault Code		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Erase Fault Code		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Live Data		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Actuation Test		Y		
RCZ		Service module / Independent telematic unit	MD_SERV			Special Function	Configuration	Y		
RCZ		Service module / Independent telematic unit	BTA			Read ECU Information		Y		
RCZ		Service module / Independent telematic unit	BTA			Read Fault Code		Y		
RCZ		Service module / Independent telematic unit	BTA			Erase Fault Code		Y		
RCZ		Service module / Independent telematic unit	BTA			Live Data		Y		
RCZ		Service module / Independent telematic unit	BTA			Actuation Test		Y		
RCZ		Service module / Independent telematic unit	BTA			Special Function	Configuration	Y		
RCZ		Rain and light sensor				Read ECU Information		Y		
RCZ		Rain and light sensor				Read Fault Code		Y		
RCZ		Rain and light sensor				Erase Fault Code		Y		
RCZ		Pedestrian impact detection unit				Read ECU Information		Y		
RCZ		Pedestrian impact detection unit				Read Fault Code		Y		
RCZ		Pedestrian impact detection unit				Erase Fault Code		Y		
RCZ		Pedestrian impact detection unit				Live Data		Y		
RCZ		Seat belt not fastened warning lights unit				Read ECU Information		Y		
RCZ		Seat belt not fastened warning lights unit				Actuation Test		Y		
RCZ		Control panel dot matrix display				Read ECU Information		Y		
RCZ		Control panel dot matrix display				Read Fault Code		Y		
RCZ		Control panel dot matrix display				Erase Fault Code		Y		
RCZ		Control panel dot matrix display				Live Data		Y		
RCZ		Control panel dot matrix display				Actuation Test		Y		
RCZ		Control panel dot matrix display				Special Function	Configuration	Y		
RCZ		Diesel additive pump	POMPE_MUX_MGI			Read ECU Information		Y		
RCZ		Diesel additive pump	POMPE_MUX_MGI			Read Fault Code		Y		
RCZ		Diesel additive pump	POMPE_MUX_MGI			Erase Fault Code		Y		

Diagnostic List Peugeot_V10.50

Note: New functions are marked in red color compared to the previous version.

Models	Year classification	System	Subsystem or system type (YES stands for China, NO stands for other areas)	Subsystem (YES stands for China, NO stands for other area)	Subsystem or system type	Function type	Special function submenu	Add (Y/N)	Verification(Y/N)	Remarks
RCZ		Diesel additive pump	POMPE MUX MGI			Live Data		Y		
RCZ		Diesel additive pump	POMPE MUX MGI			Actuation Test		Y		
RCZ		Diesel additive pump	POMPE MUX MGI			Special Function	Configuration	Y		
RCZ		Diesel additive pump	POMPE MUX MGI			Special Function	Pack repair	Y		
RCZ		Diesel additive pump	POMPE_MUX_TI			Read ECU Information		Y		
RCZ		Diesel additive pump	POMPE MUX TI			Read Fault Code		Y		
RCZ		Diesel additive pump	POMPE MUX TI			Erase Fault Code		Y		
RCZ		Diesel additive pump	POMPE MUX TI			Live Data		Y		
RCZ		Diesel additive pump	POMPE_MUX_TI			Actuation Test		Y		
RCZ		Diesel additive pump	POMPE MUX TI			Special Function	Configuration	Y		
RCZ		High frequency receiver				Read ECU Information		Y		
RCZ		High frequency receiver				Read Fault Code		Y		
RCZ		High frequency receiver				Erase Fault Code		Y		
RCZ		High frequency receiver				Live Data		Y		