- 1.  $\sqrt{\ }$ : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu			Function									
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active	Special Function	Can Diag Support Monitor				
Test by System	ENGINE	√	√	√	√	√	√	√				
Test by System	TRANSMISSION	√	√	√	√	√	√	√				
Test by System	ABS	√	√	√	√	√	$\checkmark$	$\checkmark$				
Test by System	AIR BAG	√	√	√	√	_	√	√				
Test by System	BCM	√	√	√	√	√	√	√				
Test by System	METER/M&A	√	√	√	√	_	_	√				
Test by System	HVAC	√	√	√	√	√	$\checkmark$	$\checkmark$				
Test by System	ICC/ADAS	√	√	√	√	√	√	√				
Test by System	MULTI AV	√	√	√	√	√	√	√				
Test by System	EHS/PKB	√	√	√	√	_	_	-				
Test by System	MOTOR CONTROL	√	√	√	√	_	-	-				
Test by System	EPS/DAST 3	√	√	√	√	_	-	√				
Test by System	IPDM E/R	√	√	√	√	√	-	-				
Test by System	AIR PRESSURE MONITOR	√	√	√	√	√	√	√				
Test by System	BAC	√	√	√	√	_	_	_				
Test by System	SUB METER	_	√	√	√	_	_	_				
Test by System	CONVERTIBLE ROOF	√	√	√	√	√	√	√				
Test by System	HEAD LAMP LEVELIZER	√	√	√	√	√	√	√				
Test by System	e-4WD	√	√	√	√	√	_	_				
Test by System	LASER/RADAR	√	√	√	√	_	√	$\checkmark$				
Test by System	INTELLIGENT KEY	√	√	√	√	√	$\checkmark$	$\checkmark$				
Test by System	DIU	_	√	√	√	_	_	-				
Test by System	AUTO SLIDE DOOR	√	√	√	√	√	√	-				
Test by System	PRECRASH SEATBELT	√	√	√	√	_	√	_				
Test by System	AUTO DRIVE POS.	√	√	√	√	√	√	√				
Test by System	ALL MODE AWD/4WD	√	√	√	√	√	√ √	-				
Test by System	DIFF LOCK	√	√	√	√	_	_	_				
Test by System	4WAS (MAIN) /RAS/HICAS	√	√	√	√	√	-	_				
Test by System	SONAR	√	√	√	√	√	√	_				

- 1.  $\sqrt{\ }$ : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu			Function									
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active	Special Function	Can Diag Support Monitor				
Test by System	LANE CAMERA	√	√	√	√	√	√	√				
Test by System	ADAPTIVE LIGHT	√	√	√	√	√	√	√				
Test by System	AUTO SLIDE DOOR RIGHT	√	√	√	√	√	_	_				
Test by System	CAN GATEWAY	√	√	√	√	_	_	_				
Test by System	SHIFT	√	√	√	√	_	_	_				
Test by System	EV/HEV	√	√	√	√	√	_	-				
Test by System	POP UP HOOD	√	√	√	√	_	_	_				
Test by System	AUTO BACK DOOR	√	√	√	√	_	√	_				
Test by System	Diag Data Recorder	_	√	√	_	_	_	_				
Test by System	4WAS (FRONT)	√	√	√	√	√	√	_				
Test by System	E-SUS	√	√	√	√	√	√	_				
Test by System	ACCELE PEDAL ACT	√	√	√	√	√	_	_				
Test by System	HV BATTERY	√	√	√	√	_	_	_				
Test by System	TOTAL ILLUM C/U	√	√	√	√	√	√	_				
Test by System	OCCUPANT DETECTION	_	_	_	√	_	_	_				
Test by System	SmFOB	√	√	√	√	_	_	_				
Test by System	BRAKE	√	√	√	√	_	_	_				
Test by System	SIDE RADAR LEFT	√	√	√	√	√	√	_				
Test by System	ANC	√	√	√	√	_	_	_				
Test by System	MULTI DISPLAY	_	√	√	√	√	-	_				
Test by System	SIDE RADAR RIGHT	√	√	√	√	√	√	_				
Test by System	ADCM	√	√	√	√	_	-	_				
Test by System	CHARGER/PD MODULE	√	√	√	√	_	-	_				
est by System	PTC HEATER	√	√	√	√	√	√	-				
Test by System	TELEMATICS	√	√	√	√	_	√	_				
Test by System	HAS	√	√	√	√	-	-	-				
est by System	EMCM	√	√	√	√	-	-	-				
est by System	SVT	√	√	√	√	_	√	-				
est by System	BSW/BUZZER	√	√	√	√	_	_	√				

- 1.  $\sqrt{\ }$ : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu			Function								
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active	Special Function	Can Diag Support Monitor			
Test by System	AVM	√	√	√	√	-	√	-			
Test by System	CHASSIS CONTROL	√	√	√	√	_	_	_			
Test by System	DAST 1	√	√	√	√	_	_	-			
Test by System	DAST 2	√	√	√	√	_	_	-			
Test by System	HIGH BEAM ASSIST	√	√	√	√	_	_	_			
Test by System	CIU	√	√	√	√	√	√	_			
Test by System	MM CONN	√	√	√	√	_	√	-			
Test by System	ICC/ADAS 2	√	√	√	√	_	_	$\checkmark$			
Test by System	Lane camera 2	√	√	√	√	-	-	-			
Test by System	CAN GATEWAY3	√	√	√	√	_	_	-			
Test by System	(TBD) GEN-INV	√	√	√	√	_	_	_			
est by System	CAN GATEWAY2	√	√	√	√	-	-	_			
est by System	Vehicle data transmitter	√	√	√	√	-	-	_			
est by System	Cluster	√	√	√	√	√	√	-			
est by System	NATS IMMU	√	√	√	-	-	-	_			
est by System	SMART ENTRANCE	-	√	√	√	√	√	_			
est by System	AIR LEVELIZER	√	√	√	√	√	√	-			
est by System	REARVIEW CAMERA	√	-	_	√	-	√	-			
est by System	S/BLIND CAMERA	√	_	-	√	-	√	_			
est by System	ACTIVE ENG MOUNT	√	√	√	√	√		-			
est by System	ACTIVE SUS	_	√	√	√	-		-			
est by System	ASCD	-	√	√	√	-	-	-			
est by System	HANDS FREE MODULE	√	√	√	√			-			
est by System	DISTANCE CONTROL	-	√	√	√	√	-	-			
est by System	MOTOR ASSIST	√	√	√	√	-	-	_			
est by System	IVMS	_	√	√	√	√	_	_			
est by System	TCS	_	√	<b>√</b>	<b>√</b>	√	_	_			
est by System	CHA	√	√ √	√ √	<del>\</del> √	√	√	_			
est by System	VSP	1	1 1	√ √	1 1		_	_			

- 1.  $\checkmark$ : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu		Function								
Models	System Type	ECU Info	Read Codes	Erase Codes	Live Data	Active	Special Function	Can Diag Support Monitor		
Test by System	FSCM	√	√	√	√	_	_	_		
Test by System	PMAS	√	√	√	√	_	-	_		
Test by System	RADIO	√	√	√	√	√	√	_		
Test by System	Left front door control unit	√	√	√	√	-	-	_		
Test by System	Right front door control unit	√	√	√	√	_	-	_		
Test by System	Siren control unit	√	√	√	√	_	_	_		
Test by System	Alarm siren	√	√	√	√	_	-	_		
Test by System	Passenger seat control unit	√	√	√	√	_	_	_		
Test by System	Intelligent battery sensor	√	√	√	√	-	_	_		
Test by System	Upper control panel cont unit	√	√	√	√	-	-	_		
Test by System	EC mirror compass	√	√	√	√	-	-	_		
Test by System	Universal garage door opener	√	√	√	√	-	-	-		
Test by System	Light&rain sensor	√	√	√	√	_	_	_		
Test by System	Overhead control panel unit	√	√	√	√	_	_	_		
Test by System	Electronic ign switch cont unit	√	√	√	√	_	_	_		
Test by System	Trailer recognition control unit	√	√	√	√	-	-	_		
Test by System	Occupant classification unit	√	√	√	√	-		_		
Test by System	ICC sensor	√	√	√	√	-	-	_		
Test by System	Parking assist	√	√	√	√	-	-	_		
Test by System	Steering column cont module	√	√	√	√	-	-	_		
Test by System	Steering wheeling switch pad	√	√	√	√	-	-	-		
Test by System	Radar sensor	√	√	√	√	-	-	-		
Test by System	LED H/L control module RH	√	√	√	√	_	-	-		
Test by System	LED H/L control module LH	√	√	√	√	_	-	-		
Test by System	Side radar RH	√	√	√	√	-	-	√		
Test by System	Side radar LH	√	√	√	√	_	_	_		

- 1.  $\checkmark$ : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu		Function								
Models	System Type	ECU Info	Read Codes	Erase Codes		Active	Special Function	Can Diag Support Monitor		
Test by System	Front camera unit	√	√	√	√	_	_	_		
Test by System	PT cont module	√	√	√	√	_	_	_		
Test by System	H/L control module RH	√	√	√	√	_	-	-		
Test by System	H/L control module LH	<b>√</b>	<b>√</b>	√	<b>√</b>	_	_	_		
Test by System	(TBD)Audio Amplier Unit	√	√	√	√	_	_	_		