Diagnostic List Suzuki_v8.62

Remark:

- 1. \checkmark : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu		Function							
Enter Type	System	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function		
Test by System	Engine/ Powertrain	√	√	√	√	√	\checkmark		
Test by System	CNG/LPG	√	√	√	√	√	-		
Test by System	TCM	√	√	√	√	√	\checkmark		
Test by System	Engine Auto Stop and Start	√	√	√	√	√	√		
Test by System	ABS/ESP	√	√	√		√	√ 		
Test by System	Power Steering	√	√ .	√	√	√	√		
Test by System	Airbag	√	√	√	√	√	√ ,		
Test by System	AC	√	√	√	√	√	√ ,		
Test by System	AC2	√	√ ,	√	√	√	√ ,		
Test by System	BCM OCM	√ √	√ √	√ √	√ /	√ √	√ /		
Test by System	4WD	√ √		-	√ ,	<u> </u>	- √ -		
Test by System		_	√ ,	√ .	√	√ .			
Test by System	Immobi and/or Keyless System	√	√	√	√	√	√		
Test by System	Keyless Start	√	√	√	√	√	=		
Test by System	EMCD	√	√	√	√	√	-		
Test by System	EV_MOTOR	√	√	√	√	√	-		
Test by System	EV_AC	√	√	√	√	√	-		
Test by System	TPMS	√	√	√	√	√	\checkmark		
Test by System	I-KEY	√	√	√	√	√	√		
Test by System	IPDM E/R	√	√	√	√	√	=		
Test by System	OCMCombination Meter / Meter/M&A	√	√	√	√	√	-		
Test by System	Auto Slide Door (Left)	√	√	√	√	√	=		
Test by System	Auto Slide Door (Right)	√	√	√	√	√	-		
Test by System	Headlight Auto Leveling	√	√	√	√	√	\checkmark		
Test by System	Lighting and Turn Signal	√	√	√	√	√	_		
Test by System	Motor Assist AT	√	√	√	√	√	-		
Test by System	AFS	√	√	√	√	√	-		
Test by System	Speed Convert Controller	√	√	√	√	√	<i>√</i>		

Diagnostic List Suzuki_v8.62

Remark:

- 1. \checkmark : means that the system has this function
- 2. -: means that the system does not have this function
- 3. compared with the last version, the new added function is marked in red color.

Vehicle menu		Function							
Enter Type	System	ECU Info	Read Codes	Erase Codes	Live Data	Active Test	Special Function		
Test by System	ACCM	√	√	√	√	√	-		
Test by System	DIFFLOCK	√	√	√	√	√	_		
Test by System	Radar Brake Support / Adaptive Cruise Control	√	√	√	√	√	√		
Test by System	Dual Camera Brake Support	√	√	√	√	√	√		
Test by System	AVM	√	√	√	√	√	√		
Test by System	ADAS	√	√	√	√	√	=		
Test by System	Immobilizer Engine/ Powertrain	√	√	√	√	√	√		
Test by System	Immobilizer BCM	√	√	√	√	√	√		
Test by System	Immobilizer I-KEY	√	√	√	√	√	√		
Test by System	Auxiliary Power	√	√	√	√	√	=		
Test by System	ISG	√	√	√	√	√	=		
Test by System	Fr-Camera	√	√	√	√	√	=		
Test by System	Sonar	√	√	√	√	√	-		
Test by System	Emergency Road Assistance based on Global Navigation Satellite / Emergency Call	√	√	√	√	√	√		
Test by System	ADM	√	√	√	√	√	√		
Test by System	Gateway	√	√	√	√	√	√		
Test by System	Hybrid Control Unit	√	√	√	√	√	√		
Test by System	HV Battery Management	√	√	√	√	√	√		
Test by System	Inverter	√	√	√	√	√	√		
Test by System	AVAS	√	√	√	√	√	-		