- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

			Function										
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)				
Jinbei Auto	Jinbei Engine system	Delphi MT20U2	√	√	√	√	√	-	Read history fault code; system status; Crankshaft position sensor target gear error learning				
Jinbei Auto	Jinbei Engine system	MM Single-point electronic control system	-	√	√	√	-	-	Execute component control				
Jinbei Auto	Jinbei Engine system	MM Multiple-point electronic control system electronic injection system	√	√	√	√	√	-	Adaptive value parameter adjustment				
Jinbei Auto	Jinbei Engine system	Delphi electronic control system	√	√	√	√	√	-	System status				
Jinbei Auto	Jinbei Engine system	ITMS 6F engine	√	√	√	√	√	-	_				
Jinbei Auto	Jinbei Engine system	Toyota electronic injection system	-	√	√	√	-	-	_				
Jinbei Auto	Jinbei Engine system	Delphi (4G24) electronic control system	√	√	√	-	√	-	Read dynamic data stream; system status				
Jinbei Auto	Jinbei Engine system	Delphi Euro III electronic control system	√	√	√	-	√	-	Read dynamic data stream				
Jinbei Auto	Jinbei Engine system	Mitsubishi engine system (SY6480BC)(U.Sspec engine)	√	√	√	√	=	-	Execute component control				
Jinbei Auto	Jinbei Engine system	Mitsubishi engine system (SY6480BC)(Asian engine)	√	√	√	√	-	-	Execute component control				
Jinbei Auto	Jinbei Engine system	Marelli 491 engine	√	√	√	-	√	-	Read dynamic data stream; system status				
Jinbei Auto	Jinbei Engine system	Delphi EOBD engine system	-	√	√	-	√	-	Read history fault code; Read dynamic data stream				
Jinbei Auto	Jinbei Engine system	Delphi EOBD engine system II	-	√	√	√	√	-	Read history fault code; system status; Crankshaft position sensor target gear error learning				
Jinbei Auto	Jinbei Engine system	Delphi common rail diesel system	√	√	√	√	√	-	Programming VIN code				
Jinbei Auto	Jinbei Engine system	Delphi MT80 engine system	√	√	√	√	√	-	-				
Jinbei Auto	Jinbei Engine system	UMC M780(4RB2 engine)	√	√	√	√	√	√	-				
Jinbei Auto	Jinbei Engine system	491Q Delphi Euro III system	√	√	√	√	√	-	System status				
Jinbei Auto	Jinbei Engine system	3TZ engine Delphi MT22.1 system	√	√	√	√	√	√	Write VIN code; Crankshaft position sensor target gear error learning				
Jinbei Auto	S50	4G63\4G69 Delphi MT22.1 system	√	√	√	√	√	√	Write VIN code, Crankshaft position sensor target gear error learning				
Jinbei Auto	S50	Delphi 7.8ABS	√	√	√	√	√	-	Bleeding mode				
Jinbei Auto	ABS	Ruichi electronic control system	-	√	√	√	-	-	-				
Jinbei Auto	ABS	SABS brake system	-	√	√	√	√	-	-				

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

								Functio	n
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)
Jinbei Auto	ABS	BOSCH ABS8	√	√	√	√	√	-	_
Jinbei Auto	ABS	2RZ-E ABS(Toyota ABS)	-	√	√	√	√	-	-
Jinbei Auto	ABS	Delphi ABS	-	√	√	√	√	-	Exhaust, self exhaust
Jinbei Auto	Sealion H2 DK4R engine BOS	SCH EDC16 engine	√	√	√	√	√	√	_
Jinbei Auto	Sealion H2 BOSCH ABS8 syste	em	√	√	√	√	√	√	Exhaust function
Jinbei Auto	Airbag	Autoliv airbag	√	√	√	-	-	-	ECU module lock
Jinbei Auto	Airbag	Sealion H2L Bosch Airbag system	√	√	√	√	-	_	Programming function; 2 airbag fast matching
Jinbei Auto	Airbag	Jinheng Four-channel airbag	√	√	√	√	-	-	Read history fault code
Grace Series	Engine system	Delphi MT20U2	√	√	√	√	√	-	Read history fault code; system status; Crankshaft position sensor target gear error learning
Grace Series	Engine system	Delphi Engine system	-	√	√	-	-	-	Read dynamic data stream
Grace Series	Engine system	495 Delphi system	√	√	√	√	√	-	Read system status
Grace Series	Engine system	4G20D4Delphi EOBD system	√	√	√	-	√	-	Read history fault code; Read dynamic data stream; Read state data stream; Off-line detection
Grace Series	Engine system	4G22D4Delphi EOBD system	√	√	√	-	√	-	Read history fault code; Read dynamic data stream; Read state data stream; Off-line detection
Grace Series	Engine system	491Q Delphi system	√	√	√	√	√	-	Read system status
Grace Series	Engine system	Delphi Engine system	√	√	√	√	√	-	Read system status
Grace Series	Engine system	Toyota electronic control system	-	√	√	√	√	-	system status
Grace Series	Engine system	Toyota engine 3RZ EOBD system	-	√	√	√	√	-	Read history fault code
Grace Series	Engine system	Delphi EOBD engine system	√	√	√	-	√	-	Read history fault code; Read dynamic data stream; Read state data stream; Off-line detection
Grace Series	Engine system	UMC EOBD engine system	√	√	√	√	√	-	system status
Grace Series	Engine system	Delphi MT80 engine system	√	√	√	√	√	-	-
Grace Series	Engine system	DOSCH EDC16 diesel engine	√	√	√	√	√	√	-
Grace Series	Engine system	Toyota TR engine system	√	√	√	√	√	-	Read history fault code

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

			Function								
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)		
Grace Series	Engine system	Toyota electronic injection system	-	√	√	√	-	-	-		
Grace Series	Airbag system	Jinheng airbag (Continental ECU)	√	√	√	√	-	-	-		
Grace Series	Airbag system	Siemens single airbag+double pretension seat belt system (non-TR engine)	√	√	√	√	_	-	-		
Grace Series	Airbag system	Siemens double airbag+double pretension seat belt system (non-TR engine)	√	√	√	√	_	-	-		
Grace Series	Airbag system	Siemens single airbag+double pretension seat belt system (TR engine)	√	√	√	√	-	-	-		
Grace Series	Airbag system	Siemens double airbag+double pretension seat belt system (TR engine)	√	√	√	√	_	-	-		
Grace Series	ABS	SABS brake system	-	√	√	√	√	-	_		
Grace Series	ABS	Toyota anti-lock braking	-	√	√	√	√	-	_		
Grace Series	ABS	BOSCH ABS8	√	√	√	√	√	-	_		
Grace Series	ABS	Toyota ABS (flash code)	-	√	√	-	_	-	-		
Jinbei Others	Engine system	ITMS 6F engine	√	√	√	√	√	-	-		
Jinbei Others	Engine system	JM491Q-ME	-	√	√	√	√	-	-		
Jinbei Others	Engine system	MM Multiple-point electronic control system electronic injection system	√	√	√	√	√	-	-		
Jinbei Others	Engine system	Delphi electronic injection system	-	√	√	√	√	-	Read anti-theft status; Read state data stream		
Jinbei Others	Engine system	Delphi Euro-II system	-	√	√	√	√	-	-		
Jinbei Others	Engine system	Delphi Euro-III system	-	√	√	√	√	-	-		
Jinbei Others	Engine system	Delphi Euro III E_OBD	-	√	√	√	√	-	-		
Jinbei Others	Engine system	Delphi electronic injection system 4G24-1	-	√	√	√	√	-	Read state data stream		
Jinbei Others	Engine system	Delphi electronic injection system 4G24-2	-	√	√	√	√	-	_		
Jinbei Others	Engine system	Delphi electronic injection system 4G24-3	√	√	√	√	√	-	System status		
Jinbei Others	Engine system	Mitsubishi engine system (SY6480BC)(U.Sspec engine)	√	√	√	√	-	-	Execute component control		
Jinbei Others	Engine system	Mitsubishi engine system (SY6480BC)(Asian engine)	√	√	√	√	=	-	Execute component control		

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		System						Functio	n
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)
Jinbei Others	Engine system	Toyota electronic injection system	-	√	√	√	-	-	_
Jinbei Others	Engine system	Marelli single-point electronic injection system	-	√	√	√	-	-	Execute component control
Jinbei Others	Engine system	Jinbei H2anti-theft system	√	√	√	√	-	-	Programming function; Delete key
Jinbei Others	Engine system Jinbei Sealion anti-theft system		-	√	√	√	-	-	Matching function
ZHONGHUA 4G63	MM multi-point engine system		√	√	√	√	√	-	Adaptive parameter adjustment
ZHONGHUA 4G63	Mitsubishi engine system		√	√	√	√	-	-	Execute component control
ZHONGHUA 4G63	Delphi (Euro 3) system		√	√	√	√	√	-	system status
ZHONGHUA 4G63	Delphi EOBD engine system		√	√	√	-	√	√	Read history fault code; Read dynamic data stream; Read state data stream
ZHONGHUA 4G63	Automatic transmission syst	tem	√	√	√	√	-	-	Execute component control
ZHONGHUA 4G63	Mitsubishi automatic transm	nission system (MIVEC 2.0L Euro IV)	√	√	√	√	-	-	Execute component control
ZHONGHUA 4G63	ABS		√	-	=	√	√	-	Read chassis area DTC; Read the whole area DTC; Clear chassis area DTC; Clear the whole area DTC
ZHONGHUA 4G63	BOSCH ABS8		√	√	√	√	√	-	-
ZHONGHUA 4G63	ABS (ISO)		-	√	√	-	-	-	Read dynamic data stream; Read vehicle computer model
ZHONGHUA 4G63	Passive safety system (Pret	tension)	√	√	√	-	-	-	-
ZHONGHUA 4G63	Passive safety system (Pret	tension+Front airbag)	√	√	√	-	-	-	_
ZHONGHUA 4G63	Autoliv airbag		√	√	√	√	=	-	ECU module lock
ZHONGHUA 4G63	Jinheng airbag system		√	=	√	=	=	-	Read active DTC; Read history fault code; Read intermittent DTC
ZHONGHUA 4G63	Jinheng airbag (AUTONET)-4 loop		√	√	√	√	-	-	-
ZHONGHUA 4G63	Jinheng airbag (AUTONET)-6 loop		√	√	√	√	-	-	_
ZHONGHUA 4G63	Delphi anti-theft system		-	√	√	√	-	-	Matching function
ZHONGHUA 4G63	Mitsubishi anti-theft system		√	√	√	√	-	-	Special function
ZHONGHUA 4G63	Central control system	√	√	√	√	√	-	_	

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		System						Function	n
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)
ZHONGHUA 4G63	MM multi-point engine syste	em 2	-	√	√	√	√	-	Adaptive parameter adjustment
ZHONGHUA 4G63	UAES M7 electronic injection	on system	√	√	√	√	√	-	System status
ZHONGHUA 4G63	elphi MT80 engine		√	√	√	-	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning
ZHONGHUA 4G63	MC ME797		√	√	√	√	√	-	System status
ZHONGHUA 4G63	UAES M7 electronic injection	ES M7 electronic injection system		√	√	√	-	-	-
ZHONGHUA 4G63	UMC EOBD engine system	C EOBD engine system		√	√	√	-	-	_
ZHONGHUA Junjie	ZHONGHUA 4G63	MM multi-point engine system	√	√	√	√	√	-	Adaptive parameter adjustment
ZHONGHUA Junjie	ZHONGHUA 4G63	Mitsubishi engine system	√	√	√	√	=	-	Execute component control
ZHONGHUA Junjie	ZHONGHUA 4G63	Delphi (Euro 3) system	√	√	√	√	√	-	System status
ZHONGHUA Junjie	ZHONGHUA 4G63	Delphi EOBD engine system	√	√	√	-	√	√	Read history fault code; Read dynamic data stream; Read state data stream
ZHONGHUA Junjie	ZHONGHUA 4G63	Automatic transmission system	√	√	√	√	-	-	Execute component control
ZHONGHUA Junjie	ZHONGHUA 4G63	Mitsubishi automatic transmission system (MIVEC 2.OL Euro IV)	√	√	√	√	=	-	Execute component control
ZHONGHUA Junjie	ZHONGHUA 4G63	ABS	√	=	-	√	√	-	Read chassis area DTC; Read the whole area DTC; Clear chassis area DTC; Clear the whole area DTC
ZHONGHUA Junjie	ZHONGHUA 4G63	BOSCH ABS8	√	√	√	√	√	-	_
ZHONGHUA Junjie	ZHONGHUA 4G63	ABS (ISO)	-	√	√	-	-	-	Read dynamic data stream; Read vehicle computer model
ZHONGHUA Junjie	ZHONGHUA 4G63	Passive safety system (Pretension)	√	√	√	=	=	-	_
ZHONGHUA Junjie	ZHONGHUA 4G63	Passive safety system (Pretension+Front airbag)	√	√	√	=	=	-	_
ZHONGHUA Junjie	ZHONGHUA 4G63	Autoliv airbag	√	√	√	√	-	-	ECU module lock
ZHONGHUA Junjie	ZHONGHUA 4G63	Jinheng airbag system	√	-	√	-	=	-	Read active DTC; Read history fault code; Read intermittent DTC
ZHONGHUA Junjie	ZHONGHUA 4G63	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	=	-	_
ZHONGHUA Junjie	ZHONGHUA 4G63	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	=	-	_
ZHONGHUA Junjie	ZHONGHUA 4G63	Delphi anti-theft system	-	√	√	√	-	-	Matching function

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		Systom						Function	n
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)
ZHONGHUA Junjie	ZHONGHUA 4G63	Mitsubishi anti-theft system	√	√	√	√	-	-	Special function
ZHONGHUA Junjie	ZHONGHUA 4G63	Central control system	√	√	√	√	√	-	_
ZHONGHUA Junjie	ZHONGHUA 4G63	MM multi-point engine system 2	-	√	√	√	√	-	Adaptive parameter adjustment
ZHONGHUA Junjie	ZHONGHUA 4G63	UAES M7 electronic injection system	√	√	√	√	√	-	System status
ZHONGHUA Junjie	ZHONGHUA 4G63	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning
ZHONGHUA Junjie	ZHONGHUA 4G63	UMC ME797	√	√	√	√	√	-	system status
ZHONGHUA Junjie	ZHONGHUA 4G63	UAES M7 electronic injection system	-	√	√	√	-	-	_
ZHONGHUA Junjie	ZHONGHUA 4G63	UMC EOBD engine system	-	√	√	√	-	-	_
ZHONGHUA Junjie	ZHONGHUA 4G64	MM multi-point engine system	√	√	√	√	√	-	Adaptive parameter adjustment
ZHONGHUA Junjie	ZHONGHUA 4G64	Delphi (Euro 3) system	√	√	√	√	√	-	System status
ZHONGHUA Junjie	ZHONGHUA 4G64	Delphi EOBD engine system	√	√	√	-	√	-	Read history fault code; Read dynamic data stream; Read state data stream
ZHONGHUA Junjie	ZHONGHUA 4G64	UMC M7971 system (1.8L/2.0L)	√	√	√	√	√	-	_
ZHONGHUA Junjie	ZHONGHUA 4G64	Mitsubishi engine system	√	√	√	√	_	-	Execute component control
ZHONGHUA Junjie	ZHONGHUA 4G64	Automatic transmission system	√	√	√	√	-	-	Execute component control
ZHONGHUA Junjie	ZHONGHUA 4G64	ABS	√	-	-	√	√	-	Read chassis area DTC; Read the whole area DTC; Clear chassis area DTC; Clear the whole area DTC; Read state data stream
ZHONGHUA Junjie	ZHONGHUA 4G64	ABS (ISO)	-	√	√	-	_	-	Read dynamic data stream; Read vehicle computer model
ZHONGHUA Junjie	ZHONGHUA 4G64	Passive safety system (Pretension)	-	√	√	-	√	-	-
ZHONGHUA Junjie	ZHONGHUA 4G64	Passive safety system (Pretension+Front airbag)	√	√	√	-	_	-	_
ZHONGHUA Junjie	ZHONGHUA 4G64	Autoliv airbag	√	√	√	√	-	-	ECU module lock
ZHONGHUA Junjie	ZHONGHUA 4G64	Jinheng airbag system	√	-	√	-	-	=	Read active DTC; Read history fault code; Read intermittent DTC
ZHONGHUA Junjie	ZHONGHUA 4G64	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	-	-	-
ZHONGHUA Junjie	ZHONGHUA 4G64	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	-	-	-

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		System						Functio	n
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)
ZHONGHUA Junjie	ZHONGHUA 4G64	Delphi anti-theft system	=	√	√	√	=	-	Matching function
ZHONGHUA Junjie	ZHONGHUA 4G64	Mitsubishi anti-theft system	√	√	√	√	-	-	Special function
ZHONGHUA Junjie	ZHONGHUA 4G64	Central control system	√	√	√	√	√	-	_
ZHONGHUA Junjie	ZHONGHUA 4G64	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; Read state data stream; Crankshaft position sensor target gear error learning
ZHONGHUA Junjie	ZHONGHUA 4G64	UMC ME797	√	√	√	√	√	-	System status
ZHONGHUA Junjie	ZHONGHUA 4G64	UAES M7 electronic injection system	-	√	√	√	-	-	_
ZHONGHUA Junjie	ZHONGHUA 4G64	UMC EOBD engine system	-	√	√	√	-	-	-
ZHONGHUA Junjie	ZHONGHUA 4G93	MM multi-point engine system	√	√	√	√	√	-	Adaptive parameter adjustment
ZHONGHUA Junjie	ZHONGHUA 4G93	Delphi Euro III system	√	√	√	√	√	-	system status
ZHONGHUA Junjie	ZHONGHUA 4G93	Delphi EOBD engine system	√	√	√	-	√	-	Read history fault code; Read dynamic data stream; Read state data stream
ZHONGHUA Junjie	ZHONGHUA 4G93	UMC M7971 system (1.8L/2.0L)	√	√	√	√	√	√	_
ZHONGHUA Junjie	ZHONGHUA 4G93	Delphi (Euro 3) system	√	√	√	√	√	-	System status
ZHONGHUA Junjie	ZHONGHUA 4G93	Mitsubishi engine system	√	√	√	√	-	-	Execute component control
ZHONGHUA Junjie	ZHONGHUA 4G93	Automatic transmission system	√	√	√	√	-	-	Execute component control
ZHONGHUA Junjie	ZHONGHUA 4G93	ABS	√	-	=	√	√	-	Read chassis area DTC; Read the whole area DTC; Clear chassis area DTC; Clear the whole area DTC; Read state data stream
ZHONGHUA Junjie	ZHONGHUA 4G93	ABS (ISO)	-	√	√	-	-	-	Read dynamic data stream; Read vehicle computer model
ZHONGHUA Junjie	ZHONGHUA 4G93	Passive safety system (Pretension)	√	√	√	-	_	-	_
ZHONGHUA Junjie	ZHONGHUA 4G93	Passive safety system (Pretension+Front airbag)	√	√	√	-	-	-	_
ZHONGHUA Junjie	ZHONGHUA 4G93	Autoliv airbag	√	√	√	√	-	-	ECU module lock
ZHONGHUA Junjie	ZHONGHUA 4G93	Jinheng airbag system	√	_	√	_	-	-	Read active DTC; Read history fault code; Read intermittent DTC
ZHONGHUA Junjie	ZHONGHUA 4G93	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	-	-	_
ZHONGHUA Junjie	ZHONGHUA 4G93	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	-	-	_

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		Sugton			Function										
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)						
ZHONGHUA Junjie	ZHONGHUA 4G93	Delphi anti-theft system	-	√	√	√	-	-	Matching function						
ZHONGHUA Junjie	ZHONGHUA 4G93	Mitsubishi anti-theft system	√	√	√	√	-	-	Special function						
ZHONGHUA Junjie	ZHONGHUA 4G93	Central control system	√	√	√	√	√	-	-						
ZHONGHUA Junjie	ZHONGHUA 4G93	Mitsubishi automatic transmission system (1.8L Euro IV)	√	√	√	√	-	-	Execute component control						
ZHONGHUA Junjie	ZHONGHUA 4G93	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning						
ZHONGHUA Junjie	ZHONGHUA 4G93	UMC ME797	√	√	√	√	√	-	System status						
ZHONGHUA Junjie	ZHONGHUA 4G93	UAES M7 electronic injection system	-	√	√	√	-	-	-						
ZHONGHUA Junjie	ZHONGHUA 4G93	BOSCH ESP8	√	√	√	√	√	√	Exhaust function						
ZHONGHUA Junjie	ZHONGHUA 4G93	UMC EOBD engine system	-	√	√	√	-	-	-						
ZHONGHUA Junjie	ZHONGHUA 4G18	MM multi-point engine system	√	√	√	√	√	-	Adaptive parameter adjustment						
ZHONGHUA Junjie	ZHONGHUA 4G18	Delphi (Euro 3) system	√	√	√	√	√	-	System status						
ZHONGHUA Junjie	ZHONGHUA 4G18	Delphi Euro III system	√	√	√	√	√	-	System status						
ZHONGHUA Junjie	ZHONGHUA 4G18	Delphi EOBD engine system	√	√	√	=	√	√	Read history fault code; Read dynamic data stream						
ZHONGHUA Junjie	ZHONGHUA 4G18	UMC M7971 system (1.8L/2.0L)	√	√	√	√	√	-	-						
ZHONGHUA Junjie	ZHONGHUA 4G18	Mitsubishi engine system	√	√	√	√	-	-	Execute component control						
ZHONGHUA Junjie	ZHONGHUA 4G18	Automatic transmission system	√	√	√	√	-	-	Execute component control						
ZHONGHUA Junjie	ZHONGHUA 4G18	ABS	√	-	-	√	√	-	Read chassis area DTC; Read the whole area DTC; Clear chassis area DTC; Clear the whole area DTC; Read state data stream						
ZHONGHUA Junjie	ZHONGHUA 4G18	ABS (ISO)	-	√	√	-	-	-	Read dynamic data stream; Read vehicle computer model						
ZHONGHUA Junjie	ZHONGHUA 4G18	Passive safety system (Pretension)	-	√	√	_	√	-	-						
ZHONGHUA Junjie	ZHONGHUA 4G18	Passive safety system (Pretension+Front airbag)	√	√	√	_	-	-	-						
ZHONGHUA Junjie	ZHONGHUA 4G18	Autoliv airbag	√	√	√	√	-	-	ECU module lock						
ZHONGHUA Junjie	ZHONGHUA 4G18	Jinheng airbag system	√	-	√	_	-	_	Read active DTC; Read history fault code; Read intermittent DTC						

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

								Function	1
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)
ZHONGHUA Junjie	ZHONGHUA 4G18	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	=	=	_
ZHONGHUA Junjie	ZHONGHUA 4G18	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	-	-	_
ZHONGHUA Junjie	ZHONGHUA 4G18	Delphi anti-theft system	-	√	√	√	-	-	Matching function
ZHONGHUA Junjie	ZHONGHUA 4G18	Mitsubishi anti-theft system	√	√	√	√	-	-	Special function
ZHONGHUA Junjie	ZHONGHUA 4G18	Central control system	√	√	√	√	√	-	_
ZHONGHUA Junjie	ZHONGHUA 4G18	Delphi MT80 engine	√	√	√	-	√		Read basic information; Read state data stream; Crankshaft position sensor target gear error learning
ZHONGHUA Junjie	ZHONGHUA 4G18	UMC ME797	√	√	√	√	√	-	System status
ZHONGHUA Junjie	ZHONGHUA 4G18	UAES M7 electronic injection system	-	√	√	√	I	-	_
ZHONGHUA Junjie	ZHONGHUA 4G18	UMC EOBD engine system	-	√	√	√	-	-	_
ZHONGHUA Junjie	ZHONGHUA 1.8T	Siemens engine system	√	√	√	√	√		Anti-theft data stream; Initialization adaptation value; Idle speed adjustment
ZHONGHUA Junjie	ZHONGHUA 1.8T	Automatic transmission system	√	√	√	√	√	-	Read state data stream
ZHONGHUA Junjie	ZHONGHUA 1.8T	ABS (ISO)	√	√	√	√	-	-	Execute component control
ZHONGHUA Junjie	ZHONGHUA 1.8T	Passive safety system (Pretension)	√	√	√	-	-	-	_
ZHONGHUA Junjie	ZHONGHUA 1.8T	Autoliv airbag	√	√	√	-	ı	=	ECU module lock
ZHONGHUA Junjie	ZHONGHUA 1.8T	Jinheng airbag system	√	-	√	-	-	-	Read active DTC; Read history fault code; Read intermittent DTC
ZHONGHUA Junjie	ZHONGHUA 1.8T	Siemens anti-theft system	√	√	√	√	ı	=	Programming function
ZHONGHUA Junjie	ZHONGHUA 1.8T	Central control system	√	√	√	√	√	-	_
ZHONGHUA Junjie	ZHONGHUA 1.8T	Delphi MT80 engine	√	√	√	-	√		Read basic information; system status; Crankshaft position sensor target gear error learning
ZHONGHUA Junjie	ZHONGHUA 1.8T	UMC ME797	√	√	√	√	√	=	System status
ZHONGHUA Junjie	ZHONGHUA 1.8T	UAES M7 electronic injection system	-	√	√	√	=	=	-
ZHONGHUA Junjie	ZHONGHUA 1.8T	UMC EOBD engine system	-	√	√	√	-	-	
ZHONGHUA Junjie	D19 engine system		√	√	√	√	√	-	_

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

								Function	n
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)
ZHONGHUA Junjie	HYUNDAI HPT automatic tran	smission	√	√	√	√	√	-	_
ZHONGHUA Zunchi	4G63 engine	MM multi-point engine system	√	√	√	√	√	-	Adaptive parameter adjustment
ZHONGHUA Zunchi	4G63 engine	Mitsubishi engine system	√	√	√	√	-	-	Execute component control
ZHONGHUA Zunchi	4G63 engine	Delphi (Euro 3) system	√	√	√	√	√	-	System status
ZHONGHUA Zunchi	4G63 engine	Delphi EOBD engine system	√	√	√	-	√	√	Read history fault code; Read dynamic data stream; Read state data stream
ZHONGHUA Zunchi	4G63 engine	Automatic transmission system	√	√	√	√	-	_	Execute component control
ZHONGHUA Zunchi	4G63 engine	Mitsubishi automatic transmission system (MIVEC 2.OL Euro IV)	√	√	√	√	-	-	Execute component control
ZHONGHUA Zunchi	4G63 engine	ABS	√	-	-	√	√	-	Read chassis area DTC; Read the whole area DTC; Clear chassis area DTC; Clear the whole area DTC; Read state data stream
ZHONGHUA Zunchi	4G63 engine	BOSCH ABS8	√	√	√	√	√	-	-
ZHONGHUA Zunchi	4G63 engine	ABS (ISO)	-	√	√	-	_	-	Read dynamic data stream; Read vehicle computer model
ZHONGHUA Zunchi	4G63 engine	Passive safety system (Pretension)	√	√	√	-	_	-	_
ZHONGHUA Zunchi	4G63 engine	Passive safety system (Pretension+Front airbag)	√	√	√	-	_	-	_
ZHONGHUA Zunchi	4G63 engine	Autoliv airbag	√	√	√	√	_	-	ECU module lock
ZHONGHUA Zunchi	4G63 engine	Jinheng airbag system	√	-	√	-	_	-	Read active DTC; Read history fault code; Read intermittent DTC
ZHONGHUA Zunchi	4G63 engine	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	_	-	_
ZHONGHUA Zunchi	4G63 engine	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	-	_	-
ZHONGHUA Zunchi	4G63 engine	Delphi anti-theft system	√	√	√	√	_	-	Programming function
ZHONGHUA Zunchi	4G63 engine	Mitsubishi anti-theft system	√	√	√	√	-	-	Special function
ZHONGHUA Zunchi	4G63 engine	Central control system	√	√	√	√	1	-	-
ZHONGHUA Zunchi	4G63 engine	MM multi-point engine system 2	-	√	√	√	1	-	Adaptive parameter adjustment
ZHONGHUA Zunchi	4G63 engine	UAES M7 electronic injection system	√	√	√	√	1	-	System status
ZHONGHUA Zunchi	4G63 engine	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

			Function									
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
ZHONGHUA Zunchi	4G63 engine	UMC ME797	√	√	√	√	√	-	System status			
ZHONGHUA Zunchi	4G63 engine	UAES M7 electronic injection system	-	√	√	√	-	-	-			
ZHONGHUA Zunchi	4G63 engine	UMC EOBD engine system	-	√	√	√	-	-	-			
ZHONGHUA Zunchi	4G64 engine	MM multi-point engine system	√	√	√	√	√	-	Adaptive parameter adjustment			
ZHONGHUA Zunchi	4G64 engine	Delphi (Euro 3) system	√	√	√	√	√	-	System status			
ZHONGHUA Zunchi	4G64 engine	Delphi EOBD engine system	√	√	√	-	√	√	Read history fault code; Read dynamic data stream; Read state data stream			
ZHONGHUA Zunchi	4G64 engine	UMC M7971 system (1.8L/2.0L)	√	√	√	√	√	-	-			
ZHONGHUA Zunchi	4G64 engine	Mitsubishi engine system	√	√	√	√	I	-	Execute component control			
ZHONGHUA Zunchi	4G64 engine	Automatic transmission system	√	√	√	√	-	-	Execute component control			
ZHONGHUA Zunchi	4G64 engine	ABS	√	-	-	√	√	_	Read chassis area DTC; Read the whole area DTC; Clear chassis area DTC; Clear the whole area DTC			
ZHONGHUA Zunchi	4G64 engine	ABS (ISO)	-	√	√	-	-	-	Read dynamic data stream; Read vehicle computer model			
ZHONGHUA Zunchi	4G64 engine	Passive safety system (Pretension)	-	√	√	-	√	-	-			
ZHONGHUA Zunchi	4G64 engine	Passive safety system (Pretension+Front airbag)	√	√	√	-	-	-	-			
ZHONGHUA Zunchi	4G64 engine	Autoliv airbag	√	√	√	√	ı	=	ECU module lock			
ZHONGHUA Zunchi	4G64 engine	Jinheng airbag system	√	-	√	-	-	-	Read active DTC; Read history fault code; Read intermittent DTC			
ZHONGHUA Zunchi	4G64 engine	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	-	-	-			
ZHONGHUA Zunchi	4G64 engine	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	-	-	-			
ZHONGHUA Zunchi	4G64 engine	Delphi anti-theft system	√	√	√	√	-	-	Programming function			
ZHONGHUA Zunchi	4G64 engine	Mitsubishi anti-theft system	√	√	√	√	-	-	Special function			
ZHONGHUA Zunchi	4G64 engine	Central control system	√	√	√	√	√	-	-			
ZHONGHUA Zunchi	4G64 engine	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; Read state data stream; Crankshaft position sensor target gear error learning			
ZHONGHUA Zunchi	4G64 engine	UMC ME797	√	√	√	√	√	-	System status			

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		Sustan			Function								
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)				
ZHONGHUA Zunchi	4G64 engine	BOSCH ESP8	√	√	√	√	√	√	Exhaust function				
ZHONGHUA Zunchi	4G64 engine	UAES M7 electronic injection system	-	√	√	√	-	-	_				
ZHONGHUA Zunchi	4G64 engine	UMC EOBD engine system	-	√	√	√	-	-	-				
ZHONGHUA Zunchi	4G93 engine	MM multi-point engine system	√	√	√	√	√	_	Adaptive parameter adjustment				
ZHONGHUA Zunchi	4G93 engine	Delphi EOBD engine system	√	√	√	-	√	√	Read history fault code; Read dynamic data stream; Read state data stream				
ZHONGHUA Zunchi	4G93 engine	UMC M7971 system (1.8L/2.0L)	√	√	√	√	√	√	-				
ZHONGHUA Zunchi	4G93 engine	Delphi (Euro 3) system	√	√	√	√	√	-	System status				
ZHONGHUA Zunchi	4G93 engine	Mitsubishi engine system	√	√	√	√	-	-	Execute component control				
ZHONGHUA Zunchi	4G93 engine	Automatic transmission system	√	√	√	√	-	-	Execute component control				
ZHONGHUA Zunchi	4G93 engine	ABS	√	-	-	√	√	-	Read chassis area DTC; Read the whole area DTC; Clear chassis area DTC; Clear the whole area DTC; Read state data stream				
ZHONGHUA Zunchi	4G93 engine	ABS (ISO)	-	√	√	-	-	-	Read vehicle computer model				
ZHONGHUA Zunchi	4G93 engine	Passive safety system (Pretension)	√	√	√	-	-	-	-				
ZHONGHUA Zunchi	4G93 engine	Passive safety system (Pretension+Front airbag)	√	√	√	-	-	-	-				
ZHONGHUA Zunchi	4G93 engine	Autoliv airbag	√	√	√	√	-	-	ECU module lock				
ZHONGHUA Zunchi	4G93 engine	Jinheng airbag system	√	-	√	-	-	-	Read active DTC; Read history fault code; Read intermittent DTC				
ZHONGHUA Zunchi	4G93 engine	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	-	-	_				
ZHONGHUA Zunchi	4G93 engine	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	-	-	_				
ZHONGHUA Zunchi	4G93 engine	Delphi anti-theft system	√	√	√	√	=	-	Programming function				
ZHONGHUA Zunchi	4G93 engine	Mitsubishi anti-theft system	√	√	√	√	=	-	Special function				
ZHONGHUA Zunchi	4G93 engine	Central control system	√	√	√	√	√	-					
ZHONGHUA Zunchi	4G93 engine	Mitsubishi automatic transmission system (1.8L Euro IV)	√	√	√	√	-	-	Execute component control				
ZHONGHUA Zunchi	4G93 engine	Delphi MT80 engine	√	√	√	_	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning				

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		Function									
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)		
ZHONGHUA Zunchi	4G93 engine	UMC ME797	√	√	√	√	√	-	System status		
ZHONGHUA Zunchi	4G93 engine	UAES M7 electronic injection system	-	√	√	√	-	-	_		
ZHONGHUA Zunchi	4G93 engine	UMC EOBD engine system	-	√	√	√	-	-	-		
ZHONGHUA Zunchi	1.8T engine	Siemens engine system	√	√	√	√	√	√	Anti-theft data stream; Initialization adaptation value; Idle speed adjustment		
ZHONGHUA Zunchi	1.8T engine	Automatic transmission system	√	√	√	√	√	-	Read state data stream		
ZHONGHUA Zunchi	1.8T engine	ABS (ISO)	√	√	√	√	-	-	Execute component control		
ZHONGHUA Zunchi	1.8T engine	Passive safety system (Pretension)	√	√	√	-	-	-	_		
ZHONGHUA Zunchi	1.8T engine	Autoliv airbag	√	√	√	-	-	-	ECU module lock		
ZHONGHUA Zunchi	1.8T engine	Jinheng airbag system	√	=	√	-	-	-	Read active DTC; Read history fault code; Read intermittent DTC		
ZHONGHUA Zunchi	1.8T engine	Siemens anti-theft system	√	√	√	√	-	-	Programming function		
ZHONGHUA Zunchi	1.8T engine	Central control system	√	√	√	√	√	-	-		
ZHONGHUA Zunchi	1.8T engine	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning		
ZHONGHUA Zunchi	1.8T engine	UMC ME797	√	√	√	√	√	-	system status		
ZHONGHUA Zunchi	1.8T engine	UAES M7 electronic injection system	-	√	√	√	-	-	_		
ZHONGHUA Zunchi	1.8T engine	UMC EOBD engine system	-	√	√	√	_	-	-		
ZHONGHUA Zunchi	D19 engine system		√	√	√	√	√	-	-		
ZHONGHUA Zunchi	Jinheng airbag (Continenta	1 ECU)	√	√	√	√	_	-	-		
ZHONGHUA Zunchi	Zunchi driver door module		√	√	√	√	√	-	Version information; Automatic testing		
ZHONGHUA Zunchi	Zunchi front body module		√	√	√	√	\checkmark	-	Read SSM information; Version information; Automatic testing		
ZHONGHUA Zunchi	Zunchi passenger door module		√	√	√	√	\checkmark	-	Version information; Automatic testing		
ZHONGHUA Zunchi	Zunchi rear body module		√	√	√	√	\checkmark	-	Version information; Automatic testing		
ZHONGHUA Zunchi	HYUNDAI HPT automatic transmission		√	√	√	√	\checkmark	-	_		

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		Function									
Model Menu	System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
ZHONGHUA Zunchi	Zunchi instrumentation module	√	√	√	-	√	_	_			
ZHONGHUA 1.8T	Siemens engine system	√	√	√	√	√	√	Anti-theft data stream; Initialization adaptation value; Idle speed adjustment			
ZHONGHUA 1.8T	Automatic transmission system	√	√	√	√	√	-	Read state data stream			
ZHONGHUA 1.8T	ABS (ISO)	√	√	√	√	-	-	Execute component control			
ZHONGHUA 1.8T	Passive safety system (Pretension)	√	√	√	-	-	-	_			
ZHONGHUA 1.8T	Autoliv airbag	√	√	√	-	-	-	ECU module lock			
ZHONGHUA 1.8T	Jinheng airbag system	√	-	√	-	-	-	Read active DTC; Read history fault code; Read intermittent DTC			
ZHONGHUA 1.8T	anti-theft system	√	√	√	√	=	-	Programming function; Delete key			
ZHONGHUA 1.8T	Central control system	√	√	√	√	√	-	_			
ZHONGHUA 1.8T	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning			
ZHONGHUA 1.8T	UMC ME797	√	√	√	√	√	-	System status			
ZHONGHUA 1.8T	UAES M7 electronic injection system	-	√	√	√	-	-	_			
ZHONGHUA 1.8T	UMC EOBD engine system	=	√	√	√	-	-	_			
ZHONGHUA Kubao (M3)	Delphi (Euro 3) system	√	√	√	√	√	-	System status			
ZHONGHUA Kubao (M3)	Siemens engine system	√	√	√	√	√	√	Anti-theft data stream; Initialization adaptation value; Idle speed adjustment			
ZHONGHUA Kubao (M3)	ABS (ISO)	-	√	√	-	=	-	Read vehicle computer model			
ZHONGHUA Kubao (M3)	Jinheng airbag M3(Kubao)	√	√	√	√	-	-	_			
ZHONGHUA Kubao (M3)	Siemens anti-theft system	√	√	√	√	-	-	Programming function			
ZHONGHUA Kubao (M3)	Delphi anti-theft system	-	√	√	√	-	-	Matching function			
ZHONGHUA Kubao (M3)	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning			
ZHONGHUA Kubao (M3)	UMC ME797	√	√	√	√	√	-	System status			
ZHONGHUA Kubao (M3)	UAES M7 electronic injection system	-	√	√	√	-	_	_			

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

	Swaton	Function									
Model Menu	System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
ZHONGHUA Kubao (M3)	UMC EOBD engine system	-	√	√	√	-	-	_			
ZHONGHUA Junjie FRV	UMC EOBD engine system	√	√	√	√	√	-	System status			
ZHONGHUA Junjie FRV	Delphi MT80 engine system	√	√	√	√	√	-	-			
ZHONGHUA Junjie FRV	UMC M7971 system (1.8L/2.0L)	√	√	√	√	√	√	-			
ZHONGHUA Junjie FRV	SABS MK70/ABS system	√	√	√	√	√	-	-			
ZHONGHUA Junjie FRV	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	-	-	-			
ZHONGHUA Junjie FRV	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	-	-	-			
ZHONGHUA Junjie FRV	Mitsubishi automatic transmission system	√	√	√	√	-	-	Execute component control			
ZHONGHUA Junjie FRV	Jinheng electronic power steering system	√	√	√	√	-	-	_			
ZHONGHUA Junjie FRV	Jinheng airbag (Continental ECU)	√	√	√	√	-	-	_			
ZHONGHUA Junjie FRV	Delphi MT80 engine	√	√	√	-	√	-	Read basic information; system status; Crankshaft position sensor target gear error learning			
ZHONGHUA Junjie FRV	UMC ME797	√	√	√	√	√	-	System status			
ZHONGHUA Junjie FRV	UAES M7 electronic injection system	-	√	√	√	_	-	-			
ZHONGHUA Junjie FRV	UMC EOBD engine system	-	√	√	√	-	-	-			
ZHONGHUA Junjie FRV	Brilliance anti-theft system (after 2009)	√	√	√	-	_	-	-			
ZHONGHUA Junjie FRV	Mitsubishi anti-theft system	-	√	√	√	_	-	Special function			
ZHONGHUA ER 1.8/2.0UMC	M7971 system	√	√	√	√	√	√	-			
ZHONGHUA Junjie FSV	Delphi MT80 engine system	√	√	√	√	√	√	Write VIN code, Crankshaft position sensor target gear error learning			
ZHONGHUA Junjie FSV	Mitsubishi engine system	√	√	√	√	-	-	Execute component control			
ZHONGHUA Junjie FSV	UMC M7971Engine system	√	√	√	√	√	√	-			
ZHONGHUA Junjie FSV	UMC ME7 start-stop system	√	√	√	√	√	√	system status, Condition description of prohibition of automatic shutdown, Read start and stop times, Read EBS information, Write battery ID number, Clear number of motor start			
ZHONGHUA Junjie FSV	Mitsubishi automatic transmission system (Euro IV)	√	√	√	√	-	-	Execute component control			

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		Function									
Model Menu	System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
ZHONGHUA Junjie FSV	HYUNDAI HPT automatic transmission	√	√	√	√	√	-	-			
ZHONGHUA Junjie FSV	SABS MK70/ABS system	√	√	√	√	-	-	Component test, Exhaust filling, Hydraulic control unit test			
ZHONGHUA Junjie FSV	Delphi 7.8ABS system	√	√	√	√	√	-	Bleeding mode			
ZHONGHUA Junjie FSV	Jinheng airbag (Continental ECU)	√	√	√	√	-	-	-			
ZHONGHUA Junjie FSV	Mando electronic power steering system	√	√	√	√	_	-	-			
AO	Engine UMC ME788 system	√	√	√	√	√	√	EOL function			
AO	HYUNDAI HPT automatic transmission	√	√	√	√	√	-	-			
AO	SABS MK70/ABS system	√	√	√	√	-	-	Component test, Exhaust filling, Hydraulic control unit test			
AO	(anti-lock braking) SABS MK70/ABS system	√	√	√	√	√	-	Hydraulic control unit test; Filling and exhausting			
AO	Mando electronic power steering system (CANBUS)	√	√	√	√	-	-	Steering angle calibration; Clear steering angle sensor information			
AO	Continental Airbag (CANBUS)	√	√	√	√	-	-	Write VIN code; Ignition function setting			
AO	Automatic transmission system	√	√	√	√	-	-	-			
AO	BOSCH SRS (UDS)	-	√	√	√	-	-	Read controller information; Read vehicle information			
AO	BOSCH ABS9 (UDS)	-	√	√	√	√	-	Write data function; Special function; Maintenance exhausting			
V5	Continental MK60 ESC system (UDS)/ABS system	√	√	√	√	√	-	Sensor calibration; Hydraulic control unit test			
V5	BM15T engine UMC system	√	√	√	√	√	√	EOL function; Write VIN code			
V5	Engine UMC ME788 system	√	√	√	√	√	√	EOL function			
V5	HYUNDAI HPT automatic transmission	√	√	√	√	√	-	-			
V5	Continental MK60 ESC system (UDS)/ABS system	√	√	√	√	\checkmark	-	Sensor calibration; Hydraulic control unit test			
V5	Continental MK70 ABS system	√	√	√	√	\checkmark	-	Hydraulic control unit test; Filling and exhausting			
V5	Continental MK70 ABS 4 wheel-drive system (UDS	√	√	√	√	\checkmark	-	Hydraulic control unit test; Filling and exhausting			
V5	Mando electronic power steering system (CANBUS)	√	√	√	√	-	-	Steering angle calibration; Clear steering angle sensor information			

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		Function									
Model Menu	System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
V5	Continental Airbag (CANBUS)	√	√	√	√	-	-	Write VIN code; Ignition function setting			
Н530	UMC M7971Engine system	√	√	√	√	√	√	-			
Н530	BM15T engine UMC system	√	√	√	√	√	√	EOL function; Write VIN code			
Н530	HYUNDAI HPT automatic transmission	√	√	√	√	√	-	-			
Н530	SABS MK70/ABS system	√	√	√	√	-	-	Component test, Exhaust filling, Hydraulic control unit test			
Н530	Continental MK60 ESC system (UDS)/ABS system	√	√	√	√	√	=	Sensor calibration; Hydraulic control unit test			
Н530	(anti-lock braking) SABS MK70/ABS system	√	√	√	√	√	-	Hydraulic control unit test; Filling and exhausting			
Н530	Mando electronic power steering system (CANBUS)	√	√	√	√	-	-	Steering angle calibration; Clear steering angle sensor information			
Н530	Continental Airbag (CANBUS)	√	√	√	√	ı	=	Write VIN code; Ignition function setting			
Junjie CROSS	Delphi MT80 engine system	√	√	√	√	√	√	Write VIN code, Crankshaft position sensor target gear error learning			
Junjie CROSS	Mitsubishi engine system	√	√	√	√	-	-	Execute component control			
Junjie CROSS	UMC M7971Engine system	√	√	√	√	√	√	_			
Junjie CROSS	Mitsubishi automatic transmission system (Euro IV)	√	√	√	√	-	-	Execute component control			
Junjie CROSS	HYUNDAI HPT automatic transmission	√	√	√	√	√	-	_			
Junjie CROSS	SABS MK70/ABS system	√	√	√	√	-	-	Component test, Exhaust filling, Hydraulic control unit test			
Junjie CROSS	BOSCH ABS8	√	√	√	√	√	√	Exhaust function			
Junjie CROSS	Jinheng airbag (Continental ECU)	√	√	√	√	-	-	-			
Junjie CROSS	Central control system	√	√	√	√	√	-	_			
Junjie WAGON	1.8L Siemens engine system	√	√	√	√	√	√	Anti-theft data stream, Initialization adaptation value, Idle speed adjustment			
Junjie WAGON	MT Delphi EOBD system	√	√	√	√	√	√	Read history fault code, Read state data stream, Crankshaft position sensor target gear error learning, Idle catalytic converter diagnose, Diagnose of oxygen sensor feedback plausibility, DTC diagnostic test			
Junjie WAGON	(2. OL) Mitsubishi engine system (MIVEC)	√	√	√	√	-	_	Execute component control			

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

	_	Function										
Model Menu	System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)				
Junjie WAGON	(1.8L)MT Delphi EOBD system	√	√	√	√	√	√	Read history fault code, Read state data stream, Crankshaft position sensor target gear error learning, Idle catalytic converter diagnose, Diagnose of oxygen sensor feedback plausibility, DTC diagnostic test				
Junjie WAGON	1.8/2.0LUMC M7971 system	√	√	√	√	√	√	_				
Junjie WAGON	Mitsubishi automatic transmission system (MIVEC)	1	√	√	√	-	-	Execute component control				
Junjie WAGON	1.8T ZFAutomatic transmission system	1	√	√	√	1	√	Read state data stream, Data calibration				
Junjie WAGON	HYUNDAI HPT automatic transmission	1	√	√	√	1	-	-				
Junjie WAGON	SABS MK20/ABS system	√	√	√	√	-	-	Execute component control				
Junjie WAGON	SABS MK70/ABS system	√	√	√	√	-	-	Component test, Exhaust filling, Hydraulic control unit test				
Junjie WAGON	BOSCH ABS8	√	√	√	√	√	√	Exhaust function				
Junjie WAGON	Jinheng airbag (AUTONET)-4 loop	√	√	√	√	-	-	-				
Junjie WAGON	Jinheng airbag (AUTONET)-6 loop	√	√	√	√	-	-	-				
Junjie WAGON	Jinheng airbag (Continental ECU)	√	√	√	√	-	-	-				
Junjie WAGON	Central control system	√	√	√	√	√	-	-				
H220	BM15T engine UMC system	√	√	√	√	√	√	EOL function; Write VIN code				
H220	Electric automatic transmission system (KWP2000)	1	√	√	√	-	-	Write VIN code				
H220	Bosch anti-lock braking system 9(UDS)	√	√	√	√	-	-	Write data function, Special function, Maintenance exhausting				
H220	Bosch airbag (UDS)	√	√	√	√	=	-	Write version information				
H220	Jinbei Henglong electric steering system (CANBUS)	√	√	√	√	-	-	Steering angle calibration, Clear steering angle sensor information				
Н320	4A91 UMC M7971Engine system	√	√	√	√	4	√	Write VIN code				
Н320	HYUNDAI HPT automatic transmission	√	√	√	√	√	-	_				
Н320	Jinheng airbag	√	√	√	√	√	-	Bleeding mode				
Н320	Bosch airbag (UDS)	√	√	√	√	=	=	_				
Н320	Jinbei Henglong electric steering system (KWP2000)	√	√	√	√	=	=	Steering angle calibration, Clear steering angle sensor information				

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

			Function									
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
Н330	BM15T engine UMC system		√	√	√	√	√	√	EOL function; Write VIN code			
Н330	HYUNDAI HPT automatic trans	smission	√	√	√	√	√	I	_			
Н330	Mitsubishi automatic trans	mission system (Euro IV)	√	√	√	√	-	I	Execute component control			
Н330	SABS MK79ABS		√	√	√	√	-	I	Exhaust filling, Hydraulic control unit test			
Н330	Delphi 7.8 ABS		√	√	√	√	√	-	Bleeding mode			
Н330	Jinheng airbag		√	√	√	√	-	-	-			
Н330	Mando electronic power ste	ering system	√	√	√	√	-	-	_			
V3	Engine UMC ME788 system		√	√	√	√	√	√	EOL function			
V3	Automatic transmission system	HYUNDAI HPT automatic transmission	√	√	√	√	√	-	_			
V3	V3 Body control system (BCM)		-	√	√	√	-	-	ECU Hardware reset			
V3	V3 Multimedia controller (MMC) (UDS)	-	√	√	√	-	-	ECU reset			
V3	V3 Instrument system contr	oller (IPC)	-	√	√	√	-	-	Write total mileage			
V3	V3 Keyless matching system	(PEPS)	-	√	√	√	-	-	New FOB learning; New ESCL learning; Reset PEPS; Reset FOB; Read FOB status			
V3	Anti-theft system	Brilliance anti-theft system (after 2009)	√	√	√	√	-	-	_			
V3	ABS	Bosch ABS9 (UDS)	√	√	√	√	√	-	Write data; Maintenance exhausting; Steering wheel angle sensor calibration (only ESP); Speed limit; Valve relay off; External yaw rate sensor calibration (selection of-ESP)			
V3	ABS	Bosch ESP9 (UDS)	J	√	√	√	√	-	Write data; Maintenance exhausting; Steering wheel angle sensor calibration (only ESP); Speed limit; Valve relay off; External yaw rate sensor calibration (selection of-ESP)			
HUASONG 7	Engine controller (DME)		-	_	-	√	-	-	-			
HUASONG 7	Transmission control unit (TCU)		-	_	-	√	-	-	-			
HUASONG 7	Electronic stability system (ESC)		T.	√	√	√	-	I	_			
HUASONG 7	Body control module (BCM)		√	√	√	-	-	-	_			
HUASONG 7	Instrument cluster (IPC)		=	√	√	√	=	=				

- 1. \checkmark : means that the system has this function 2. -: means that the system does not have this function 3. compared with the last version, the new added function is marked in red color.

			Function									
Model Menu		System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
HUASONG 7	Multimedia controller (MMU)		√	√	√	-	-	-	-			
HUASONG 7	Parking sensor controller (PDC)		√	√	√	-	-	-	_			
HUASONG 7	Reversing video controller	(RVC)	√	√	√	-	-	-	-			
HUASONG 7	A/C controller (AC)		√	√	√	-	-	-	-			
HUASONG 7	Airbag controller (SRS)		√	√	√	-	-	-	-			
H230	Anti-theft system (IMMO)		√	√	√	√	-	-	Anti-theft remote control matching; Anti-theft controller state			
H230	Engine system (EMS)		√	√	√	√	√	-	Write VIN code			
H230	Automatic transmission syst	em (AT)	√	√	√	√	-	-	Write VIN code			
Н230	ABS (ABS)		√	√	√	√	√	_	Write data function; Steering wheel angle sensor calibration(ESP); Inertial sensor calibration (only ESP); Speed limit; Valve relay off; Maintenance exhausting			
H230	Airbag system (SRS)		√	√	√	√	-	-	-			
H230	Power steering system (EPS)		√	√	√	√	-	-	Steering angle calibration; Clear steering angle sensor information			
H230 (electric)	Charging generator system (ACDC)	√	√	√	√	-	-	ECU Hardware reset; Write data			
H230 (electric)	Battery management system (BMS)	√	√	√	-	-	-	ECU reset; Write data; Relay control			
H230 (electric)	Motor controller system	Motor controller system (MCU)	-	√	√	√	-	√	ECU reset; Write data; Extended data			
H230 (electric)	Motor controller system	Motor controller system (EPB)	-	√	√	√	-	√	ECU reset; Write data			
H230 (electric)	ABS (ABS)		√	√	√	√	√		Write data function; Steering wheel angle sensor calibration(ESP); External yaw rate sensor calibration (selection of-ESP); Speed limit; Valve relay off; Maintenance exhausting			
H230 (electric)	Airbag system (SRS)		√	√	√	√	-	-	-			
H230 (electric)	Vehicle controller system (VMS)		√	√	√	-	√	√	Write VIN code; ECU software reset			
H230 (electric)	Power steering system (EPS)		√	√	√	√	-	-	Steering angle calibration; Clear steering angle sensor information			
H230 (electric)	Gateway control system (GW)		-	√	√	√	_	-	ECU reset; Write vehicle identification code (VIN)			
H230 (electric)	Multi-media system (MMU)		√	√	√	√	√	-	ECU reset; Write data			

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

			Function									
Model Menu	System		Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
Н3	Engine system (EMS)		√	√	√	√	√	-	EOL function; Write vehicle identification code (VIN)			
Н3	Automatic transmission syst	tem (AT)	√	√	√	√	√	-	-			
НЗ	ABS (ABS)		√	√	√	√	√	√	Write data function; software reset; Speed limit; Valve relay off; Maintenance exhausting			
Н3	Airbag system (SRS)		√	√	√	√	-	-	Software reset; Write data; off-line configuration; Configuration information			
Н3	Instrument panel system (IC	CM)	√	√	√	√	√	=	Write data; Write total mileage			
Н3	Electronic stability system	n (ESC)	√	√	√	√	√	√	Software reset; Write data; Maintenance exhausting; Calibration function			
НЗ	Body control system (BCM)		√	√	√	√	√	_	ECU Hardware reset; Write data			
НЗ	Anti-theft system (IMMO)		√	√	√	√	-	-	_			
НЗ	Keyless entry system (PEPS)		√	√	√	√	√	-	Write data			
Н3	Power steering system (EPS)		√	√	√	√	_	-	Zero learning function			
Н3	Auto A/C system (AC)	A/C controller (AC)	√	√	√	√	√	_	ECU reset; Write data			
Н3	Auto A/C system (AC)	A/C controller (AC) (Elite)	√	√	√	√	√	_	ECU reset; Write data			
Н3	Gateway control system (GW)		√	√	√	-	_	_	Write data			
Н3	Multi-media system (MMU)	Multimedia controller (MMC)	√	√	√	√	√	_	ECU reset; Write data			
Н3	Multi-media system (MMU)	Multimedia controller (MMC)(Elite)	√	√	√	√	√	-	ECU reset; Write data			
V3 (generation 3)	Engine system (EMS)	Engine UMC ME788 system	√	√	√	√	√	-	EOL function; Write vehicle identification code (VIN)			
V3 (generation 3)	Engine system (EMS)	Engine UMC ME788 system (Fuel-saving)	√	√	√	√	√	-	Read and write VIN code			
V3 (generation 3)	Automatic transmission system (AT)		√	√	√	√	✓	-	_			
V3 (generation 3)	ABS (ABS)		√	√	√	√	√	-	Write data function; Steering wheel angle sensor calibration(ESP); External yaw rate sensor calibration (selection of-ESP); Speed limit; Valve relay off; Maintenance exhausting			
V3 (generation 3)	Airbag system (SRS)		√	√	√	√	-	-	Software reset; Write vehicle configuration information; Configuration information			
V3 (generation 3)	Instrument panel system (ICM)		√	√	√	√	√	-	Write data			
V3 (generation 3)	Power steering system (EPS)		√	√	√	√	-	-	Steering angle calibration; Clear steering angle sensor information			

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

			Function									
Model Menu		System		Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
V3 (generation 3)	Keyless entry system (PEPS)		√	√	√	√	√	-	Write data;			
V3 (generation 3)	Body control system (BCM)		√	√	√	√	✓	-	Write data; ECU Hardware reset			
V3 (generation 3)	Auto A/C system (AC)		√	√	√	√	√	-	Write VIN code			
V3 (generation 3)	Multi-media system (MMU)		√	√	√	√	√	_	Write data; ECU reset			
V3 (generation 3)	Anti-theft system (IMMO)	Brilliance anti-theft system (after 2009)	√	√	√	√	-	_	-			
V3 (generation 3)	Anti-theft system (IMMO)	Brilliance anti-theft system (Fuel-saving)	√	√	√	√	-	_	-			
V3 (generation 3)	Look around and overlook sy	vstem (AVM)	√	√	√	√	-	_	Write data; AVM internal calibration			
V3 (generation 3)	Gateway control system (GW)		√	√	√	-	-	-	Write data			
V6	Engine system (EMS)	Engine control system (EMS-4K11)	√	√	√	√	√	-	Write data; Crankshaft position sensor target gear error learning			
V6	Engine system (EMS)	Engine control system (EMS-BM15TD)	√	√	√	√	✓	-	Write data			
V6	Automatic transmission syst	tem (AT)	√	√	√	-	-	-	_			
V6	Airbag system (SRS)		√	√	√	√	√	-	Write data			
V6	Instrument panel system (IC	CM)	√	√	√	√	√	-	Write data			
V6	Power steering system (EPS)		√	√	√	√	-	-	Steering angle sensor calibration			
V6	Auto A/C system (AC)	Electric air conditioning control system (E-CCU)	√	√	√	√	√	-	Write data; Routine control			
V6	Auto A/C system (AC)	Auto A/C control system (A-CCU)	√	√	√	√	✓	-	Write data			
V6	Electronic stability system (ESC)		√	√	√	√	√	-	Software reset; Write data; Maintenance exhausting; Sensor calibration; Speed limit; Valve relay off; PBC control; TPMF reset			
V6	Body control system (BCM)		√	√	√	√	√	-	Write data			
V6	Keyless entry system (PEPS)		√	√	√	√	√	-	Write data; System self-test test			
V6	Multi-media system (MMU)		√	√	√	-	-	-	_			
V6	Look around and overlook system (AVM)		√	√	√	-	-	-	_			
V6	Reversing video control sys	Reversing video control system (RVC)		√	√	√	-	-	_			

- 1. √: means that the system has this function
 2. -: means that the system does not have this function
 3. compared with the last version, the new added function is marked in red color.

		Function									
Model Menu	System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
V6	Vehicle communication terminal system (T-BOX)	√	√	√	√	-	-	Write data			
V6	Electronic shifter system (GS)	√	√	√	√	-	-	Write data			
V6	Reversing radar control system (PDC)	√	-	-	-	-	-	_			
V6	Light / rain sensor system (RLS)	√	-	-	-	-	-	_			
V6	Combination switch and steering wheel switch system (SCM)	√	-	-	√	-	-	_			
V6	Door control system (DCM)	√	ı	-	-	-	-	_			
Zhishang S30	Engine system (EMS)	√	√	√	√	√	√	Idle catalytic converter diagnose; Diagnose of oxygen sensor feedback plausibility; DTC diagnostic test			
Zhishang S30	ABS (ABS)	√	√	√	√	√	-	_			
Zhishang S30	Airbag system (SRS)	√	√	√	√	√	-	2 airbag automatic matching; 6 airbag automatic matching			
Jinbei F50	Engine system (EMS)	√	√	√	√	√	-	EOL function; Write vehicle identification code (VIN)			
Jinbei F50	ABS (ABS)	-	√	√	√	√	-	Write data; Speed limit; Valve relay off; Maintenance exhausting			
Jinbei F50	Airbag system (SRS)	√	√	√	√	√	-	Write data			
Jinbei F50	Power steering system (EPS)	√	√	√	√	-	-	Clear steering angle sensor information			
Jinbei F50	Anti-theft system (IMMO)	√	√	√	√	-	-	_			
V5	Body control system (BCM)	√	√	√	√	√	-	Version information; Automatic testing; Write VIN code			
V5	Power supply system (PMS)	√	√	√	√	√	-	Version information; Automatic testing; Write VIN code			
V5	Keyless entry system-diagnosis function	√	√	√	√	√	-	Version information; Automatic testing; Write VIN code			
Н530	Body control system (BCM)	√	√	√	√	√	-	Version information; Automatic testing; Write VIN code			
Н530	Power supply system (PMS)	√	√	√	√	√	-	Version information; Automatic testing; Write VIN code			
Н530	Keyless entry system-diagnosis function	√	√	√	√	√	-	Version information; Automatic testing; Write VIN code			
V3	Airbag system (SRS)	√	√	√	√	-	-	Software reset; Write vehicle configuration information;			
V3	Instrument panel system (ICM)	√	√	√	√	√	_	Write data; Write total mileage			

- √: means that the system has this function
 -: means that the system does not have this function
 compared with the last version, the new added function is marked in red color.

		Function									
Model Menu	System	Read Version Information	Read Fault	Clear Fault	Read Data Stream	Actuation Test	Read Frozen Frame	Remarks (Other Functions)			
V3	Anti-theft system (IMMO)	√	√	√	√	-	=	_			
V3	Keyless entry system (PEPS)	√	√	√	√	√	-	Write data			
V3	Body control system (BCM)	√	√	√	√	√	-	ECU Hardware reset; Write data			
V3	Power steering system (EPS)	√	√	√	√	-	-	Steering angle sensor calibration; Delet steering angle sensor calibration data			
V3	Gateway control system (GW)	√	√	√	-	-	-	Write data			
V3	Multi-media system (MMU)	√	√	√	√	√	-	ECU reset; Write data			
Н330	Keyless entry system (PEPS)	-	√	√	-	-	-	_			
			l	l			l				