



FCAR Diagnostic List Ankai Bus_v5.64

Remark:

1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Models | System Menu | System | Function | | | | | | Remarks(other functions) |
|-----------|-----------------------------|-------------------------|----------------------|-----------------|------------------|------------------|----------------|-------------------|---|
| | | | Read ECU Information | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Read Freeze Frame | |
| Ankai bus | Xichai DENSO | | √ | √ | √ | √ | √ | √ | QR code, write VIN, write EIN |
| | Xichai 4DF3 engine | | √ | √ | √ | √ | - | √ | Function test, actuator control, modification of the electric control |
| | BOSCH common rail_EDC16UC40 | Static diagnostic data | √ | √ | √ | - | - | √ | Oil balance matching |
| | | Dynamic diagnostic data | √ | - | - | √ | √ | - | Function test |
| | BOSCH common rail_EDC7UC31 | Static diagnostic data | √ | √ | √ | - | - | √ | Read historical fault codes |
| | | Dynamic diagnostic data | √ | - | - | √ | √ | - | - |
| | Nanyue unit pump | Nanyue unit pump | - | √ | √ | √ | - | - | - |
| | Nanyue unit pump | Nanyue unit pump | - | √ | √ | √ | - | - | - |
| | Nanyue unit pump | Nanyue unit pump | - | √ | √ | √ | - | - | - |
| | Nanyue unit pump | Nanyue unit pump | - | √ | √ | √ | - | - | - |