

Remark:

1. √ : means that the system has this function

2. - : means that the system does not have this function

3.compared with the last version, the new added function is marked in red color.

System Menu	System	System	System	Function				
				Read ECU Info.	Read DTCs	Erase DTCs	Read Data Stream	Actuation Test
ERF	Engine	360	EDC 7 BOSCH	-	√	√	√	-
ERF	Engine	360	EDC 7C32 BOSCH	-	√	√	-	-
ERF	Engine	440	EDC 7 BOSCH	-	√	√	√	-
ERF	Engine	440	EDC 7C32 BOSCH	-	√	√	-	-
ERF	Engine	480	EDC 7 BOSCH	-	√	√	√	-
ERF	Engine	480	EDC 7C32 BOSCH	-	√	√	-	-
ERF	Engine - Car adjustment	Engine - Car adjustment	VDO FFR car - engine (navigator)	-	√	√	√	-
ERF	Dashboard	Dashboard	Kienzle-Stoneridge	-	√	√	√	-
ERF	Heating / air conditioning	Heating / air conditioning	Behr / GKR air- conditioning control	-	√	√	√	-
ERF	Heating / air conditioning	Heating / air conditioning	Hydronic D5W,Eberspaecher	-	√	√	√	-
ERF	Heating / air conditioning	Heating / air conditioning	Air Top 2000 OEM,Webasto	-	√	√	√	-
ERF	Heating / air conditioning	Heating / air conditioning	Air Top 3500 ST,Webasto	-	√	√	√	-
ERF	Heating / air conditioning	Heating / air conditioning	Thermo 50,Webasto	-	√	√	√	-