Disgnostic List JMC_v8.90

			DISGNOSTIC LIS	t Jmc_vo. a	, O				
Remark: 1. √ : means that t	he system has this function								
2 : means that t	he system does not have this function last version, the new added function is	marked in red color.							
Menu		System						Function	
Tella		оув. свш —	1	ECU informaton	Read DTC	Clear DTC	Read data stream	Actuation test	Special function
MU-X	Diesel engine	4JJ1-TC	_	√	√	√	√	4	Read and write injector code etc.
MU-X	Transmission	AT	-	-	√	√	√	√	Clear learning value
MU-X	Chassis	Anti-lock brake system	_	-	√	√	√	4	Clear the steering center position, Register th steering center position
MU-X	Chassis	Transfer case module	_	4	√	√	4	4	-
MU-X	Body	Immobilizer (BETA)	_	√	√	√	4	4	Procedure designs response key, Clear response key
MU-X	Body	PESS(Passive entry and start system)	_	√	√	√	-	√	-
MU-X	Body	Body control module	-	√	√	√	-	-	-
MU-X	Body	Instrument	_	√	-	-	-	-	-
MU-X	Body	SRS Airbag	-	√	√	√	-	-	_
YUSHENG series	YUSHENG (manual transmission)	Engine management system	Bosch diesel system	√	√	√	√	4	Read and write injector code etc.
YUSHENG series	YUSHENG (manual transmission)	Engine management system	Delphi Euro IV gasoline engine	√	√	√	4	√	Gear learning etc
YUSHENG series	YUSHENG (manual transmission)	Anti-lock brake	Bosch Anti-lock brake	√	√	√	4	√	Exhaust function etc.
YUSHENG series	YUSHENG (manual transmission)	Anti-lock brake	ABS9	√	√	√	4	√	-
YUSHENG series	YUSHENG (manual transmission)	Airbag	Continental Airbag	√	√	√	√	4	Reset ECU etc.
YUSHENG series	New YUSHENG (automatic transmission)	Engine management system	Bosch_EDC17	√	√	√	√	4	Read and write injector code etc.
YUSHENG series	New YUSHENG (automatic transmission)	Transmission system	ZF Transmission	√	√	√	√	-	Reset ECU etc.
YUSHENG series	New YUSHENG (automatic transmission)	Splitter system	Borg Warner Splitter	√	√	√	√	4	-
YUSHENG series	New YUSHENG (automatic transmission)	ESP	Bosch ESP	4	√	√	4	4	-
YUSHENG series	New YUSHENG (automatic transmission)	Gateway	-	4	√	√	4	-	-
YUSHENG series	New YUSHENG (automatic transmission)	PEPS	-	√	4	√	√	-	PEPS learning
YUSHENG series	New YUSHENG (automatic transmission)	Body controller	-	√	√	√	√	√	-
YUSHENG series	New YUSHENG (automatic transmission)	Instrument	-	√	√	√	√	4	-
YUSHENG series	New YUSHENG (automatic transmission)	Airbag	Continental Airbag	√	√	√	√	√	Reset ECU etc.
YUSHENG series	New YUSHENG (manual transmission)	Engine management system	Bosch diesel system	√	√	√	√	4	Read and write injector code etc.
YUSHENG series	New YUSHENG (manual transmission)	Engine management system	Delphi gasoline engine	√	√	√	√	4	Read and write injector code etc.
YUSHENG series	New YUSHENG (manual transmission)	ABS9	_	√	√	√	4	√	-
YUSHENG series	New YUSHENG (manual transmission)	Airbag	Continental Airbag	√	√	√	4	√	Reset ECU etc.
YUSHENG series	New YUSHENG (S350)	Gasoline-UMC-EMS	-	√	√	√	4	√	-
YUSHENG series	New YUSHENG (S350)	Diesel-Continental-EMS	-	√	√	√	4	_	
YUSHENG series	New YUSHENG (S350)	ZF-six-speed transmission -TCU	_	√	√	√	√	-	_
YUSHENG series	New YUSHENG (S350)	Bosch-Body stability control-ESP	-	√	√	√	4	4	-
YUSHENG series	New YUSHENG (S350)	Continental-Airbag-SRS	_	√	√	√	√	√	_
YUSHENG series	New YUSHENG (S350)	TungThih -Body controller -BCM	_	4	4	√	√	4	-
YUSHENG series	New YUSHENG (S350)	Visteon-Instrument-IC	_	√	√	√	4	4	-
YUSHENG series	New YUSHENG (S350)	Visteon-air conditioning -AC	_	4	4	√	√	_	-
YUSHENG series	New YUSHENG (S350)	Gasoline-Lear-PESP	_	4	4	√	√	_	-
YUSHENG series	New YUSHENG (S350)	Diesel-Lear-PEPS	_	4	4	√	√	-	-
YUSHENG series	New YUSHENG (S350)	BorgWarner-4WD system-TCCU	_	4	4	1	√	4	-
YUSHENG series	New YUSHENG (S350)	WHETRON -360° panoramic image-AVM (WEIQUAN)	_	4	4	√	√	-	Hardware reset, AVM after-sale calibration
YUSHENG series	New YUSHENG (S350)	WHETRON -360° panoramic image-AVM (RENESAS)	_	_	_	_	_	_	Automatic joint, Joint projection matrix backup Joint completed
YUSHENG series	New YUSHENG (S350)	East Joy Long-anti-clamp system - APM	-	4	4	1	√	4	Read-write configuration, Anti-clamp selflearning, Anti-clamp erase
YUSHENG series	YUSHENG (330)	Continental-Engine Control Module- EMS	_	√	4	√	4	4	-
YUSHENG series	YUSHENG (330)	Bosch-Body electronic stability system-ESP9	_	√	√	√	4	√	_
YUSHENG series	YUSHENG (330)	Continent/AVL-Automatic transmission-TCU		4	4	√	4	4	-
YUSHENG series	YUSHENG (330)	ZF-Electric power steering system- EPS	_	J	4	√	1	_	-
YUSHENG series	YUSHENG (330)	Bosch-Airbag-SRS		√	√	√		- √	-
YUSHENG series	YUSHENG (330)	Lear-Passive keyless entry system-		J	4	√	-		-
YUSHENG series	YUSHENG (330)	PESP TungThih -Body control module-BCM	-	, ,		· √	- √	-	-
YUSHENG series	YUSHENG (330)		-	<i>√</i>	√ √	√ √	1	7	
		Visteon—Instrument cluster-ICM	_				-		
YUSHENG series	YUSHENG (330)	WHETRON -360° panoramic image-AVM	-	√	4	√	4	4	-
YUSHENG series	YUSHENG (330)	WHETRON -Immobilizer system-IMMO	_	4	√	√	4	-	-
YUSHENG series	YUSHENG (330)	BAOLONG-Tire pressure Monitoring system-TPMS	-	√	√	√	√	-	-
YUSHENG series	YUSHENG (330)	New Electricity-Automatic air conditioning (high	-	√	√	√	√	4	-
YUSHENG series	YUSHENG (330)	HUAYANG-media(high configuration) - MP5	_	4	4	√	4	1	-
YUSHENG series	New YUSHENG (manual transmission)	Immobilizer system IMMO(exported to Chile)		4	√	√	4	_	
YUHU series	Engine management system	Bosch diesel system	_	4	√	√	4	4	Read and write injector code etc.
YUHU series	Engine management system	Delphi Euro IV gasoline engine		√	4	√	4	√	Gear learning etc
YUHU series	Anti-lock brake	Bosch Anti-lock brake	-	,		· √	· ·	· ·	Exhaust function etc.
		ABS9	-	√ ·	√ √	√ √	1	√ √	-
YUHU series	Anti-lock brake		-						B
YUHU series	Airbag	Continental Airbag	-	√	4	√	1	4	Reset ECU etc. Check key quantity, Match key, Match IMMO, Writ
YUHU series	TungThih anti-theft system	-	- PDY P. YYY	√	4	√	√	4	Check key quantity, Match key, Match IMMU, Write VIN code
Transit series	Engine management system	Delphi system	EFI Euro III gasoline engine with EOBD	√	√	√	√	4	Gear learning etc
Transit series	Engine management system	Delphi system	EFI Euro III gasoline engine	4	√	√	4	√	Reset ECU etc.
	+								-

Disgnostic List JMC_v8.90

			Disgnostic Disc							
	e system has this function									
 -: means that the land of the	e system does not have this function ast version, the new added function is	marked in red color.								
Menu	System			Function						
menu		System		BCU informaton	Read DTC	Clear DTC	Read data stream	Actuation test	Special function	
Transit series	Engine management system	Delphi system	EFI Euro III diesel engine 3.1	4	√	√	√	√	_	
Transit series	Engine management system	Delphi system	EFI Euro III diesel engine 3.2 upgrade	4	4	√	4	4	Read and write injector code etc.	
Transit series	Engine management system		EFI Euro II gasoline engine	4	4	√	√	-	-	
Transit series	Engine management system	Delphi system	Delphi gasoline	4	4	√	√	J	Gear learning etc	
Transit series	Engine management system	Delphi system Ford Transit 2.2L	engine (Euro V)	4	4	√	√	_	_	
Transit series	Engine management system	Ford Transit 2.4L	_	√	4	√	√	_	Read and write injector code etc.	
							√ √			
Transit series	Engine management system	Bosch Diesel engine Euro IV	=	4	4	√		√	Read and write injector code etc.	
Transit series	Body control module	Ford Transit 2.4L	_	4	4	√	√	-	-	
Transit series	Anti-lock brake	ABS1. 0	-	-	√	√	-	-	-	
Transit series	Anti-lock brake	Ford Transit 2.4L	_	√	4	√	√	-	ABS detection	
Transit series	Instrument system	Ford Transit 2.4L	=	4	4	√	√	-	-	
Transit series	Airbag	Ford Transit 2.4L	_	4	4	√	√	-	_	
Transit series	Parking brake system	Ford Transit 2.4L	=	-	√	√	√	-	_	
Transit series	Parking assist system	Ford Transit 2.4L	-	-	4	4	√	-	-	
Transit series	EGR system	-	-	-	4	√	√	-	-	
Baodian series	Bosch common rail_EDC16C39_self-	-	-	√	4	4	√	√	Read and write injector code	
Baodian series	recognition Gasoline engine(Mitsubishi electronic	_	_	4	· ·	· ·	√ .	· ·	-	
Baodian series	control system) Gasoline engine(Delphi Euro II		_	4	4	√ √	√ √	√ √		
	electronic control system) Gasoline engine(Delphi Euro III									
Baodian series	electronic control system) Diesel engine (Bosch Euro III	-	_	4	4	√	√	√	Gear learning etc	
Baodian series	electronic control system)	-	-	4	4	√	√	√	Read and write injector code etc.	
Baodian series	Bosch diesel (Euro IV)	-	_	4	√	√	√	-	Read and write injector code etc.	
Baodian series	Delphi gasoline engine(Euro V)	-	-	√	√	√	√	√	Gear learning etc	
Baodian series	Asia-Pacific ABS system	_	_	4	4	√	√	-	_	
Baodian series	East Joy Long airbag	-	-	4	4	4	4	-	_	
Baowei series	Bosch common rail_EDC16C39_self- recognition	_	_	4	4	√	√	√	Read and write injector code	
Baowei series	Gasoline engine (Mitsubishi electronic control system)	-	=	4	√	√	√	J	=	
Baowei series	Gasoline engine((Delphi Euro II	_	_	4	4	√	4	√	_	
Baowei series	electronic control system) Gasoline engine((Delphi Euro III		_	4	4	√	√	4	Gear learning etc	
	electronic control system) Diesel engine (Bosch Euro III			√	1	1	√ √	√	-	
Baowei series	electronic control system)								Read and write injector code etc.	
Baowei series	Bosch diesel (Euro IV)	-	-	4	4	√	√	-	Read and write injector code etc.	
Baowei series	Delphi gasoline engine(Euro V)		_	4	4	√	√	√	Gear learning etc	
Baowei series	Asia-Pacific ABS system	-	_	4	4	√	√	-	-	
Baowei series	East Joy Long airbag	-	=	4	4	√	√	-	-	
Light-duty truck series	N800 BEV	VCU vehicle controller	_	4	√	√	√	√	Write VIN, Write operator code, Pedal position self-learning	
Light-duty truck series	N800 BEV	MCU motor controller	=	4	4	√	√	-	Write VIN	
Light-duty truck series	N800 BEV	OBC on-board charger	-	4	4	4	√	-	Write VIN	
Light-duty truck series	N800 BEV	BMS high voltage battery management system	=	4	√	√	√	J	Write VIN	
Light-duty truck	N800 BEV	DCDC direct-current-directcurrent	_	4	4	4	√	-	Write VIN	
series Light-duty truck	N800 BEV	ABS anti Lock brake system	_	4	4	√	√	_	-	
series Light-duty truck					· .		_	√	W-: UTN	
series Light-duty truck	N800 BEV	SCU shift gear		4					Write VIN	
series Light-duty truck	N800 BEV	BCM Body Control Module	_	4	4	√	√	√	Write VIN, Telecontrol learning, Hardware rese	
series Light-duty truck	N800 BEV	ICM Instrument cluster	_	4	4	√	√	√	Write VIN, Reset ECU	
series	N800 BEV	ACM(air conditioning panel)	-:	1	4	√	√	-	Write VIN	
Light-duty truck series	N800 BEV	TBOX	-	4	√	√	√	-	Write VIN	
Light-duty truck series	N800 BEV	GW Gateway Controller	_	4	4	4	√	-	Write VIN	
Light-duty truck series	N800	N800 KAIRUI with Bosch system		4	4	√	√	√	Read and write injector code etc.	
Light-duty truck series	N800	Asia-Pacific ABS system	_	4	4	√	√	-	-	
Light-duty truck series	N800	VIE air brake ABS		4	4	√	4	4	-	
Light-duty truck	N800	N800 KAIRUI with Bosch system(4D30	-	√	4	4	J	√	-	
series Light-duty truck	N800	IV) N800 KAIRUI with Bosch system(PUMA	_	· √		· √	√ .	√	_	
series Light-duty truck	N800	IV) N800 KAIRUI with Bosch system(PUMA	_	4	1	√ √	√ √	<i>1</i>	_	
series Light-duty truck		V) N800 KAIRUI with Bosch system(4D30								
series Light-duty truck	N800	V) Weifu Lida (Non-gas-assisted	_	4	4	√	√	-	-	
series	N800	SCR system)	-	√	4	√	√	√	-	
Light-duty truck series	N800	Weifu Lida (Gas-assisted SCR system)	_	4	1	√	√	√	-	
Light-duty truck series	N600HD5	N600EDC17C81	-	√	4	√	√	√	-	
Light-duty truck series	N601	JoyLong Airbag KD5.2	_	4	4	4	√	-	_	
Light-duty truck series	N601	Asia-Pacific ABS system	-	4	4	√	√	-	-	
Light-duty truck series	N900	N900 Kaiwei (Chaoyang Diesel Engine)	Diagnosis of static data	4	4	√	√	4	-	
Light-duty truck	N900	N900 Kaiwei (Chaoyang Diesel	Diagnosis of dynamic data	-	_	-	√	4	-	
series Light-duty truck	N900	Engine) N900 Kaiwei (Yuchai Engine)	Diagnosis of static data	4	4	√	√ .	· .	-	
series	1	(January States Guid	<u> </u>	· .	•			l	

Disgnostic List JMC_v8.90

1. J : means that the system has this function 2 : means that the system does not have this function 3. compared with the last version, the new added function is marked in red color.											
	System			Function							
Menu				ECU informaton	Read DTC	Clear DTC	Read data stream	Actuation test	Special function		
ight-duty truck series	N900	N900 Kaiwei (Yuchai Engine)	Diagnosis of dynamic data	-	-	-	7	√	-		
ight-duty truck series		N900 KAIWEI with WuXi WEIFU SCR system	-	-	4	√	7	-	-		
ight-duty truck series	N800HP	Body control module-BCM	-	4	√	√	4	4	Telecontrol learning, Erase all remote controllers, Hardware reset, Write VIN		
Light-duty truck series	N800HP	VIE air brake ABS	-	√	4	√	√	J	Input ECU Number, Input VIN code, Input vehicle model code		
ight-duty truck series	Beijing heavy China V TBOX	-	-	4	4	√	4	-	Write VIN		
ight-duty truck series	493 engine Euro IV	-	-	√	4	√	4	√	Read and write injector code etc.		
Light-duty truck series	Bosch common rail_EDC16C39_self- recognition	-	-	√	4	√	4	√	Read and write injector code		
ight-duty truck series	Delphi diesel Euro III system	-	-	√	4	√	4	√	Read and write injector code etc.		
ight-duty truck series	Diesel engine system(Bosch diesel Euro III)	=	-	4	4	√	7	√	Read and write injector code etc.		
ight-duty truck series	Delphi engine system	-	-	-	4	√	4	√	-		
MC Light-duty ehicles	Qi Ling Series	Wolff EDC17CV54_CAN system(493 Light-duty truck)	=	√	4	√	4	-	Read and write injector code etc.		
MC Light-duty ehicles	Qi Ling Series	Delphi gasoline engine(4G22B)	=	√	4	√	√	-	Gear learning etc		
MC Light-duty phicles	Qi Ling Series	Bosch diesel(4JB1)	=	√	4	√	√	√	Read and write injector code etc.		
MC Light-duty phicles	Qi Ling Series	JE493ZLQ5D type WIT (China V) engine		4	√	√	7	4	-		
		Electronically controlled dispensing pump Euro III	-	-	4	√	-	-	-		