

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
Read out vehicle data													
VIN													
1 Series	E81/E82/E87/E88	Drive	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-			
1 Series	E81/E82/E87/E88	Drive	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	-			
1 Series	E81/E82/E87/E88	Drive	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Chassis	AL [Active steering]	✓	✓	✓	✓	-	✓	-			
1 Series	E81/E82/E87/E88	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	-			
1 Series	E81/E82/E87/E88	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	CCC-A [Applications]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	ANT [Aerial tuner]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	ASK [Audio system controller]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	CD-GW/M-ASK-GW [Gateway -CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	DWA [Antitheft alarm system]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	FZD [Function Centre, Roof]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	SGM-ZGM [Safety and Gateway Module (ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	RLS [Rain/light solar sensor]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-			
1 Series	E81/E82/E87/E88	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	-	-	-			
1 Series	E81/E82/E87/E88	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-			

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	1 Series	E81/E82/E87/E88	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	1 Series	E81/E82/E87/E88	Body	TCU [Telematic Control unit - TEL/ULF/ULF-SBX]	✓	✓	✓	✓	✓	-	-	
	1 Series	E81/E82/E87/E88	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	1 Series	E81/E82/E87/E88	Quick test	[Start vehicle test]								
	1 Series	E81/E82/E87/E88	Quick test	[Delete fault memory]								
	1 Series	E81/E82/E87/E88	Service function	Maintenance CBS reset								
	1 Series	E81/E82/E87/E88	Service function	Maintenance CBS correct								
	1 Series	E81/E82/E87/E88	Service function	Adjustment, steering-angle sensor								
	1 Series	E81/E82/E87/E88	Service function	Tyre air pressure warning lamp reset								
	1 Series	F20	Drive	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	1 Series	F20	Drive	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Drive	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	1 Series	F20	Drive	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	1 Series	F20	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	-	✓	-	
	1 Series	F20	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	TRSVC [All round view camera]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	FCON [Rear Compartment controller]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	1 Series	F20	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	1 Series	F20	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	1 Series	F20	Quick test	[Start vehicle test]								
	1 Series	F20	Quick test	[Delete fault memory]								
	1 Series	F20	Service function	Maintenance CBS reset Software re								
	1 Series	F20	Service function	Maintenance CBS correct								
	1 Series	F20	Service function	EMF [Parking brake]								
	2 Series	F22	Drive	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F22	Drive	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Drive	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F22	Drive	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Drive	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Drive	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F22	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F22	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	-	-	-	
	2 Series	F22	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	-	-	-	
	2 Series	F22	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F22	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F22	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	TRSVC [All round view camera]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	HKL [Automatic luggage compartment lid actuation]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	2 Series	F22	Body	CHAS [Regulated different lock]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	SEC1 [Supplementary control unit 1]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	CANSIN [Anti theft alarm system]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F22	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	2 Series	F22	Quick test	[Start vehicle test]								
	2 Series	F22	Quick test	[Delete fault memory]								
	2 Series	F22	Service function	Maintenance CBS reset Software re								
	2 Series	F22	Service function	Maintenance CBS correct								
	2 Series	F22	Service function	EMF [Parking brake]								
	2 Series	F22	Service function	Brake Pad Change								
	2 Series	F45	Drive	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F45	Drive	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	2 Series	F45	Drive	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F45	Drive	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Drive	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Drive	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F45	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F45	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	-	-	-	
	2 Series	F45	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	-	-	-	
	2 Series	F45	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F45	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F45	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	TRSV [All round view camera]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	HKL [Automatic luggage compartment lid actuation]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	CHAS [Regulated different lock]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	SEC1 [Supplementary control unit 1]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	CANSIN [Anti_theft alarm system]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	2 Series	F45	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	2 Series	F45	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	2 Series	F45	Quick test	[Start vehicle test]								
	2 Series	F45	Quick test	[Delete fault memory]								
	2 Series	F45	Service function	Maintenance	CBS reset	Software re						
	2 Series	F45	Service function	Maintenance	CBS correct							
	2 Series	F45	Service function	EMF [Parking brake]								
	2 Series	F45	Service function	Brake Pad Change								
	3 Series	E30	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	3 Series	E30	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	3 Series	E30	Drive	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Drive	GR [Cruise Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Drive	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	3 Series	E30	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	Remark
	3 Series	E30	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Quick test	[Start vehicle test]	✓	✓	✓	✓	✓	-	-	
	3 Series	E30	Quick test	[Delete fault memory]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	3 Series	E36	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	3 Series	E36	Drive	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Drive	GR [Cruise control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Drive	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	3 Series	E36	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	SRS [Safety airbag system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	
	3 Series	E36	Quick test	[Start vehicle test]								
	3 Series	E36	Quick test	[Delete fault memory]								
	3 Series	E46	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	✓	
	3 Series	E46	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	✓	
	3 Series	E46	Drive	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Drive	GR [Cruise control]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	3 Series	E46	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Chassis	LEW [Adjustment, steering-angle sensor]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	BIT [Basic Interface Telephone]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	BM [On-board monitor]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Body	LSZ/LCM [Light switch center]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Body	MFL [Multi-function steering wheel]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Body	SMB [Entrance aid, passenger]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	SMF [Seat memory, driver]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Body	SPMBT [Mirror memory, passenger]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	SPMFT [Mirror memory, driver]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	SRS [Safety airbag system]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Body	SZM [Switching center, center console]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	3 Series	E46	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E46	Quick test	[Start vehicle test]								
	3 Series	E46	Quick test	[Delete fault memory]								
	3 Series	E46	Service function	Maintenance								
	3 Series	E46	Service function	Reset service interval indicator								
	3 Series	E46	Service function	Adjustment, steering-angle sensor								
	3 Series	E46	Service function	Tyre air pressure warning lamp reset								
	3 Series	E46	Car key memory	DME - Digital Motor Electronics								
	3 Series	E46	Car key memory	EGS - Electronic Gearbox Control								
	3 Series	E46	Car key memory	EWS - Electronic Car Immobilisation System								
	3 Series	E46	Car key memory	ABS - Anti-lock Braking System with ASC/DSC								
	3 Series	E46	Car key memory	A/C - Heater and Automatic Conditioner Control								
	3 Series	E46	Car key memory	SRS - Supplemental Restraint System								
	3 Series	E46	Car key memory	IKE - Instrument Cluster Electronics								
	3 Series	E46	Car key memory	LCM - Light Check Module								
	3 Series	E46	Car key memory	ZKE - Central Body Electronic								
	3 Series	E46	Car key memory	PDC - Park Distance Control								
	3 Series	E46	Car key memory	AIC - Automatic Interval Control								
	3 Series	E46	Car key memory	RAD - Radio								
	3 Series	E46	Car key memory	TEL - Car Telephone								

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
	3 Series	E46	Car key memory	SZM - Switching Center, Centre Console									
	3 Series	E46	Car key memory	LEW - Steering-Angle Sensor									
	3 Series	E46	Car key memory	SHD - Sliding/Tilting Sunroof									
	3 Series	E46	Car key memory	SMF - Seats Memory, Driver									
	3 Series	E46	Car key memory	EKP - Electric Fuel Pump									
	3 Series	E46	Recoding										
	3 Series	E90/E91/E92/E93	Drive	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	✓	✓	
	3 Series	E90/E91/E92/E93	Drive	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	✓	✓	
	3 Series	E90/E91/E92/E93	Drive	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Drive	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Drive	VTC [Valvetronic]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Drive	VTC2 [Valvetronic 2]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Drive	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-		
	3 Series	E90/E91/E92/E93	Chassis	ARS [Dynamic Drive]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	ABS [Antilock brake system - -DSC]	✓	✓	✓	✓	✓	✓	✓	✓	
	3 Series	E90/E91/E92/E93	Chassis	EDCSHL [Damper satellite, rear left]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	EDCSHR [Damper satellite, rear right]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	EDCSVL [Damper satellite, front left]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	EDCSVR [Damper satellite, front right]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-		
	3 Series	E90/E91/E92/E93	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	LDM [Longitudinal Dynamics Management]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Chassis	EDC [Electronic Damper Control]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	CCC-A [Applications]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	ANT [Aerial tuner]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	ASK [Audio system controller]	✓	✓	✓	✓	✓	-	✓		
	3 Series	E90/E91/E92/E93	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-		
	3 Series	E90/E91/E92/E93	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	✓		
	3 Series	E90/E91/E92/E93	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-		

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	3 Series	E90/E91/E92/E93	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	DVDC [DVD Changer]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	DWA [Antitheft alarm system]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	FD [Rear-cabin display]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	FKA [Rear heater/air conditioning]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	FRM [Footwell module]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	FZD [Function Center, Roof]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E90/E91/E92/E93	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	IBOC [Digital tuner US]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E90/E91/E92/E93	Body	SGM-ZGM [Safety and Gateway Module (ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	KHI [Headphones module]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	RFK [Reversing camera]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	RLS [Rain/Light solar sensor]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	TCU [Transmission Control unit - TEL/ULF/ULF-SBX]	✓	✓	✓	✓	✓	-	✓	
	3 Series	E90/E91/E92/E93	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	3 Series	E90/E91/E92/E93	Quick test	[Start vehicle test]								
	3 Series	E90/E91/E92/E93	Quick test	[Delete fault memory]								
	3 Series	E90/E91/E92/E93	Service function	Maintenance								
				CBS reset								
	3 Series	E90/E91/E92/E93	Service function	Maintenance								
				CBS correct								
	3 Series	E90/E91/E92/E93	Service function	Adjustment, steering-angle sensor								
	3 Series	E90/E91/E92/E93	Service function	EMF [Parking brake]								
	3 Series	E90/E91/E92/E93	Service function	Tyre air pressure warning lamp reset								
	3 Series	E90/E91/E92/E93	Programming/Coding	ZGM/SGM/JBBF [Safety and Gateway Module]								

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
	3 Series	E90/E91/E92/E93	Programming/Coding	SIM/SGM/ACSM [Safety And Information]									
	3 Series	E90/E91/E92/E93	Programming/Coding	CCC-ASK [Audio system controller]									
	3 Series	E90/E91/E92/E93	Programming/Coding	CAS [Car Access System]									
	3 Series	E90/E91/E92/E93	Programming/Coding	TEL [Telephone]									
	3 Series	E90/E91/E92/E93	Programming/Coding	FZD [Functional center roof]									
	3 Series	E90/E91/E92/E93	Programming/Coding	KBM [Body Basic Module]									
	3 Series	E90/E91/E92/E93	Programming/Coding	INSTR [Instrument cluster]									
	3 Series	E90/E91/E92/E93	Programming/Coding	M-ASK-GW [Gateway]									
	3 Series	E90/E91/E92/E93	Programming/Coding	MMI/CCC [MMI Audio System Controller]									
	3 Series	E90/E91/E92/E93	Programming/Coding	FAS [Seat Module Front]									
	3 Series	E90/E91/E92/E93	Programming/Coding	BFS [Seat Module Back]									
	3 Series	E90/E91/E92/E93	Programming/Coding	KLIMA [Climate Module]									
	3 Series	E90/E91/E92/E93	Programming/Coding	ABS-DSC [Dynamic Stability Control]									
	3 Series	E90/E91/E92/E93	Programming/Coding	oc3 1(Seat airbag)									
	3 Series	E90/E91/E92/E93	Programming/Coding	Seat air battery									
	3 Series	E90/E91/E92/E93	Programming/Coding	Automatic close window									
	3 Series	F30/F31/F34/F35	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-		
	3 Series	F30/F31/F34/F35	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-		
	3 Series	F30/F31/F34/F35	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	-	-	-		
	3 Series	F30/F31/F34/F35	Chassis	SME [Accumlator management electronics]	✓	✓	✓	✓	-	-	-		
	3 Series	F30/F31/F34/F35	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-		
	3 Series	F30/F31/F34/F35	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-		
	3 Series	F30/F31/F34/F35	Chassis	ACC [ACC Full range redar]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-		
	3 Series	F30/F31/F34/F35	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-		
	3 Series	F30/F31/F34/F35	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Body	TRSV [All round view camera]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-		
	3 Series	F30/F31/F34/F35	Body	SCR [Selective Catalytic Reduction]	✓	✓	✓	✓	✓	-	-		

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	3 Series	F30/F31/F34/F35	Body	HKL [Automatic luggage compartment lid actuation]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	GHAS [Regulated different lock]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	SEC1 [Supplementary control unit]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	CANSIN [Anti_theft alarm system]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	3 Series	F30/F31/F34/F35	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	3 Series	F30/F31/F34/F35	Quick test	[Start vehicle test]								
	3 Series	F30/F31/F34/F35	Quick test	[Delete fault memory]								
	3 Series	F30/F31/F34/F35	Service function	Maintenance								
				CBS reset								
	3 Series	F30/F31/F34/F35	Service function	Maintenance								
				CBS correct								
	3 Series	F30/F31/F34/F35	Service function	EMF [Parking brake]								
	3 Series	F80	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	3 Series	F80	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	3 Series	F80	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	3 Series	F80	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	-	-	-	
	3 Series	F80	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	-	-	-	
	3 Series	F80	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	3 Series	F80	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	3 Series	F80	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	3 Series	F80	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	3 Series	F80	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	TRSV [All round view camera]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	SCR [Selective Catalytic Reduction]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	HKL [Automatic luggage compartment lid actuation]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	GHAS [Regulated different lock]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	SEC1 [Supplementary control unit]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	CANSIN [Anti_theft alarm system]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	3 Series	F80	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	3 Series	F80	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	3 Series	F80	Quick test	[Start vehicle test]								
	3 Series	F80	Quick test	[Delete fault memory]								
	3 Series	F80	Service function	Maintenance								
	3 Series	F80	Service function	Maintenance								
	3 Series	F80	Service function	EMF [Parking brake]								
	4 Series	F32	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	4 Series	F32	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	4 Series	F32	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Driver	VTG [Transfer case]	✓	✓	✓	✓	-	-	-	
	4 Series	F32	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	-	-	-	
	4 Series	F32	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	-	-	-	
	4 Series	F32	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	4 Series	F32	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	4 Series	F32	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	4 Series	F32	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	Remark
	4 Series	F32	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	TRSVL [All round view camera]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	HKL [Automatic luggage compartment lid actuation]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	GHAS [Regulated different lock]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	CVM [Convertible Top Module]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	SEC1 [Supplementary control unit]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	CANSIN [Anti_theft alarm system]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	4 Series	F32	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	4 Series	F32	Quick test	[Start vehicle test]								

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
	4 Series	F32	Quick test	[Delete fault memory]									
	4 Series	F32	Service function	Maintenance CBS reset									
	4 Series	F32	Service function	Maintenance CBS correct									
	4 Series	F32	Service function	EMF [Parking brake]									
	4 Series	F32	Service function	Brake Pad Change									
	5 Series	E28	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-		
	5 Series	E28	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-		
	5 Series	E28	Drive	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Drive	GR [Cruise control]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Drive	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-		
	5 Series	E28	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-		
	5 Series	E28	Quick test	[Start vehicle test]									
	5 Series	E28	Quick test	[Delete fault memory]									
	5 Series	E34	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-		
	5 Series	E34	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-		
	5 Series	E34	Drive	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-		
	5 Series	E34	Drive	GR [Cruise control]	✓	✓	✓	✓	✓	-	-		
	5 Series	E34	Drive	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-		
	5 Series	E34	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-		

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	5 Series	E34	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	5 Series	E34	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	
	5 Series	E34	Quick test	[Start vehicle test]								
	5 Series	E34	Quick test	[Delete fault memory]								
	5 Series	E39	Drive	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	✓	
	5 Series	E39	Drive	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	5 Series	E39	Drive	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Drive	GR [Cruise control]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	5 Series	E39	Chassis	LEW [Adjustment, steering-angle sensor]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	AIC [Automatic Interval Control]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	BIT [Basic Interface Telephone]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	BM [On-board monitor]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	MFL [Multi-function steering wheel]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	NAV [Navigation system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	✓	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	5 Series	E39	Body	SES [Language-input system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	SZM [Switching center, center console]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	VID [Video Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E39	Body	DSP [Digital Sound Processor]	✓	✓	✓	✓	✓	-	-	
	5 Series	E39	Quick test	[Start vehicle test]								
	5 Series	E39	Quick test	[Delete fault memory]								
	5 Series	E39	Service function	Maintenance Reset service interval indicator								
	5 Series	E39	Service function	Adjustment, steering-angle sensor								
	5 Series	E39	Car key memory	DME - Digital Motor Electronics								
	5 Series	E39	Car key memory	EGS - Electronic Gearbox Control								
	5 Series	E39	Car key memory	EWS - Electronic Car Immobilisation System								
	5 Series	E39	Car key memory	LEW - Steering-Angle Sensor								
	5 Series	E39	Car key memory	A/C - Heater and Automatic Conditioner Control								
	5 Series	E39	Car key memory	SRS - Supplemental Restraint System								
	5 Series	E39	Car key memory	IKE - Instrument Cluster Electronics								
	5 Series	E39	Car key memory	LCM - Light Check Module								
	5 Series	E39	Car key memory	ZKE - Central Body Electronic								
	5 Series	E39	Car key memory	PDC - Park Distance Control								
	5 Series	E39	Car key memory	AIC - Automatic Interval Control								
	5 Series	E39	Car key memory	RAD - Radio								
	5 Series	E39	Car key memory	TEL - Car Telephone								
	5 Series	E39	Car key memory	MID - Multi-Information Display								
	5 Series	E39	Recoding									
	5 Series	E60/E61	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	✓	
	5 Series	E60/E61	Driver	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	✓	
	5 Series	E60/E61	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Chassis	ACC [Active Cruise Control]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	5 Series	E60/E61	Chassis	ARS [Dynamic Drive]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	✓	
	5 Series	E60/E61	Chassis	EDC [Damper Control]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	5 Series	E60/E61	Chassis	LDM [Longitudinal Dynamics Management]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	AFS [Active front steering]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	ALBBF [Active backrest width, front passenger]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	ALBFA [Active backrest width, driver]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	CCC-A [Applications]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	ANT [Aerial tuner]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	ASK [Audio system controller]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	DVD-C [DVD Changer]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	DWA [Antitheft alarm system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	FBZM [Rear compartment, control centre, center co	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	FD [Rear-cabin display]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	FRM [Footwell module]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	KHI [Headset interface]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	LM [Light module]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	PM [Power module]	✓	✓	✓	✓	✓	✓	-	
	5 Series	E60/E61	Body	NVE [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	RLS [Rain/Light Sensor]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	RLSS [Rain/Light solar sensor]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	AIRBAG-SBSL [Satellite, B-pillar, left]	✓	✓	✓	✓	✓	-	✓	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	5 Series	E60/E61	Body	AIRBAG-SBSR [Satellite, B-pillar, right]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	SFZ [Satellite vehicle center]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	SGM-ZGM [Safety and Gateway Module(ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	SHZH [Independent/auxiliary heater]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	SVS [Language processing system]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	SZL [Switch center, steering column]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	SZM/BZM [Switching center, center console]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	TCU [Telematic Control unit]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	TLC [Lane Departure Warning]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	AIRBAG-STVR [Door module, front passenger]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	AIRBAG-STVL [Door module, driver]	✓	✓	✓	✓	✓	-	✓	
	5 Series	E60/E61	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	E60/E61	Quick test	[Start vehicle test]								
	5 Series	E60/E61	Quick test	[Delete fault memory]								
	5 Series	E60/E61	Service function	Maintenance								
	5 Series	E60/E61	Service function	Maintenance								
	5 Series	E60/E61	Service function	Adjustment, steering-angle sensor								
	5 Series	E60/E61	Service function	Tyre air pressure warning lamp reset								
	5 Series	E60/E61	Service function	Locking and security functions								
	5 Series	E60/E61	Programming/Coding	CAS [Car Access System]								
	5 Series	E60/E61	Programming/Coding	KBM [Body Basic Module]								
	5 Series	E60/E61	Programming/Coding	KLIMA [Climate Module]								
	5 Series	E60/E61	Programming/Coding	INSTR [Instrument cluster]								
	5 Series	E60/E61	Programming/Coding	LM [Light Module]								
	5 Series	E60/E61	Programming/Coding	RLS [Rain/Light Sensor]								
	5 Series	E60/E61	Programming/Coding	AIRBAG-SBSL [Satellite, B-pillar, left]								
	5 Series	E60/E61	Programming/Coding	AIRBAG-SBSR [Satellite, B-pillar, right]								
	5 Series	E60/E61	Programming/Coding	SFZ [Satellite vehicle center]								
	5 Series	E60/E61	Programming/Coding	ACSM/SRS [Crash Safety Module]								
	5 Series	E60/E61	Programming/Coding	AIRBAG-TMFA [Door module, driver]								
	5 Series	E60/E61	Programming/Coding	AIRBAG-TMBF [Door module, front passenger]								
	5 Series	E60/E61	Programming/Coding	SZL [Switch center steering column]								

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
	5 Series	E60/E61	Programming/Coding	TEL [Telephone]									
	5 Series	E60/E61	Programming/Coding	ZGM [Safety Gateway Module]									
	5 Series	E60/E61	Programming/Coding	CID [Central Info Display]									
	5 Series	E60/E61	Programming/Coding	BZM [Base Control Center]									
	5 Series	E60/E61	Programming/Coding	FLA [Full Beam Assistent]									
	5 Series	E60/E61	Programming/Coding	CCC-BO [User interface]									
	5 Series	E60/E61	Programming/Coding	PDC [Park Distance Control]									
	5 Series	E60/E61	Programming/Coding	SHD [Multi Drive Sliding]									
	5 Series	F07	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-		
	5 Series	F07	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-		
	5 Series	F07	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-		
	5 Series	F07	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-		
	5 Series	F07	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	HSR [Rear-axle slip-angle control]	✓	✓	✓	✓	✓	✓	-		
	5 Series	F07	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-		
	5 Series	F07	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-		
	5 Series	F07	Chassis	RKVL/EDCSVL [Damper satellite, front left]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	RKVL/EDCSVR [Damper satellite, front right]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	RKVL/EDCSHL [Damper satellite, rear left]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Chassis	RKVL/EDCSHR [Damper satellite, rear right]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	JBE/JBBF [Junction-box electronics]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	TRSVC [All round view camera]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-		
	5 Series	F07	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-		

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	5 Series	F07	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	NIVI [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	ECALL [ComBox emergency	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	FD [Rear compartment display]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	FD2 [Rear compartment display 2]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F07	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Body	AC2 [Air conditioning system - IHKA2]	✓	✓	✓	✓	✓	-	-	
	5 Series	F07	Quick test	[Start vehicle test]								
	5 Series	F07	Quick test	[Delete fault memory]								
	5 Series	F07	Service function	Maintenance								
				CBS reset								
	5 Series	F07	Service function	Maintenance								
				CBS correct								
	5 Series	F07	Service function	EMF [Parking brake]								
	5 Series	F10/F11/F18	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F10/F11/F18	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	5 Series	F10/F11/F18	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F10/F11/F18	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	-	-	-	
	5 Series	F10/F11/F18	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F10/F11/F18	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F10/F11/F18	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	HSR [Rear-axle slip-angle control]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F10/F11/F18	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F10/F11/F18	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F10/F11/F18	Chassis	RKVL/EDCSVL [Damper satellite, front left]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	RKVL/EDCSVR [Damper satellite, front right]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	RKVL/EDCSHL [Damper satellite, rear left]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Chassis	RKVL/EDCSHR [Damper satellite, rear right]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	JBE/JBBF [Junction-box electronics]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	TRSVC [All round view camera]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	SCR [Selective catalytic reduct	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	HKL [Automatic luggage compartment lid actuation]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	GHAS [Regulated differential lock]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	CVM [Convertible-top Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	TBX [Touchbox]<	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	EME2 [Electrical Machine Electronics 2]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	5 Series	F10/F11/F18	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	SEC [Supplementary control unit]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	NIVI [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	FCON [Rear Compartment controller]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	FD [Rear compartment display]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	FD2 [Rear compartment display 2]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	5 Series	F10/F11/F18	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Body	AC2 [Air conditioning system - IHKA2]	✓	✓	✓	✓	✓	-	-	
	5 Series	F10/F11/F18	Quick test	[Start vehicle test]								
	5 Series	F10/F11/F18	Quick test	[Delete fault memory]								
	5 Series	F10/F11/F18	Service function	Maintenance								
	5 Series	F10/F11/F18	Service function	Maintenance								
	5 Series	F10/F11/F18	Service function	EMF [Parking brake]								
	6 Series	E24	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	6 Series	E24	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	6 Series	E24	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Driver	GR [Cruise control]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	6 Series	E24	Driver	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	6 Series	E24	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	
	6 Series	E24	Quick test	[Start vehicle test]								
	6 Series	E24	Quick test	[Delete fault memory]								
	6 Series	E63/E64	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	6 Series	E63/E64	Driver	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	-	
	6 Series	E63/E64	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Driver	VTC [Valvetronic]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Driver	VTC2 [Valvetronic 2]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Chassis	ACC2 [Active Cruise Control 2]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	6 Series	E63/E64	Chassis	ARS [Dynamic Drive]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	-	
	6 Series	E63/E64	Chassis	EDC [Damper Control]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Chassis	LDM [Longitudinal Dynamics Management]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	AFS [Active front steering]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	6 Series	E63/E64	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	CCC-A [Applications]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	ANT [Aerial tuner]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	ASK [Audio system controller]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	DVDC [DVD Changer]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	DWA [Antitheft alarm system]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	FBZM [Rear compartment, control centre, center console]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	IBOC [Digital tuner US]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	FRM [Footwell module]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	LM2 [Light Module 2]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	PM [Power module]	✓	✓	✓	✓	✓	✓	-	
	6 Series	E63/E64	Body	NVE [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	RLS [Rain/Light Sensor]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	AIRBAG-SBSL [Satellite, B-pillar, left]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	AIRBAG-SBSR [Satellite, B-pillar, right]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SFZ [Satellite vehicle center]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SGM-ZGM [Safety and Gateway Module (ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SHZH [Independent/auxiliary heater]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	6 Series	E63/E64	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SVS [Language processing system]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	SZM [Switching center, centre console]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	TCU [Telematic Control unit]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	TLC [Lane Departure Warning]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	AIRBAG-STVR [Door module, front passenger]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	AIRBAG-STVL [Door module, driver]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	6 Series	E63/E64	Quick test	[Start vehicle test]								
	6 Series	E63/E64	Quick test	[Delete fault memory]								
	6 Series	E63/E64	Service function	Maintenance								
	6 Series	E63/E64	Service function	Maintenance								
	6 Series	E63/E64	Service function	Adjustment, steering-angle sensor								
	6 Series	E63/E64	Service function	Tyre air pressure warning lamp reset								
	6 Series	F06/F12/F13	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	6 Series	F06/F12/F13	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	6 Series	F06/F12/F13	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	-	-	-	
	6 Series	F06/F12/F13	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	6 Series	F06/F12/F13	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	6 Series	F06/F12/F13	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Chassis	HSR [Rear-axle slip-angle control]	✓	✓	✓	✓	✓	✓	-	
	6 Series	F06/F12/F13	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	6 Series	F06/F12/F13	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	6 Series	F06/F12/F13	Chassis	RKVL/EDCSVL [Damper satellite, front left]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Chassis	RKVL/EDCSVR [Damper satellite, front right]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Chassis	RKVL/EDCSHL [Damper satellite, rear left]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	6 Series	F06/F12/F13	Chassis	RKVL/EDCSHR [Damper satellite, rear right]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	JBE/JBBF [Junction-box electronics]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	TRSVC [All round view camera]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	SCR [Selective catalytic reduction]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	HKL [Automatic luggage compartment lid actuation]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	GHAS [Regulated differential lock]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	CVM [Convertible-top Module]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	EME2 [Electrical Machine Electronics 2]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	SEC [Supplementary control unit]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	NIVI [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	FCON [Rear Compartment controller]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	6 Series	F06/F12/F13	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	FD [Rear compartment display]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	FD2 [Rear compartment display 2]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	6 Series	F06/F12/F13	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Body	AC2 [Air conditioning system - IHKA2]	✓	✓	✓	✓	✓	-	-	
	6 Series	F06/F12/F13	Quick test	[Start vehicle test]								
	6 Series	F06/F12/F13	Quick test	[Delete fault memory]								
	6 Series	F06/F12/F13	Service function	Maintenance								
	6 Series	F06/F12/F13	Service function	Maintenance								
	6 Series	F06/F12/F13	Service function	EMF [Parking brake]								
	7 Series	E23	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	7 Series	E23	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	7 Series	E23	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Driver	GR [Cruise control]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Driver	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	7 Series	E23	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	7 Series	E23	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function								
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	Remark	
Diagnosis, Basic features	7 Series	E23	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-		
	7 Series	E23	Quick test	[Start vehicle test]									
	7 Series	E23	Quick test	[Delete fault memory]									
	7 Series	E32	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-		
	7 Series	E32	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-		
	7 Series	E32	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Driver	GR [Cruise control]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Driver	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Chassis	ABS [Antilock brake]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-		
	7 Series	E32	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	✓		
	7 Series	E32	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-		
	7 Series	E32	Quick test	[Start vehicle test]									
	7 Series	E32	Quick test	[Delete fault memory]									
	7 Series	E38	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	✓	-	
	7 Series	E38	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	✓	-	
	7 Series	E38	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	✓	-	-	
7 Series	E38	Driver	GR [Cruise control]	✓	✓	✓	✓	✓	✓	-	-		
7 Series	E38	Driver	EML [Electronic throttle]	✓	✓	✓	✓	✓	✓	-	-		
7 Series	E38	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	-	-		
7 Series	E38	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	✓	-		

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	7 Series	E38	Chassis	LEW [Adjustment, steering-angle sensor]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	AIC [Automatic Interval Control]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	BIT [Basic Interface Telephone]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	BM [On-board monitor]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E38	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E38	Body	MFL [Multi-function steering wheel]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	NAV [Navigation system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E38	Body	SES [Language-input system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	SZM [Switching center, center console]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	VID [Video Module]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E38	Body	DSP [Digital Sound Processor]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Body	FGB [Rear Compartment blower]	✓	✓	✓	✓	✓	-	-	
	7 Series	E38	Quick test	[Start vehicle test]								
	7 Series	E38	Quick test	[Delete fault memory]								
	7 Series	E38	Service functions	Maintenance								
	7 Series	E38	Service functions	Reset service interval indicator								
	7 Series	E38	Service functions	Adjustment, steering-angle sensor								
	7 Series	E38	Car key memory	DME - Digital Motor Electronics								
	7 Series	E38	Car key memory	EGS - Electronic Gearbox Control								
	7 Series	E38	Car key memory	EWS - Electronic Car Immobilisation System								
	7 Series	E38	Car key memory	LEW - Steering-Angle Sensor								
	7 Series	E38	Car key memory	A/C - Heater and Automatic Conditioner Control								
	7 Series	E38	Car key memory	SRS [Air bag]								
	7 Series	E38	Car key memory	IKE/IKI/KOMBI [Instrument cluster]								
	7 Series	E38	Car key memory	LSZ/LCM [Light switching center]								
	7 Series	E38	Car key memory	ZKE [Central body electronic]								
	7 Series	E38	Car key memory	PDC [Park Distance Control]								
	7 Series	E38	Car key memory	AIC - Automatic Interval Control								
	7 Series	E38	Car key memory	RAD - Radio								
	7 Series	E38	Car key memory	TEL - Car Telephone								
	7 Series	E38	Car key memory	SZM - Switching Center, Centre Console								

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
	7 Series	E38	Car key memory	MID - Multi-Information Display									
	7 Series	E65/E66	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	✓		
	7 Series	E65/E66	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-		
	7 Series	E65/E66	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Driver	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	-		
	7 Series	E65/E66	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Driver	VTC [Valvetronic]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Driver	VTC2 [Valvetronic 2]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Chassis	ACC [Active Cruise Control]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Chassis	ARS [Dynamic Drive]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Chassis	CIM [Chassis Integration Module]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	-		
	7 Series	E65/E66	Chassis	EDC [Damper Control]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-		
	7 Series	E65/E66	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	AFS [Active front steering]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	ANT [Aerial/antenna tuner]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	ASK [Audio System Controller]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	SZM/BZM [Control centre, centre console]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	CEM [Clean Energy Module]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	DVDC [DVD Changer]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	DWA [Antitheft alarm system]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	FBI [Flexible Bus Interface]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	FBZM [Rear compartment, control centre, center console]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	FCON [Rear Compartment controller]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	FD [Rear-cabin display]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	FKA [Rear heater/air conditioning]	✓	✓	✓	✓	✓	-	-		
	7 Series	E65/E66	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-		

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	7 Series	E65/E66	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	IBOC [Digital tuner US]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E65/E66	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	KHI [Headset interface]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	LM [Light Module]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E65/E66	Body	NVE [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	NVK [Night Vision Camera]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	PM [Power module]	✓	✓	✓	✓	✓	✓	-	
	7 Series	E65/E66	Body	RLS [Rain/Light Sensor]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	AIRBAG-SASL [Satellite, A-pillar, left]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	AIRBAG-SASR [Satellite, A-pillar, right]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	AIRBAG-SBSL [Satellite, B-pillar, left]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E65/E66	Body	AIRBAG-SBSR [Satellite, B-pillar, right]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E65/E66	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SFZ [Satellite vehicle center]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SG-FD [Control module, rear-compartment]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SG-FD-GW [Control module, rear-compartment]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SHZH [Independent/auxiliary heater]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SMBFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SMFAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SSBF [Satellite, seat, passenger]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E65/E66	Body	SSFA [Satellite, seat, driver]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E65/E66	Body	SSH [Satellite, seat, rear]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E65/E66	Body	AIRBAG-STVL [Satellite, door, front left]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	AIRBAG-STVR [Satellite, door, front right]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SVS [Language processing system]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	✓	
	7 Series	E65/E66	Body	TMBFH [Door module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	TMBFT [Door module, passenger door]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	TMFAH [Door module, driver's side rear]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	7 Series	E65/E66	Body	TMFAT [Door module, driver's door]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	TCU [Telematic Control unit - TEL/ULF/ULF-SBX]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	WIM [Wiper module]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Body	SGM-ZGM [Safety and Gateway Module(ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-	
	7 Series	E65/E66	Quick test	[Start vehicle test]								
	7 Series	E65/E66	Quick test	[Delete fault memory]								
	7 Series	E65/E66	Service function	Maintenance								
	7 Series	E65/E66	Service function	Maintenance								
	7 Series	E65/E66	Service function	Adjustment, steering-angle sensor								
	7 Series	E65/E66	Service function	EMF [Parking brake]								
	7 Series	E65/E66	Service function	Tyre air pressure warning lamp reset								
	7 Series	E65/E66	Programming/Coding	CAS [Car Access System]								
	7 Series	E65/E66	Programming/Coding	INSTR [Instrument cluster]								
	7 Series	E65/E66	Programming/Coding	LM [Light Module]								
	7 Series	E65/E66	Programming/Coding	ACSM/SRS [Crash Safety Module]								
	7 Series	E65/E66	Programming/Coding	AIRBAG-SBSL [Satellite, B-pillar, left]								
	7 Series	E65/E66	Programming/Coding	AIRBAG-SBSR [Satellite, B-pillar, right]								
	7 Series	E65/E66	Programming/Coding	SSBF [Satellite, seat, passenger]								
	7 Series	E65/E66	Programming/Coding	SSFA [Satellite, seat, driver]								
	7 Series	E65/E66	Programming/Coding	SSH [Satellite, seat, rear]								
	7 Series	E65/E66	Programming/Coding	SZL [Switch center steering column]								
	7 Series	E65/E66	Programming/Coding	SASL [Satellite Apillar Left]								
	7 Series	E65/E66	Programming/Coding	SASR [Satellite Apillar Right]								
	7 Series	E65/E66	Programming/Coding	STVL [Satellite door front left]								
	7 Series	E65/E66	Programming/Coding	STVR [Satellite door front right]								
	7 Series	E65/E66	Programming/Coding	SFZ [Satellite vehicle center]								
	7 Series	E65/E66	Programming/Coding	EMF [Electromechanical Parking Brake]								
	7 Series	E65/E66	Programming/Coding	ASK [Audio System Controller]								
	7 Series	E65/E66	Programming/Coding	SHD [Multi Drive Sliding]								
	7 Series	E65/E66	Programming/Coding	TMFT [Door Module Driver]								
	7 Series	E65/E66	Programming/Coding	TMBT [Door Module Passenger]								
	7 Series	E65/E66	Programming/Coding	TMFTH [Door Module Driver Rear]								
	7 Series	E65/E66	Programming/Coding	TMBTH [Door Module Passenger Rear]								
	7 Series	E65/E66	Programming/Coding	CCC-BO [User interface]								
	7 Series	E65/E66	Programming/Coding	PDC [Park Distance Control]								
	7 Series	E65/E66	Programming/Coding	KLIMA [Climate Module]								
	7 Series	E65/E66	Programming/Coding	WIM [Wiper module]								

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	7 Series	F01/F02/F03/F04	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	7 Series	F01/F02/F03/F04	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	7 Series	F01/F02/F03/F04	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	-	-	-	
	7 Series	F01/F02/F03/F04	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	7 Series	F01/F02/F03/F04	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	7 Series	F01/F02/F03/F04	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	HSR [Rear-axle slip-angle control]	✓	✓	✓	✓	✓	✓	-	
	7 Series	F01/F02/F03/F04	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	7 Series	F01/F02/F03/F04	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	7 Series	F01/F02/F03/F04	Chassis	RKVL/EDCSVL [Damper satellite, front left]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	RKVL/EDCSVR [Damper satellite, front right]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	RKVL/EDCSHL [Damper satellite, rear left]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Chassis	RKVL/EDCSHR [Damper satellite, rear right]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	JBE/JBBF [Junction-box electronics]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	TRSVC [All round view camera]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	GHAS [Regulated differential lock]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	CVM [Convertible-top Module]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	7 Series	F01/F02/F03/F04	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	EME2 [Electrical Machine Electronics 2]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	STML [Headlight driver module, left]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	STMR [Headlight driver module, right]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	LHML [LED main light module, left]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	LHMR [LED main light module, right]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	GZAL [Targeted illumination, left]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	GZAR [Targeted illumination, right]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	SEC [SUpplementary control unit]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	NIVI [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	FCON [Rear Compartment controller]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	FD [Rear compartment display]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	FD2 [Rear compartment display 2]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	RFK [Reversing camera]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	AC2 [Air conditioning system - IHKA2]	✓	✓	✓	✓	✓	-	-	
	7 Series	F01/F02/F03/F04	Body	AC3 [Air conditioning system - IHKA3]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
	7 Series	F01/F02/F03/F04	Quick test	[Start vehicle test]									
	7 Series	F01/F02/F03/F04	Quick test	[Delete fault memory]									
	7 Series	F01/F02/F03/F04	Service function	Maintenance CBS reset									
	7 Series	F01/F02/F03/F04	Service function	Maintenance CBS correct									
	7 Series	F01/F02/F03/F04	Service function	EMF [Parking brake]									
	7 Series	F01/F02/F03/F04	Service function	Brake Pad Change									
	8 Series	E31	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	-	
	8 Series	E31	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	-	
	8 Series	E31	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Driver	GR [Cruise control]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Driver	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	-	
	8 Series	E31	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	-	
	8 Series	E31	Quick test	[Start vehicle test]									
	8 Series	E31	Quick test	[Delete fault memory]									
	I Series	I01/I12	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	-	
	I Series	I01/I12	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	-	
	I Series	I01/I12	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	I Series	I01/I12	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	-	-	-	
	I Series	I01/I12	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	I Series	I01/I12	Quick test	[Start vehicle test]								
	I Series	I01/I12	Quick test	[Delete fault memory]								
	I Series	I01/I12	Service function	Maintenance CBS reset								
	I Series	I01/I12	Service function	Maintenance CBS correct								
	I Series	I01/I12	Service function	EMF [Parking brake]								
	I Series	I01/I12	Service function	Brake Pad Change								
	X Series	X1_E84	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	X Series	X1_E84	Driver	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	-	
	X Series	X1_E84	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	ACC [Active Cruise Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	X Series	X1_E84	Chassis	ARS [Dynamic Drive]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	EDCSHL [Damper satellite, rear left]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	EDCSHR [Damper satellite, rear right]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X1_E84	Chassis	EDCSVL [Damper satellite, front left]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	EDCSVR [Damper satellite, front right]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	X Series	X1_E84	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	LDM [Longitudinal Dynamics Management]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Chassis	EDC [Electronic Damper Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	CCC-A [Applications]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	ANT [Aerial tuner]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	ASK [Audio system controller]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	DVDC [DVD Changer]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	DWA [Antitheft alarm system]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	FD [Rear-cabin display]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	FKA [Rear heater/air conditioning]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	FRM [Footwell module]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	FZD [Function Center, Roof]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	IBOC [Digital tuner US]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	SGM-ZGM [Safety and Gateway Module (ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	KHI [Headphones module]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	RFK [Reversing camera]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	Remark
	X Series	X1_E84	Body	RLS [Rain/light solar sensor]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	TCU [Telematic Control unit]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X1_E84	Quick test	[Start vehicle test]								
	X Series	X1_E84	Quick test	[Delete fault memory]								
	X Series	X1_E84	Service function	Maintenance								
	X Series	X1_E84	Service function	Maintenance								
	X Series	X1_E84	Service function	EMF [Parking brake]								
	X Series	X3_E83	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	✓	
	X Series	X3_E83	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	X Series	X3_E83	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Chassis	LEW [Adjustment, steering-angle sensor]	✓	✓	✓	✓	✓	-	✓	
	X Series	X3_E83	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	AIC [Automatic Interval Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	✓	
	X Series	X3_E83	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	✓	
	X Series	X3_E83	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	✓	
	X Series	X3_E83	Body	MFL [Multi-function steering wheel]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	NAV [Navigation system]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	✓	
	X Series	X3_E83	Body	SES Language-input System	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	SMF Driver Seat Memory	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	✓	
	X Series	X3_E83	Body	VID [Video Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	✓	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X3_E83	Body	DSP [Digital Sound Processor]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_E83	Quick test	[Start vehicle test]								
	X Series	X3_E83	Quick test	[Delete fault memory]								
	X Series	X3_E83	Service function	Maintenance Reset service interval indicator								
	X Series	X3_E83	Service function	Adjustment, steering-angle sensor								
	X Series	X3_E83	Service function	Tyre air pressure warning lamp reset								
	X Series	X3_E83	Car key memory	DME - Digital Motor Electronics								
	X Series	X3_E83	Car key memory	EGS - Electronic Gearbox Control								
	X Series	X3_E83	Car key memory	EWS - Electronic Car Immobilisation System								
	X Series	X3_E83	Car key memory	LEW - Steering-Angle Sensor								
	X Series	X3_E83	Car key memory	A/C - Heater and Automatic Conditioner Control								
	X Series	X3_E83	Car key memory	IKE - Instrument Cluster Electronics								
	X Series	X3_E83	Car key memory	SRS - Supplemental Restraint System								
	X Series	X3_E83	Car key memory	RAD - Radio								
	X Series	X3_E83	Car key memory	AIC - Automatic Interval Control								
	X Series	X3_E83	Car key memory	LCM - Light Check Module								
	X Series	X3_E83	Car key memory	ZKE - Central Body Electronic								
	X Series	X3_E83	Car key memory	SLM - Mirrors/seat system								
	X Series	X3_E83	Recoding									
	X Series	X5_E53	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	✓	
	X Series	X5_E53	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	✓	
	X Series	X5_E53	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Driver	VTG [Gearbox control]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E53	Chassis	LEW [Adjustment, steering-angle sensor]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	AIC [Automatic Interval Control]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Body	BIT [Basic Interface Telephone]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	BM [On-board monitor]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Body	MFL [Multi-function steering wheel]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	NAV [Navigation system]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	✓	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X5_E53	Body	SES [Language-input system]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Body	SZM [Switching center, center console]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Body	VID [Video Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E53	Body	DSP [Digital Sound Processor]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E53	Quick test	[Start vehicle test]								
	X Series	X5_E53	Quick test	[Delete fault memory]								
	X Series	X5_E53	Service function	Maintenance Reset service interval indicator								
	X Series	X5_E53	Service function	Adjustment, steering-angle sensor								
	X Series	X5_E53	Service function	Tyre air pressure warning lamp reset								
	X Series	X5_E53	Car key memory	DME - Digital Motor Electronics								
	X Series	X5_E53	Car key memory	EGS - Electronic Gearbox Control								
	X Series	X5_E53	Car key memory	EWS - Electronic Car Immobilisation System								
	X Series	X5_E53	Car key memory	LEW - Steering-Angle Sensor								
	X Series	X5_E53	Car key memory	A/C - Heater and Automatic Conditioner Control								
	X Series	X5_E53	Car key memory	SRS - Supplemental Restraint System								
	X Series	X5_E53	Car key memory	IKE - Instrument Cluster Electronics								
	X Series	X5_E53	Car key memory	LCM - Light Check Module								
	X Series	X5_E53	Car key memory	ZKE - Central Body Electronic								
	X Series	X5_E53	Car key memory	PDC - Park Distance Control								
	X Series	X5_E53	Car key memory	AIC - Automatic Interval Control								
	X Series	X5_E53	Car key memory	RAD - Radio								
	X Series	X5_E53	Car key memory	TEL - Car Telephone								
	X Series	X5_E53	Car key memory	SZM - Switching Center, Centre Console								
	X Series	X5_E53	Car key memory	MID - Multi-Information Display								
	X Series	X5_E53	Car key memory	SLM - Mirrors/seat system								
	X Series	X5_E53	Recoding									
	X Series	X5_E70	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E70	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Driver	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E70	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Driver	QMVH [Lateral-moment distribution, rear axle]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Driver	VTC [Valvetronic]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Driver	VTC2 [Valvetronic 2]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X5_E70	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E70	Chassis	ARS [Dynamic Drive]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E70	Chassis	EDCSHL [Damper satellite, rear left]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E70	Chassis	EDCSHR [Damper satellite, rear right]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E70	Chassis	EDCSVL [Damper satellite, front left]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E70	Chassis	EDCSVR [Damper satellite, front right]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E70	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_E70	Chassis	EMF [Parking brake]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Chassis	EDC [Electronic Damper Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E70	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	CCC-A [Applications]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	ANT [Aerial tuner]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	ASK [Audio system controller]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E70	Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	CNAV [Navigation system, China]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	DVDC [DVD Changer]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	FD [Rear-cabin display]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	FKA [Rear heater/air conditioning]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	FRM [Footwell module]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E70	Body	FZD [Function Center, Roof]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E70	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	IBOC [Digital tuner US]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	✓	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	Remark
	X Series	X5_E70	Body	SGM-ZGM [Safety and Gateway Module(ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	KHI [Headphones module]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	✓	
	X Series	X5_E70	Body	RFK [Reversing camera]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	RLS [Rain/light solar sensor]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	SFZ [Satellite vehicle center]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	TCU [Telematic Control unit]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_E70	Quick test	[Start vehicle test]								
	X Series	X5_E70	Quick test	[Delete fault memory]								
	X Series	X5_E70	Service function	Maintenance CBS reset								
	X Series	X5_E70	Service function	Maintenance CBS correct								
	X Series	X5_E70	Service function	Adjustment, steering-angle sensor								
	X Series	X5_E70	Service function	EMF [Parking brake]								
	X Series	X5_E70	Car key memory	CAS [Car Access System]								
	X Series	X5_E70	Car key memory	FZD [Function Center, Roof]								
	X Series	X5_E70	Car key memory	KBM [Body Basic Module]								
	X Series	X5_E70	Car key memory	INSTR [Instrument cluster]								
	X Series	X5_E70	Car key memory	CCC-BO [User interface]								
	X Series	X5_E70	Car key memory	ACSM/SRS [Crash Safety Module]								
	X Series	X5_E70	Car key memory	PDC [Park Distance Control]								
	X Series	X5_E70	Car key memory	SGM-ZGM [Safety and Gateway Module(ZGM)]								
	X Series	X5_E70	Car key memory	EDC [Electronic Damper Control K]								
	X Series	X5_E70	Car key memory	SMFA [Seat Module Front]								
	X Series	X5_E70	Car key memory	GWS [Gear selector switch]								
	X Series	X5_E70	Car key memory	CA [Comfort access system]								
	X Series	X5_E70	Car key memory	RSE [Rear Seat Entertainment]								
	X Series	X5_E70	Car key memory	VTG [Transfer case]								
	X Series	X6_E71	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	✓	
	X Series	X6_E71	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
X Series	X6_E71		Driver	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	-	
X Series	X6_E71		Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Driver	QMVH [Lateral-moment distribution, rear axle]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
X Series	X6_E71		Chassis	ARS [Dynamic Drive]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	-	
X Series	X6_E71		Chassis	EDCSHL [Damper satellite, rear left]	✓	✓	✓	✓	✓	✓	-	
X Series	X6_E71		Chassis	EDCSHR [Damper satellite, rear right]	✓	✓	✓	✓	✓	✓	-	
X Series	X6_E71		Chassis	EDCSVL [Damper satellite, front left]	✓	✓	✓	✓	✓	✓	-	
X Series	X6_E71		Chassis	EDCSVR [Damper satellite, front right]	✓	✓	✓	✓	✓	✓	-	
X Series	X6_E71		Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
X Series	X6_E71		Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Chassis	LDM [Integrated chassis management -ICM]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Chassis	EDC [Electronic Damper Control]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	✓	
X Series	X6_E71		Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	CCC-A [Applications]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	ANT [Aerial tuner]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	ASK [Audio system controller]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	✓	
X Series	X6_E71		Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	DVDC [DVD Changer]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	FD [Rear compartment display]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	FKA [Rear heater/air conditioning]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	FRM [Footwell module]	✓	✓	✓	✓	✓	-	✓	
X Series	X6_E71		Body	FZD [Function Center, Roof]	✓	✓	✓	✓	✓	-	-	
X Series	X6_E71		Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X6_E71	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	IBOC [Digital tuner US]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	✓	
	X Series	X6_E71	Body	SGM-ZGM [Safety and Gateway Module(ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	KHI [Headset interface]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	✓	
	X Series	X6_E71	Body	RFK [Reversing camera]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	RLS [Rain/light solar sensor]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	TCU [Telematic Control unit]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E71	Quick test	[Start vehicle test]								
	X Series	X6_E71	Quick test	[Delete fault memory]								
	X Series	X6_E71	Service function	Maintenance CBS reset								
	X Series	X6_E71	Service function	Maintenance CBS correct								
	X Series	X6_E71	Service function	Adjustment, steering-angle sensor								
	X Series	X6_E71	Service function	EMF [Parking brake]								
	X Series	X6_E71	Car key memory	CAS [Car Access System]								
	X Series	X6_E71	Car key memory	FZD [Function Center, Roof]								
	X Series	X6_E71	Car key memory	KBM [Body Basic Module]								
	X Series	X6_E71	Car key memory	INSTR [Instrument cluster]								
	X Series	X6_E71	Car key memory	CCC-BO [User interface]								
	X Series	X6_E71	Car key memory	ACSM/SRS [Crash Safety Module]								
	X Series	X6_E71	Car key memory	PDC [Park Distance Control]								
	X Series	X6_E71	Car key memory	SGM-ZGM [Safety and Gateway Module(ZGM)]								
	X Series	X6_E71	Car key memory	EDC [Electronic Damper Control K]								
	X Series	X6_E71	Car key memory	SMFA [Seat Module Front]								
	X Series	X6_E71	Car key memory	GWS [Gear selector switch]								
	X Series	X6_E71	Car key memory	CA [Comfort access system]								
	X Series	X6_E71	Car key memory	RSE [Rear Seat Entertainment]								

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
	X Series	X6_E71	Car key memory	VTG [Transfer case]									
	X Series	X6_E72	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	✓		
	X Series	X6_E72	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-		
	X Series	X6_E72	Driver	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	✓	-		
	X Series	X6_E72	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-		
	X Series	X6_E72	Chassis	ARS [Dynamic Drive]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	-		
	X Series	X6_E72	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-		
	X Series	X6_E72	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	✓		
	X Series	X6_E72	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	CCC-A [Applications]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	ANT [Aerial tuner]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	ASK [Audio system controller]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	✓		
	X Series	X6_E72	Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	DVDC [DVD Changer]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	FD [Rear compartment display]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	FKA [Rear heater/air conditioning]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	FRM [Footwell module]	✓	✓	✓	✓	✓	-	✓		
	X Series	X6_E72	Body	FZD [Function Center, Roof]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	IBOC [Digital tuner US]	✓	✓	✓	✓	✓	-	-		
	X Series	X6_E72	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-		

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X6_E72	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	✓	
	X Series	X6_E72	Body	SGM-ZGM [Safety and Gateway Module(ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	KHI [Headset interface]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	✓	
	X Series	X6_E72	Body	RFK [Reversing camera]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	RLS [Rain/light solar sensor]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	SDARS [Satellite tuner]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	SMBF [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	TCU [Telematic Control unit]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Body	VSW [Video switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_E72	Quick test	[Start vehicle test]								
	X Series	X6_E72	Quick test	[Delete fault memory]								
	X Series	X6_E72	Service function	Maintenance CBS reset								
	X Series	X6_E72	Service function	Maintenance CBS correct								
	X Series	X6_E72	Service function	Adjustment, steering-angle sensor								
	X Series	X6_E72	Service function	EMF [Parking brake]								
	X Series	X6_E72	Car key memory	CAS [Car Access System]								
	X Series	X6_E72	Car key memory	FZD [Function Center, Roof]								
	X Series	X6_E72	Car key memory	KBM [Body Basic Module]								
	X Series	X6_E72	Car key memory	INSTR [Instrument cluster]								
	X Series	X6_E72	Car key memory	CCC-BO [User interface]								
	X Series	X6_E72	Car key memory	ACSM/SRS [Crash Safety Module]								
	X Series	X6_E72	Car key memory	PDC [Park Distance Control]								
	X Series	X6_E72	Car key memory	SGM-ZGM [Safety and Gateway Module(ZGM)]								
	X Series	X6_E72	Car key memory	EDC [Electronic Damper Control K]								
	X Series	X6_E72	Car key memory	SMFA [Seat Module Front]								
	X Series	X6_E72	Car key memory	GWS [Gear selector switch]								
	X Series	X6_E72	Car key memory	CA [Comfort access system]								
	X Series	X6_E72	Car key memory	RSE [Rear Seat Entertainment]								
	X Series	X6_E72	Car key memory	VTG [Transfer case]								
	X Series	X3_F25	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X3_F25	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	X Series	X3_F25	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	X Series	X3_F25	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	X Series	X3_F25	Body	JBE/JBBF [Junction-box electronics]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	TRSVC [All round view camera]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	HKL [Automatic luggage compartment lid actuation]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	GHAS [Regulated different lock]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	FAH [Seat module, driver's side rear]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	BFH [Seat module, passenger's side rear]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X3_F25	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	FD [Rear compartment display]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	X Series	X3_F25	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	X Series	X3_F25	Quick test	[Start vehicle test]								
	X Series	X3_F25	Quick test	[Delete fault memory]								
	X Series	X3_F25	Service function	Maintenance								
				CBS reset								
	X Series	X3_F25	Service function	Maintenance								
				CBS correct								
	X Series	X3_F25	Service function	EMF [Parking brake]								
	X Series	X4_F26	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	X Series	X4_F26	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	X Series	X4_F26	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Driver	GHAS [Regulated differential lock]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	
	X Series	X4_F26	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-	
	X Series	X4_F26	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-	
	X Series	X4_F26	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	X Series	X4_F26	Body	JBE/JBBF [Junction-box electronics]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Body	TRSVK [All round view camera]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	X Series	X4_F26	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	Remark
X Series	X4_F26		Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	STML [Headlight driver module, left]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	STMR [Headlight driver module, right]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	SEC1 [Supplementary control unit 1]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	NIVI [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
X Series	X4_F26		Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Body	AC2 [Air conditioning system - IHKA2]	✓	✓	✓	✓	✓	-	-	
X Series	X4_F26		Quick test	[Start vehicle test]								
X Series	X4_F26		Quick test	[Delete fault memory]								
X Series	X4_F26		Service function	Maintenance								
				CBS reset								
X Series	X4_F26		Service function	Maintenance								
				CBS correct								
X Series	X4_F26		Service function	EMF [Parking brake]								

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark	
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding		
	X Series	X4_F26	Service function	Brake Pad Change									
	X Series	X5_F15/F85	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-		
	X Series	X5_F15/F85	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-		
	X Series	X5_F15/F85	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Driver	GHAS [Regulated differential lock]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-		
	X Series	X5_F15/F85	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	-		
	X Series	X5_F15/F85	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	-		
	X Series	X5_F15/F85	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-		
	X Series	X5_F15/F85	Body	JBE/JBBF [Junction-box electronics]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	TRSVC [All round view camera]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	TEL [Telephone]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	-	-		
	X Series	X5_F15/F85	Body	STML [Headlight driver module, left]	✓	✓	✓	✓	✓	-	-		

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X5_F15/F85	Body	STMR [Headlight driver module, right]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	SEC1 [Supplementary control unit 1]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	TVM [Video Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	NIVI [Night Vision Electronics]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	X Series	X5_F15/F85	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Body	AC2 [Air conditioning system - IHKA2]	✓	✓	✓	✓	✓	-	-	
	X Series	X5_F15/F85	Quick test	[Start vehicle test]								
	X Series	X5_F15/F85	Quick test	[Delete fault memory]								
	X Series	X5_F15/F85	Service function	Maintenance CBS reset								
	X Series	X5_F15/F85	Service function	Maintenance CBS correct								
	X Series	X5_F15/F85	Service function	EMF [Parking brake]								
	X Series	X5_F15/F85	Service function	Brake Pad Change								
	X Series	X6_F16/F86	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	X Series	X6_F16/F86	Driver	ECM2 [Engine control module 2 - DME2]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Driver	EKPS [Electronic Fuel pump]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	X Series	X6_F16/F86	Driver	VTG [Transfer case]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Driver	EME [Electrical machine electronics]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Driver	GHAS [Regulated differential lock]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
X Series	X6_F16/F86	Chassis	SME [Accumulator management electronics]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Chassis	AL [Active steering]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Chassis	ICM [Integrated chassis management]	✓	✓	✓	✓	✓	✓	✓	-	
X Series	X6_F16/F86	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Chassis	EHC [Electronic Ride-Height Control]	✓	✓	✓	✓	✓	✓	✓	-	
X Series	X6_F16/F86	Chassis	ACC [ACC Full range radar]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Chassis	ICMV [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	✓	-	
X Series	X6_F16/F86	Body	JBE/JBBF [Junction-box electronics]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	SZL [Switch center steering column]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	TRSVL [All round view camera]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	HC/SWW [Lane change warning]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	SVT [Servotronic]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	ZGM [Central Gateway Module]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	RSE [Rear Seat Entertainment]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	PMA [Parking assistant]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	MMC [DVD changer]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	TBX [Touchbox]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	TEL [Telephone]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	EME2 [Electrical machine electronics 2]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	HUD [Head-Up Display]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	ASD [Active Sound Design]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	STML [Headlight driver module, left]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	STMR [Headlight driver module, right]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	SEC1 [Supplementary control unit 1]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	TVM [Video Module]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	EMA_LI [Left electric motor reel]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	EMA_RE [Right electric motor reel]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	FZD [Function centre, roof]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	NIVI [Night Vision Electronics]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	KAFAS [Camera based driver assist systems]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	✓	-	-	
X Series	X6_F16/F86	Body	ECALL [ComBox emergency call]	✓	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	X Series	X6_F16/F86	Body	CIC [Car headunit platform]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	HKL [Rear-lid lift]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	FAS [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	BFS [Seat module, passenger]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	AHM [Trailer module]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	VDC/VDM [Vertical Dynamics Management]	✓	✓	✓	✓	✓	✓	-	
	X Series	X6_F16/F86	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Body	AC2 [Air conditioning system - IHKA2]	✓	✓	✓	✓	✓	-	-	
	X Series	X6_F16/F86	Quick test	[Start vehicle test]								
	X Series	X6_F16/F86	Quick test	[Delete fault memory]								
	X Series	X6_F16/F86	Service function	Maintenance CBS reset								
	X Series	X6_F16/F86	Service function	Maintenance CBS correct								
	X Series	X6_F16/F86	Service function	EMF [Parking brake]								
	X Series	X6_F16/F86	Service function	Brake Pad Change								
	Z Series	Z1_E30	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z1_E30	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z1_E30	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Driver	GR [Cruise control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Driver	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z1_E30	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	Z Series	Z1_E30	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z1_E30	Quick test	[Start vehicle test]								
	Z Series	Z1_E30	Quick test	[Delete fault memory]								
	Z Series	Z3_E36	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z3_E36	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z3_E36	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Driver	GR [Cruise control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Driver	EML [Electronic throttle]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Chassis	EHC/EDC [Signal-axle air suspension]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z3_E36	Body	AHK [Active Rear-Axle Kinematics]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	DWA [Burglar-alarm system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	EKM [Electronic Body Module]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	GSA [Closed-Loop-Controlled Differential-Lock AWD]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	MID [Multi Information Display]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	SHD [Sliding/tilting sunroof]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	SLM/SM [Rear view mirror/Seat memory system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	VNC [Variable Camshaft Control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z3_E36	Quick test	[Start vehicle test]								
	Z Series	Z3_E36	Quick test	[Delete fault memory]								
	Z Series	Z3_E36	Service function	Adjustment, steering-angle sensor								
	Z Series	Z4_E85/E86	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z4_E85/E86	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z4_E85/E86	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	Z Series	Z4_E85/E86	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Chassis	LEW [Adjustment, steering-angle sensor]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	AIC [Automatic Interval Control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	CVM [Convertible-top module]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	LSZ/LCM [Light switching center]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	AIRBAG-SBSL [Satellite, B-pillar, left]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	AIRBAG-SBSR [Satellite, B-pillar, right]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	SRS [Safety airbag system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	SMF [Seat memory, driver]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	SZM [Switching center, center console]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	VID [Video Module]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E85/E86	Body	AIRBAG-STVL [Satellite, door, front left]	✓	✓	✓	✓	✓			
	Z Series	Z4_E85/E86	Body	AIRBAG-STVR [Satellite, door, front right]	✓	✓	✓	✓	✓			
	Z Series	Z4_E85/E86	Body	CDC [CD Changer]	✓	✓	✓	✓	✓			
	Z Series	Z4_E85/E86	Quick test	[Start vehicle test]								
	Z Series	Z4_E85/E86	Quick test	[Delete fault memory]								
	Z Series	Z4_E85/E86	Service function	Maintenance								
	Z Series	Z4_E85/E86	Service function	Reset service interval indicator								
	Z Series	Z4_E85/E86	Service function	Adjustment, steering-angle sensor								
	Z Series	Z4_E85/E86	Service function	Tyre air pressure warning lamp reset								
	Z Series	Z4_E89	Driver	CAS [Car Access System]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z4_E89	Driver	TCM [Automatic transmission control module - EGS/DKG/SMG]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Driver	EKPS [Fuel-pump control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Driver	GWS [Gear selector switch]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Chassis	EDC [Damper Control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Chassis	EPB [Parking brake - EMF]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Chassis	EPS [Electronic Power Steering]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	AMP [Amplifier]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	CA [Comfort Access system]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							Remark
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	
	Z Series	Z4_E89	Body	CDC [CD Changer]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	CID [Central Information Display]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	CON [Controller]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	DAB [Digital tuner]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	DVDC [DVD Changer]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	DWA [Antitheft alarm system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	FLA [High Beam Assist]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	FRM [Footwell Module]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	FZD [Function Centre, Roof]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	AC [Air conditioning system - IHKA]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	IC [Instrument cluster - INSTR]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	SGM-ZGM [Safety and Gateway Module (ZGM) - JBE/JBE2/JBBF/KGM]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	CD [User interface - CIC/CCC-BO/CHAMP-BO/M-ASK-BO/RAD/RAD2-BO]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	CD-GW/M-ASK-GW [Gateway - CIC-GW/CCC-GW/CHAMP-GW/RAD2-GW]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	SRS [Safety airbag - AIRBAG/SGM-SIM]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	NAV [Navigation system - JNAV/CNAV/KNAV/M-ASK-NAV]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	PDC [Park Distance Control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	RLS [Rain/light solar sensor]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	SINE [Siren and tilt sensor]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	SMFA [Seat module, driver]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	TCU [Telematic Control unit]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	ULF-SBX-H [Interface box High]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Body	VM [Video Module]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z4_E89	Quick test	[Start vehicle test]								
	Z Series	Z4_E89	Quick test	[Delete fault memory]								
	Z Series	Z4_E89	Service function	Maintenance								
	Z Series	Z4_E89	Service function	Maintenance								
	Z Series	Z4_E89	Service function	Adjustment, steering-angle sensor								
	Z Series	Z4_E89	Service function	EMF [Parking brake]								
	Z Series	Z8_E52	Driver	ECM [Engine control module - DME/DDE]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z8_E52	Driver	TCM [Automatic transmission control module - EGS]	✓	✓	✓	✓	✓	✓	-	
	Z Series	Z8_E52	Driver	EWS [Electronic immobilize system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Chassis	ABS [Antilock brake system - DSC]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Chassis	LEW [Adjustment, steering-angle sensor]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Chassis	RDC [Tyre pressure control]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Body	BIT [Basic Interface Telephone]	✓	✓	✓	✓	✓	-	-	

Diagnostic List bmw_v9.88

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

BMW Diagnosis select	Series	Chassis	Module	Systems	Function							
					Read ECU Information	Read Fault Code	Erase Fault Code	Read Data Stream	Actuation Test	Service Function	Unit Coding	Remark
	Z Series	Z8_E52	Body	A/C [Air conditioning system]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Body	KOM [Instrument cluster]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Body	RAD [Radio]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Body	SRS [Air bag]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Body	URS [Rollover sensor]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Body	ZKE [Central body electronic]	✓	✓	✓	✓	✓	-	-	
	Z Series	Z8_E52	Quick test	[Start vehicle test]								
	Z Series	Z8_E52	Quick test	[Delete fault memory]								
	Z Series	Z8_E52	Service function	Maintenance Reset service interval indicator								
	Z Series	Z8_E52	Service function	Adjustment, steering-angle sensor								