Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0052 0x0153 0x0154 0x00B2 0x0155
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	–	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	–	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	2008 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0018 0x0157 0x0158 0x0158 0x0158 0x0158 0x0159 0x0159 0x0159 0x0159 0x015A 0x00DB 0x015B 0x00B1 0x0052 0x0153 0x0154 0x00B2 0x0155
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0157 0x0158 0x0158 0x0158 0x0158 0x0159 0x0159 0x0159 0x0159 0x015A 0x00DB 0x015B 0x00B1 0x0052 0x0153 0x0154 0x00B2 0x0155 0x015C
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	4X4(4X4 Control Module)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0157 0x0158 0x0158 0x0158 0x0158 0x0159 0x0159 0x0159 0x0159 0x015A 0x00DB 0x015B 0x00B1 0x0052 0x0153 0x0154 0x00B2 0x0155
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0157 0x0158 0x0158 0x0158 0x0158 0x0159 0x0159 0x0159 0x0159 0x015A 0x00DB 0x015B 0x00B1 0x0052 0x0153 0x0154 0x00B2 0x015D 0x015E 0x0155 0x00A4 0x00A5 0x00AF 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00AC 0x00A3
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	-	-	0x0086 0x00B1 0x0052
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	4X4(4X4 Control Module)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5	2.0L	LF	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x0064 0x011A 0x016A 0x016B 0x0065 0x0066 0x0067 0x00BE
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	4X4(4X4 Control Module)	✔	✔	–	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	–	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x016C 0x00B2 0x0161
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0162 0x0163 0x0164
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0165 0x0166 0x0167
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0168 0x0169 0x016D
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	–	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	–	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	TCM(Transmission Control Module)	✔	✔	–	–	0x0164 0x0165 0x0166
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0167 0x0168 0x0169
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	–	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	–	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00A2 0x0158 0x0159
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x00DB 0x015B 0x016E 0x016C 0x00B2 0x0161
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0162 0x0163 0x0164
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0165 0x0166 0x0167
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	0x0168 0x0169 0x016D
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	–	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	TCM(Transmission Control Module)	✔	✔	–	–	0x0164 0x0165 0x0166
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0167 0x0168 0x0169
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	-	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	4X4(4X4 Control Module)	✔	✔	-	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	-	-	
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x00A2 0x0158 0x0159
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x00DB 0x015B 0x016E 0x0086 0x0052 0x016C
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	0x00B2 0x0161 0x0162
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0163 0x0164 0x0165
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	0x0166 0x0167 0x0168
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	VSM(Vehicle Security Module)	✔	✔	-	-	0x0169 0x016D
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x00A2 0x0158 0x0159
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x00DB 0x015B 0x016E 0x0086 0x0052 0x016C
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	0x00B2 0x0161 0x0162
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0163 0x0164 0x0165
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	0x0166 0x0167 0x0168
Demio (JPN) / Mazda 2 (OTHER)	1.5L	ZY	Other	VSM(Vehicle Security Module)	✔	✔	-	-	0x0169 0x016D
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Probe / MX-6	2.0L	Other	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.3L	Other	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.5L	Other	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	Other	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	-	-	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	-	-	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	CSM(Security module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1995 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1995 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	Other	1995 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1995 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Probe / MX-6	2.0L	Other	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.0L	Other	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Probe / MX-6	2.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1998 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1998 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	-	-	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	1996 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	PCM(Powertrain Control Module)	-	-	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	CSM(Security module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.5 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.5 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996.75 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996.75 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996.75 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996.75 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999.5 MY	CSM(Security module)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999.5 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	–	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999.5 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999.5 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Cougar	2.5L	Duratec-VE	2001 MY	PCM(Powertrain Control Module)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Cougar	2.5L	Duratec-VE	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Cougar	2.5L	Duratec-VE	2001 MY	IC(Instrument Cluster)	✔	✔	-	-	
Cougar	2.5L	Duratec-VE	2001 MY	MC(Message Center Module)	✔	✔	✔	-	
Cougar	2.5L	Duratec-VE	2001 MY	REM(Rear Electronic Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	IAB(Integrated Air Bag Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	OHC	1997 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	FFV	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	FIP(Fuel Injection Pump)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.5L	ZL	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ECS(Electronic Crash Sensor)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002 0x000D
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002 0x000D
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002 0x000D
Escape / Tribute / Maverick	3.0L	4V	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2001 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	F8	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	F8	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.2L	R2	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.2L	R2	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.2L	R2	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.2L	R2	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.2L	R2	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.2L	R2	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	1997 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Bongo Brawny / Econovan / Mazda E-Series	2.5L	WL	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.5L	WL	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.5L	WL	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.5L	WL	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Capella / Capella W / Telstar / Telstar W	1.8L	FP	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	1.8L	FP	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	2.0L	RF	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	1.8L	FP	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	1.8L	FP	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	2.0L	FS	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Capella / Capella W / Telstar / Telstar W	2.5L	KL	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.5L	B5	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.5L	B5	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio / 121 Demio / 121	1.5L	B5	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.5L	B5	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Marvie	2.5L	G5	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 929	3.0L	JE	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.3L	KJ	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.5L	KL	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.3L	KJ	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.5L	KL	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.5L	KL	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.5L	KL	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Millenia	2.3L	KJ	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.3L	KJ	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	JE	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	JE	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (North America / General)	2.5L	GY	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (North America / General)	2.5L	GY	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	2.5L	GY	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (North America / General)	2.5L	GY	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5	1.8L	BP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5	1.8L	BP	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5	1.8L	BP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5	1.8L	BP	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5	1.8L	BP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5	1.8L	BP	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Protege	1.5L	Z5	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.5L	Z5	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.8L	BP	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.8L	BP	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.8L	BP	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.8L	BP	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.6L	ZM	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.6L	ZM	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.6L	ZM	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.6L	ZM	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Protege	1.6L	ZM	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.6L	ZM	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Protege	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.8L	FP	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Protege	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.8L	FP	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Proceed	2.5L	G5	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Proceed	2.5L	G5	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Proceed	2.6L	G6	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Sentia	3.0L	JE	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Sentia	3.0L	JE_HO	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Xedos 9	2.3L	KJ	1996 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia / Laser	1.3L	B3	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.3L	B3	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.8L	FP	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.8L	FP	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	RF	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	RF	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Friendee / Freda / Bongo Friendee	2.0L	FE	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Friendee / Freda / Bongo Friendee	2.5L	WL_T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
626 / 626 Wagon / Telstar	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	1998 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	-	-	
626 / 626 Wagon / Telstar	2.0L	FS	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	-	-	
626 / 626 Wagon / Telstar	2.0L	FS	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	-	-	
626 / 626 Wagon / Telstar	2.0L	FS	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	RF_T	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	RF_T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	RF_T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	1.8L	FP	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Titan	4.0L	TF	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.5L	B5	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Friendee / Freda / Bongo Friendee	2.0L	FE	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy/ Ixion	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy/ Ixion	1.8L	FP	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy/ Ixion	2.0L	RF_T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy/ Ixion	2.0L	RF_T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Premacy/ Ixion	1.8L	FP_DE	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy/ Ixion	1.8L	FP_DE	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.3L	B3	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.5L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	CSM(Security module)	✔	✔	✔	-	
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	HEC(Hybrid Electronic Cluster)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	RF	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.5L	ZL	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.5L	ZL	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.8L	FP	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.8L	BP	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	B6	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.5L	Z5	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.3L	B3	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	RF	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	RF_T	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	RF_T	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Laser / 323 / Tierra	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.5L	KL	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.5L	KL	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.5L	B5	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.5L	B5	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.5L	B5	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.5L	B5	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio / 121 Demio / 121	1.3L	B3	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	FS	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MPV (Europe/General)	2.5L	GY	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (Europe/General)	2.5L	GY	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.5L	GY	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (Europe/General)	2.5L	GY	1999 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	2.0L	FS	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MPV (JPN/General)	2.5L	GY	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	2.5L	GY	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy	1.8L	FP	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy	2.0L	RF_T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy	2.0L	RF_T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5	1.6L	B6	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5	1.6L	B6	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5	1.6L	B6	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5	1.6L	B6	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy	1.8L	FP	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy	1.8L	FP	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy	2.0L	RF_T	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy	2.0L	RF_T	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Titan Dash	2.0L	FE	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Titan Dash	2.0L	FE	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Xedos 9	2.5L	KL	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Xedos 9	2.5L	KL	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Millenia	2.3L	KJ	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.3L	KJ	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Millenia	2.5L	KL	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia	2.5L	KL	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	2.5L	GY	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (North America / General)	2.5L	GY	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.5L	KL	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.5L	KL	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Probe / MX-6	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.3L	B3	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	ZM	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	ZM	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.5L	Z5	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.5L	Z5	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	B6	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	B6	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.8L	BP	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.8L	BP	1996 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Bongo Brawny / Econovan / Mazda E-Series	1.8L	F8	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	1.8L	F8	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Roadster / MX-5	1.6L	B6	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Roadster / MX-5	1.8L	BP	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio / Festiva Mini Wagon	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	RF_T	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	RF_T	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.5L	KL	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002 0x000D
Escape / Tribute / Maverick	3.0L	4V	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2002 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002 0x000D
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2002 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2002 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	Other	2002 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Protege	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Protege	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Protege	1.6L	ZM	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	1.6L	ZM	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia Wagon/VAN (B*Y11-500000-)	1.3L	QG13	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	1999 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-OFFROAD	660cc	K6A-T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-OFFROAD	660cc	K6A-T	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	F6A-T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	F6A-T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	F6A-T	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Laputa	660cc	F6A-T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	F6A-T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laputa	660cc	F6A-T	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Laputa	660cc	K6A-T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A-T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laputa	660cc	K6A-T	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum	660cc	F6A	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	F6A	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	F6A	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum	660cc	F6A	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum	660cc	F6A	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	F6A	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum	660cc	F6A	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum	660cc	F6A-T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	F6A-T	1999 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Scrum	660cc	F6A-T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum	660cc	F6A-T	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum	660cc	F6A-T	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	F6A-T	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum	660cc	F6A-T	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol	660cc	K6A	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol	660cc	K6A	1999 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Carol	660cc	K6A	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol	660cc	K6A	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol	660cc	K6A	1999 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
Carol	660cc	K6A	1999 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol	660cc	K6A	1999 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	-	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol	660cc	F6A	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol	660cc	F6A	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol	660cc	F6A	-	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol	660cc	F6A	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol	660cc	K6A	-	PCM(Powertrain Control Module)	✔	✔	✔	-	
Carol	660cc	K6A	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol	660cc	K6A	-	TCM(Transmission Control Module)	✔	✔	✔	-	
Carol	660cc	K6A	-	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol	660cc	K6A	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Laputa	660cc	F6A-T	-	PCM(Powertrain Control Module)	✔	✔	-	-	
Laputa	660cc	F6A-T	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	F6A-T	-	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laputa	660cc	F6A-T	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Laputa	660cc	K6A-T	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A-T	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A-T	-	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laputa	660cc	K6A-T	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum	660cc	F6A-T	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	F6A-T	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	F6A-T	-	TCM(Transmission Control Module)	✔	✔	✔	-	
Scrum	660cc	F6A-T	-	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum	660cc	F6A-T	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
626 / 626 Wagon / Telstar	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	1.8L	FP	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
626 / 626 Wagon / Telstar	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	RF_T	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	RF_T	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	ZM	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	ZM	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	ZM	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.6L	ZM	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.8L	Other	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.8L	Other	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.8L	Other	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.8L	Other	2001 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.8L	Other	2001 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.8L	Other	2001 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	2.0L	FS	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2003 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	Other	2003 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Premacy	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1998 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1998 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1998 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	1998 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	1998 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	1998 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	1998 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol	660cc	F6A	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol	660cc	F6A	1998 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol	660cc	F6A	1998 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol	660cc	K6A	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol	660cc	K6A	1998 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol	660cc	K6A	1998 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Carol	660cc	K6A	1998 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Laputa	660cc	F6A-T	1998 MY	PCM(Powertrain Control Module)	✔	✔	–	–	
Laputa	660cc	F6A-T	1998 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	F6A-T	1998 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Laputa	660cc	F6A-T	1998 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Laputa	660cc	F6A-T	1998 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	F6A-T	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	F6A-T	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	F6A-T	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol	660cc	K6A	2000 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol	660cc	K6A	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Carol	660cc	K6A	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	–	
Carol	660cc	K6A	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Carol	660cc	K6A	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Laputa	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A	2000 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Laputa	660cc	K6A	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Laputa	660cc	F6A-T	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	F6A-T	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Laputa	660cc	F6A-T	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Laputa	660cc	F6A-T	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	F6A-T	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Laputa	660cc	F6A-T	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Laputa	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Laputa	660cc	K6A	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laputa	660cc	K6A	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Laputa	660cc	K6A-T	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A-T	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laputa	660cc	K6A-T	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Laputa	660cc	K6A	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A	-	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A	-	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laputa	660cc	K6A	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV (North America / General)	3.0L	AJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (North America / General)	3.0L	AJ	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY - 2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY - 2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY - 2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY - 2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY - 2004 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY - 2004 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x015F 0x00A8 0x016F 0x0170
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2002 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY - 2004 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2002 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
MPV (Europe/General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	RF_T	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0171
MPV (Europe/General)	2.0L	RF_T	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	RF_T	2002 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
MPV (JPN/General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	3.0L	AJ	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002 0x000D
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002 0x000D
Escape / Tribute / Maverick	3.0L	4V	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2003 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2003 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Premacy/ Ixion	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy/ Ixion	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laser / 323 / Tierra	1.3L	B3	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laser / 323 / Tierra	1.3L	B3	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	3.0L	AJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	3.0L	AJ	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	3.0L	AJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	3.0L	AJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (Europe/General)	3.0L	AJ	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	3.0L	AJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A-T	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	K6A	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum	660cc	K6A	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Scrum	660cc	K6A-T	2001 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	K6A-T	2001 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Scrum	660cc	K6A-T	2001 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Scrum	660cc	K6A-T	2001 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Laputa	660cc	K6A	2001.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A	2001.5 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Laputa	660cc	K6A	2001.5 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Laputa	660cc	K6A-T	2001.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A-T	2001.5 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Laputa	660cc	K6A-T	2001.5 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Laputa	660cc	K6A-T	2001.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A-T	2001.5 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Laputa	660cc	K6A-T	2001.5 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Scrum	660cc	K6A	–	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	K6A	–	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum	660cc	K6A	–	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Scrum	660cc	K6A	–	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Protege	2.0L	FS	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	2.0L	FS	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
MX-5 MIATA	1.8L	BP	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	–	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	–	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	–	IC(Instrument Cluster)	✔	✔	✔	–	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	–	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	–	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2002 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2002 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	-	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	-	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy/ Ixion	1.8L	FP	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy/ Ixion	1.8L	FP	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy/ Ixion	1.8L	FP	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy/ Ixion	1.8L	FP	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0009
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 MY	RAP(Remote Anti-Theft / Personality Module)	✔	✔	✔	✔	
Roadster / MX-5	1.6L	B6	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Roadster / MX-5	1.6L	B6	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Roadster / MX-5	1.8L	BP	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Roadster / MX-5	1.8L	BP	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.9L	W9	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Titan	4.0L	TF	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
Titan Dash	2.0L	FE	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
Titan Dash	2.0L	FE	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Titan Dash	2.0L	FE_LPG	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
Titan Dash	2.0L	FE_LPG	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Laputa	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Laputa	660cc	K6A	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Laputa	660cc	K6A	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol	660cc	K6A	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol	660cc	K6A	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Protege	2.0L	FS_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Protege	2.0L	FS_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard-Power	2003 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2004 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2004 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
Bongo / Bongo Brawny / Spectron	1.8L	F8	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
Bongo / Bongo Brawny / Spectron	1.8L	F8	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	F8	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo Brawny / Econovan / Mazda E-Series	2.0L	FE	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	2.0L	FS	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Familia / Laser	1.5L	ZL	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia / Laser	1.5L	ZL	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Friendee / Freda / Bongo Friendee	2.0L	FE	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
Friendee / Freda / Bongo Friendee	2.0L	FE	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Ranger / Courier / Mazda B-Series /Bravo	4.0L	V6 SOHC	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Courier / Mazda B-Series /Bravo	4.0L	V6 SOHC	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Courier / Mazda B-Series /Bravo	4.0L	V6 SOHC	2003 MY	ESOF(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002 0x000D
Escape / Tribute / Maverick	3.0L	4V	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2004 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2004 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0002

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Millenia / Eunos 800	2.5L	KL	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Millenia / Eunos 800	2.5L	KL	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.25L	MZI	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.25L	MZI	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.25L	MZI	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.25L	MZI	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2002 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2002 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2002 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2002 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x001B 0x0172 0x00B2
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY - 2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY - 2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY - 2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY - 2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY - 2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY - 2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY - 2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY - 2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY - 2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY - 2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY - 2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY - 2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY - 2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY - 2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	FACM(Fuel Additive Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2004 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x015F 0x00A8 0x016F 0x0170

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001 0x015F 0x00A8 0x016F 0x0170
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2003 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
MPV (Europe/General)	2.0L	RF_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0171
MPV (Europe/General)	2.0L	RF_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	RF_T	2003 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	RF_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0171
MPV (Europe/General)	2.0L	RF_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	RF_T	2003 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Premacy	2.0L	RF_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy	2.0L	RF_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV (North America / General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV (North America / General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV (JPN/General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Mazda 6 (North America / General)	2.3L	L3	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MX-5 MIATA	1.8L	BP Turbo	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP Turbo	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Carol (2003 / 9 -)	660cc	K6A	-	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Carol (2003 / 9 -)	660cc	K6A	-	RCM(Restraint Control Module)[SRS]	✔	✔	-	-	
Scrum (2003 / 9 -)	660cc	K6A	-	PCM(Powertrain Control Module)	✔	✔	-	-	
Scrum (2003 / 9 -)	660cc	K6A	-	PCM(Powertrain Control Module)	✔	✔	-	-	
Scrum (2003 / 9 -)	660cc	K6A	-	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Scrum (2003 / 9 -)	660cc	K6A	-	RCM(Restraint Control Module)[SRS]	✔	✔	-	-	
Scrum (2003 / 9 -)	660cc	K6A-T	-	PCM(Powertrain Control Module)	✔	✔	-	-	
Scrum (2003 / 9 -)	660cc	K6A-T	-	TCM(Transmission Control Module)	✔	✔	-	-	
Scrum (2003 / 9 -)	660cc	K6A-T	-	ABS(Anti-Lock Brake System)	✔	✔	-	-	
Scrum (2003 / 9 -)	660cc	K6A-T	-	RCM(Restraint Control Module)[SRS]	✔	✔	-	-	
AZ-OFFROAD	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-OFFROAD	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-OFFROAD	660cc	K6A-T	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon (MJ)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-Wagon (MJ)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0006 0x0002 0x0001 0x0009 0x0007
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0006 0x0002 0x0001 0x0009 0x0007
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0001 0x0006 0x0009 0x0007 0x0002 0x000D
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
(All 2005 Model Year) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0001
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Escape / Tribute (- 2006/3)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Roadster / MX-5	1.8L	BP Turbo	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Roadster / MX-5	1.8L	BP Turbo	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Roadster / MX-5	1.8L	BP Turbo	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Roadster / MX-5	1.8L	BP Turbo	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2003 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol (2003 / 9 -)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (2003 / 9 -)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (2003 / 9 -)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol (2003 / 9 -)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (2003 / 9 -)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (2003 / 9 -)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2003 / 9 -)	660cc	K6A-T	2003 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2003 / 9 -)	660cc	K6A-T	2003 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2004 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	3.1L	4JG2	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	3.1L	4JG2_LPG	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.8L	4HL1	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.8L	4HL1	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Titan (Isuzu OEM)	4.8L	4HL1_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Titan (Isuzu OEM)	4.8L	4HL1_T	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Titan (Isuzu OEM)	4.6L	4HG1_LPG	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (2003 / 9 -)	660cc	K6A	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (2003 / 9 -)	660cc	K6A	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (2003 / 9 -)	660cc	K6A	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP Standard-Power	2005 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2005 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
MPV (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MPV (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MPV (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MPV (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MPV (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
MX-5 MIATA	1.8L	BP	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
MX-5 MIATA	1.8L	BP	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Titan Dash	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Titan Dash	2.0L	RF_T	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Titan Dash	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Titan Dash	2.0L	RF_T	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Titan Dash	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Ranger	3.0L	I4 DSL Electronic	2005.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger	3.0L	I4 DSL Electronic	2005.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger	3.0L	I4 DSL Electronic	2005.5 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger	3.0L	I4 DSL Electronic	2005.5 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger	3.0L	I4 DSL Electronic	2005.5 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
MPV (JPN/General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	2.3L	L3	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D
MPV (JPN/General)	2.3L	L3	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (JPN/General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV (JPN/General)	2.3L	L3	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
MX-5 MIATA	1.8L	BP	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
MX-5 MIATA	1.8L	BP	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 MIATA	1.8L	BP	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001E 0x001B 0x0086 0x00B0 0x00B1 0x00B2 0x000D 0x0052 0x00B3
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001E 0x001B 0x0086 0x00B0 0x00B1 0x00B2 0x000D
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001E 0x001B 0x0086 0x00B0 0x00B1 0x00B2 0x000D
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001E 0x001B 0x0086 0x00B0 0x00B1 0x00B2 0x000D
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001E 0x001B 0x0086 0x00B0 0x00B1 0x00B2
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001E 0x001B 0x0086 0x00B0 0x00B1 0x00B2
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001E 0x001B 0x0086 0x00B0 0x00B1 0x00B2 0x000D
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x00B0 0x00B1 0x00B2 0x000D 0x00B3
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	4X4(4X4 Control Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x00B1 0x000D 0x00B2
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x00B1 0x00B2 0x0174
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x00B0 0x00B1 0x00B2 0x000D 0x00B3
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x00B1 0x00B2 0x000D
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (North America / General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
MPV (Europe/General)	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0171
MPV (Europe/General)	2.0L	RF_T	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (Europe/General)	2.0L	RF_T	2004 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x015F 0x00A8 0x016F 0x0170
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x015F 0x00A8 0x016F 0x0170
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2004 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Carol (HB24S)	660cc	K6A	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol (HB24S)	660cc	K6A	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00A3 0x00A4 0x00A5
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2004 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x00A6 0x00A7 0x00A8
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0024 0x001E
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0024 0x001E
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0024 0x001E
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0024 0x001E
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0024 0x001E
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0024 0x001E
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x00B0 0x00B1 0x00B2 0x000D 0x00B3
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x00B1 0x00B2 0x000D
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x00B1 0x00B2
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x00B1 0x00B2 0x00A3 0x00A4 0x00A5
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00AC 0x00AD 0x00AE 0x00AF 0x0004
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2005 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x00B0 0x00B1 0x00B2 0x000D 0x00B3
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x00B1 0x00B2 0x00B3
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2 0x00B0
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2 0x00B0
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2 0x00B0
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2 0x00B0
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.3L	ZJ	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2 0x00B0
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2 0x00B0
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2 0x00B0
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x00B2 0x00B0
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Demio (JPN) / Verisa (JPN) / Mazda 2 (General)	1.5L	ZY	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0002 0x00B0 0x0086
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x00B0 0x0171 0x00A3 0x00A4 0x00A5 0x00AF 0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x0176 0x00AC 0x00AD 0x00AE
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	RF_T	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000D 0x00B0 0x0175 0x00B2
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175 0x00B0
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175 0x00B0
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175 0x00B0
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3_T	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154 0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY - 2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154 0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154 0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0154 0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	✔	✔	-	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	GEM(Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY -	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0175 0x00B0
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge Lamp)	✔	✔	✔	-	
Atenza (JPN) / Mazda 6 (General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-OFFROAD	660cc	K6A-T	2004 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-OFFROAD	660cc	K6A-T	2004 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Titan Dash	2.0L	RF_T	2004.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Titan Dash	2.0L	RF_T	2004.5 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Titan Dash	2.0L	RF_T	2004.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0004 0x009F
Titan Dash	2.0L	RF_T	2004.5 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Titan Dash	2.0L	RF_T	2004.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00A3 0x00A4 0x00A5 0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00AC 0x00AD 0x00AE 0x00AF 0x0004
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x00B2 0x0052 0x00B3
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	TCM(Transmission Control Module)	✔	✔	–	–	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x00B2 0x0052 0x00B3
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x00B2 0x0052 0x00B3
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x0173 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x001E 0x00B2 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x001E
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x001E 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x001E 0x0086
Mazda 3 (North America / General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	-	PCM(Powertrain Control Module)	✔	✔	✔	-	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	-	TCM(Transmission Control Module)	✔	✔	-	-	
MX-5 (North America / General Specs.)	2.0L	LF	-	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	-	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	-	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	-	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0018 0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0018 0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV (North America / General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0018 0x0086 0x000D
MPV (North America / General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV (North America / General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0002 0x00B2 0x00B3 0x015C 0x00B0 0x000D
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	4X4(4X4 Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	AM(Amplifier Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	HCM(Headlamp Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	LCM(Lighting Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY - 2012 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B0 0x00B2 0x00B3
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	4X4(4X4 Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	AM(Amplifier Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	HCM(Headlamp Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	-	0x0041 0x0018 0x001B
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00DB 0x001E 0x00B0
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x00B2 0x00B3
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	AM(Amplifier Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	HCM(Headlamp Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x001B
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00DB 0x001E 0x00B0
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x00B2 0x00B3
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	4X4(4X4 Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	AM(Amplifier Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	HCM(Headlamp Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	–	0x0041 0x0018 0x001B
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00DB 0x001E 0x00B0
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B2 0x00B3
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	AM(Amplifier Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	HCM(Headlamp Control Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LCM(Lighting Control Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	–	0x0041 0x0018 0x001B
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00DB 0x001E 0x00B0
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00B2 0x00B3
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	4X4(4X4 Control Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	AM(Amplifier Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	HCM(Headlamp Control Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LCM(Lighting Control Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	–	0x0041 0x0018 0x001B
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00DB 0x001E 0x00B0

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x0002 0x00B3 0x015C 0x00B2
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	4X4(4X4 Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	HCM(Headlamp Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B0 0x00B2 0x00B3 0x015C
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	HCM(Headlamp Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B0 0x00B2 0x00B3 0x015C
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	4X4(4X4 Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	HCM(Headlamp Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
Mazda 2 (EURO STG3/4 Specs.)	1.25L	MZI	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0017 0x0002 0x00B2
Mazda 2 (EURO STG3/4 Specs.)	1.25L	MZI	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.25L	MZI	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.25L	MZI	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0017 0x0002 0x00B2
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0017 0x0002 0x00B2
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZI	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0017 0x0002 0x00B2
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.4L	MZ_CD DI	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0017 0x0002 0x00B2
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0017 0x0002 0x00B2
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (EURO STG3/4 Specs.)	1.6L	MZI	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Escape / Tribute / Maverick	3.0L	4V	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017
Escape / Tribute / Maverick	3.0L	4V	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x001B 0x001C 0x001D
Escape / Tribute / Maverick	3.0L	4V	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	0x0024 0x001E 0x0005
Escape / Tribute / Maverick	3.0L	4V	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x0001 0x0006 0x0009

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape / Tribute / Maverick	3.0L	4V	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0007 0x0002 0x000D
Escape / Tribute / Maverick	3.0L	4V	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2006 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x001B 0x001C 0x001D 0x0024 0x001E 0x0005 0x0006 0x0002 0x0001 0x0009 0x0007 0x000D
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x001B 0x001C 0x001D 0x0024 0x001E 0x0005 0x0006 0x0002 0x0001 0x0007
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0035 0x0017 0x0084 0x0024 0x0081
Ranger	2.3L	DURATEC-HE / I4	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2006 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2006 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x001B 0x001C 0x001D 0x0024 0x001E 0x0005 0x0006 0x0002 0x0001 0x0007
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2004 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2004 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0173 0x00DB 0x001E
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0173 0x00DB 0x001E
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0173 0x00DB 0x001E
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2006 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	FACM(Fuel Additive Control Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B2 0x0174 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY - 2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x0174
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY - 2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY - 2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY - 2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY - 2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY - 2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY - 2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY - 2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY - 2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x000D 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2
Mazda 3 (North America / General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x000D 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x001B 0x001C 0x001D 0x0024 0x001E 0x0005 0x0006 0x0002 0x0001 0x0007
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x001B 0x001C 0x001D 0x0024 0x001E 0x0005 0x0006 0x0002 0x0001 0x0007
Escape / Tribute / Maverick	3.0L	4V	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute / Maverick	3.0L	4V	2007 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0018 0x0019 0x001E 0x0001 0x0009
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0018 0x0019 0x001E 0x0002 0x0001 0x0009 0x0007
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0018 0x0019 0x001E
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0018 0x0019 0x001E

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0018 0x001E 0x0005 0x0007 0x0002 0x0001 0x000D
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0018 0x0019 0x001E
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0018 0x0019 0x001E
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0035 0x0017 0x0018 0x0019 0x001E
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Scrum (2005 / 9 -) DG64V / DG64W	660cc	K6A-T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x001B 0x00DB 0x001E 0x00B2 0x00B3
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	–	PCM(Powertrain Control Module)	✔	✔	✔	–	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.5L	CY	–	TCM(Transmission Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	–	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	–	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	–	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	–	4X4(4X4 Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	–	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	–	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	–	LCM(Lighting Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	–	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	–	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x00DB 0x001E
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon (MJ)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A-T	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x001E
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x001E
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol (HB24S)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol (HB24S)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
Carol (HB24S)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MD/MJ)/ SPIANO (HF)	660cc	K6A	2005 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0041 0x0035 0x0017 0x0037 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (North America / General)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	2.3L	L3	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0002
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C 0x000D 0x0178 0x0002 0x00B0
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0035 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B0 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0035 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B0 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0035 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B0 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x001E 0x0002 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2007 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001E 0x001B 0x0086 0x00B0 0x00B1 0x00B2 0x000D
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0041 0x0018 0x0173
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001E 0x001B 0x0086
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B0 0x00B1 0x00B2
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0041 0x0018 0x0173
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001E 0x001B 0x0086
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B0 0x00B1 0x00B2
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	0x000D
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0041 0x0018 0x0173
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001E 0x001B 0x0086
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B0 0x00B1 0x00B2
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2005 MY	TCM(Transmission Control Module)	✔	✔	–	–	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2005 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	–	0x0016 0x0017 0x007E
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0019 0x001A
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	0x00CB 0x0003 0x001B

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	BCM(Battery Control Module)	✔	✔	✔	–	0x001D 0x0025 0x001E 0x0086 0x001C 0x00CC 0x0024 0x0005 0x0006 0x0009 0x0007 0x00CD 0x002A 0x0003 0x00CE 0x0013 0x0012 0x0011 0x0014 0x000D 0x0028
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	FDIM(Front Display Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x0019 0x001A 0x00CB 0x0003 0x001B 0x001D 0x0025 0x001E 0x0086 0x001C 0x00CC 0x0024 0x0005 0x0006 0x0009 0x0007 0x0002 0x0003 0x002A 0x00CE 0x0013 0x0012 0x0011 0x0014 0x000D 0x0028
Escape /Tribute / Mariner	3.0L	4V	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	FDIM(Front Display Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	3.0L	4V	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x0019 0x001A 0x00CB 0x0003 0x001B 0x001D 0x0025 0x001E 0x0086 0x001C 0x00CC 0x0024 0x0005 0x0006 0x0009 0x0007 0x0002 0x0003 0x002A 0x00CE 0x0013 0x0012 0x0011 0x0014 0x000D 0x0028
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	FDIM(Front Display Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0016 0x0017 0x007E
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	0x0018 0x0019 0x001A
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x00CB 0x0003 0x001B
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	0x001D 0x0025 0x001E
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ACM(Audio Control Module)	✔	✔	✔	✔	0x0086 0x001C 0x00CC
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	0x0024 0x0005 0x0006
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	FDIM(Front Display Interface Module)	✔	✔	✔	✔	0x0009 0x0007 0x0002
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	0x0003 0x002A 0x00CE 0x0013 0x0012 0x0011 0x0014 0x0028
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C 0x000D 0x0002 0x00B0
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	TCM(Transmission Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY - 2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0035 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x00DB 0x0179 0x001E 0x00B0 0x00B1 0x00B2 0x00B3
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x00DA 0x0035 0x0017 0x0037 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x015E 0x00A3 0x00A4 0x00A5 0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00AC 0x00AD 0x00AE 0x00AF 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x00DA 0x0035 0x0017 0x0037 0x0018 0x001B 0x00DB 0x001E 0x00B2 0x017A 0x00A3 0x00A4 0x00A5 0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00AC 0x00AD 0x00AE 0x00AF 0x00B3
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (EURO STG3/4/5 and General Specs.)	2.0L	RF_T	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x001B 0x00DB 0x001E
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0161 0x017B 0x017C
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x0164 0x0165 0x0166 0x0167 0x0168 0x0169
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001B 0x00DB 0x001E
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x0161 0x017B 0x017C 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001B 0x00DB 0x001E
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x0161 0x017B 0x017C 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x001B 0x00DB 0x001E
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0161 0x017B 0x017C
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x000D
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0161 0x017B 0x017C 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0161 0x017B 0x017C 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0161 0x017B 0x017C 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0161 0x017B 0x017C 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x000D
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (General)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
AZ-Wagon (MJ)	660cc	K6A	2006 MY	PCM(Powertrain Control Module)	✔	✔	–	–	
AZ-Wagon (MJ)	660cc	K6A	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-Wagon (MJ)	660cc	K6A	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon (MJ)	660cc	K6A	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon (MJ)	660cc	K6A	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	-	
AZ-Wagon (MJ)	660cc	K6A	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Familia Wagon/VAN (B*Y11-500000-)	1.8L	QG18	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia Wagon/VAN (B*Y11-500000-)	1.3L	QG13	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia Wagon/VAN (B*Y11-500000-)	1.3L	QG13	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia Wagon/VAN (B*Y11-500000-)	1.5L	QG15	2002 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia Wagon/VAN (B*Y11-500000-)	1.5L	QG15	2002 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x017D 0x00DB 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x00B3 0x000D
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B0 0x00B1 0x00B2
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00B3 0x000D
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x017D 0x00DB 0x001E 0x00B0 0x00B1 0x00B2 0x00B3 0x000D
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2006 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.2L	CR12	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Familia VAN (BV*Y12)	1.2L	CR12	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.2L	CR12	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Familia VAN (BV*Y12)	1.2L	CR12	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.2L	CR12	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.2L	CR12	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.2L	CR12	2007 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Familia VAN (BV*Y12)	1.5L	HR15	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2007 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Familia VAN (BV*Y12)	1.8L	MR18	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2007 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x000F 0x0005 0x0002 0x000F 0x0001 0x0009 0x000D 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x001E 0x0007 0x0005 0x0009 0x0007 0x0002 0x0001 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x0007 0x0005 0x0007 0x0002 0x0001 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x0007 0x0005 0x0007 0x0002 0x0001 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041 0x0004 0x00D0 0x00D1
BT-50 / Ranger	2.5L	WL-CD	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041 0x0004
BT-50 / Ranger	2.5L	WL-CD	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041 0x0004
BT-50 / Ranger	2.5L	WL-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041 0x0004
BT-50 / Ranger	2.5L	WL-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041 0x00A0 0x0004 0x00D0 0x00D1 0x000D
BT-50 / Ranger	2.5L	WL-CD	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041 0x0004
BT-50 / Ranger	2.5L	WL-CD	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	3.0L	WE-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041 0x0004
BT-50 / Ranger	3.0L	WE-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	3.0L	WE-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.5L	WL	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
BT-50 / Ranger	2.5L	WL	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.2L	F2	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
BT-50 / Ranger	2.2L	F2	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.2L	F2	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.6L	G6	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.6L	G6	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.6L	G6	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000F 0x0028
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	ESOF(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x000F 0x0028
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	ESOF(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x0007 0x0005 0x0007 0x0002 0x0001 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x0007 0x0005 0x0007 0x0002 0x0001
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0009 0x0028
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	3.0L	Other	2008 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Titan (Isuzu OEM)	5.2L	4HK1_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	5.2L	4HK1_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Titan (Isuzu OEM)	5.2L	4HK1_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Titan (Isuzu OEM)	5.2L	4HK1_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Titan (Isuzu OEM)	5.2L	4HK1_T	2007 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	-	
Titan (Isuzu OEM)	5.2L	4HK1_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0158 0x0159 0x0172 0x00DB 0x0179 0x016C 0x017E 0x00B2 0x0161 0x017B 0x017C
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0158 0x0159 0x0172 0x00DB 0x0179 0x016C 0x017E 0x00B2 0x0161 0x017B 0x017C
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (Europe)	1.3L	ZJ	2007 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0158 0x0159 0x0172 0x00DB 0x0179 0x016C 0x017E 0x00B2 0x0161 0x017B 0x017C
Mazda 2 (Europe)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0158 0x0159 0x0172 0x00DB 0x0179 0x016C 0x017E 0x00B2 0x0161 0x017B 0x017C
Mazda 2 (Europe)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0158 0x0159 0x0172 0x00DB 0x0179 0x016C 0x017E 0x00B2 0x0161 0x017B 0x017C
Mazda 2 (Europe)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (Europe)	1.5L	ZY	2007 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x0052 0x00B1 0x00B2 0x00B3 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0173 0x001E 0x0086 0x0052

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0173 0x001E 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0173 0x001E 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0173 0x001E 0x0086

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0173 0x001E 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0173 0x001E 0x0086
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.0L	AJ	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x0173 0x001E 0x0086

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0052
Mazda 6 (North America / General)	2.3L	L3	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x0173 0x001E 0x0001 0x0086
Mazda 6 (North America / General)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x0173 0x001E 0x0086
Mazda 6 (North America / General)	2.3L	L3	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x0173 0x001E 0x0086

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0041 0x0173 0x001E 0x0086
Mazda 6 (North America / General)	2.3L	L3	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0154 0x0086 0x00B2 0x0052 0x00B3
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0086 0x00B2 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0173 0x00DB 0x001E
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0086 0x00B2 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0173 0x00DB 0x001E
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0086 0x00B2 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0173 0x00DB 0x001E
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0086 0x00B2 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0017 0x0037 0x0037 0x0041 0x0018 0x0173 0x00DB 0x001E 0x0086 0x00B2 0x0154
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B-MSP High-Power	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3_T	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x001E 0x0086
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x001E 0x0086
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x001E 0x0086 0x000D
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	1.6L	Z6	2006 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.4L	Y4	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0018 0x0158 0x0159 0x0172 0x00DB 0x0179 0x016C 0x017E 0x00B2 0x0161 0x017B 0x017C 0x017F 0x0180 0x0181 0x0182
Mazda 2 (Europe)	1.4L	Y4	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.4L	Y4	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (Europe)	1.4L	Y4	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.4L	Y4	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (Europe)	1.4L	Y4	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.4L	Y4	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (Europe)	1.4L	Y4	2007 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0157 0x001B 0x001C 0x00DB 0x0024 0x001E 0x00B1 0x0052 0x0153 0x0154 0x0155
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0157 0x001B 0x001C 0x00DB 0x0024 0x001E 0x00B1 0x0052 0x0153 0x0154 0x0155
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x0024
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001E 0x00B1 0x0052 0x0153 0x0154 0x0155
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	TCM(Transmission Control Module)	✔	✔	–	–	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x0024
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001E 0x00B1 0x0052 0x0153 0x0154 0x0155
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001C 0x00DB 0x0024 0x001E 0x00B1 0x0052 0x0153 0x0154 0x0155
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	1.8L	L8	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x0024
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001E 0x00B1 0x0052 0x0153 0x0154 0x0155
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001C 0x00DB 0x0024 0x001E 0x00B1 0x0052
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0154 0x0155
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x0024
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001E 0x00B1 0x0052 0x0153 0x0154 0x0155
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, Before Facelift)	2.0L	LF	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	TCM(Transmission Control Module)	✔	✔	–	–	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x0024
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001E 0x0154 0x00B1 0x0052 0x0153 0x015D
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0155 0x015E 0x00A4
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A5 0x00AF 0x015F
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x00A7 0x00A8 0x00A9
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	0x00AA 0x00AB 0x00AC
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	0x00A3 0x00AD 0x00AE
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	0x0004
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001C 0x00DB 0x0024 0x001E 0x0154 0x00B1
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0052 0x0153 0x015D
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x0155 0x015E 0x00A4
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x00A5 0x00AF 0x015F
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	0x00AA 0x00AB 0x00AC
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	0x00A3 0x00AD 0x00AE
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	0x0004
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001C 0x00DB 0x0024 0x001E 0x0154 0x00B1
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0052 0x0153 0x015D
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x0155 0x015E 0x00A4
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x00A5 0x00AF 0x015F
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	0x00AA 0x00AB 0x00AC
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	0x00A3 0x00AD 0x00AE 0x0004

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, Before Facelift)	2.0L	RF_T	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0153 0x0155 0x00B1 0x0052
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0157 0x001B 0x001C 0x00DB 0x001E 0x00B1 0x0153 0x0154 0x0155
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x0041 0x0018 0x0157 0x001B 0x001C 0x00DB 0x001E 0x00B1 0x0153 0x0154 0x0155
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001B
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x001E
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x00B1 0x0153 0x0154 0x0155
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 2 (China)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Mazda 2 (China)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Mazda 2 (China)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001B 0x00DB 0x001E
Mazda 2 (China)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x0161 0x017B 0x017C
Mazda 2 (China)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (China)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (China)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (China)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Mazda 2 (China)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Mazda 2 (China)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001B 0x00DB 0x001E
Mazda 2 (China)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x0161 0x017B 0x017C
Mazda 2 (China)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (China)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (China)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (China)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 2 (China)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0161 0x017B 0x017C
Mazda 2 (China)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (China)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (China)	1.3L	ZJ	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (China)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (China)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x017D 0x00DB 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x000D
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x017D 0x00DB 0x001E 0x00B0 0x00B1 0x00B2 0x000D 0x00B3
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.3L	L3	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x017D 0x00DB 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x000D 0x00B3
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	4X4(4X4 Control Module)	✔	✔	-	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY -	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x017D 0x00DB 0x001E 0x00B0 0x00B1 0x00B2 0x000D 0x00B3
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	4X4(4X4 Control Module)	✔	✔	-	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x017D 0x00DB 0x001E 0x00B0 0x00B1 0x00B2 0x000D 0x00B3
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5 (Japan / General Specs.)	2.0L	LF	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0173 0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x000D 0x0178 0x00B3 0x0183 0x0184
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x000D 0x00B3 0x0183 0x0184
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00A3 0x00A4 0x00A5 0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00A3 0x00A4 0x00A5 0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00A3 0x00A4 0x00A5 0x00A6 0x00A7 0x00A8
Bongo / Bongo Brawny / Spectron	2.0L	RF_T	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x00DA 0x0035 0x0017 0x0037 0x0018 0x001B 0x008F 0x00DB 0x001E 0x0086 0x00B1 0x00B2 0x00B0 0x00A3 0x00A4 0x00A5 0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00AC 0x00AD 0x00AE 0x00AF 0x0004 0x00B3
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	TCM(Transmission Control Module)	✔	✔	–	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x00DA 0x0035 0x0017 0x0037 0x0018 0x001B 0x008F 0x00DB 0x001E 0x00A3 0x00A4 0x00A5 0x00A6 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00AC 0x00AD 0x00AE 0x00AF 0x0004
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF_T	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x008F 0x00DB 0x001E 0x00B1 0x00B2 0x00B0 0x000D 0x00B3
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x008F 0x00DB 0x001E 0x00B1 0x00B2 0x00B0 0x00B3
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x008F 0x00DB 0x001E 0x00B1 0x00B2 0x00B0 0x000D 0x00B3
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x008F 0x00DB 0x001E 0x00B1 0x00B2 0x00B0 0x000D 0x00B3
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	PCM(Powertrain Control Module)	✔	✔	-	-	0x002F 0x0034 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B1 0x00B2 0x000D
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	TCM(Transmission Control Module)	✔	✔	-	-	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x0052 0x00B3
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x0052 0x000D 0x00B3
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x0052 0x00B3
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0161 0x017B 0x017C
Mazda 2 (China)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0161 0x017B 0x017C
Mazda 2 (China)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0161 0x017B 0x017C
Mazda 2 (China)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (China)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (China)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0157 0x001B 0x001C 0x00DB 0x001E 0x00B1 0x0153 0x0154 0x0155
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001B
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x001E
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x00B1 0x0153 0x0154 0x0155
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	MPM(Motor Pretensioner Module)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Atenza (JPN) / Mazda 6 (General)	2.0L	LF	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	TCM(Transmission Control Module)	✔	✔	–	–	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001B
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x0024
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001E 0x00B1 0x0052 0x0153 0x0154 0x015D
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015E 0x0155 0x00A4
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A5 0x00AF 0x015F
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x00A7 0x00A8 0x00A9
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	0x00AA 0x0160 0x00AC 0x00A3
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001B

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001C 0x00DB 0x0024 0x001E 0x00B1 0x0052 0x0153 0x0154 0x015D 0x015E 0x0155 0x00A4 0x00A5 0x00AF 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00AC 0x00A3
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2007 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	–	0x00B1 0x0052 0x0153 0x0154 0x015D 0x015E 0x0155 0x00A4 0x00A5 0x00AF 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00AC 0x00A3
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	TCM(Transmission Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, Before Facelift)	2.2L	R2_T	2008 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Biante(Japan)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Biante(Japan)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Biante(Japan)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Biante(Japan)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Biante(Japan)	2.3L	L3	2008 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x008F 0x00DB 0x001E
Biante(Japan)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Biante(Japan)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0185
Biante(Japan)	2.3L	L3	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Biante(Japan)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.3L	L3	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Biante(Japan)	2.3L	L3	2008 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0034 0x0017 0x0037
Biante(Japan)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x001B
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x008F 0x00DB 0x001E
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0185
Biante(Japan)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Biante(Japan)	2.0L	LF	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0034 0x0017 0x0037
Biante(Japan)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x001B
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x008F 0x00DB 0x001E
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0185
Biante(Japan)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0034 0x0017 0x0037
Biante(Japan)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x001B
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x008F 0x00DB 0x001E

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0185
Biante(Japan)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x008F 0x00DB 0x001E 0x0185
Biante(Japan)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Biante(Japan)	2.0L	LF	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Biante(Japan)	2.0L	LF	2008 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0052 0x0086 0x0153
Mazda 6 (North America / General)	2.5L	L5	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x00B1 0x0052 0x0086 0x0153
Mazda 6 (North America / General)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x00B1 0x0052 0x0086 0x0153
Mazda 6 (North America / General)	2.5L	L5	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.5L	L5	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x0005 0x00B1 0x0052 0x0086 0x0153 0x015C
Mazda 6 (North America / General)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x0005 0x00B1 0x0052 0x0086 0x0153 0x015C
Mazda 6 (North America / General)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.7L	CA	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0037 0x00D9 0x0041 0x0018 0x0173 0x001B 0x00DB 0x001E 0x0154 0x0086 0x00B2 0x0052 0x00B3 0x00B0
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0037 0x00D9 0x0041 0x0018 0x0173 0x001B 0x00DB 0x001E 0x0154 0x0086 0x00B2 0x0052 0x00B3 0x00B0
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x00D9 0x0041 0x0018 0x0173 0x001B 0x00DB 0x001E 0x0154 0x0086 0x00B2 0x0052 0x00B3 0x00B0
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0037 0x00D9 0x0041 0x0018 0x0173 0x001B 0x00DB 0x001E 0x0154 0x0086 0x00B2 0x0052 0x00B3 0x00B0
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0037 0x00D9 0x0041 0x0018 0x0173 0x001B 0x00DB 0x001E 0x0154 0x0086 0x00B2 0x0052 0x00B3 0x00B0
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (North America Specs.)	654x2cc	13B	2009 MY	SASM(Steering Angle Sensor Module)	✔	✔	–	–	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0037 0x00D9 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0154 0x0086
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x00B3 0x000D
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	LCM(Lighting Control Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0037 0x00D9 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0154 0x00B2 0x00B3 0x000D
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	LCM(Lighting Control Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0037 0x00D9 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0154 0x00B2 0x00B3
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	LCM(Lighting Control Module)	✔	✔	-	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	SASM(Steering Angle Sensor Module)	✔	✔	-	-	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x00B1 0x0052 0x0086 0x0153
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x00B1 0x0052 0x0086 0x0153
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x00B1 0x0052 0x0086 0x0153
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x0005 0x00B1 0x0052 0x0086 0x0153 0x0154
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x0005 0x0001 0x00B1 0x0052 0x0086 0x0153 0x0154
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x0019 0x001A 0x00CB 0x0003 0x001B 0x001D 0x0025 0x0086 0x001C 0x00CC 0x0024 0x0005 0x0006 0x0009 0x0002 0x002A 0x00CE 0x0012 0x0011 0x0014 0x0027 0x0007 0x0003 0x000D 0x0076 0x0028
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	FDIM(Front Display Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x0019 0x001A 0x00CB 0x001B 0x001D 0x0025 0x0086 0x001C 0x00CC 0x0024 0x0005 0x0006 0x000F 0x00CD 0x002A 0x00CE 0x0012 0x0011 0x0014 0x0027 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	BCM(Battery Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	FDIM(Front Display Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0016 0x0017 0x007E
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0019 0x001A
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x00CB 0x0003 0x001B
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	0x001D 0x0025 0x0086
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ACM(Audio Control Module)	✔	✔	✔	–	0x001C 0x00CC 0x0024
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ACM(Audio Control Module)	✔	✔	✔	✔	0x0005 0x0006 0x0002
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	0x002A 0x00CE 0x0012
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	0x0011 0x0014 0x0027
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	0x0007 0x0003 0x000D
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	FDIM(Front Display Interface Module)	✔	✔	✔	✔	0x0009 0x0076 0x0028
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0016 0x0017 0x007E
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0019 0x001A
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x00CB 0x0003 0x001B
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	0x001D 0x0025 0x0086
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ACM(Audio Control Module)	✔	✔	✔	–	0x001C 0x00CC 0x0024
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ACM(Audio Control Module)	✔	✔	✔	✔	0x0005 0x0006 0x0007
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	0x0002 0x002A 0x00CE
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	0x0003 0x0012 0x0011
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	0x0014 0x0027 0x0009
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	FDIM(Front Display Interface Module)	✔	✔	✔	✔	0x0076 0x0028
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PAM(Parking Aid Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
AZ-OFFROAD	660cc	K6A-T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-OFFROAD	660cc	K6A-T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
AZ-OFFROAD	660cc	K6A-T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-OFFROAD	660cc	K6A-T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
AZ-OFFROAD	660cc	K6A-T	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-OFFROAD	660cc	K6A-T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
AZ-OFFROAD	660cc	K6A-T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	–	
AZ-OFFROAD	660cc	K6A-T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x0174 0x00B3
Mazda 3 (China / General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (China / General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (China / General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x000D 0x00B3
Mazda 3 (China / General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (China / General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (China / General)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (China / General)	1.6L	Z6	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x000D 0x00B3
Mazda 3 (China / General)	1.6L	Z6	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (China / General)	1.6L	Z6	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (China / General)	1.6L	Z6	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (China / General)	1.6L	Z6	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (China / General)	1.6L	Z6	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (China / General)	1.6L	Z6	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x00B2 0x0052 0x00B3
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	DHS(Deployable Hood System)	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x00B2 0x0052 0x00B3
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	DHS(Deployable Hood System)	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x00B2 0x0052 0x00B3
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	DHS(Deployable Hood System)	✔	✔	✔	–	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.3L	L3	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (North America / General)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x000D 0x00B3
Mazda 3 (North America / General)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.0L	LF	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.0L	LF	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	-	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x0173 0x001B 0x001E 0x0086 0x0052 0x00B2 0x00B3
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	–	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	–	–	
Mazda 3 (North America / General)	2.3L	L3_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (China)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (China)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (China)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x001B 0x00DB
Mazda 6 (China)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0024 0x001E 0x0154
Mazda 6 (China)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x00B1 0x0153
Mazda 6 (China)	2.5L	L5	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (China)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (China)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (China)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (China)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (China)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (China)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (China)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x001B 0x00DB
Mazda 6 (China)	2.5L	L5	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0024 0x001E 0x0154
Mazda 6 (China)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x00B1 0x0153
Mazda 6 (China)	2.5L	L5	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (China)	2.5L	L5	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (China)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (China)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (China)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (China)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (China)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x001B 0x00DB
Mazda 6 (China)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0024 0x001E 0x0154
Mazda 6 (China)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x00B1 0x0153
Mazda 6 (China)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (China)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (China)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034
Mazda 6 (China)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0017 0x0037 0x0041
Mazda 6 (China)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x001B 0x00DB

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (China)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0024 0x001E 0x0154 0x00B1 0x0153
Mazda 6 (China)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (China)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (China)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x0024 0x001E 0x0154 0x00B1 0x0153
Mazda 6 (China)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (China)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (China)	2.0L	LF	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (China)	2.0L	LF	2007 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (China)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Mazda 6 (China)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x0183 0x0184 0x000D 0x00B3
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0041 0x0018 0x0173 0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x0183 0x0184 0x00B3
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x0183 0x0184 0x000D 0x00B3
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0034 0x0017 0x0041 0x0018 0x0173 0x001B 0x008F 0x001E 0x0086 0x00B0 0x00B1 0x00B2 0x0183 0x0184 0x00B3
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 5 (North America Specs.)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x0086 0x00B2 0x0052 0x00B3
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x00B2 0x00B3
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	DHS(Deployable Hood System)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0017 0x0037 0x0041 0x0018 0x00DB 0x001E 0x00B2 0x00B3
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	✔	✔	✔	-	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Roadster / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	DHS(Deployable Hood System)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x0007 0x0005 0x0007 0x0002 0x0001 0x0009 0x0014 0x000D 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x0007 0x0005 0x0007 0x0002 0x0014 0x0001 0x0009 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x0007 0x0005 0x0007 0x0002 0x0001 0x0014 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0016 0x0017 0x0018 0x0019 0x001C 0x0025 0x001E 0x0007 0x0005 0x0007 0x0002 0x0001 0x0014 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2009 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2009.5 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0080 0x0035 0x0017 0x0084 0x008F 0x0079 0x0024 0x0081 0x001E 0x0005 0x0007 0x0002 0x0014 0x000D
Ranger	2.3L	DURATEC-HE / I4	2009.5 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2009.5 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2009.5 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2009.5 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger	2.3L	DURATEC-HE / I4	2009.5 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.6L	Y6	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	–	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0158 0x0159 0x0172 0x00DB 0x0179 0x016C 0x017E 0x00B2 0x0161 0x017B 0x017C 0x0004 0x011A 0x0047 0x0046 0x0065 0x0066 0x0067 0x0068 0x00BE
Mazda 2 (Europe)	1.6L	Y6	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.6L	Y6	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 (Europe)	1.6L	Y6	2008 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.6L	Y6	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 (Europe)	1.6L	Y6	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 (Europe)	1.6L	Y6	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 2 (Europe)	1.6L	Y6	2008 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0035 0x0017 0x0037 0x00D9
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0186 0x0041 0x0018 0x0157 0x001B 0x008F 0x015A 0x001C 0x0079 0x00DB 0x0179 0x001E 0x0185 0x0086 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0 0x015C 0x0155
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0035 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0157 0x001B 0x008F 0x015A 0x001C 0x0079 0x00DB 0x0179 0x001E 0x0185 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0 0x0155 0x015C
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0035 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0157 0x001B 0x008F 0x015A 0x001C 0x0079 0x00DB 0x0179 0x001E 0x0185 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0 0x0155
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0188 0x001B 0x008F 0x001C 0x001D 0x0079 0x00DB 0x0179 0x001E 0x0185 0x0086 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0188 0x001B 0x008F 0x001C 0x001D 0x0079 0x00DB 0x0179 0x001E 0x0185 0x0086 0x00B1 0x0052 0x00B2 0x0187 0x0012
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B0 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	ACU(Audio Control Unit)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	LCM(Lighting Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	MID#1(Multi-Information Display)	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0188 0x001B 0x008F 0x001C 0x001D 0x0079 0x00DB 0x0179 0x001E 0x0185 0x0086 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0 0x015C
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	ACU(Audio Control Unit)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.6L	HR16	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.6L	HR16	2007 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.6L	HR16	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Familia VAN (BV*Y12)	1.6L	HR16	2007 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.6L	HR16	2007 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.6L	HR16	2007 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.6L	HR16	2007 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0034
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0035 0x0017 0x0037
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00D9 0x0186 0x0041
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0018 0x0157 0x0189
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x001B 0x008F 0x015A
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	4X4(4X4 Control Module)	✔	✔	–	–	0x001C 0x0079 0x00DB
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	0x0179 0x001E 0x0185
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	AM(Amplifier Module)	✔	✔	–	–	0x0086 0x00B1 0x00B2
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x0052 0x0187 0x0012
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	0x00B0 0x0155 0x00A4
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	0x00A5 0x015F 0x00A7
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	0x00A8 0x018A 0x00AA
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	0x00AB 0x018B 0x00AF
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	SCR CU(Selective Catalytic Reduction)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0034
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0035 0x0017 0x0037
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00D9 0x0186 0x0041
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0018 0x0157 0x0189
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x001B 0x008F 0x015A

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	4X4(4X4 Control Module)	✔	✔	–	–	0x001C 0x0079 0x00DB 0x0179 0x001E 0x0185 0x00B1 0x00B2 0x0052 0x0187 0x0012 0x00B0 0x0155 0x00A4 0x00A5 0x015F 0x00A7 0x00A8 0x018A 0x00AA 0x00AB 0x018B 0x00AF
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	SCR CU(Selective Catalytic Reduction)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0035 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0157 0x001B 0x008F 0x015A 0x001C 0x00DB 0x001E 0x0185 0x0086 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0 0x015C 0x0155
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY -	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0035 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0157 0x001B 0x008F 0x015A 0x001C 0x00DB 0x001E 0x0185 0x00B1 0x0155 0x00B2 0x0187 0x0012 0x00B0 0x015C
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0035 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0157 0x001B 0x008F 0x015A 0x001C 0x00DB 0x001E 0x0185 0x00B1 0x0155 0x00B2 0x0187 0x0012 0x00B0 0x015C
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0035 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0157 0x001B 0x008F 0x015A 0x001C 0x00DB 0x001E 0x0185 0x0086 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0 0x015C 0x0155
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0035 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0157 0x001B 0x008F
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x015A 0x001C 0x00DB 0x001E 0x0185 0x00B1 0x0155 0x00B2 0x0187 0x0012 0x00B0
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C 0x0012
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	DSM(Drivers Seat Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ACU(Audio Control Unit)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	DSM(Drivers Seat Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ACU(Audio Control Unit)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	DSM(Drivers Seat Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ACU(Audio Control Unit)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	DSM(Drivers Seat Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x001C 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ACU(Audio Control Unit)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	DSM(Drivers Seat Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0005 0x0086 0x00B1 0x0052 0x0153
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x00D9 0x0018
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x001B 0x008F 0x001C
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x00DB 0x001E
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0005 0x0086 0x00B1 0x0052 0x0153
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x00D9 0x0041
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x001B 0x008F
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x001C 0x00DB
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001E 0x00B1 0x0052 0x0086 0x0153
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x00D9 0x0041
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x001B 0x008F
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x001C 0x00DB
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001E 0x00B1 0x0052 0x0086 0x0153

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (Middle East / General)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0086 0x00B1 0x0052 0x0153 0x0154
Mazda 6 (North America / General)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x0086 0x00B1 0x0052 0x0153 0x0154
Mazda 6 (North America / General)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	3.7L	CA	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0052 0x0086 0x0153
Mazda 6 (North America / General)	2.5L	L5	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x00B1 0x0052 0x0086 0x0153
Mazda 6 (North America / General)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (North America / General)	2.5L	L5	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x008F 0x001C 0x001C 0x00DB 0x001E 0x00B1 0x0052 0x0086 0x0153
Mazda 6 (North America / General)	2.5L	L5	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
Mazda 6 (North America / General)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0188 0x001B 0x008F 0x001C 0x001D 0x0079 0x00DB 0x0179 0x001E 0x0185
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0086 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0 0x015C 0x0155
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	4X4(4X4 Control Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0177 0x0017 0x0037 0x00D9 0x0186 0x0041 0x0018 0x0188 0x001B 0x008F 0x001C 0x001D 0x0079 0x00DB 0x0179 0x001E 0x0185 0x0086 0x00B1 0x0052 0x00B2 0x0187 0x0012 0x00B0
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	✔	✔	–	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	PCM(Powertrain Control Module)	✔	✔	✔	–	0x0086 0x00B1 0x0052
Axela / Mazda 3	2.3L	L3_T	2008 MY -	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0153 0x00B2 0x0187
Axela / Mazda 3	2.3L	L3_T	2008 MY -	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0012 0x0155
Axela / Mazda 3	2.3L	L3_T	2008 MY -	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	4X4(4X4 Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	2008 MY -	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Axela / Mazda 3	2.3L	L3_T	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0186 0x0041
Axela / Mazda 3	2.3L	L3_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001A
Axela / Mazda 3	2.3L	L3_T	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0188 0x001B 0x008F 0x0172 0x001C 0x001C
Axela / Mazda 3	2.3L	L3_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x001C 0x001C 0x001D
Axela / Mazda 3	2.3L	L3_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x001D 0x00DB 0x00DB
Axela / Mazda 3	2.3L	L3_T	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x00DB 0x00DB 0x0024
Axela / Mazda 3	2.3L	L3_T	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	0x0081 0x001E 0x001E 0x001F 0x001F 0x0185

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	2.3L	L3_T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012 0x0155
Axela / Mazda 3	2.3L	L3_T	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.3L	L3_T	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.3L	L3_T	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	2.3L	L3_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.5L	L5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012 0x0155
Axela / Mazda 3	2.5L	L5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.5L	L5	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3	2.5L	L5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	2.5L	L5	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	2.5L	L5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.5L	L5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	2.5L	L5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	2.5L	L5	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Axela / Mazda 3	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	2.5L	L5	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.5L	L5	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.5L	L5	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.5L	L5	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.5L	L5	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	2.5L	L5	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012 0x0155
Axela / Mazda 3	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	2.0L	LF	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.0L	LF	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	2.0L	LF	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Axela / Mazda 3	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0186 0x0041
Axela / Mazda 3	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001A
Axela / Mazda 3	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0188 0x001B 0x008F
Axela / Mazda 3	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0172 0x001C 0x001C 0x001C 0x001C 0x001D
Axela / Mazda 3	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x001D 0x00DB 0x00DB
Axela / Mazda 3	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00DB 0x00DB 0x0024
Axela / Mazda 3	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0081 0x001E 0x001E
Axela / Mazda 3	2.0L	LF	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	0x001E 0x001E 0x0185
Axela / Mazda 3	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x0086 0x00B1 0x0052
Axela / Mazda 3	2.0L	LF	Other	LCM(Lighting Control Module)	✔	✔	–	–	0x0153 0x00B2 0x0187 0x0012 0x0155
Axela / Mazda 3	2.0L	LF	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Axela / Mazda 3	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0186 0x0041
Axela / Mazda 3	2.0L	LF	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001A
Axela / Mazda 3	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0188 0x001B 0x008F
Axela / Mazda 3	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0172 0x001C 0x001C 0x001C 0x001C 0x001D
Axela / Mazda 3	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x001D 0x00DB 0x00DB
Axela / Mazda 3	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00DB 0x00DB 0x0024
Axela / Mazda 3	2.0L	LF	Other	4X4(4X4 Control Module)	✔	✔	–	–	0x0081 0x001E 0x001E
Axela / Mazda 3	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x001E 0x001E 0x0185
Axela / Mazda 3	2.0L	LF	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	0x0086 0x00B1 0x0052
Axela / Mazda 3	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x0153 0x00B2 0x0187 0x0012 0x0155
Axela / Mazda 3	2.0L	LF	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.0L	LF	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	2.0L	LF	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.2L	R2_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Axela / Mazda 3	2.2L	R2_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0186 0x0018
Axela / Mazda 3	2.2L	R2_T	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0157 0x001A 0x0188
Axela / Mazda 3	2.2L	R2_T	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x001B 0x008F 0x0172
Axela / Mazda 3	2.2L	R2_T	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x001C 0x001C 0x001C
Axela / Mazda 3	2.2L	R2_T	2008 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB
Axela / Mazda 3	2.2L	R2_T	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00DB 0x0024 0x0081
Axela / Mazda 3	2.2L	R2_T	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x001E 0x001E 0x001E
Axela / Mazda 3	2.2L	R2_T	2008 MY	4X4(4X4 Control Module)	✔	✔	–	–	0x001E 0x0185 0x0086
Axela / Mazda 3	2.2L	R2_T	2008 MY	ACU(Audio Control Unit)	✔	✔	–	–	0x00B1 0x0052 0x0153
Axela / Mazda 3	2.2L	R2_T	2008 MY	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	0x00B2 0x0187 0x0012
Axela / Mazda 3	2.2L	R2_T	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x0155 0x018C 0x00A4
Axela / Mazda 3	2.2L	R2_T	2008 MY	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	0x00A5 0x00AF 0x015F
Axela / Mazda 3	2.2L	R2_T	2008 MY	LCM(Lighting Control Module)	✔	✔	–	–	0x00A7 0x00A8 0x00A9
Axela / Mazda 3	2.2L	R2_T	2008 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	0x00AA 0x0160 0x00AC 0x00A3
Axela / Mazda 3	2.2L	R2_T	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.2L	R2_T	2008 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.2L	R2_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Axela / Mazda 3	2.2L	R2_T	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0186 0x0041
Axela / Mazda 3	2.2L	R2_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001A
Axela / Mazda 3	2.2L	R2_T	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0188 0x001B 0x008F 0x0172 0x001C 0x001C
Axela / Mazda 3	2.2L	R2_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x001C 0x001C 0x001D
Axela / Mazda 3	2.2L	R2_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x001D 0x00DB 0x00DB
Axela / Mazda 3	2.2L	R2_T	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x00DB 0x00DB 0x0024
Axela / Mazda 3	2.2L	R2_T	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	0x0081 0x001E 0x001E
Axela / Mazda 3	2.2L	R2_T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x001E 0x001E 0x0185
Axela / Mazda 3	2.2L	R2_T	Other	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	✔	0x0086 0x00B1 0x0052
Axela / Mazda 3	2.2L	R2_T	Other	LCM(Lighting Control Module)	✔	✔	–	–	0x0153 0x00B2 0x0187
Axela / Mazda 3	2.2L	R2_T	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	0x0012 0x0155 0x00A4
Axela / Mazda 3	2.2L	R2_T	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	0x00A5 0x00AF 0x015F
Axela / Mazda 3	2.2L	R2_T	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	0x00A7 0x00A8 0x00A9
Axela / Mazda 3	2.2L	R2_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	0x00AA 0x0160 0x00AC 0x00A3
Axela / Mazda 3	2.2L	R2_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	2008 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x00D6

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	1.6L	Y6	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0037 0x0186 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012
Axela / Mazda 3	1.6L	Y6	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	2008 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	2008 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	2008 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	2008 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	2008 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	2008 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	2008 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Y6	2008 MY	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Y6	2008 MY	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	2008 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	2008 MY	FACM(Fuel Additive Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	2008 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Y6	2008 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	2008 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	2008 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x00D6 0x0017 0x0037 0x0186 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012
Axela / Mazda 3	1.6L	Y6	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Y6	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	FACM(Fuel Additive Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Y6	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041
Axela / Mazda 3	1.6L	Z6	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	1.6L	Z6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001A
Axela / Mazda 3	1.6L	Z6	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0188 0x001B 0x008F 0x0172 0x001C 0x001C
Axela / Mazda 3	1.6L	Z6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x001C 0x001C 0x001D
Axela / Mazda 3	1.6L	Z6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x001D 0x00DB 0x00DB
Axela / Mazda 3	1.6L	Z6	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x00DB 0x00DB 0x0024
Axela / Mazda 3	1.6L	Z6	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	0x0081 0x001E 0x001E
Axela / Mazda 3	1.6L	Z6	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x001E 0x001E 0x0185
Axela / Mazda 3	1.6L	Z6	Other	LCM(Lighting Control Module)	✔	✔	–	–	0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187
Axela / Mazda 3	1.6L	Z6	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	0x0012 0x0155
Axela / Mazda 3	1.6L	Z6	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Axela / Mazda 3	1.6L	Z6	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0037 0x0186 0x0041
Axela / Mazda 3	1.6L	Z6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0157 0x001A
Axela / Mazda 3	1.6L	Z6	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0188 0x001B 0x008F 0x0172 0x001C 0x001C
Axela / Mazda 3	1.6L	Z6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x001C 0x001C 0x001D
Axela / Mazda 3	1.6L	Z6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x001D 0x00DB 0x00DB
Axela / Mazda 3	1.6L	Z6	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x00DB 0x00DB 0x0024
Axela / Mazda 3	1.6L	Z6	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	0x0081 0x001E 0x001E
Axela / Mazda 3	1.6L	Z6	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x001E 0x001E 0x0185
Axela / Mazda 3	1.6L	Z6	Other	LCM(Lighting Control Module)	✔	✔	–	–	0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187
Axela / Mazda 3	1.6L	Z6	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	0x0012 0x0155
Axela / Mazda 3	1.6L	Z6	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	1.5L	ZY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Axela / Mazda 3	1.5L	ZY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0186 0x0041
Axela / Mazda 3	1.5L	ZY	Other	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	0x0018 0x0157 0x001A
Axela / Mazda 3	1.5L	ZY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0188 0x001B 0x008F
Axela / Mazda 3	1.5L	ZY	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0172 0x001C 0x001C 0x001C 0x001C 0x001D
Axela / Mazda 3	1.5L	ZY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x001D 0x00DB 0x00DB

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	1.5L	ZY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012 0x0155 0x000D
Axela / Mazda 3	1.5L	ZY	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	1.5L	ZY	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Axela / Mazda 3	1.5L	ZY	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	1.5L	ZY	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	1.5L	ZY	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	1.5L	ZY	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	1.5L	ZY	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	1.5L	ZY	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	1.5L	ZY	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x001A 0x001B 0x001D 0x0085 0x0025 0x0086 0x001C 0x0024 0x0005 0x0006 0x000F 0x00CD 0x00CE 0x0085 0x0012 0x0011 0x0014 0x0027 0x000D 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	BCM(Battery Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ACCM#2(Air Conditioning Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x001A 0x0003 0x001B 0x001D 0x0085 0x0025 0x0086 0x001C 0x0024 0x0005 0x0006 0x0007 0x0002 0x0003 0x00CE 0x0085 0x00A1
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ACM(Audio Control Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	0x0027 0x0012 0x0014 0x000D 0x0076 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x001A 0x0003 0x001B 0x001D 0x0085 0x0025 0x0086 0x001C 0x0024 0x0005 0x0006 0x0007 0x0002 0x0003 0x00CE 0x0085 0x00A1 0x0027 0x0012 0x0014 0x0076 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x001A 0x0003 0x001B 0x001D 0x0085 0x0025 0x0086 0x001C 0x0024 0x0005 0x0006 0x0007 0x0002 0x0003 0x00CE 0x0085 0x00A1 0x0027 0x0012 0x0014 0x000D 0x0076 0x0009 0x0028
Escape /Tribute / Mariner	3.0L	4V	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	3.0L	4V	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	GPSM(Global Positioning System Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	3.0L	4V	2010 MY	PSCM(Power Steering Control Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003 0x001C 0x0025 0x0007 0x0005 0x0007 0x0001 0x0002 0x0003 0x0014 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003 0x001C 0x0025 0x0007 0x0005 0x0007 0x0001 0x0002 0x0003 0x0014 0x0009 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003 0x001C 0x0025 0x0007 0x0005 0x0007 0x0001 0x0002 0x0003 0x0014 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003 0x001C 0x0025 0x0007 0x0005 0x0007 0x0001 0x0002 0x0003 0x0014 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x001C 0x0025 0x0007 0x0005 0x0007 0x0001 0x0002 0x0003 0x0014 0x0009 0x0028
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	ABS(Anti-Lock Brake System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012 0x0155
Axela / Mazda 3	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	2.0L	LF	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.0L	LF	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB
Axela / Mazda 3	2.0L	LF	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	2011 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	2011 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	2.0L	LF	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012
Axela / Mazda 3	2.0L	LF	2011 MY	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	2.0L	LF	2011 MY	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	2011 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	2011 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	2011 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	2011 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.0L	LF	2011 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	LF	2011 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	LF	2011 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012 0x004F 0x0064 0x0047 0x0046 0x0066 0x004A 0x0062 0x0068 0x00ED 0x006A 0x00EF 0x006C
Axela / Mazda 3	1.6L	Y6	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Y6	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Y6	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Y6	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Y6	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187
Axela / Mazda 3	1.6L	Z6	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Z6	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	1.6L	Z6	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x0012 0x0155
Axela / Mazda 3	1.6L	Z6	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Z6	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012 0x0155
Axela / Mazda 3	1.6L	Z6	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Z6	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	1.6L	Z6	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	1.6L	Z6	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	1.6L	Z6	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x0188 0x0158 0x0158 0x0158 0x0158 0x0159 0x0159 0x0159 0x0159 0x018D 0x00DB 0x015B 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x015C
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	3.7L	CA	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	PCM(Powertrain Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	4X4(4X4 Control Module)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	MPM(Motor Pretensioner Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0018 0x0188 0x0158 0x0158 0x0158 0x0158

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x0159 0x0159 0x018D 0x00DB 0x015B 0x0086 0x00B1 0x0052 0x0153 0x00B2
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0156 0x0017 0x0037 0x00D9 0x0041 0x0018 0x0188 0x0158 0x0158 0x0158 0x0158 0x0159 0x0159 0x0159 0x0159 0x018D 0x00DB 0x015B 0x0086 0x00B1 0x0052 0x0153 0x00B2
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.5L	L5	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	AFS(Adaptive Front Lighting System)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	FFH(Fuel Fired Coolant Heating Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	MPM(Motor Pretensioner Module)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	RKE(Remote Keyless Entry)	✔	✔	✔	–	
Mazda 6 (GH, After Facelift) / Atenza	2.2L	R2_T	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0158 0x0159 0x0158
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0159 0x015B 0x0158
Premacy / Mazda 5	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0158 0x0159
Premacy / Mazda 5	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x00DB 0x0086 0x00B1 0x0052 0x00B2

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0158 0x0159 0x0158
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0159 0x015B 0x0158
Premacy / Mazda 5	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0158 0x0159
Premacy / Mazda 5	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x00DB 0x0086 0x00B1 0x0052 0x00B2
Premacy / Mazda 5	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	4X4(4X4 Control Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0158 0x0159 0x0158
Premacy / Mazda 5	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x015B 0x0158
Premacy / Mazda 5	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x0159 0x0158 0x0159 0x00DB 0x0086 0x00B1 0x0052 0x00B2
Premacy / Mazda 5	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0158 0x0159 0x0158 0x0159 0x015B 0x0158 0x0159 0x0158 0x0159 0x00DB 0x0086 0x00B1 0x0052 0x00B2
Premacy / Mazda 5	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	1.6L	Y6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x0158 0x0159 0x0158 0x0159 0x015B 0x0158 0x0159 0x0158 0x0159 0x00DB 0x0086 0x00B1 0x0052 0x00B2 0x0064 0x004F 0x0047 0x0046 0x0066 0x004A 0x0062 0x0068 0x00ED 0x006A 0x00EF 0x006C
Premacy / Mazda 5	1.6L	Y6	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	1.6L	Y6	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	1.6L	Y6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Premacy / Mazda 5	1.6L	Y6	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Premacy / Mazda 5	1.6L	Y6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Premacy / Mazda 5	1.6L	Y6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Premacy / Mazda 5	1.6L	Y6	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Premacy / Mazda 5	1.6L	Y6	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5	1.6L	Y6	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	1.6L	Y6	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5	1.6L	Y6	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x00A2 0x0158 0x0159 0x00DB 0x015B 0x016E 0x016C 0x00B2 0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x016D
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x00A2 0x0158 0x0159
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x00DB 0x015B 0x016E 0x016C 0x00B2 0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x016D
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x00A2 0x0158 0x0159 0x00DB 0x015B 0x016E 0x016C 0x00B2 0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x016D 0x000D
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x00A2 0x0158 0x0159 0x00DB 0x015B 0x016E 0x016C 0x00B2 0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x016D
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.6L	Y6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x00A2 0x0158 0x0159 0x00DB 0x015B 0x016E 0x016C 0x00B2 0x0161 0x0162 0x0163 0x0164 0x0165 0x0166 0x0167 0x0168 0x0169 0x0064 0x004F 0x0047 0x0046 0x0118 0x0066 0x0067
Demio (JPN) / Mazda 2 (OTHER)	1.6L	Y6	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.6L	Y6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.6L	Y6	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.6L	Y6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.6L	Y6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.6L	Y6	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.6L	Y6	Other	VSM(Vehicle Security Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x018E 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x001C 0x00DB 0x0024 0x001E 0x018F 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x0190 0x015C 0x016C
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x018E 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x001C 0x00DB 0x0024 0x001E 0x018F 0x0086 0x0052 0x0002 0x00B0 0x00B2
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B3 0x0190 0x015C 0x016C
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x018E 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x001C 0x00DB 0x0024 0x001E 0x018F 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x0190 0x015C 0x016C
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ACU(Audio Control Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x018E 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x001C 0x00DB 0x0024 0x001E 0x018F 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x0190 0x015C 0x016C
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LCM(Lighting Control Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	VSM(Vehicle Security Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0041 0x0018 0x00A2 0x0158 0x0159 0x00DB 0x015B 0x016E 0x00B1 0x016C 0x00B2 0x0161 0x0162 0x0163 0x0164 0x0191 0x0192 0x016D
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	VSM(Vehicle Security Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017 0x0037 0x0186 0x0041 0x0018 0x0157 0x001A 0x0188 0x001B 0x008F 0x0172 0x001C 0x001C 0x001C 0x001C 0x001D 0x001D 0x00DB 0x00DB 0x00DB 0x00DB 0x0024 0x0081 0x001E 0x001E 0x001E 0x001E 0x0185 0x0086 0x00B1 0x0052 0x0153 0x00B2 0x0187 0x0012 0x0155
Axela / Mazda 3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.0L	PE	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	2.0L	PE	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Axela / Mazda 3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0186 0x0041
Axela / Mazda 3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0018 0x0157 0x001A
Axela / Mazda 3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0188 0x001B 0x008F
Axela / Mazda 3	2.0L	PE	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	0x0172 0x001C 0x001C 0x001C 0x001C 0x001C 0x001D
Axela / Mazda 3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x001D 0x00DB 0x00DB
Axela / Mazda 3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00DB 0x00DB 0x0024
Axela / Mazda 3	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0081 0x001E 0x001E
Axela / Mazda 3	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x001E 0x001E 0x0185
Axela / Mazda 3	2.0L	PE	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	0x0086 0x00B1 0x0052
Axela / Mazda 3	2.0L	PE	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	0x0153 0x00B2 0x0187
Axela / Mazda 3	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	0x0012 0x0155
Axela / Mazda 3	2.0L	PE	Other	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.0L	PE	Other	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x0159
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x015B
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x018F 0x0196 0x0196
CX-5	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0196 0x0196 0x0197
CX-5	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x0197 0x0197 0x0197
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	0x00B1 0x0153 0x0198
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00B2 0x002C 0x0199
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x0190 0x019A 0x00A5
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x015F 0x00A7 0x00A8
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x00A9 0x00AA 0x00AB
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x00A3 0x019B 0x019C
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	0x019D 0x0191 0x0192 0x016D
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0159
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x015B
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0196
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0197
CX-5	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x0197
CX-5	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	0x00B2 0x002C 0x0199
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x0190 0x019A 0x00A5
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x015F 0x00A7 0x00A8
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x00A9 0x00AA 0x00AB
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x00A3 0x019B 0x019C
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x019D 0x0191 0x0192
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	0x016D
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0018 0x0195 0x0159
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x0159
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015B 0x018F 0x0196
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0197 0x0197 0x0197
CX-5	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x00B1 0x0153
CX-5	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	0x0199 0x0190 0x019A
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A5 0x015F 0x00A7
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00A8 0x00A9 0x00AA
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x00AB 0x00A3 0x019B
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x019C 0x019D 0x0191
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x0192 0x016D
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0159
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x0159
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x015B 0x018F 0x0196
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-5	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x0197
CX-5	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	0x0198 0x00B2 0x002C
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x0199 0x0190 0x019A
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00A5 0x015F 0x00A7
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x00A8 0x00A9 0x00AA
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x00AB 0x00A3 0x019B
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x019C 0x019D 0x0191
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	0x0192 0x016D
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x0159
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x015B
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x018F 0x0196 0x0196
CX-5	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0196 0x0196 0x0197
CX-5	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x0197 0x0197 0x0197
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	0x00B1 0x0153 0x0198
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00B2 0x002C 0x0199
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x0190 0x019A 0x0191
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x0192 0x016D
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0159
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x015B
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0196
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0197
CX-5	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x0197
CX-5	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	0x00B2 0x002C 0x0199
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x0190 0x019A 0x0191
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	0x0192 0x016D
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0018 0x0195 0x0159
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x0159
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015B 0x018F 0x0196
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0197 0x0197 0x0197
CX-5	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x00B1 0x0153
CX-5	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	0x0191 0x0192 0x016D
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0159
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x0159
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x015B 0x018F 0x0196
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-5	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x0197
CX-5	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	0x0198 0x00B2 0x002C
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x0199 0x0190 0x019A
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x0191 0x0192 0x016D
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Titan (Isuzu OEM)	3.0L	4JJ1_T	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Titan (Isuzu OEM)	3.0L	4JJ1_T	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	3.0L	4JJ1_T	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Titan (Isuzu OEM)	3.0L	4JJ1_T	2011 MY	PATS(Passive Anti-Theft System)	✔	✔	✔	–	
Titan (Isuzu OEM)	3.0L	4JJ1_T	2011 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Titan (Isuzu OEM)	3.0L	4JJ1_T	2011 MY	ISS/HSA(Idling Start and Stop/Hill Start Aid)	✔	✔	✔	-	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2011 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Titan (Isuzu OEM)	4.6L	4HV1_CNG	2011 MY	ISS/HSA(Idling Start and Stop/Hill Start Aid)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A-T	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon / Carol / Scrum / AZ-OFFROAD	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0035 0x0017 0x001E
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	✔	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003 0x001C 0x0025 0x0007 0x0005 0x0009 0x000F 0x0002 0x0003 0x0028
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003 0x001C 0x0025 0x0007 0x0005 0x0009 0x000F
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x0002 0x0003 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	BCMii(Body Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	DDM(Driver Front Door Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	-	-	2011 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	PDM(Passenger Front Door Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	SRM(Speech Recognition Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	-	-	2011 MY	TRM(Trailer Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0015 0x00F4 0x006E 0x006F 0x0018 0x0091 0x0002 0x0119 0x011B
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	BCMii(Body Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	DDM(Driver Front Door Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	PDM(Passenger Front Door Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	SRM(Speech Recognition Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	TRM(Trailer Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0015 0x00F4 0x006E 0x006F 0x0018 0x00E0 0x00A0 0x0091 0x0002 0x0119 0x00B2 0x0064 0x0046 0x0065 0x004F 0x0047 0x0066 0x004A
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0062 0x0068 0x00ED 0x006A 0x00EF 0x006C 0x011B
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	BCMii(Body Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	DDM(Driver Front Door Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	PDM(Passenger Front Door Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	SRM(Speech Recognition Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	TRM(Trailer Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x001A 0x001B 0x001D 0x0085 0x0025 0x0086 0x001C 0x0024 0x0005 0x0006 0x000F 0x00CD 0x00CE 0x0085 0x0012 0x0011 0x0014 0x000D 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	BCM(Battery Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	BCM(Battery Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ACCM#2(Air Conditioning Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	3.0L	4V	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0015 0x0015
Escape /Tribute / Mariner	3.0L	4V	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x007A 0x0016 0x0017
Escape /Tribute / Mariner	3.0L	4V	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x007E 0x0018 0x001C
Escape /Tribute / Mariner	3.0L	4V	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x001A 0x0003 0x001B
Escape /Tribute / Mariner	3.0L	4V	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	0x001D 0x0085 0x0025
Escape /Tribute / Mariner	3.0L	4V	2011 MY	ACM(Audio Control Module)	✔	✔	✔	–	0x0086 0x0005 0x0006
Escape /Tribute / Mariner	3.0L	4V	2011 MY	ACM(Audio Control Module)	✔	✔	✔	–	0x0009 0x0007 0x0002
Escape /Tribute / Mariner	3.0L	4V	2011 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	0x0003 0x0012 0x0011
Escape /Tribute / Mariner	3.0L	4V	2011 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	0x0014 0x00CE 0x0085
Escape /Tribute / Mariner	3.0L	4V	2011 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	0x000D 0x0076 0x0028
Escape /Tribute / Mariner	3.0L	4V	2011 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2011 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2011 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2011 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2011 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0015 0x0015
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x007A 0x0016 0x0017
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x007E 0x0018 0x001A
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	0x0003 0x001B 0x001D
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0085 0x0025 0x0086
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ACM(Audio Control Module)	✔	✔	✔	–	0x0005 0x0006 0x0007
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ACM(Audio Control Module)	✔	✔	✔	–	0x0002 0x0003 0x0012
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	0x0011 0x0014 0x00CE
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	0x0085 0x0076 0x0009
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	0x0028
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0015 0x0015

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x007A 0x0016 0x0017 0x007E 0x0018 0x001A 0x0003 0x001B 0x001D 0x0085 0x0025 0x0086 0x0005 0x0006 0x0007 0x0002 0x0003 0x0012 0x0011 0x0014 0x00CE 0x0085 0x000D 0x0076 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ACM(Audio Control Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ACM(Audio Control Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	FDIM(Front Display Interface Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	GPSM(Global Positioning System Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PSCM(Power Steering Control Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003 0x001C 0x0025 0x0007 0x0005 0x0007 0x0002 0x0003 0x0014 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0016 0x0017 0x0018 0x0019 0x0003 0x001C 0x0025 0x0007 0x0005 0x0007 0x0002 0x0003 0x0014 0x000D 0x0009 0x0028
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2011 MY	SDARS(Satellite Digital Audio Receiver System)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0015 0x007A 0x0016 0x0017 0x007E 0x0018 0x001A 0x001B 0x001D 0x0085 0x0025 0x0086 0x001C 0x0024 0x0005 0x0006 0x000F 0x00CD 0x0086 0x00CE 0x0085 0x0012 0x0011 0x0014 0x000D 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	BCM(Battery Control Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	BCM(Battery Control Module)	✔	✔	-	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ACCM#2(Air Conditioning Control Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ACM(Audio Control Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ACM(Audio Control Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	FDIM(Front Display Interface Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	GPSM(Global Positioning System Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	PSCM(Power Steering Control Module)	✔	✔	-	-	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0015 0x0015 0x007A 0x0016 0x0017
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0041 0x007E 0x0018 0x001A 0x0003 0x001B 0x001D 0x0085 0x0025 0x0086 0x0005 0x0006 0x0007 0x0002 0x0003 0x0012 0x0011 0x0014 0x00CE 0x0085 0x0076 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0015 0x0015 0x007A 0x0016 0x0017 0x0041 0x007E 0x0018 0x001A 0x0003 0x001B 0x001D 0x0085 0x0025 0x0086 0x0005 0x0006 0x0007 0x0002 0x0003 0x0012 0x0011 0x0014 0x00CE 0x0085 0x000D 0x0076 0x0009 0x0028
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x0015 0x0015 0x007A 0x0016 0x0017 0x0041 0x007E 0x0018 0x001A 0x0003 0x001B 0x001D 0x0085 0x0025 0x0086 0x0005 0x0006 0x0007 0x0002 0x0003 0x0012 0x0011 0x0014
Escape /Tribute / Mariner	3.0L	4V	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	ACM(Audio Control Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	ACM(Audio Control Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Escape /Tribute / Mariner	3.0L	4V	2012 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	–	0x00CE 0x0085 0x000D 0x0076 0x0009 0x0028
Escape /Tribute / Mariner	3.0L	4V	2012 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	FDIM(Front Display Interface Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	GEM / SJB(Generic Electronic Module / Smart Junction Box)	✔	✔	✔	✔	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	OCSM(Occupant Classification System Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Escape /Tribute / Mariner	3.0L	4V	2012 MY	PSCM(Power Steering Control Module)	✔	✔	–	–	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	–	0x0015 0x00F4 0x006E 0x006F 0x0018 0x00E0 0x00A0 0x0091 0x0002 0x00B2 0x0064 0x0046 0x0065 0x004F 0x0047 0x0066 0x004A 0x0062 0x0068 0x00ED 0x006A 0x00EF 0x006C 0x011B
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	BCMii(Body Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	DDM(Driver Front Door Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	HVAC(Heating Ventilation Air Conditioning)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	PAM(Parking Aid Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	PDM(Passenger Front Door Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	SRM(Speech Recognition Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Courier	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2011 MY	TRM(Trailer Module)	✔	✔	✔	–	
BT-50 / Ranger	3.0L	WE-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041
BT-50 / Ranger	3.0L	WE-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	3.0L	WE-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
BT-50 / Ranger	3.0L	WE-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
BT-50 / Ranger	3.0L	WE-CD	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	3.0L	WE-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	3.0L	WE-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0041
BT-50 / Ranger	2.5L	WL-CD	2007 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	ABS/TCS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
BT-50 / Ranger	2.5L	WL-CD	2007 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x00D9 0x0018 0x001B 0x00DB 0x001E 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x015C
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	IC(Instrument Cluster)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	4X4(4X4 Control Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	AM(Amplifier Module)	✔	✔	-	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x001B 0x001E
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x002F 0x0035 0x0017 0x0041 0x0018 0x001B 0x001E
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Mazda 3 (North America / General)	1.6L	Z6	2012 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037 0x0041 0x0018 0x001B 0x00DB 0x001E 0x00B0 0x00B2 0x00B3
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	AM(Amplifier Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	HCM(Headlamp Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	LCM(Lighting Control Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	-	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	-	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A-T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
Mazda 6 / Atenza	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 / Atenza	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x015B 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 6 / Atenza	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 / Atenza	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6 / Atenza	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x015B 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 6 / Atenza	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 / Atenza	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6 / Atenza	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 / Atenza	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6 / Atenza	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6 / Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F
Mazda 6 / Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 6 / Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0197 0x0197
Mazda 6 / Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0197 0x0197 0x015B
Mazda 6 / Atenza	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x00B1 0x0153 0x0198
Mazda 6 / Atenza	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B2 0x002C 0x0199
Mazda 6 / Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
Mazda 6 / Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x015F 0x00A7 0x00A8
Mazda 6 / Atenza	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x00A9 0x00AA 0x00AB
Mazda 6 / Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00A3 0x019B 0x019C
Mazda 6 / Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x019D 0x0191 0x0192
Mazda 6 / Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x016D
Mazda 6 / Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6 / Atenza	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6 / Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F
Mazda 6 / Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 6 / Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0197 0x0197
Mazda 6 / Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0197 0x0197 0x015B
Mazda 6 / Atenza	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x00B1 0x0153 0x0198
Mazda 6 / Atenza	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B2 0x002C 0x0199
Mazda 6 / Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
Mazda 6 / Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x015F 0x00A7 0x00A8
Mazda 6 / Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00A9 0x00AA 0x00AB
Mazda 6 / Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x00A3 0x019B 0x019C
									0x019D 0x0191 0x0192

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 / Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x016D
Mazda 6 / Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6 / Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6 / Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
Mazda 6 / Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 6 / Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0197 0x0197
Mazda 6 / Atenza	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x015B
Mazda 6 / Atenza	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
Mazda 6 / Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00B2 0x002C 0x0199
Mazda 6 / Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x0190 0x019A 0x00A5
Mazda 6 / Atenza	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x015F 0x00A7 0x00A8
Mazda 6 / Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00A9 0x00AA 0x00AB
Mazda 6 / Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x00A3 0x019B 0x019C
Mazda 6 / Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x019D 0x0191 0x0192
Mazda 6 / Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x016D
Mazda 6 / Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6 / Atenza	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6 / Atenza	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
Mazda 6 / Atenza	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 6 / Atenza	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0197 0x0197
Mazda 6 / Atenza	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x015B
Mazda 6 / Atenza	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
Mazda 6 / Atenza	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00B2 0x002C 0x0199
Mazda 6 / Atenza	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x0190 0x019A 0x0191 0x0192 0x016D

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 / Atenza	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6 / Atenza	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6 / Atenza	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
Mazda 6 / Atenza	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 6 / Atenza	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0197 0x0197
Mazda 6 / Atenza	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x015B
Mazda 6 / Atenza	2.0L	PE	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
Mazda 6 / Atenza	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00B2 0x002C 0x0199
Mazda 6 / Atenza	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x0190 0x019A 0x0191
Mazda 6 / Atenza	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x0192 0x016D
Mazda 6 / Atenza	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6 / Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6 / Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
Mazda 6 / Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 6 / Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0197 0x0197
Mazda 6 / Atenza	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x015B
Mazda 6 / Atenza	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
Mazda 6 / Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00B2 0x002C 0x0199
Mazda 6 / Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x0190 0x019A 0x00A5
Mazda 6 / Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x015F 0x00A7 0x00A8
Mazda 6 / Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x00A9 0x00AA 0x00AB
Mazda 6 / Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x00A3 0x019B 0x019C
Mazda 6 / Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x019D 0x0191 0x0192
Mazda 6 / Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	0x016D
Mazda 6 / Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0159
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x015B
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0196
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0197
CX-5	2.5L	PY	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x0197
									0x00B1 0x0153 0x0198

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0159 0x0159 0x0159 0x015B 0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ACU(Audio Control Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	-	
Premacy / Mazda 5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0156 0x0034 0x0017
Premacy / Mazda 5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0037 0x0041 0x0018
Premacy / Mazda 5	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0158 0x0159 0x0158
Premacy / Mazda 5	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0159 0x015B 0x0158
Premacy / Mazda 5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x0159 0x0158 0x0159
Premacy / Mazda 5	2.0L	PE	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	0x00DB 0x0086 0x00B1 0x00B2

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Premacy / Mazda 5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	-	-	
Premacy / Mazda 5	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	PE	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Premacy / Mazda 5	2.0L	PE	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	PE	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	-	
Biante(Japan)	2.0L	PE	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0034 0x0017 0x0037 0x0041 0x0018 0x001B 0x008F 0x00DB 0x001E 0x0185 0x00B1 0x00B2 0x00B3
Biante(Japan)	2.0L	PE	2012 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Biante(Japan)	2.0L	PE	2012 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Biante(Japan)	2.0L	PE	2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Biante(Japan)	2.0L	PE	2012 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	-	
Biante(Japan)	2.0L	PE	2012 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
VX-1	1.4L	K14B	Other	ABS(Antilock braking system)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
Mazda 3 / Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0041
Mazda 3 / Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	–	0x0041 0x0194 0x0018
Mazda 3 / Axela	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0159
Mazda 3 / Axela	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0159 0x0159 0x015B
Mazda 3 / Axela	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x018F 0x0196 0x0196
Mazda 3 / Axela	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0197
Mazda 3 / Axela	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x0197 0x0197
Mazda 3 / Axela	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B1 0x0153 0x00B2
Mazda 3 / Axela	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x002C 0x0199 0x0190
Mazda 3 / Axela	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x019A 0x0192 0x016D
Mazda 3 / Axela	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x001B
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x00DB 0x001E 0x00B0

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B2 0x00B3 0x015C
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	4X4(4X4 Control Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	AM(Amplifier Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	HCM(Headlamp Control Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	LCM(Lighting Control Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0159 0x0159 0x0159 0x015B 0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3 / Axela	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3 / Axela	2.5L	PY	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 / Axela	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0159 0x0159 0x0159 0x015B 0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3 / Axela	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0159 0x0159 0x0159 0x015B 0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3 / Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 / Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0159
Mazda 3 / Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x015B
Mazda 3 / Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0196
Mazda 3 / Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0197
Mazda 3 / Axela	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x0197
Mazda 3 / Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F
Mazda 3 / Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A7 0x00A8 0x00A9
Mazda 3 / Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00AA 0x00AB 0x00A3
Mazda 3 / Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x019B 0x019C 0x019D
Mazda 3 / Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x0191 0x0192 0x016D
Mazda 3 / Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x0159
Mazda 3 / Axela	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x015B
Mazda 3 / Axela	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x018F 0x0196 0x0196
Mazda 3 / Axela	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0196 0x0196 0x0197
Mazda 3 / Axela	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2
Mazda 3 / Axela	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x002C 0x0199 0x0190
Mazda 3 / Axela	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x019A 0x0191 0x0192
Mazda 3 / Axela	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x016D
Mazda 3 / Axela	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 / Axela	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	1.6L	Z6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	1.6L	Z6	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	1.6L	Z6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x0159
Mazda 3 / Axela	1.6L	Z6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x015B
Mazda 3 / Axela	1.6L	Z6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x018F 0x0196 0x0196
Mazda 3 / Axela	1.6L	Z6	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0196 0x0196 0x0197
Mazda 3 / Axela	1.6L	Z6	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2
Mazda 3 / Axela	1.6L	Z6	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x002C 0x0199 0x0190 0x019A 0x016D
Mazda 3 / Axela	1.6L	Z6	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	1.6L	Z6	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.6L	Z6	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.6L	Z6	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	1.6L	Z6	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	1.6L	Z6	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	1.6L	Z6	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x0159
Mazda 3 / Axela	1.6L	Z6	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x015B
Mazda 3 / Axela	1.6L	Z6	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x018F 0x0196 0x0196
Mazda 3 / Axela	1.6L	Z6	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0196 0x0196 0x0197
Mazda 3 / Axela	1.6L	Z6	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2
Mazda 3 / Axela	1.6L	Z6	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x002C 0x0199 0x0190 0x019A 0x016D

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 / Axela	1.6L	Z6	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x019A 0x016D
Mazda 3 / Axela	1.6L	Z6	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.6L	Z6	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.6L	Z6	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	1.6L	Z6	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0159
Mazda 3 / Axela	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x015B
Mazda 3 / Axela	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0196
Mazda 3 / Axela	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0197
Mazda 3 / Axela	1.5L	P5	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x0197
Mazda 3 / Axela	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3 / Axela	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
Mazda 3 / Axela	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
Mazda 3 / Axela	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0018 0x0195 0x0159
Mazda 3 / Axela	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x0159

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 / Axela	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015B 0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3 / Axela	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 3 / Axela	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0159 0x0159 0x0159 0x018F 0x015B 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197
Axela (Hybrid)	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	ACN(ACN)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
Axela (Hybrid)	2.0L	PE	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela (Hybrid)	2.0L	PE	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Axela (Hybrid)	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	ECRB(ECRB)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	HV-ECU(HV-ECU)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	PLK(PLK)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x0159
Mazda 3 / Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x015B
Mazda 3 / Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x018F 0x0196 0x0196
Mazda 3 / Axela	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0196 0x0196 0x0197
Mazda 3 / Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2
Mazda 3 / Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x002C 0x0199 0x0190
Mazda 3 / Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x019A 0x00A5 0x015F
Mazda 3 / Axela	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9
Mazda 3 / Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00AA 0x00AB 0x00A3
Mazda 3 / Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3 / Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0159
Mazda 3 / Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x015B

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 / Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3 / Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
Mazda 2 / Demio	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
Mazda 2 / Demio	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
Mazda 2 / Demio	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x00B1 0x0153
Mazda 2 / Demio	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
Mazda 2 / Demio	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x0199 0x01A0 0x0190
Mazda 2 / Demio	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x019A 0x016D 0x0191
Mazda 2 / Demio	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	0x0192 0x018C 0x00A5
Mazda 2 / Demio	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x015F 0x00A7 0x00A8
Mazda 2 / Demio	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	0x00A9 0x00AA 0x0160
Mazda 2 / Demio	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x00A3 0x01A1 0x019C
Mazda 2 / Demio	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	0x01A2 0x019B 0x0004
Mazda 2 / Demio	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
Mazda 2 / Demio	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
Mazda 2 / Demio	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
Mazda 2 / Demio	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x00B1 0x0153
Mazda 2 / Demio	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
Mazda 2 / Demio	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x0199 0x01A0 0x0190
Mazda 2 / Demio	1.3L	P3	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x019A 0x016D 0x0161
Mazda 2 / Demio	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	0x0162 0x0163 0x0164
Mazda 2 / Demio	1.3L	P3	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x0191 0x0192
Mazda 2 / Demio	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
Mazda 2 / Demio	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
Mazda 2 / Demio	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0159 0x018F 0x0196
Mazda 2 / Demio	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x00B1 0x0153
Mazda 2 / Demio	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 2 / Demio	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x01A0 0x0190 0x019A 0x016D 0x0161 0x0162 0x0163 0x0164 0x0191 0x0192
Mazda 2 / Demio	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
Mazda 2 / Demio	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x016D 0x0191 0x0192 0x018C 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x019C 0x01A2 0x019B 0x0004
Mazda 2 / Demio	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x016D 0x0191 0x0192 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x019C 0x01A2 0x019B
Mazda 2 / Demio	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 2 / Demio	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
Mazda 6 / Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
Mazda 6 / Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0159
Mazda 6 / Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0196
Mazda 6 / Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0197
Mazda 6 / Atenza	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0197 0x0197 0x0197
Mazda 6 / Atenza	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x015B 0x00B1 0x0153
Mazda 6 / Atenza	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C
Mazda 6 / Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x0199 0x0190 0x019A
Mazda 6 / Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A5 0x015F 0x00A7
Mazda 6 / Atenza	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x00A8 0x00A9 0x00AA
Mazda 6 / Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00AB 0x00A3 0x019B
Mazda 6 / Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x019C 0x019D 0x0191
Mazda 6 / Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x0192 0x016D
Mazda 6 / Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
Mazda 6 / Atenza	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
Mazda 6 / Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0018 0x0195 0x0159
Mazda 6 / Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x018F 0x0196 0x0196
Mazda 6 / Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0196 0x0197
Mazda 6 / Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0197 0x0197 0x0197
Mazda 6 / Atenza	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x015B 0x00B1 0x0153
Mazda 6 / Atenza	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0198 0x00B2 0x002C
Mazda 6 / Atenza	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x0199 0x0190 0x019A
Mazda 6 / Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A5 0x015F 0x00A7
Mazda 6 / Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A8 0x00A9 0x00AA
Mazda 6 / Atenza	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x00AB 0x00A3 0x019B
Mazda 6 / Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x019C 0x019D 0x0191
									0x0192 0x016D

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 / Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
Mazda 2 / Demio	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
Mazda 2 / Demio	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F
Mazda 2 / Demio	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x00B1
Mazda 2 / Demio	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2
Mazda 2 / Demio	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x002C 0x0199 0x01A0
Mazda 2 / Demio	1.3L	P3	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0190 0x019A 0x016D
Mazda 2 / Demio	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x0161 0x0162 0x0163
Mazda 2 / Demio	1.3L	P3	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x0164 0x0191 0x0192
Mazda 2 / Demio	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	4X4(4X4 Control Module)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Premacy / Mazda 5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Premacy / Mazda 5	2.0L	LF	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Premacy / Mazda 5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x018E 0x0017 0x0037 0x00D9 0x0041 0x0018 0x001B 0x001C 0x00DB 0x0024 0x001E 0x018F 0x0086 0x0052 0x0002 0x00B0 0x00B2 0x00B3 0x0012 0x016C
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	–	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	DSM(Driver's Seat Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LCM(Lighting Control Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	-	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	VSM(Vehicle Security Module)	✔	✔	✔	-	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Bongo / Bongo Brawny / Spectron	1.8L	L8	2010 MY	IC(Instrument Cluster)	✔	✔	✔	-	
None	2.5L	L5	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
None	2.5L	L5	2012 MY	IC(Instrument Cluster)	✔	✔	-	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0161 0x0162 0x0163 0x0164 0x0191 0x0192
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	-	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Demio (JPN) / Mazda 2 (OTHER)	1.3L	P3	Other	VSM(Vehicle Security Module)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	ACU(Audio Control Unit)	✔	✔	–	–	
CX-5	2.5L	PY	2012 MY	AFS(Adaptive Front Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	AM(Amplifier Module)	✔	✔	–	–	
CX-5	2.5L	PY	2012 MY	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	2012 MY	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	2012 MY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.5L	PY	2012 MY	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	PCM(Powertrain Control Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	PCM(Powertrain Control Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Axela / Mazda 3	2.0L	PE	2014 MY	BCM/GEM(Body Control Module / Generic Electronic Module)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	4X4(4X4 Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.0L	PE	2014 MY	ACU(Audio Control Unit)	✔	✔	–	–	
Axela / Mazda 3	2.0L	PE	2014 MY	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	LCM(Lighting Control Module)	✔	✔	–	–	
Axela / Mazda 3	2.0L	PE	2014 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	MID#1(Multi-Information Display)	✔	✔	✔	–	
Axela / Mazda 3	2.0L	PE	2014 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Axela / Mazda 3	2.0L	PE	2014 MY	RVM(Rear Vehicle Monitoring)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	4X4(4X4 Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	AFS(Adaptive Front Steering)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6 / Atenza	2.0L	PE	2013 MY	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6 / Atenza	2.0L	PE	2013 MY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 6 / Atenza	2.0L	PE	2013 MY	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Biante(Japan)	2.0L	PE	2012 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Biante(Japan)	2.0L	PE	2012 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	PE	2012 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	✔	–	
Biante(Japan)	2.0L	PE	2012 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
Biante(Japan)	2.0L	PE	2012 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0177 0x0017 0x0037
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x001B
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x00DB 0x001E
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	IC(Instrument Cluster)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	4X4(4X4 Control Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	AM(Amplifier Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	HCM(Headlamp Control Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	ICCM(Intelligent Cruise Control Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	LCM(Lighting Control Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	LPSDM(Left Power Sliding Door Module)	✔	✔	–	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	LTM(Liftgate / Trunk Module)	✔	✔	✔	–	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	RKE(Remote Keyless Entry)	✔	✔	✔	✔	
MPV / Mazda8 (JPN/General)	2.3L	L3	2013 MY	RPSDM(Right Power Sliding Door Module)	✔	✔	–	–	
Mazda 2 / Demio	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0159 0x018F 0x0196
Mazda 2 / Demio	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x019F 0x0161 0x0162
Mazda 2 / Demio	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0163 0x0164 0x0191
Mazda 2 / Demio	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0192

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 2 / Demio	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 / Demio	1.3L	P3	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
Mazda 2 / Demio	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
Mazda 2 / Demio	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
Mazda 2 / Demio	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F
Mazda 2 / Demio	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x0191
Mazda 2 / Demio	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0192 0x018C 0x00A5
Mazda 2 / Demio	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x015F 0x00A7 0x00A8
Mazda 2 / Demio	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x00A9 0x00AA 0x0160
Mazda 2 / Demio	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A3 0x01A1 0x01A3
Mazda 2 / Demio	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x01A4 0x019B 0x0004
Mazda 2 / Demio	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	TCM(TCM)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	GEM(Generic Electronic Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
Mazda 2 / Demio	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
Mazda 2 / Demio	1.3L	P3	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0159 0x018F 0x0196
Mazda 2 / Demio	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x00B1 0x0153
Mazda 2 / Demio	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C
Mazda 2 / Demio	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x01A0 0x0190
Mazda 2 / Demio	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x019A 0x016D 0x0161
Mazda 2 / Demio	1.3L	P3	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x0162 0x0163 0x0164
Mazda 2 / Demio	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	0x0191 0x0192
Mazda 2 / Demio	1.3L	P3	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
Mazda 2 / Demio	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
Mazda 2 / Demio	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
Mazda 2 / Demio	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x00B1 0x0153
Mazda 2 / Demio	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
Mazda 2 / Demio	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x0199 0x01A0 0x0190
Mazda 2 / Demio	1.5L	P5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x019A 0x016D 0x0191
Mazda 2 / Demio	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	0x0192
Mazda 2 / Demio	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 2 / Demio	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
Mazda 2 / Demio	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
Mazda 2 / Demio	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
Mazda 2 / Demio	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x00B1 0x0153
Mazda 2 / Demio	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
Mazda 2 / Demio	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x0199 0x01A0 0x0190
Mazda 2 / Demio	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x019A 0x016D 0x0191
Mazda 2 / Demio	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	0x0192 0x018C 0x00A5
Mazda 2 / Demio	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x015F 0x00A7 0x00A8
Mazda 2 / Demio	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x00A9 0x00AA 0x0160
Mazda 2 / Demio	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	0x00A3 0x01A1 0x019C
Mazda 2 / Demio	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x01A2 0x019B 0x0004
Mazda 2 / Demio	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
Mazda 2 / Demio	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
Mazda 2 / Demio	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F
Mazda 2 / Demio	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x00B1
Mazda 2 / Demio	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x00B2 0x002C
Mazda 2 / Demio	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x016D
Mazda 2 / Demio	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0191 0x0192 0x018C
Mazda 2 / Demio	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A5 0x015F 0x00A7
Mazda 2 / Demio	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x00A8 0x00A9 0x00AA
Mazda 2 / Demio	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	0x0160 0x00A3 0x01A1
Mazda 2 / Demio	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x019C 0x01A2 0x019B
Mazda 2 / Demio	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	0x0004
Mazda 2 / Demio	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
Mazda 2 / Demio	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
Mazda 2 / Demio	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F
Mazda 2 / Demio	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
Mazda 2 / Demio	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x00B1

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 2 / Demio	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x00B2 0x002C 0x0199 0x019A 0x016D 0x0191 0x0192 0x018C 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x019C 0x01A2 0x019B 0x0004
Mazda 2 / Demio	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
Mazda 2 / Demio	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 2 / Demio	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	K6A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A	Other	LCM(Lighting Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
AZ-Wagon/Carol/Scrum/AZ-OFFROAD/Flair Wagon/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	ABS(Antilock braking system)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	IC(Instrument Cluster)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	BMU(Battery Management Unit)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	LCM(Lighting Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	K6A	Other	RBS(Rader Brake Support)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0018 0x0195 0x0159
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x0159

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015B 0x018F 0x0196
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0197 0x0197 0x0197
CX-5	2.2L	SH	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x00B1 0x0153
CX-5	2.2L	SH	Other	AFS(Adaptive Front Steering)	✔	✔	✔	–	0x00B2 0x002C 0x0199
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	0x019A 0x00A5 0x015F
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A7 0x00A8 0x00A9
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00AA 0x00AB 0x00A3
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x019B 0x019C 0x019D
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x0191 0x0192 0x016D
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
VX-1	1.4L	K14B	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
VX-1	1.4L	K14B	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
VX-1	1.4L	K14B	Other	ABS(Antilock braking system)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x00B1 0x0153
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0199 0x01A0 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x01A1 0x019B 0x019C 0x01A2 0x0191 0x0192 0x016D
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x01A1 0x019B 0x019C 0x01A2 0x0191 0x0192 0x016D
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x00A3 0x01A1 0x019B 0x019C 0x01A2 0x0191 0x0192 0x016D
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x01A1 0x019B 0x019C 0x01A2 0x0191 0x0192 0x016D
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x01A1 0x019B 0x019C
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x01A2 0x0191 0x0192 0x016D
CX-3	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x01A1 0x019B 0x019C 0x01A2 0x0191 0x0192 0x016D
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x01A5
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x01A5
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192 0x016D
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192 0x016D
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0159 0x018F 0x0196
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x00B1 0x0153
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x01A0 0x0190
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x0191 0x0192 0x016D
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x00B1 0x0153
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192 0x016D

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	0x016D
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x019F 0x00B1
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x002C 0x0199 0x01A0
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0190 0x019A 0x0191 0x0192 0x016D
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x019F 0x00B1
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x002C 0x0199 0x01A0
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0190 0x019A 0x0191 0x0192 0x016D
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192 0x016D
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	ABS(Antilock braking system)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	IC(Instrument Cluster)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	LCM(Lighting Control Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x01A6
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
MX-5 / Roadster	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MX-5 / Roadster	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MX-5 / Roadster	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
MX-5 / Roadster	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
MX-5 / Roadster	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x00B1 0x0153
MX-5 / Roadster	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
MX-5 / Roadster	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192 0x016D
MX-5 / Roadster	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / Roadster	1.5L	P5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / Roadster	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / Roadster	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / Roadster	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / Roadster	1.5L	P5	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / Roadster	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / Roadster	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / Roadster	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 / Roadster	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192 0x016D
MX-5 / Roadster	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 / Roadster	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MX-5 / Roadster	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 / Roadster	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / Roadster	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / Roadster	1.5L	P5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / Roadster	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / Roadster	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / Roadster	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / Roadster	1.5L	P5	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / Roadster	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / Roadster	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192 0x016D
MX-5 / Roadster	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / Roadster	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / Roadster	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / Roadster	2.0L	PE	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196
MX-5 / Roadster	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 / Roadster	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192 0x016D
MX-5 / Roadster	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / Roadster	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / Roadster	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / Roadster	2.0L	PE	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / Roadster	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Titan (Isuzu OEM)	3.0L	4JJ1_T	2014 MY	ISS/HSA(Idling Start and Stop/Hill Start Aid)	✔	✔	–	–	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-3	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MX-5 / Roadster	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MX-5 / Roadster	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MX-5 / Roadster	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	-	-	
MX-5 / Roadster	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MX-5 / Roadster	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MX-5 / Roadster	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MX-5 / Roadster	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
MX-5 / Roadster	2.0L	PE	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / Roadster	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MX-5 / Roadster	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x00F4 0x0088 0x00D8 0x011D 0x00FC 0x0036 0x006F 0x00E6 0x0023 0x0041 0x011E 0x007E 0x0018 0x011F 0x0070 0x0078 0x00E0 0x0108 0x0003 0x001C 0x0116 0x001E 0x0007 0x0075 0x0091 0x0109 0x0002 0x0003 0x010A 0x0105 0x008E 0x000D 0x0064 0x004F 0x0047 0x0046 0x0065 0x0066 0x004A 0x0062 0x0068 0x00ED 0x006A 0x00EF 0x006C
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	BCM#1(Body Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ATCM(All Terrain Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	C-CM(Cruise-Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	DDM(Driver Front Door Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	GPSM(Global Positioning System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	GWM(Gateway Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	HCM(Headlamp Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	HUD(Head Up Display)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	IPM-A(Image Processing Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PDM(Passenger Front Door Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PSCM(Power Steering Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RGTM(Rear Gate/Trunk Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RTM(Radio Transceiver Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SCCM(Steering Column Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SOD-L(Side Obstacle Detection Control Module - Left)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SOD-R(Side Obstacle Detection Control Module - Right)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TBM(Tracking and Blocking Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TCU#1(Telematic Control Unit Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TRM(Trailer Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x00F4 0x0088 0x00D8 0x011D 0x00FC
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0036 0x006F 0x00E6 0x0023 0x0041 0x011E
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x007E 0x0018 0x011F 0x0070 0x0078 0x0108

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0003 0x001C 0x0116 0x001E 0x0007 0x0075 0x0091 0x0109 0x0002 0x0003 0x010A 0x0105 0x008E 0x000D 0x0064 0x004F 0x0047 0x0046 0x0065 0x0066 0x004A 0x0062 0x0068 0x00ED 0x006A 0x00EF 0x006C
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ATCM(All Terrain Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	C-CM(Cruise-Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	DDM(Driver Front Door Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	GPSM(Global Positioning System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	GWM(Gateway Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	HCM(Headlamp Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	HUD(Head Up Display)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	IPM-A(Image Processing Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PDM(Passenger Front Door Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PSCM(Power Steering Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RGTM(Rear Gate/Trunk Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RTM(Radio Transceiver Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SCCM(Steering Column Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SOD-L(Side Obstacle Detection Control Module - Left)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SOD-R(Side Obstacle Detection Control Module - Right)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TBM(Tracking and Blocking Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TCU#1(Telematic Control Unit Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	3.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TRM(Trailer Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x00F4 0x0088 0x00D8 0x011D 0x00FC 0x0036 0x006F 0x00E6 0x0023 0x0041 0x011E 0x007E 0x0018 0x011F 0x0070 0x0078 0x00E0 0x0108 0x0003 0x001C 0x0116 0x001E 0x0007 0x0075 0x0091 0x0109 0x0002 0x0003 0x010A 0x0105 0x008E 0x000D 0x0064 0x004F 0x0047 0x0046 0x0065 0x0066 0x004A 0x0062 0x0068 0x00ED 0x006A 0x00EF 0x006C
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	BCM#1(Body Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ATCM(All Terrain Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	C-CM(Cruise-Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	DDM(Driver Front Door Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	GPSM(Global Positioning System Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	GWM(Gateway Module A)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	HCM(Headlamp Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	HUD(Head Up Display)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	IPM-A(Image Processing Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PDM(Passenger Front Door Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PSCM(Power Steering Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RGTM(Rear Gate/Trunk Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RTM(Radio Transceiver Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SCCM(Steering Column Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SOD-L(Side Obstacle Detection Control Module - Left)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SOD-R(Side Obstacle Detection Control Module - Right)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TBM(Tracking and Blocking Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TCU#1(Telematic Control Unit Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TRM(Trailer Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x00F4 0x0088 0x00D8 0x011D 0x00FC
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0036 0x006F 0x00E6 0x0023 0x0041 0x011E
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x007E 0x0018 0x011F 0x0070 0x0078 0x0108
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0003 0x001C 0x0116 0x001E 0x0007 0x0075
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	0x0091 0x0109 0x0002 0x0003 0x010A 0x0105
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ACM(Audio Control Module)	✔	✔	✔	✔	0x008E 0x000D 0x0064 0x004F 0x0047 0x0046

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	✔	0x0065 0x0066 0x004A 0x0062 0x0068 0x00ED 0x006A 0x00EF 0x006C
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	ATCM(All Terrain Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	C-CM(Cruise-Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	DDM(Driver Front Door Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	GPSM(Global Positioning System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	GWM(Gateway Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	HCM(Headlamp Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	HUD(Head Up Display)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	IPM-A(Image Processing Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PDM(Passenger Front Door Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	PSCM(Power Steering Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RGTM(Rear Gate/Trunk Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	RTM(Radio Transceiver Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SCCM(Steering Column Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SOD-L(Side Obstacle Detection Control Module - Left)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	SOD-R(Side Obstacle Detection Control Module - Right)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TBM(Tracking and Blocking Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TCU#1(Telematic Control Unit Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.2L	Duratorq-Turbo Diesel Common Rail Injection	2015 MY	TRM(Trailer Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x00F4 0x0088 0x00D8 0x011D 0x00FC 0x0036 0x006F 0x00E6 0x0023 0x0041 0x011E 0x007E 0x0018 0x011F 0x0070 0x0078 0x0108 0x0003 0x001C 0x0116 0x001E 0x0005 0x0007 0x0075 0x0091 0x0109 0x0002 0x0003 0x010A 0x0105 0x008E 0x0076 0x0077 0x0028
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	BCM#1(Body Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	ATCM(All Terrain Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	C-CM(Cruise-Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	DDM(Driver Front Door Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	GPSM(Global Positioning System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	GWM(Gateway Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	HCM(Headlamp Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	HUD(Head Up Display)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	IPM-A(Image Processing Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	PAM(Parking Aid Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	PDM(Passenger Front Door Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	PSCM(Power Steering Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	RGTM(Rear Gate/Trunk Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	RTM(Radio Transceiver Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	SCCM(Steering Column Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	TBM(Tracking and Blocking Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	TCU#1(Telematic Control Unit Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	TRM(Trailer Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	SCAM(Stereo Camera)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
VX-1	1.4L	K14B	Other	ABS(Antilock braking system)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	IC(Instrument Cluster)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
VX-1	1.4L	K14B	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
VX-1	1.4L	K14B	Other	ABS(Antilock braking system)	✔	✔	✔	–	
VX-1	1.4L	K14B	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
VX-1	1.4L	K14B	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
VX-1	1.4L	K14B	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
VX-1	1.4L	K14B	Other	IC(Instrument Cluster)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	SCAM(Stereo Camera)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.6L	HR16	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.6L	HR16	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.6L	HR16	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.6L	HR16	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	-	-	
Familia VAN (BV*Y12)	1.6L	HR16	2013 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.6L	HR16	2013 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.6L	HR16	2013 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.6L	HR16	2013 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	TCM(TCM)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	-	-	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	IC(Instrument Cluster)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	SCAM(Stereo Camera)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x0159
Mazda 3 / Axela	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0159 0x0159 0x015B
Mazda 3 / Axela	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x018F 0x0196 0x0196
Mazda 3 / Axela	1.5L	S5	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0196 0x0196 0x0197
Mazda 3 / Axela	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2
Mazda 3 / Axela	1.5L	S5	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x002C 0x0199 0x0190
Mazda 3 / Axela	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x019A 0x00A5 0x015F
Mazda 3 / Axela	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9
Mazda 3 / Axela	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	0x00AA 0x00AB 0x00A3
Mazda 3 / Axela	1.5L	S5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	0x01A1 0x019B 0x019C 0x01A2 0x0191 0x016D
Mazda 3 / Axela	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	S5	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3 / Axela	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3 / Axela	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0159
Mazda 3 / Axela	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x0159 0x015B
Mazda 3 / Axela	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0196
Mazda 3 / Axela	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0196 0x0196 0x0197
Mazda 3 / Axela	1.5L	S5	Other	ACU(Audio Control Unit)	✔	✔	–	–	0x0197 0x0197 0x0197
Mazda 3 / Axela	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3 / Axela	1.5L	S5	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x019A 0x00A3 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x01A1 0x019B 0x019C 0x01A2 0x0191 0x016D
Mazda 3 / Axela	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	S5	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0159 0x0159 0x0159 0x015B 0x018F 0x0196 0x0196 0x0196 0x0196 0x0197 0x0197 0x0197 0x0197 0x00B1 0x0153 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3 / Axela	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	ACU(Audio Control Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3 / Axela	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3 / Axela	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
Mazda 3 / Axela	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9	2.5L	PY_T	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0196 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0192 0x016D
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0196 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0192 0x016D
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x0017
CX-4	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-4	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0196
CX-4	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0197 0x00B1 0x0153
CX-4	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x01A0 0x016D
CX-4	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-9	2.5L	PY_T	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x0196

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x00B2 0x002C 0x0199 0x019A 0x0192 0x016D
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0196 0x00B1 0x0153 0x00B2 0x002C 0x0199 0x019A 0x0192 0x016D
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x01A0 0x016D
CX-4	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D
CX-4	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-4	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D
CX-4	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module (For use with VSTM))	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
Carol/Flair Wagon/Scrum/Flair	660cc	R06A-T (A-STOP)	Other	SCAM(Stereo Camera)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	1.5L	P5	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	–	–	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6/ Atenza	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3/ Axela	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3/ Axela	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F
Mazda 3/ Axela	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0197 0x00B1
Mazda 3/ Axela	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2
Mazda 3/ Axela	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x002C 0x0199 0x0190
Mazda 3/ Axela	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3/ Axela	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3/ Axela	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
Mazda 3/ Axela	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0197 0x00B1

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x01A1 0x019B 0x019C 0x01A2 0x0191 0x0192 0x016D
Mazda 3/ Axela	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	1.5L	S5	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	1.5L	P5	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3/ Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3/ Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
Mazda 3/ Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0197 0x00B1
Mazda 3/ Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
Mazda 3/ Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F
Mazda 3/ Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A7 0x00A8 0x00A9
Mazda 3/ Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00AA 0x00AB 0x00A3
Mazda 3/ Axela	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3/ Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3/ Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
Mazda 3/ Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0197 0x00B1
Mazda 3/ Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
Mazda 3/ Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F
Mazda 3/ Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1
Mazda 3/ Axela	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x01A1 0x019B 0x019C 0x01A2 0x0191 0x0192 0x016D
Mazda 3/ Axela	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	1.5L	S5	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3/ Axela	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3/ Axela	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
Mazda 3/ Axela	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0197 0x00B1
Mazda 3/ Axela	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
Mazda 3/ Axela	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 3/ Axela	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 3/ Axela	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F
Mazda 3/ Axela	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0197 0x00B1
Mazda 3/ Axela	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2
Mazda 3/ Axela	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x002C 0x0199 0x0190
Mazda 3/ Axela	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	–	–	0x0193 0x018E 0x0017
Mazda 6/ Atenza	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6/ Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x018F 0x0196
Mazda 6/ Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0197 0x00B1 0x0153
Mazda 6/ Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C
Mazda 6/ Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x0190 0x019A
Mazda 6/ Atenza	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	–	–	0x0193 0x018E 0x0017
Mazda 6/ Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6/ Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x018F 0x0196
Mazda 6/ Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6/ Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	–	–	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6/ Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	–	–	0x019E 0x0193 0x018E
Mazda 6/ Atenza	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
Mazda 6/ Atenza	2.2L	SH	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0018 0x0195 0x018F
Mazda 6/ Atenza	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0197 0x00B1
Mazda 6/ Atenza	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2
Mazda 6/ Atenza	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x002C 0x0199 0x0190
Mazda 6/ Atenza	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019A 0x00A5 0x015F
Mazda 6/ Atenza	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6/ Atenza	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6/ Atenza	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x018F 0x0196
Mazda 6/ Atenza	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0197 0x00B1 0x0153
Mazda 6/ Atenza	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C
Mazda 6/ Atenza	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x0190 0x019A
Mazda 6/ Atenza	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6/ Atenza	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6/ Atenza	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6/ Atenza	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x018F 0x0196
Mazda 6/ Atenza	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153
Mazda 6/ Atenza	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
Mazda 6/ Atenza	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6/ Atenza	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6/ Atenza	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x018F 0x0196
Mazda 6/ Atenza	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0197 0x00B1 0x0153
Mazda 6/ Atenza	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C
Mazda 6/ Atenza	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x0190 0x019A
Mazda 6/ Atenza	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6/ Atenza	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6/ Atenza	2.0L	PE	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6/ Atenza	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x018F 0x0196
Mazda 6/ Atenza	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153
Mazda 6/ Atenza	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
Mazda 6/ Atenza	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 6/ Atenza	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
Mazda 6/ Atenza	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
Mazda 6/ Atenza	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x018F 0x0196
Mazda 6/ Atenza	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 6/ Atenza	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x002C 0x0199 0x019A 0x0191 0x016D
Mazda 6/ Atenza	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
Mazda 6/ Atenza	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 6/ Atenza	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 6/ Atenza	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 6/ Atenza	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
Mazda 6/ Atenza	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x0153 0x016D
Axela (Hybrid)	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	ACN(ACN)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
Axela (Hybrid)	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Axela (Hybrid)	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	ECRB(ECRB)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	HV-ECU(HV-ECU)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	PLK(PLK)	✔	✔	✔	–	
Axela (Hybrid)	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Axela (Hybrid)	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018
Mazda 3/ Axela	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	2.5L	PY	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	TCM(TCM)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.5L	HR15	2013 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	IC(Instrument Cluster)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
Familia VAN (BV*Y12)	1.8L	MR18	2013 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Mazda 3/ Axela	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
Mazda 3/ Axela	1.5L	P5	Other	ABS(Anti-Lock Brake / Traction Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
Mazda 3/ Axela	1.5L	P5	Other	DCM(Data Communication Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
Mazda 3/ Axela	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
Mazda 3/ Axela	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	ABS(Antilock braking system)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	IC(Instrument Cluster)	✔	✔	✔	–	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	ABS(Antilock braking system)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	IC(Instrument Cluster)	✔	✔	✔	–	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	ABS(Antilock braking system)	✔	✔	✔	✔	
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2016 MY	IC(Instrument Cluster)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA3 / AXELA	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	ACU(Audio Control Unit)	✔	✔	–	–	
MAZDA3 / AXELA	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA3 / AXELA	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	RVM(Rear Vehicle Monitoring)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA3 / AXELA	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA3 / AXELA	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	-	-	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA6/ ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA3/ AXELA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA3/ AXELA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA3/ AXELA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA3/ AXELA	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA3/ AXELA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA3/ AXELA	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA3/ AXELA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA3/ AXELA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA3/ AXELA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA3/ AXELA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA3/ AXELA	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA3/ AXELA	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
AXELA (Hybrid)	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
AXELA (Hybrid)	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	ACN#1(Air Conditioning Electronic control unit)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
AXELA (Hybrid)	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	-	-	
AXELA (Hybrid)	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
AXELA (Hybrid)	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
AXELA (Hybrid)	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	ECRB(Electronically Controlled Regenerative Cooperative Brake)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
AXELA (Hybrid)	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	HV-ECU(Hybrid Vehicle Electronic control unit)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	PLK#1(Parking lock Electronic control unit)	✔	✔	✔	-	
AXELA (Hybrid)	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
AXELA (Hybrid)	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA2 / DEMIO	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA2 / DEMIO	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	-	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-3	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-5	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	-	-	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x00B2 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x0153 0x00B2
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x002C 0x016D
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x0199 0x0190 0x019A
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A5 0x015F 0x00A7
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	0x00A8 0x00A9 0x00AA
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x0160 0x00A3 0x01A1
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	0x0191 0x0192 0x019C
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	0x01A2 0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0159 0x018F 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x0153 0x00B2
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x002C 0x016D
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x0190 0x019A
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A5 0x015F 0x00A7
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A8 0x00A9 0x00AA
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	0x0160 0x00A3 0x01A1
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x0191 0x0192 0x019C
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	0x01A2 0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x0153
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x0198 0x002C
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x016D 0x0199 0x0190
MAZDA2 / DEMIO	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019A 0x00A5 0x015F
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00AA 0x0160 0x00A3
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	0x01A1 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x019C 0x01A2 0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0159 0x018F 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x0153 0x00B2
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x002C 0x016D
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x0190 0x019A
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A5 0x015F 0x00A7
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A8 0x00A9 0x00AA
MAZDA2 / DEMIO	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	0x0160 0x00A3 0x01A1
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	0x0191 0x0192 0x019C
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	0x01A2 0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.3L	P3	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A
MAZDA2 / DEMIO	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0159 0x018F 0x0196
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x0153 0x00B2
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x002C 0x016D
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x0190 0x019A
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x0153
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x0198 0x002C
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x016D 0x0199 0x0190
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0018
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x019F 0x0153
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x0198 0x002C
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x016D 0x0199 0x0190
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x01A1 0x0191 0x0192
CX-3	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x019C 0x01A2 0x019B
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
CX-3	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0018 0x0195
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0159 0x018F 0x0196
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x019F 0x0153 0x00B2
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x002C 0x016D
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A8 0x00A9 0x00AA
CX-3	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x0160 0x00A3 0x01A1
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x0153
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x0198 0x002C
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x016D 0x0199 0x0190
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019A 0x00A5 0x015F
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
CX-3	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0159 0x018F 0x0196
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x0153 0x00B2
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x002C 0x016D
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x0190 0x019A
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
CX-3	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0197 0x01A7
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x0199 0x0190
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x0191 0x0192 0x016D
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0194

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0197 0x01A7
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x0199 0x0190
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00AA 0x00AB 0x00A3
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x0199 0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192 0x016D
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x0199 0x0190 0x019A 0x0191 0x0192 0x016D
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0197 0x01A7
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00B2 0x0199 0x0190 0x019A 0x00A5 0x015F
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A7 0x00A8 0x00A9
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00AA 0x00AB 0x00A3
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	0x019B 0x019C 0x019D
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x0191 0x0192 0x016D
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0159
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x018F 0x0196 0x0197
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x01A7 0x00B1 0x0153
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0198 0x00B2 0x0199
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0190 0x019A 0x00A5 0x015F 0x00A7 0x00A8
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A9 0x00AA 0x00AB
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	0x016D
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0018 0x0195 0x0159
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x018F 0x0196 0x0197
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01A7 0x00B1 0x0153
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x0199
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x00AB
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x019D 0x0191 0x0192 0x016D
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0018

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x019F 0x0153
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x0198 0x002C
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x016D 0x0199 0x0190
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x0153
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x0198 0x002C
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x016D 0x0199 0x0190
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0018
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x00B2 0x002C 0x016D 0x0199 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0159 0x018F 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x00B2 0x002C 0x016D 0x0199 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	TCM(Transmission Control Module)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	ABS(Antilock braking system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	ABS(Antilock braking system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	ABS(Antilock braking system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	IC(Instrument Cluster)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	ADAS(Advanced driver assistance system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	LDW(Lane Departure Warning)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MAZDA2 / DEMIO	1.3L	P3	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.3L	P3	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0159 0x018F 0x0196
MAZDA2 / DEMIO	1.3L	P3	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.3L	P3	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x0153 0x00B2
MAZDA2 / DEMIO	1.3L	P3	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x002C 0x016D 0x0199
MAZDA2 / DEMIO	1.3L	P3	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.3L	P3	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.3L	P3	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.3L	P3	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.3L	P3	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	ABS(Antilock braking system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	IC(Instrument Cluster)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	ADAS(Advanced driver assistance system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	LDW(Lane Departure Warning)	✔	✔	–	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	ABS(Antilock braking system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	IC(Instrument Cluster)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	ADAS(Advanced driver assistance system)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	LDW(Lane Departure Warning)	✔	✔	-	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	ABS(Antilock braking system)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	IC(Instrument Cluster)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	ADAS(Advanced driver assistance system)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	LDW(Lane Departure Warning)	✔	✔	-	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	ABS(Antilock braking system)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	IC(Instrument Cluster)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	ADAS(Advanced driver assistance system)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	-	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 MY	LDW(Lane Departure Warning)	✔	✔	-	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x01A8 0x01A5
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	AVAS(HOT$AVAS)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	DSBS(HOT$MFL)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	L/T_SW(HOT$CSW)	✔	✔	✔	-	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x00B2 0x0199 0x019A 0x0191 0x0192 0x016D
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	EATC(Electronic Automatic Temperature Control)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	RBS(Rader Brake Support)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-4	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-4	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	ABS(Antilock braking system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	ABS(Antilock braking system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	ABS(Antilock braking system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	IC(Instrument Cluster)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	ADAS(Advanced driver assistance system)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	GEM(Generic Electronic Module)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	IPDM(Intelligent Power Distribution Module)	✔	✔	✔	–	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 MY	LDW(Lane Departure Warning)	✔	✔	–	–	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0159 0x018F 0x0196
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x019F 0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x01A9 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x00A5 0x015F 0x01AA 0x01AB 0x01AC 0x01AD 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x01A9 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x00A5 0x015F 0x01AA 0x01AB 0x01AC 0x01AD 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0192
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-9	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0018 0x0195 0x0159
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x018F 0x0196 0x0197
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
CX-9	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0190 0x019A 0x0192
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-9	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0197 0x00B1
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x016D 0x0199 0x0190
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x0192
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-9	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-9	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0018 0x0195 0x0159
CX-9	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x018F 0x0196 0x0197
CX-9	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
CX-9	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x016D 0x0199 0x0190 0x019A 0x0192

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-9	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0190 0x019A 0x0192
CX-9	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSML(Blind Spot Monitoring (Left))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	BSMR(Blind Spot Monitoring (Right))	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-9	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-9	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
CX-9	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x0190 0x019A 0x00A5 0x015F 0x01AA 0x01AB 0x01AC 0x01AD 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192
CX-8	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-8	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-8	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-8	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
CX-8	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-8	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-8	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0018 0x0195 0x0159
CX-8	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x018F 0x0196 0x0197
CX-8	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01A7 0x00B1 0x0153
CX-8	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
CX-8	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
CX-8	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x015F 0x01AA 0x01AB 0x01AC 0x01AD 0x00AB
CX-8	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192
CX-8	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-8	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	
CX-8	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0143 0x006D 0x0107 0x00D8 0x011D 0x00FC
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0036 0x006F 0x00E6 0x0023 0x0041 0x011E
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	ABS(Antilock braking system)	✔	✔	–	–	0x007E 0x0018 0x011F 0x0070 0x0078 0x0108
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	RCM(Restraint Control Module)[SRS]	✔	✔	–	–	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	BCM#1(Body Control Module)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	IPC(Instrument Panel Control Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	APIM(Accessory Protocol Interface Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	DDM(Driver Front Door Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	FCIM(Front Controls Interface Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	GPCM(Glow Plug Control Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	GPSM(Global Positioning System Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	GWM(Gateway Module A)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	HCM(Headlamp Control Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	HUD(Head Up Display)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	IPM-A(Image Processing Module A)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	NOx11M(Nitrogen Oxides Module - Feedgas)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	PAM(Parking Aid Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	PDM(Passenger Front Door Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	PM_SENSOR(Particulate Matter Sensor)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	PSCM(Power Steering Control Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	RDCM#1(Reductant Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	RGTM(Rear Gate/Trunk Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	RTM(Radio Transceiver Module)	✔	✔	-	-	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	SCCM(Steering Column Control Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	SOD-L(Side Obstacle Detection Control Module - Left)	✔	✔	–	–	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	SOD-R(Side Obstacle Detection Control Module - Right)	✔	✔	–	–	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	TBM(Tracking and Blocking Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	TCU#1(Telematic Control Unit Module)	✔	✔	–	–	
Ranger / Mazda B-Series / Troller	2.0L	Duratorq-Turbo Diesel Common Rail Injection	2018 MY	TRM(Trailer Module)	✔	✔	–	–	
Ranger / Mazda B-Series / Troller	2.3L	EcoBoost - Gas Turbocharged Direct Injection	2019 MY	TBM(Tracking and Blocking Module)	✔	✔	✔	–	0x0041 0x0078 0x004D 0x0091
ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-8	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-8	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-8	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-8	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-8	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	-	-	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA6/ ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	-	-	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	-	-	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-5	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	-	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	-	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	DCDC(DC to DC Converter Control Module)	✔	✔	-	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
MAZDA6/ ATENZA	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	0x0196 0x0197 0x00B1
ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	0x0153 0x00B2 0x016D
ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x01A0 0x0190
ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	0x019A 0x0191 0x0192
ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	-	-	
ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F
ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0197 0x00B1
ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x00B2 0x016D
ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x01A0 0x0190
ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019A 0x0191 0x0192
ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	–	–	0x0193 0x018E 0x0017
ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0194 0x0018 0x0195
ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0159 0x018F 0x0196
ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0197 0x00B1 0x0153
ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0199
ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x01A0 0x0190 0x019A
ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	–	–	0x0193 0x018E 0x0017
ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0194 0x0018 0x0195
ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0159 0x018F 0x0196
ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0197 0x00B1 0x0153
ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0199
ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x01A0 0x0190 0x019A
ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192
ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x01A0 0x0190 0x019A 0x0191 0x0192
ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0159 0x018F
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0196 0x0197 0x01A7
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0159 0x018F

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x01A7 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-4	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x01A0 0x0190 0x019A
CX-4	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-4	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x01A0 0x0190 0x019A
CX-4	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-4	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-4	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x01A0 0x0190 0x019A
CX-4	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-4	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0159 0x018F 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x01A0 0x0190 0x019A
CX-4	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-4	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-4	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x01A8
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	AVAS(HOT$AVAS)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	CGW(Central Gateway)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	DSBS(HOT$MFL)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	HUD(Head Up Display)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	L/T_SW(HOT$CSW)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	REBS(Rear Sonar Brake Support)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x01A8
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	AVAS(HOT$AVAS)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	BMU(Battery Management Unit)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	CGW(Central Gateway)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	DSBS(HOT$MFL)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	HUD(Head Up Display)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	ISG(Integrated Starter Generator)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	L/T_SW(HOT$CSW)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T (A-STOP)	Other	REBS(Rear Sonar Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0153 0x00B2 0x0198 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x0191
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0192
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0190 0x019A 0x0191
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0192
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0190 0x019A 0x0191
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0192
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x0191
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0192
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x0191
MAZDA6/ ATENZA	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0192
MAZDA6/ ATENZA	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0190 0x019A 0x00A5

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015F 0x01AA 0x01AB 0x01AC 0x01AD 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x00A5 0x015F 0x01AA 0x01AB 0x01AC 0x01AD 0x00AB 0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x015F 0x01AA 0x01AB
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01AC 0x01AD 0x00AB
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A3 0x019B 0x019C 0x019D 0x0191 0x0192

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019D 0x0191 0x0192
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x0191
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0192
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x0191
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0192
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x015F 0x01AA 0x01AB
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01AC 0x01AD 0x00AB
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x019D 0x0191 0x0192
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x00B1 0x0153 0x0198
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0190 0x019A 0x00A5
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x015F 0x01AA 0x01AB
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x01AC 0x01AD 0x00AB
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00A3 0x019B 0x019C
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x019D 0x0191 0x0192
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x019F 0x0153
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x016D 0x0190 0x0199
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x019A 0x00A5 0x015F
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00AA 0x0160 0x00A3
MAZDA2 / DEMIO	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x01A1 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	0x019C 0x01A2 0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x0153
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0198 0x00B2 0x002C
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x016D 0x0190 0x0199
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MAZDA2 / DEMIO	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0196 0x0196 0x0196

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1
MX-5 / ROADSTER	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 / ROADSTER	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x01A0 0x019A 0x0191 0x0192
MX-5 / ROADSTER	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x01A0 0x019A 0x0191 0x0192
MX-5 / ROADSTER	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 / ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MX-5 / ROADSTER	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MX-5 / ROADSTER	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0196 0x0196 0x0196
MX-5 / ROADSTER	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x019F 0x00B1
MX-5 / ROADSTER	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
MX-5 / ROADSTER	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x002C 0x016D 0x0199
MX-5 / ROADSTER	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0190 0x01A0 0x019A
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MX-5 / ROADSTER	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MX-5 / ROADSTER	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0196 0x0196 0x0196
MX-5 / ROADSTER	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x019F 0x00B1
MX-5 / ROADSTER	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
MX-5 / ROADSTER	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x002C 0x016D 0x0199
MX-5 / ROADSTER	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0190 0x01A0 0x019A
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 / ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / ROADSTER	1.5L	P5	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 / ROADSTER	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MX-5 / ROADSTER	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MX-5 / ROADSTER	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
MX-5 / ROADSTER	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x00B1
MX-5 / ROADSTER	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2
MX-5 / ROADSTER	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x002C 0x016D 0x0199
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0190 0x01A0 0x019A 0x0191 0x0192
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MX-5 / ROADSTER	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MX-5 / ROADSTER	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x0196
MX-5 / ROADSTER	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x019F 0x00B1

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 / ROADSTER	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x01A0 0x019A 0x0191 0x0192
MX-5 / ROADSTER	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x00B1 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x01A0 0x019A 0x0191 0x0192
MX-5 / ROADSTER	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MX-5 / ROADSTER	2.0L	PE	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MX-5 / ROADSTER	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MX-5 / ROADSTER	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0196 0x0196 0x0196
MX-5 / ROADSTER	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x019F 0x00B1
MX-5 / ROADSTER	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
MX-5 / ROADSTER	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x002C 0x016D 0x0199
MX-5 / ROADSTER	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0190 0x01A0 0x019A
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MX-5 / ROADSTER	2.0L	PE	Other	EVP#1(Electrical Vacuum Pump)	✔	✔	✔	✔	
MX-5 / ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	RHT(Retractable Hard Top)	✔	✔	✔	–	
MX-5 / ROADSTER	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0196 0x0196 0x0196
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x019F 0x0153
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x016D 0x0199 0x0190
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0190
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x00A5
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0196
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x016D
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0196
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x016D
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0199 0x0190 0x019A
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0018
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0196 0x0196
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0196 0x0196 0x019F
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0153 0x0198 0x00B2

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0190 0x0199 0x019A 0x01A0
CX-4	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-4	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-4	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0190
CX-4	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-4	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x01A0
CX-4	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-4	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x007C 0x00F4 0x0104 0x00D8 0x0089 0x011D 0x00F5 0x00FC 0x0036 0x006F 0x00E6 0x0023 0x0041 0x011E 0x007E 0x0018 0x0129 0x011F 0x0070 0x00FF 0x0108 0x001C 0x001E 0x0116 0x0005 0x0007 0x0075 0x0091 0x0109 0x0002 0x0003 0x010A 0x0105 0x008E 0x0076 0x0077 0x0028
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	ABS(Antilock braking system)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	BCM#1(Body Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	IPC(Instrument Panel Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	ACM(Audio Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	APIM(Accessory Protocol Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	ATCM(All Terrain Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	C-CM(Cruise-Control Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	DDM(Driver Front Door Module)	✔	✔	✔	–	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	FCDIM(Front Control/Display Interface Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	FCIM(Front Controls Interface Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	GPSM(Global Positioning System Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	GWM(Gateway Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	HCM(Headlamp Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	HUD(Head Up Display)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	IPM-A(Image Processing Module A)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	PAM(Parking Aid Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	PDM(Passenger Front Door Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	PSCM(Power Steering Control Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	RGTM(Rear Gate/Trunk Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	RTM(Radio Transceiver Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	SCCM(Steering Column Control Module)	✔	✔	✔	✔	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	TBM(Tracking and Blocking Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	TCU#1(Telematic Control Unit Module)	✔	✔	✔	-	
Ranger / Mazda B-Series / Troller	2.5L	IVCT	2015 MY	TRM(Trailer Module)	✔	✔	✔	✔	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	PCM(Powertrain Control Module)	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	TCM(Transmission Control Module)	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	ABS(Antilock braking system)	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	EDU(Electronic Driver Unit)	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	GEM(Generic Electronic Module)	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	ISS/HSA(Idling Start and Stop/Hill Start Aid)	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	RKE(Remote Keyless Entry)	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	SCAM(Stereo Camera)	✔	✔	✔	-	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 MY	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-5	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-5	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	-	-	
CX-5	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	PLG(Power Liftgate)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-5	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	-	-	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-8	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	
CX-8	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	-	
CX-8	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	-	-	
CX-8	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	-	
CX-8	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	-	
CX-8	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	-	
CX-8	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	-	
CX-8	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	-	
CX-8	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	-	
CX-8	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	-	
CX-8	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	-	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-8	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-8	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY_T	Other	DCDC(DC to DC Converter Control Module)	✔	✔	–	–	
CX-5	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
MAZDA3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	–	–	
CX-4	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-4	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-4	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0018 0x0195 0x0196
CX-4	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0197 0x00B1 0x0153
CX-4	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0190
CX-4	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x01A0
CX-4	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	BSM(Blind Spot Monitoring)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-4	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	PSM#1(Parking Sensor Module)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-4	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-4	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	–	–	
CX-4	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	REBS(Rear Sonar Brake Support)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	ABS(Antilock braking system)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	REBS(Rear Sonar Brake Support)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA3/ AXELA	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA3/ AXELA	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
MAZDA3/ AXELA	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA3/ AXELA	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x002C 0x016D
MAZDA3/ AXELA	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0190 0x0199 0x019A
MAZDA3/ AXELA	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192
MAZDA3/ AXELA	1.5L	P5	Other	AM(Amplifier Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA3/ AXELA	1.5L	P5	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA3/ AXELA	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA3/ AXELA	1.5L	P5	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA3/ AXELA	1.5L	P5	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA3/ AXELA	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA3/ AXELA	1.5L	P5	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA3/ AXELA	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA3/ AXELA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA3/ AXELA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
MAZDA3/ AXELA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA3/ AXELA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x002C 0x016D
MAZDA3/ AXELA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0190 0x0199 0x019A 0x0191 0x0192

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA3/ AXELA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0191 0x0192
MAZDA3/ AXELA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA3/ AXELA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA3/ AXELA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA3/ AXELA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA3/ AXELA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA3/ AXELA	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA3/ AXELA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA3/ AXELA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA3/ AXELA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA3/ AXELA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-8	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-8	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
CX-8	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x00B2
CX-8	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x016D 0x0199 0x0190
CX-8	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x019A 0x0191 0x0192
CX-8	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-8	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-8	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-8	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-8	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-8	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-8	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x0191 0x0192
CX-5	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x0191 0x0192
CX-5	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-8	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-8	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-8	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-8	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-8	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0194 0x0018
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0196 0x0197
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x016D 0x0190
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	0x00A9 0x00AA 0x0160
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A3 0x0191 0x0192
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	0x019C 0x019D 0x019B
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0194
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0196

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-5	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	PLG(Power Liftgate)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-5	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
CX-3	1.8L	S8	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CX-3	1.8L	S8	Other	HUD(Head Up Display)	✔	✔	✔	✔	
CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
CX-3	1.8L	S8	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017 0x0041 0x0018 0x0195 0x0196 0x0196 0x0196 0x0196 0x019F 0x0153 0x0198 0x00B2 0x002C 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x01A1 0x0191 0x0192 0x019C 0x01A2 0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x019F
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x002C 0x016D 0x0190
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x00A5
MAZDA2 / DEMIO	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x015F 0x00A7 0x00A8
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A9 0x00AA 0x0160
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A3 0x01A1 0x0191
MAZDA2 / DEMIO	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x0192 0x019C 0x01A2
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x019F 0x0153
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x016D 0x0190 0x0199
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x019A 0x00A5 0x015F
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A7 0x00A8 0x00A9
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00AA 0x0160 0x00A3
MAZDA2 / DEMIO	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	0x01A1 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x019C 0x01A2 0x019B

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
MAZDA2 / DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
MAZDA2 / DEMIO	1.5L	S5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x019F
MAZDA2 / DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
MAZDA2 / DEMIO	1.5L	S5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x002C 0x016D 0x0190
MAZDA2 / DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x00A5
MAZDA2 / DEMIO	1.5L	S5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x015F 0x00A7 0x00A8
MAZDA2 / DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	0x00A9 0x00AA 0x0160
MAZDA2 / DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A3 0x01A1 0x0191
MAZDA2 / DEMIO	1.5L	S5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	0x0192 0x019C 0x01A2
MAZDA2 / DEMIO	1.5L	S5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	0x019B
MAZDA2 / DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	S5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA6/ ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA6/ ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0196 0x0197
MAZDA6/ ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0190 0x019A 0x0191 0x0192
MAZDA6/ ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA6/ ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA6/ ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
MAZDA6/ ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0190 0x019A 0x0191
MAZDA6/ ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0192
MAZDA6/ ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA6/ ATENZA	2.5L	PY_T	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA6/ ATENZA	2.5L	PY_T	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
MAZDA6/ ATENZA	2.5L	PY_T	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.5L	PY_T	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0199

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.5L	PY_T	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0190 0x019A 0x0191 0x0192
MAZDA6/ ATENZA	2.5L	PY_T	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY_T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY_T	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
MAZDA3	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	–	–	
MAZDA3	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x01A8 0x01A5
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	DSBS(HOT$MFL)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	L/T_SW(HOT$CSW)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	REBS(Rear Sonar Brake Support)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x01A8 0x01A5
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	TCM(Transmission Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	ABS(Antilock braking system)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	BCM#1(Body Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	A-STOP(A-STOP System (No Idling System))	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	DSBS(HOT$MFL)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	L/T_SW(HOT$CSW)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	LCM(Lighting Control Module)	✔	✔	✔	–	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A-STOP)	Other	REBS(Rear Sonar Brake Support)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x0190 0x01A0 0x019A 0x0191 0x0192
ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x0190 0x01A0 0x019A 0x0191 0x0192
ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x0190 0x01A0 0x019A 0x0191 0x0192
ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x00B2 0x016D 0x0199 0x0190 0x01A0 0x019A 0x0191 0x0192
ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
ATENZA	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
MAZDA3	1.8L	S8	Other	PCM(Powertrain Control Module)	✔	✔	–	–	
MAZDA3	1.8L	S8	Other	TCM(Transmission Control Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0190
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0017 0x0041 0x0194
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0018 0x0195 0x0196
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x0197 0x00B1 0x0153

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SCRCU(Selective Catalytic Reduction Control Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0190
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x00A5
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA6/ ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0199 0x0190 0x019A 0x0191 0x0192
MAZDA6/ ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.0L	PE	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA6/ ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA6/ ATENZA	2.5L	PY	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0197
MAZDA6/ ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.5L	PY	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B2 0x016D 0x0199
MAZDA6/ ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0190 0x019A 0x0191
MAZDA6/ ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0192
MAZDA6/ ATENZA	2.5L	PY	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.5L	PY	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x006D 0x018E 0x0017
MAZDA2 / DEMIO	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0041 0x0018 0x0195
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0196 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x019F 0x0153
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0198 0x00B2 0x002C
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x016D 0x0190 0x0199
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x019A 0x0191 0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA2 / DEMIO	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x006D 0x018E
MAZDA2 / DEMIO	1.5L	P5	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	0x0017 0x0041 0x0018
MAZDA2 / DEMIO	1.5L	P5	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0195 0x0196 0x0196
MAZDA2 / DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0196 0x0196 0x019F
MAZDA2 / DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	✔	✔	✔	✔	0x0153 0x0198 0x00B2
MAZDA2 / DEMIO	1.5L	P5	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x002C 0x016D 0x0190
MAZDA2 / DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x0199 0x019A 0x0191
MAZDA2 / DEMIO	1.5L	P5	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	0x0192
MAZDA2 / DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	✔	✔	–	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA2 / DEMIO	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	✔	✔	✔	–	
MAZDA2 / DEMIO	1.5L	P5	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x0193 0x018E 0x0017
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0041 0x0194 0x0018
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	0x0195 0x0196 0x0197
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	0x00B1 0x0153 0x0198
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	0x00B2 0x016D 0x0190
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0193

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194 0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	✔	✔	✔	✔	0x019E 0x0193 0x018E 0x0017 0x0041 0x0194
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	✔	✔	✔	✔	

Diagnostic List Mazda_v10.62

Remark:
1. √ : means that the system has this function
2. – : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

Vehicle	Capacity	EngineType	Year	Module	Functions				
					Read Codes	Erase Codes	Live Data	Actuation Test	SpecialFun
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Antilock braking system)	✔	✔	✔	✔	0x0018 0x0195 0x0196 0x0197 0x00B1 0x0153 0x0198 0x00B2 0x016D 0x0190 0x0199 0x019A 0x00A5 0x015F 0x00A7 0x00A8 0x00A9 0x00AA 0x0160 0x00A3 0x0191 0x0192 0x019C 0x019D 0x019B
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)[SRS]	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic-Controlled Power Steering)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System / Auto Leveling Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	✔	✔	–	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC to DC Converter Control Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver's Seat Module)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EATC#1(Electronic Air Temperature Controller)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electronic Parking Brake)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Front Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	✔	✔	✔	✔	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	✔	✔	✔	–	
MAZDA6/ ATENZA	2.2L	SH	Other	SSU#1(Start Stop Unit)	✔	✔	✔	✔	
MAZDA3	1.8L	P8_U	Other	TCM(Transmission Control Module)	✔	✔	–	–	

Special Function			
Index	**Special Function Name**	**Index**	**Special Function Name**
0x0001	PATS Functions	0x00D8	DDM(Driver Front Door Module)
0x0002	ABS Service Bleed	0x00D9	LCM(Lighting Control Module)
0x0003	IVD Initialization Sequence	0x00DA	FFH(Fuel Fired Coolant Heating Module)
0x0004	Injector Correction Factors	0x00DB	RKE
0x0005	Reset KAM - PCM	0x00DC	DDM(Drivers Door Module)
0x0006	Factory Keyless Entry Code	0x00DD	HCM-2(Headlamp Control Module 2(B))
0x0007	Passenger System Reset	0x00DE	BECM(Battery Energy Control Module)
0x0008	G Sensor Calibration	0x00DF	PCSM-2(Passenger Climate-Control Seat Module 2 (rear))
0x0009	Remote Keyless Entry	0x00E0	TCM(Transmission Control Module)
0x000A	Ride Height Calibration	0x00E1	SCR(Selective Catalytic Reduction) System
0x000B	Pneumatic Test	0x00E2	DPF Parameter Reset
0x000C	Accurate Trim Test	0x00E3	DPF Regeneration Suspension
0x000D	Transmission	0x00E4	Injector Quentity Adjustment
0x000E	EVAP Test	0x00E5	Reset the Neutral Gear Position Learned Value
0x000F	Passenger System Reset/OCS Reset	0x00E6	IPM-A(Image Processing Module A)
0x0010	Passenger Zero Seat Weight Test	0x00E7	IPM-B(Image Processing Module B)
0x0011	Infotainment Display Test	0x00E8	Driver Window Motor Test
0x0012	Audio Speaker Walkaround Test	0x00E9	Passenger Window Motor Test
0x0013	Microphone Test	0x00EA	Clear Self-learning Data
0x0014	Tones Test	0x00EB	Power Liftgate Initialization
0x0015	ACM(Audio Control Module)	0x00EC	Emergency Assist Activation
0x0016	GEM / SJB(Generic Electronic Module / Smart Junction Box)	0x00ED	Reset the High Pressure Fuel System Learned Values
0x0017	IC(Instrument Cluster)	0x00EE	Reset the Turbocharger Variable Vane Position Sensor Learned Values
0x0018	RCM(Restraint Control Module)[SRS]	0x00EF	Reset the Fuel Injector Learned Values
0x0019	SDARS(Satellite Digital Audio Receiver System)	0x00F0	Enter the Fuel Injector Default Count Value
0x001A	Audio Configure	0x00F1	Powertrain Control Module Central Car Configuration Update
0x001B	Exterior Lighting	0x00F2	Powertrain Control Module(PCM) One Touch Start Configuration
0x001C	Personality	0x00F3	Stop-Start Activation
0x001D	Power Door Locks	0x00F4	BCMii(Body Control Module)
0x001E	Warning Lamps/Chimes	0x00F5	GPSM(Global Positioning System Module)
0x001F	DCSM(Driver/Dual Climate-Control Seat Module)	0x00F6	WMM Calibration
0x0020	DSM(Drivers Seat Module)	0x00F7	Enter the Ethanol Factor Value
0x0021	DSP((Audio) Digital Signal Processing Module)	0x00F8	TCM Adaptive Learning
0x0022	Power Seats	0x00F9	PBM(Park Brake Control Module)
0x0023	PAM(Parking Aid Module)	0x00FA	Clutch System Test
0x0024	SECURITY	0x00FB	Exhaust Gas Temperature Sensor Configuration
0x0025	Tire Pressure Monitoring System	0x00FC	GWM(Gateway Module A)
0x0026	MonoTones Test	0x00FD	On-demand lock test routine
0x0027	Rear Tones Test	0x00FE	Remote Key Fob Learn
0x0028	Power Balance	0x00FF	TCU#1(Telematic Control Unit Module)
0x0029	Auxiliary vehicle ID reset	0x0100	Valve Calibration
0x002A	ESP Sensor Calibration	0x0101	Reset KAM - SOBDM-C
0x002B	Show GEM configuration	0x0102	DACM-C(Digital Audio Control Module C)
0x002C	TPMS Reset	0x0103	BCM Crash Status Reset
0x002D	EPB Calibration	0x0104	CCMii(Cruise Control Module)
0x002E	Disable GDM VIN	0x0105	LIN New Module Initialization
0x002F	ABS(Anti-Lock Brake System)	0x0106	LIN New Module Initialization-IPMB
0x0030	AWD(All Wheel Drive)	0x0107	RDCM#1(Reductant Control Module)
0x0031	EATC(Electronic Automatic Temperature Control)	0x0108	TRM(Trailer Module)
0x0032	CMR(Camera Module Rear)	0x0109	LDWS Camera Alignment
0x0033	D_DCU(Driver Door Control Unit)	0x010A	TPMS Sensor Training Mode
0x0034	EPS(Electronic-Controlled Power Steering)	0x010B	EGT Engine Protection Reset
0x0035	GEM(Generic Electronic Module)	0x010C	Mass Fuel Observed Reset
0x0036	HCM(Headlamp Control Module)	0x010D	DPF Vaporizer System Priming
0x0037	RKE(Remote Keyless Entry)	0x010E	Reset the Fuel Injector Learned Values - Cylinder 1
0x0038	P_DCU(Passengers Door Control Unit)	0x010F	Reset the Fuel Injector Learned Values - Cylinder 2
0x0039	RETM(Rear Seat Entertainment Module)	0x0110	Reset the Fuel Injector Learned Values - Cylinder 3
0x003A	Speed Items	0x0111	Reset the Fuel Injector Learned Values - Cylinder 4
0x003B	Washer/Wiper	0x0112	Powertrain Control Module Selective Catalytic Reduction System Learn
0x003C	Beltminder Enable/Disable	0x0113	Reset the front Nitrogen Oxide[NOx] Sensor Learned Values
0x003D	ACM Configration	0x0114	Reset the rear Nitrogen Oxide[NOx] Sensor Learned Values

Special Function			
Index	**Special Function Name**	**Index**	**Special Function Name**
0x003E	Reset the Transmission Oil learned Values	0x0115	Reset the Turbocharger Variable Vane Actuator Learned Values
0x003F	Transmission Range Sensor Learn	0x0116	Powertrain
0x0040	Reset the Transmission Control Module Learned Values	0x0117	CLM#1(Column Lock Module)
0x0041	PCM(Powertrain Control Module)	0x0118	Reset the Diesel Particulate Filter Differential Pressure Sensor learned Values
0x0042	Passenger Airbag Deactivation Switch	0x0119	ABS reset and configuration
0x0043	Rear Brake Adjustment	0x011A	Reset The Oil Change Indicator
0x0044	Electronic-Controlled Power Steering	0x011B	Ambient Air Temp Sensor Configuration
0x0045	Reset Differential Pressure Sensor learned Values	0x011C	EPAS Configuration
0x0046	Reset the Diesel Particulate Filter Learned Values	0x011D	FCIM(Front Controls Interface Module)
0x0047	Reset the Exhaust Gas Recirculation Valve Learned Values	0x011E	PDM(Passenger Front Door Module)
0x0048	Reset the Fuel Metering Valve Learned Values	0x011F	RTM(Radio Transceiver Module)
0x0049	Reset the Knock Sensor Learned Values	0x0120	SCM-E(Seat Control Module E)
0x004A	Reset the water in fuel Warning Indicator	0x0121	Electronic Integrated park brake-Apply And Release Test
0x004B	CDP(Compact Disc Player)	0x0122	Electronic Integrated park brake-Maintenance Mode
0x004C	SRM(Speech Recognition Module)	0x0123	SCM-G(Seat Control Module G)
0x004D	TBM SIM RVA_ID	0x0124	SCM-H(Seat Control Module H)
0x004E	TPMS Reset after ABS module replacement	0x0125	DCDC(DC to DC Converter Control Module)
0x004F	Reset the Intake Air Throttle Valve Learned Values	0x0126	SOBDM-C(Secondary OBD Control Module C)
0x0050	Reset Charge Air Cooler Bypass Valve Position Offset	0x0127	Steering Wheel Position Calibration
0x0051	Reset the Cooling Fan Motor Learned Values	0x0128	Police Vehicle Top Speed Limit
0x0052	TPMS Functions	0x0129	RGTM(Rear Gate/Trunk Module)
0x0053	PBM	0x012A	Alarm
0x0054	Driver's Seat Module	0x012B	Body Type
0x0055	Read the ECU serial number	0x012C	FDSM(Front Distance Sensing Module)
0x0056	Headlamp Alignment	0x012D	NAV(Navigation Controller)
0x0057	Car Mod	0x012E	ICM#1(Information Center Module)
0x0058	Module Configuration - RCM	0x012F	AHCM(Auxiliary Heater Control Module)
0x0059	Parameter reset/configuration - RCM	0x0130	Reset the Low-Pressure Fuel Pump Learned Values
0x005A	Parameter reset/configuration - EPB	0x0131	Reset the Active Grille Shutter Learned Values
0x005B	Parameter reset/configuration - BCM	0x0132	Reset the High Pressure Fuel Pump Learned Values
0x005C	Clear crash data memory	0x0133	SASM(Steering Angle Sensor Module)
0x005D	Prime the fuel system	0x0134	Adaptive Front Steering
0x005E	Module Reset - SOD-L	0x0135	Reset the Low Pressure Fuel System Learned Values
0x005F	Module Reset - SOD-R	0x0136	Reset the Nitrogen Oxide[NOx] Sensor Learned Values
0x0060	Shift fork system learn	0x0137	Reset Battery Monitor Learned Valures
0x0061	Clutch system learn	0x0138	DSM Reset
0x0062	Reset the Powertrain Control Module Learned Values	0x0139	SCM-B(Seat Control Module B)
0x0063	Camshaft Position Reference Adaption Learn	0x013A	GFM(Generic Function Module)
0x0064	Fuel Injector Correction Factors	0x013B	SCM-C(Seat Control Module C)
0x0065	Reset the DPF Differential Pressure Sensor learned Values	0x013C	SCM-D(Seat Control Module D)
0x0066	Diesel Particulate Filter Static Regeneration	0x013D	SCM-F(Seat Control Module F)
0x0067	Reset the air conditioning compressor learned values	0x013E	Tire Siz
0x0068	Reset the Exhaust Gas Temperature Value	0x013F	AWD#1(All Wheel Drive Module)
0x0069	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	0x0140	BECM-B(Battery Energy Control Module B)
0x006A	Reset the Mass Air Flow Sensor Learned Values	0x0141	Power Window Initialization
0x006B	Reset the Fuel Injection Pump Learned Values	0x0142	RBM(Running Board Control Module)
0x006C	Reset the Turbocharger Learned Values	0x0143	ABS(Antilock braking system)
0x006D	BCM#1(Body Control Module)	0x0144	HUD(Head Up Display)
0x006E	HVAC(Heating Ventilation Air Conditioning)	0x0145	RACM(Rear Audio Control Module)
0x006F	IPC(Instrument Panel Control Module)	0x0146	DCM-E(Door Control Module E)
0x0070	SCCM(Steering Column Control Module)	0x0147	DCM-F(Door Control Module F)
0x0071	Remote Start	0x0148	DCM-G(Door Control Module G)
0x0072	Fuel	0x0149	DCM-H(Door Control Module H)
0x0073	Tire Size/Axle Ratio	0x014A	Personality Advanced
0x0074	Police Mode	0x014B	Power Door Locks Advanced
0x0075	CEI Lock Configuration	0x014C	Remote Start Advanced
0x0076	Misfire Monitor Neutral Profile Correction	0x014D	Warning Lamps/Chimes Advanced
0x0077	Relearn Vehicle Data	0x014E	WACM(Wireless Accessory Charging Module)
0x0078	TBM(Tracking and Blocking Module)	0x014F	TCCM(Transfer Case Control Module)
0x0079	Power Windows	0x0150	RDCM(Reductant Control Module)
0x007A	FDIM(Front Display Interface Module)	0x0151	CCC Learn
0x007B	ILCM(Interior Lighting Control Module)	0x0152	RHVAC(Rear Heating Ventilation Air Conditioning)

Special Function			
Index	**Special Function Name**	**Index**	**Special Function Name**
0x007C	ABS(Anti-Lock Brake / Traction Control Module)	0x0153	Special Ignition ON
0x007D	BCM-B(Body Control Module B)	0x0154	Neutral Position Setting
0x007E	PSCM(Power Steering Control Module)	0x0155	RVM Aiming
0x007F	PDC Reset	0x0156	BCM/GEM(Body Control Module / Generic Electronic Module)
0x0080	ABS/TCS(Anti-Lock Brake / Traction Control Module)	0x0157	RVM(Rear Vehicle Monitoring)
0x0081	Tire Size	0x0158	BCM/GEM
0x0082	Vehicle	0x0159	IC
0x0083	A/F(Fuel Ratio)	0x015A	RVM
0x0084	Driveline	0x015B	RCM
0x0085	Steering Wheel Position Sensor Calibration	0x015C	Neutral Position Learning
0x0086	Passenger Seat Weight Sensor ReZero	0x015D	FFH Operation Check
0x0087	APIM(Accessory Protocol Interface Module)	0x015E	Injection Amount Correction
0x0088	C-CM(Cruise-Control Module)	0x015F	PCM Reset
0x0089	FCDIM(Front Control/Display Interface Module)	0x0160	O2 Sensor reset
0x008A	RFA(Remote Function Actuator)	0x0161	Calibration After Parts Removal or Replacement
0x008B	RLCM-A(Rear Lighting Control Module A)	0x0162	Restoration Procedure for DTC_C1B00_95
0x008C	SOD-L(Side Obstacle Detection Control Module - Left)	0x0163	Restoration Procedure for DTC_C1B00_54
0x008D	SOD-R(Side Obstacle Detection Control Module - Right)	0x0164	EPS Installation
0x008E	CCM Calibration	0x0165	Program additional ignition key
0x008F	Interior Lighting	0x0166	Ignition key code erase and program
0x0090	Keyless Entry Keypad Code Reset	0x0167	Customer spare key Programming Enable
0x0091	BMS Reset	0x0168	Customer spare key Programming Disable
0x0092	RVC Configuration	0x0169	Parameter reset
0x0093	DSM(Driver Front Seat Module)	0x016A	Reset the DPF Learned Value
0x0094	HSWM(Heated Steering Wheel Module)	0x016B	Reset the EGR valve learned values
0x0095	AIM(Audio Interface Module)	0x016C	VSM Service Functions
0x0096	BEM(Body Electronic Module)	0x016D	Headlamp - Auto Leveling Sensor
0x0097	BPM(Bluetooth Phone Module)	0x016E	VSM
0x0098	HIM(HVAC Integrated Module)	0x016F	Injector PCM Reset
0x0099	Steering Angle Sensor Calibration	0x0170	MAF Sensor PCM Reset
0x009A	ACM Calibration	0x0171	FFH-Lockout Mode Reset
0x009B	ACM Security Bypass Test	0x0172	Passenger Airbag Deactivation
0x009C	Power Seat Calibration	0x0173	TPM(Tire Pressure Monitor)
0x009D	audio configuration	0x0174	Transmission Fluid Level Test
0x009E	Zero Speed Test	0x0175	Headlight Zero-set
0x009F	Mileage After injectors Replacement	0x0176	O2 Air Fuel Rario(A/F)Sensor Reset
0x00A0	Reset KAM - TCM	0x0177	AM(Amplifier Module)
0x00A1	Infotainment Display Testy Test	0x0178	TR(Transmission range) sensor
0x00A2	VSM(Vehicle Security Module)	0x0179	Security
0x00A3	DPF Reset	0x017A	Injection Amount Correction Learning
0x00A4	DPF Assessment	0x017B	Restoration Procedure for DTC_C1B00_95(Steering Angle Sensor - incorrect assembly)
0x00A5	DPF Regeneration	0x017C	Restoration Procedure for DTC_C1B00_54(Steering Angle Sensor - missing calibration)
0x00A6	PCM Data Reset	0x017D	InteriorLighting
0x00A7	Engine Oil Reset	0x017E	RCM Calibration
0x00A8	Fuel Pump Reset	0x017F	Reset of EGR valve adaptive value
0x00A9	Injector Reset	0x0180	Reset of Injector Timing Offset adaptive value
0x00AA	MAF Sensor Reset	0x0181	Reset of Throttle valve adaptive value
0x00AB	O2/Air Fuel Rario(A/F)Sensor	0x0182	Reset of VCV pump adaptive value
0x00AC	DPF Pressure Sensor Reset	0x0183	TPMS Functions(TPM)
0x00AD	DPF Data Reset	0x0184	TPMS Functions(IC)
0x00AE	ETB/EGR Reset	0x0185	WasherWiper
0x00AF	ETB/EGR Initialization	0x0186	MID#1(Multi-Information Display)
0x00B0	Rain Sensor Reset	0x0187	AM Antenna Reception Sensitivity Test
0x00B1	EATC Operation Check	0x0188	BSM
0x00B2	Sensor Initialization	0x0189	SCR CU(Selective Catalytic Reduction)
0x00B3	IC Service Functions	0x018A	Fuel Injector Reset
0x00B4	Speed Limiting	0x018B	DPF Pressure Sensor Data Reset
0x00B5	Reset the Fuel Pressure Relief Valve Open Count Learned Value	0x018C	Injector amount correction learning
0x00B6	Reset the Fuel Pressure Relief Valve Open Duration Learned Value	0x018D	LCM
0x00B7	Fuel Injection Pump Learn	0x018E	FSC(Forward Sensing Camera)
0x00B8	Fuel Injector Pilot Correction Learn	0x018F	FSC
0x00B9	The installation of a new automatic transmission with the original TCM	0x0190	FSC Aiming

Special Function			
Index	**Special Function Name**	**Index**	**Special Function Name**
0x00BA	The removal and installation of the selector lever or the selector lever cable	0x0191	Engine Oil Maintenance-Change Setting
0x00BB	Transmission fluid drain and refill	0x0192	Engine Oil Maintenance-Remaining Oil Life
0x00BC	The installation of a new TCM	0x0193	F_BCM(Front Body Control Module)
0x00BD	The installation of a new automatic transmission with a new TCM	0x0194	R_BCM(Rear Body Control Module)
0x00BE	Initialize the Exhaust Gas Related Component	0x0195	SSU#1(Start Stop Unit)
0x00BF	Rear Seat Entertainment Module	0x0196	SSU
0x00C0	Oshkosh/Plasan Sand Cat Vehicles	0x0197	R_BCM
0x00C1	Clear EGR Adaptive Tables	0x0198	Calibration for Passenger Seat Sensor
0x00C2	Clear Fuel Injector & HP Pump Adaptive Tables	0x0199	Reader Aiming
0x00C3	WIF(Water In Fuel) Reset	0x019A	System Initialize
0x00C4	DPF Manual Regeneration	0x019B	Turbo charger Initialization
0x00C5	VDM(Vehicle Dynamics Module)	0x019C	ETB Initialization
0x00C6	Climate Control	0x019D	EGR valve Initialization
0x00C7	RCU(Audio Rear Control Unit)	0x019E	4X4(4X4 Control Module)
0x00C8	Climate Control Seats	0x019F	BCM#1
0x00C9	Power Mirrors	0x01A0	BSM Aiming
0x00CA	Brake System Configuration	0x01A1	Sediment Reset
0x00CB	Configure the steering angle sensor	0x01A2	ESV Initialization
0x00CC	Power Steering	0x01A3	Exhaust Shutter Valve initialization
0x00CD	Service Routine	0x01A4	Electronic throttle body initialization
0x00CE	Steering Torque Sensor Trim	0x01A5	CVT Learning Value Setting
0x00CF	SECM(Steering Effort Control Module)	0x01A6	Oil discharge
0x00D0	PCM	0x01A7	F_BCM
0x00D1	MAF(Mass Air Flow) sensor	0x01A8	Brake stroke sensor zero point initialization
0x00D2	GDM(Generic Display Module)	0x01A9	SCRCU(Selective Catalytic Reduction Control Unit)
0x00D3	NAV(Navigation System)	0x01AA	Engine oil reset
0x00D4	Navigation System	0x01AB	Fuel pump reset
0x00D5	MC(Message Center Module)	0x01AC	Injector reset
0x00D6	FACM(Fuel Additive Control Module)	0x01AD	MAF sensor reset
0x00D7	EPB(Electric Parking Brake)		